

SANMOTION

AC SERVO SYSTEMS

R ***ADVANCED
MODEL***

TYPE F

With Ether**CAT**[®]  Interface Type H

For Rotary Motor, Linear Motor

Instruction Manual

SANYO DENKI

Details of revision history

The second edition (B)

- p. 1-7
 - Manufacturer name of general I/O connector is corrected.
 - Front view drawing is changed.

- p. 1-9
 - Instruction manual number in notes of section 1) is corrected.

- p. 2-7
 - Table is corrected.

- p. 4-9
 - Symbols in the terminal arrangement are corrected.

- p. 5-64
 - Note is deleted in 0x6067 Position Window.

- p. 5-90
 - Contents of bit14 and 15 in 0x2000 are changed.

- p. 5-134
 - Liner motor number is corrected in 0x20FE Motor code.

- p. 5-135
 - Descriptions about the R ADVANCED setup software are changed to about the MOTOR setup software.

- p. 7-19
 - Descriptions about the R ADVANCED setup software are changed to about the MOTOR setup software.

- p. 5-142
 - Comment is corrected and note is added, in 0x210D Position Synchronization Deviation Monitor.

- p. 6-12, 6-13
 - Main circuit voltage drop detection level is corrected.

- p. 9-22
 - Alarm code FF is deleted.

- p. 9-26
 - Description drawing of RF2 in section "Replacing battery for motor encoder" is corrected.

- p. 10-3
 - Information in the table for standard conformity is added and corrected.

Details of revision history

- p. 12-1
 - Description of motor sizing flowchart is corrected.

- p. 12-4
 - Contents in section "8) Judgment condition" is corrected.
 - Notes for section "8) Judgment condition" are added.

- p. 13-1
 - Table of standard conformity is corrected.

- p. 13-17
 - Cable length for CNA and CNC are changed. 3m ⇒ 2m

Please read this User Manual and its appendix carefully prior to installation, operation, maintenance or inspection and perform all tasks according to the instructions provided here. A good understanding of this equipment, its safety information as well as all Warnings / Cautions is also necessary before using. Matters that require attention are ranked as “Danger” “Warning” and “Caution” in this document.

■ Warning Symbol

	Denotes immediate hazards that will probably cause severe bodily injury or death as a result of incorrect operation.
	Denotes immediate hazards which will probably cause severe bodily injury or death as a result of incorrect operation.
	Denotes hazards which could cause bodily injury and product or property damage as a result of incorrect operation.

Caution Even those hazards denoted by this symbol could lead to a serious accident. Make sure to strictly follow these safety precautions.

■ Prohibited, Mandatory Symbols

	Indicates actions that must not be allowed to occur / prohibited actions.
	Indicates actions that must be carried out / mandatory actions.

■ Attention in use

 **Warning**


Make certain to follow these safety precautions strictly to avoid electric shock or bodily injury.


- ◆ Do not use this device in explosive environment.
Injury or fire could otherwise result.
- ◆ Do not perform any wiring, maintenance or inspection when the device is hot-wired. After switching the power off, wait at least 15 minutes before performing these tasks.
Electric shock or damage could otherwise result.
- ◆ The protective ground terminal (⊕) should always be grounded to the unit or control board. The ground terminal of the motor should always be connected to the protective ground terminal (⊕) of the amplifier.
Electric shock could otherwise result.
- ◆ Do not touch the inside of the amplifier.
Electric shock could otherwise result.
- ◆ Do not damage the cable, do not apply unreasonable stress to it, do not place heavy items on it, and do not insert it in between objects.
Electric shock could otherwise result.
- ◆ Do not touch the rotating part of the motor during operation.
Bodily injury could otherwise result.

 **Caution**


- ◆ Use the amplifier and motor together in the specified combination.
Fire or damage to the device could otherwise result.
- ◆ Only technically qualified personnel should transport, install, wire, operate, or perform maintenance and inspection on this device.
Electric shock, injury or fire could otherwise result.
- ◆ Do not expose the device to water, corrosive or flammable gases, or any flammable material.
Fire or damage to the device could otherwise result.
- ◆ Be careful of the high temperatures generated by the amplifier/motor and the peripherals.
Burn could otherwise result.
- ◆ Do not touch the radiation fin of the amplifier, the regenerative resistor, or the motor while the device is powered up, or immediately after switching the power off, as these parts generate excessive heat.
Burn could otherwise result.
- ◆ In terms of designing safety systems using the Safe Torque Off function, personnel who have expertise of relevant safety standard are supposed to do that job with good understanding of this instruction manual.
Injury or damage to the device could otherwise result.
- ◆ Please read the User Manual carefully before installation, operation, maintenance or inspection, and perform these tasks according to the instructions.
Electric shock, injury or fire could otherwise result.
- ◆ Do not use the amplifier or the motor outside their specifications.
Electric shock, injury or damage to the device could otherwise result.
- ◆ Regenerative resistor has instantaneous capacity. Contact our offices if the instantaneous regenerative power could be high as the result of high-inertia load or high-velocity rotation.


■ Storage

 Prohibited
<ul style="list-style-type: none">◆ Do not store the device where it could be exposed to rain, water, toxic gases or other liquids. Damage to the device could otherwise result.◆ Magnetic rails have been magnetized. Keep away from the magnets anyone who has electronic medical device such as a pace maker. Otherwise, the medical device will not work appropriately, leading to a serious danger to the person who has the medical device.

 Mandatory
<ul style="list-style-type: none">◆ Store the device where it is not exposed to direct sunlight, and within the specified temperature and humidity ranges {- 20°C to + 65°C, below 90% RH (non-condensing)}. Damage to the device could otherwise result.◆ Please contact our office if the amplifier is to be stored for a period of 3 years or longer. The capacity of the electrolytic capacitors decreases during long-term storage, and could cause damage to the device. Damage to the device could otherwise result.◆ Please contact our office if the amplifier is to be stored for a period of 3 years or longer. Confirmations such as bearings and the brakes are necessary.

■ Transportation

 Caution
<ul style="list-style-type: none">◆ When handling or moving this equipment, do not hold the device by the cables, the motor shaft or detector portion. Damage to the device or bodily injury could otherwise result.◆ Keep in mind that it is dangerous at the time of conveyance if it falls and overturns. Bodily injury could otherwise result.

 Mandatory
<ul style="list-style-type: none">◆ Follow the directions written on the outside box. Excess stacking could result in collapse. Bodily injury could otherwise result.◆ The motor angling bolts are used for transporting the motor itself; do not use them for transporting the machinery, etc. Damage to the device or bodily injury could otherwise result.

■ Installation



Caution

- ◆ Do not stand on the device or place heavy objects on top of it.
Bodily injury could otherwise result.
- ◆ Make sure the mounting orientation is correct.
Fire or damage to the device could otherwise result.
- ◆ Do not drop this device or subject it to excessive shock of any kind.
Damage to the device could otherwise result.
- ◆ Do not obstruct the air intake and exhaust vents, and keep them free of debris and foreign matter.
Fire could otherwise result.
- ◆ Consult the User Manual regarding the required distance inside the amplifier disposition.
Fire or damage to the device could otherwise result.
- ◆ Open the box only after checking its top and bottom location.
Bodily injury could otherwise result.
- ◆ Verify that the products correspond to the order sheet/packing list.
Injury or damage could result.
- ◆ Secure the device against falling, overturning, or shifting inadvertently during installation.
Use the hardware supplied with the motor (if applicable).
Bodily injury could otherwise result.
- ◆ Install the device on a metal or other non-flammable support.
Fire could otherwise result.
- ◆ Magnetic rails have been magnetized. A strong magnetic attraction (or repulsion between magnets) arises between the magnets themselves or the magnets and any other objects made of iron such as jigs. Treat them carefully.
Bodily injury could otherwise result.
- ◆ Magnetic rails and coil have metal edges. Handle them with care.
Bodily injury could otherwise result.
- ◆ Voltage is generated at the motor power line when the coil is moved after having been installed.
Electric shock could otherwise result.
- ◆ Place limit switch and collision safety device to linear motor stroke end.
Failure to observe this may result in injury.
- ◆ Make sure to install a limit switch and collision safety device at the stroke end.
Make the collision safety device strong enough to resist the maximum output of the system.
Bodily injury could otherwise result.

■ Wiring



Caution

- ◆ Wiring connections must be secure.
Bodily injury could otherwise result.
- ◆ Wiring should be completed based on the Wiring Diagram or the User Manual.
Electric shock or fire could otherwise result.
- ◆ Wiring should follow electric equipment technical standards and indoor wiring regulations.
An electrical short or fire could otherwise result.
- ◆ Do not connect a commercial power supply to the U, V or W terminals of the servo motor.
Fire or damage to the device could otherwise result.
- ◆ Install a safety device such as a breaker to prevent external wiring short-circuits.
Fire could otherwise result.
- ◆ Do not bind or band the power cable, input/output signal cable and/or encoder cable together or pass through the same duct or conduit.
This action will cause faulty operation.
- ◆ Do not connect DC90V or AC power to the DC24V Brake of the servo motor. Also, do not connect AC400V to the AC200V Fan of the servo motor.
An electrical short or fire could otherwise result.
- ◆ There is no safeguard on the linear motor. Use an over-voltage safeguard, short-circuit breaker, overheating safeguard, and emergency stop to ensure safe operation.
Injury or fire could otherwise result.

■ Operation




Caution

- ◆ Do not perform extensive adjustments to the device as they may result in unstable operation.
Bodily injury could otherwise result.
- ◆ Trial runs should be performed with the motor in a fixed position, separated from the mechanism. After verifying successful operation, install the motor on the mechanism.
Bodily injury could otherwise result.
- ◆ The securing brake is not to be used as a safety stop for the mechanism. Install a safety stop device on the mechanism.
Bodily injury could otherwise result.
- ◆ In the case of an alarm, first remove the cause of the alarm, and then verify safety. Next, reset the alarm and restart the device.
Bodily injury could otherwise result.
- ◆ Check that input power supply voltage is less than a specification range.
Damage to the device could otherwise result.
- ◆ Avoid getting close to the device, as a momentary power outage could cause it to suddenly restart (although it is designed to be safe even in the case of a sudden restart).
Bodily injury could otherwise result.
- ◆ Do not use motor or amplifier which is defective or failed and damaged by fire.
Injury or fire could otherwise result.
- ◆ In the case of any irregular operation, stop the device immediately.
Electric shock, injury or fire could otherwise result.
- ◆ When using the servo motor in vertical axis, provide safety devices to prevent falls during the work that will cause an alarm condition.
Injury or damage could result.
- ◆ Do not touch the rotating part of the linear motor during operation.
Bodily injury could otherwise result.
- ◆ Install sufficient protective cover in moving part of linear motor.
Bodily injury could otherwise result.
- ◆ Keep away dust, water or others from the coil moving area and the magnetic rails.
Electric shock, injury or damage to the device could otherwise result.



Prohibited


- ◆ The built-in brake is intended to secure the motor; do not use it for regular control. Damage to the brake could otherwise result.
Damage to the device could otherwise result.
- ◆ Keep the motor's encoder cables away from static electricity.
Damage to the device could otherwise result.
- ◆ Standard specification servo amplifiers have a dynamic brake resistor. Do not rotate the motor continuously from the outside when the amplifier is not powered on, because the dynamic brake resistor will heat up, and can be dangerous.
Fire or burn could otherwise result.



Mandatory


- ◆ When transporting the magnetic rail, it must be packed as it was.
Transporting it without package could result in injury, since it has been magnetized.
- ◆ Install an external emergency stop circuit that can stop the device and cut off the power instantaneously. Install an external protective circuit to the amplifier to cut off the power from the main circuit in the case of an alarm.
Motor interruption, bodily injury, burnout, fire and secondary damages could otherwise result.
- ◆ There is no safeguard on the motor. Use an over-voltage safeguard, short-circuit breaker, overheating safeguard, and emergency stop to ensure safe operation.
Injury or fire could otherwise result.
- ◆ Operate within the specified temperature and humidity range.
Servo Amplifier
Temperature 0°C to 55°C
Humidity below 90% RH (non-condensing).
Servo Motor
Temperature 0°C to 40°C
- ◆ Humidity below 90% RH (non-condensing).
Burnout or damage to the device could otherwise result.

■ Maintenance • Inspection



Caution

- ◆ Some parts of the servo amplifier (electrolytic capacitor, cooling fan, lithium battery for encoder, fuse) can deteriorate with long-term use. Please contact our offices for replacements.
Damage to the device could otherwise result.
- ◆ Do not touch or get close to the terminal while the device is powered up.
Electric shock could otherwise result.
- ◆ Be careful during maintenance and inspection, as the body of the amplifier becomes hot.
Burn could otherwise result.
- ◆ Please contact your distributor or sales office if repairs are necessary.
Disassembly could render the device inoperative.
Damage to the device could otherwise result.
- ◆ When a work must be done with the protective cover removed, start working carefully and safely paying attention to an electric shock or runaway.
Electric shock or injury could otherwise result.



Prohibited

- ◆ Do not overhaul the device.
Fire or electric shock could otherwise result.
- ◆ Do not measure the insulation resistance and the pressure resistance.
Damage to the device could otherwise result.
- ◆ Do not unplug the connector while the device is powered up.
(Except those that can be inserted or removed)
Electric shock or damage could otherwise result.
- ◆ Do not remove the nameplate cover attached to the device.

■ Disposal**Mandatory**

- ◆ If the amplifier or the motor is no longer in use, it should be discarded as industrial waste.

■ When you use SANYO DENKI amplifier with other manufacturer servo motor combined.

This Servo amplifier system is designed for using in combination of SANYO DENKI linear motor. If other companies' linear motors are used in combination, we will provide you necessary parameters (Motor parameter files) to drive that based on your motor constant provided to us. In that case, SANYO DENKI do not conduct the combination test of this servo amplifier with other companies' linear motors. Therefore, SANYO DENKI assumes no responsibility whatsoever for any motions and characteristics resulting from the use in the combination of that. Also, SANYO DENKI cannot be held responsible for any damages or failures arising out of the use or inability to use those linear motors, even if SANYO DENKI has been advised of the possibility of such damages or failures.

Table of contents

1.	Preface	
1.1	Introduction	1-1
1)	SANMOTION R ADVANCED MODEL features	1-1
1.2	Instruction Manual	1-3
1)	Contents	1-3
2)	Precautions related to these Instructions	1-3
1.3	System Configuration	1-4
1)	Rotary motor model number (R series)	1-5
2)	Servo Amplifier Model Number	1-6
1.4	Product Part Names	1-7
1)	Servo Amplifier	1-7
2)	Rotary motor	1-8
1.5	Combination	1-9
1)	Combination motor list	1-9
2)	Combination encoder list	1-9
2	Specifications	
2.1	Servo Motor	2-1
1)	General Specifications	2-1
2)	Exterior Dimensions / Specifications / Weight	2-1
3)	Mechanical Specifications / Mechanical Strength / Working Accuracy	2-1
4)	Oil Seal Type	2-2
5)	Holding Brake	2-3
6)	Degree of decrease rating for R2□A Motor, with Oil Seal and Brake	2-4
2.2	Motor Encoder	2-5
1)	Serial Encoder	2-5
2)	Pulse Encoder Specifications	2-5
2.3	Servo motor rotational and moving direction	2-6
1)	Rotary motor rotational direction	2-6
2)	Battery Specification	2-6
2.4	Servo Amplifier	2-7
1)	General Specifications	2-7
2)	General Input/Output	2-8
2.5	Power Supply, Calorific Value	2-9
1)	Main circuit Power supply capacity, Control Power supply capacity	2-9
2)	Inrush Current, Leakage Current	2-9
3)	Calorific value	2-10
2.6	Operation Pattern	2-11
1)	Time of acceleration and deceleration, Permitted repetition, Loading precaution (For rotary motor)	2-11
2)	Time of acceleration and deceleration, Permitted repetition, Loading precaution (For linear motor)	2-13
2.7	Regeneration Process	2-15
1)	Resistance value of optional regenerative resistor	2-15
3.	Installation	
3.1	Servo Amplifier	3-1
1)	Servo Amplifier	3-1
2)	Open package	3-2
3)	Mounting direction and location	3-3
4)	Control arrangement within the machine	3-3
3.2	Rotary Motor	3-4
1)	Precautions	3-4
2)	Open package	3-4
3)	Installation	3-4
4)	Mounting method	3-5
5)	Waterproofing and dust proofing	3-5
6)	Protective cover installation	3-6
7)	Gear installation and Integration with the target machinery	3-6
8)	Allowable bearing load	3-8
9)	Cable Installation Considerations	3-8
4.	Wiring	
4.1	Control power supply, Regeneration resistance, and Wiring protective ground	4-1
1)	Name and its function	4-1
2)	Wire	4-1
3)	Wire diameter - Permissible current	4-1
4)	Wiring Example	4-3
5)	Wiring of control power, main circuit power, regenerative resistor and motor power	4-5
6)	Pin disposition of IN, OUT connector	4-6

Table of contents

7)	CN1 connector disposition	4-7
8)	General input-output connector disposition	4-9
4.2	Wiring of Motor Encoder	4-10
1)	EN1 to 4: connector name and its function	4-10
2)	Servo amplifier side terminal number	4-11
3)	Recommended encoder cable specification	4-12
4)	Encoder cable length	4-12
5.	Object Dictionary	
5.1	About EtherCAT	5-1
5.2	Object Dictionary summary	5-1
1)	Structure of Object Dictionary	5-1
2)	Access types	5-1
5.3	CoE Communication Area	5-2
1)	Parameter Details of Object Group from 0x1000	5-3
2)	PDO Mapping	5-5
3)	Communication Timing	5-12
4)	Free Run Mode (Free Run:Asynchronous Operation)	5-13
5)	DC Mode (SYNC0 Event Synchronization)	5-14
6)	DC Mode (SYNC1 Event Synchronization)	5-15
5.4	PDS FSA	5-16
1)	Abstract	5-16
2)	FSA (Finite States Automaton)	5-17
3)	Control Word	5-19
4)	Status Word	5-20
5)	Manufacture specific area	5-21
5.5	Profile Area	5-22
1)	Error Code and Error Operation	5-24
2)	Operation Mode	5-27
3)	Function Group "Position" Mode	5-28
4)	Profile Position Mode	5-31
5)	Cycle Synchronization Position Mode	5-37
6)	Interpolated Position Mode	5-39
7)	Function Group "Velocity", "Homing mode"	5-44
8)	Profile Velocity Mode	5-44
9)	Cyclic Synchronous Velocity Mode	5-44
10)	Homing Mode	5-47
11)	Function Group "Torque (force)"	5-57
12)	Profile torque (force) mode	5-57
13)	Cyclic Synchronous torque (force) mode	5-57
14)	Function Group "Touch Probe"	5-60
15)	Operation Mode Parameter (Profile Area)	5-62
5.6	Manufacturer Specific Area	5-85
1)	Object Group (0x2000-)	5-85
2)	Control Command Parameter	5-90
3)	Auto-Tuning Parameter	5-92
4)	Basic Control Parameter	5-94
5)	Feed Forward vibration suppressor control / Notch filter Parameter	5-100
6)	High stabilized control settings	5-101
7)	Observer Parameter	5-102
8)	Model Following Control Settings Parameter	5-103
9)	Amplifier Function Parameter	5-105
10)	System Parameter	5-122
11)	Monitor Parameter	5-137
6.	Operations	
6.1	Standard Setting Value upon Shipment	6-1
6.2	Test operation	6-2
1)	Installation and Wiring	6-2
2)	Safe Torque OFF Function	6-2
3)	Movement Confirmation	6-3
4)	Machine Movement Check	6-4
6.3	ESC Power ON Sequence	6-5
6.4	EtherCAT Initialization Process	6-6
1)	INIT State	6-6
2)	Pre-Operational State	6-8
3)	Safe-Operational State	6-9
4)	Operational State	6-9

Table of contents

6.5	Operation Sequence	6-10
1)	Operation Sequence from Power ON to Power OFF	6-10
2)	Alarm Occurrence Stop Sequence	6-14
3)	Alarm Reset Sequence	6-17
7.	Adjustments	
7.1	Servo Tuning Functions and Basic Adjustment Procedure	7-1
1)	Servo tuning functions	7-1
2)	Tuning method selection procedure	7-2
7.2	Automatic Tuning	7-3
1)	Use the following parameters for Automatic tuning	7-3
2)	Automatically adjusted parameters in auto-tuning	7-6
3)	Adjustable parameters during auto-tuning	7-6
4)	Unstable functions during auto-tuning	7-8
5)	Adjustment method for auto-tuning	7-8
6)	Auto-Tuning Characteristic selection flowchart	7-9
7)	Monitoring servo gain adjustment parameters	7-10
8)	Manual tuning method using auto-tuning results	7-10
7.3	Automatic tuning of notch filter	7-11
1)	Operation method	7-11
2)	Setting parameters	7-11
7.4	Automatic tuning of FF Vibration Suppression Frequency	7-12
1)	Operation method	7-12
2)	Setting parameters	7-12
7.5	Using Manual Tuning	7-13
1)	Servo system structure and servo adjustment parameters	7-13
2)	Basic manual tuning method for velocity control	7-14
3)	Basic manual tuning method for position control	7-14
7.6	Model Following Control	7-15
1)	Automatic tuning method for Model following control	7-15
2)	Manual tuning method for Model following control	7-16
7.7	Tuning to Suppress Vibration	7-17
1)	FF vibration suppressor control	7-17
2)	Model tracking vibration suppressor control	7-17
3)	Tuning methods	7-19
7.8	Using the Disturbance Observer Function	7-20
8.	Indication	
8.1	EtherCAT Indicator	8-1
1)	IN/OUT Link / Activity Indicator Code: IN L/A, OUT L/A	8-1
2)	RUN Indicator Code: RUN	8-2
3)	Error Indicator Code: ERR	8-3
8.2	Servo Amplifier Indicator	8-4
1)	Main Circuit Power Supply Indicator Code: CHARGE	8-4
2)	Control Power Supply Establish Indicator Code: POW	8-4
3)	Amplifier Status Indicator Code: ST1, ST2, ST3, ST4	8-4
4)	Amplifier Alarm Indicator Code: AL1, AL2, AL3, AL4	8-5
9.	Maintenance	
9.1	Trouble shooting	9-1
9.2	Warning and Alarm List	9-3
1)	Warning Overview	9-3
2)	Warning List	9-3
9.3	Alarm Display	9-3
1)	Alarm Display Overview	9-3
2)	Alarm display list	9-4
9.4	Trouble shooting When Alarm Occurs	9-6
9.5	Encoder Clear and Alarm Reset Methods	9-23
9.6	Inspection	9-24
9.7	Maintenance Parts	9-25
1)	Inspection Parts	9-25
9.8	Replacing battery for motor encoder	9-26
10.	Safe Torque Off function	
10.1	System configuration	10-1
10.2	Safe Torque Off (STO) Function	10-2
1)	Overview	10-2

Table of contents

2)	Standards Conformity	10-3
3)	Risk assessment	10-3
4)	Residual risk	10-3
5)	Delay Circuit	10-4
10.3	Wiring.....	10-5
1)	CN1 connector disposition	10-5
2)	CN1 terminal connection circuit.....	10-5
3)	Example of wiring	10-6
4)	Safety input-off shot pulse for safety device self-diagnosis.....	10-8
10.4	Safe Torque Off Operations.....	10-8
1)	Safe Torque Off active state	10-8
2)	Recovery from Safe Torque Off active state	10-9
3)	Safe Torque Off while Servo Motor Running	10-10
4)	Safe Torque Off while Servo Motor stoppage	10-12
5)	Deviation clear	10-13
6)	Detecting HWGOFF signal errors	10-13
10.5	Error Detection Monitor (EDM).....	10-14
1)	Specifications.....	10-14
2)	Connection example.....	10-14
3)	Error detection method.....	10-15
10.6	Confirmation Test.....	10-16
1)	Preparations	10-16
2)	Confirmation procedure.....	10-16
3)	Acceptance criteria.....	10-16
10.7	Safety Precautions.....	10-17
11.	Linear motor	
11.1	System configuration diagram	11-1
11.2	Wiring.....	11-2
1)	Recommended specification for encoder cable	11-2
2)	Encoder cable length	11-2
3)	Linear encoder wiring (Incremental differential output)	11-2
4)	Terminal numbers on servo amplifier	11-3
5)	Linear encoder signal on motor (D-sub 9 pin).....	11-3
6)	Wire diameter - Permissible current	11-3
11.3	Linear motor control-related parameters	11-4
1)	Setting of system parameter.....	11-4
2)	Setting of linear scale sensor.....	11-5
3)	Setting of magnetic pole position estimation method	11-5
4)	Setting of moving direction.....	11-6
12.	Selection	
12.1	Rotary Motor Sizing.....	12-1
1)	Flowchart of Servo Motor Sizing.....	12-1
2)	Make an operation pattern	12-2
3)	Calculate motor axis conversion load inertia (J_L).....	12-2
4)	Calculate motor shaft conversion load torque (T_L).....	12-3
5)	Calculate acceleration torque (T_a)	12-4
6)	Calculate deceleration torque (T_b)	12-4
7)	Calculate effective torque (T_{rms}).....	12-4
8)	Judgment condition	12-4
12.2	Capacity Selection of Regenerative Resistor	12-5
1)	How to find "regeneration effective power (PM)" of the horizontal axis drive by a formula (Rotary motor) ...	12-5
2)	How to find "regeneration effective power (PM)" of the vertical axis drive by a formula (Rotary motor)	12-6
3)	How to find "regeneration effective power (PM)" of the vertical axis drive by a formula (Linear motor).....	12-7
4)	Capacity Selection of Regenerative Resistor	12-8
5)	Selection of external regenerative resistor instantaneous tolerance	12-8
6)	Capacity of External Regenerative Resistor and Resistor Model Name	12-8
7)	Thermostat Connection of External Regenerative Resistor	12-9
8)	Protection Function of Regenerative Resistance.....	12-9
9)	Confirmation method of regeneration effective power PM in actual operation.....	12-10
10)	Precaution for external regenerative resistor installation.....	12-10

Table of contents

13.	Appendix	
13.1	Standards Conformity	13-1
1)	Standards conformity	13-1
2)	Appliance classes, Degrees of Protection, Pollution Level	13-2
3)	Connection and installation	13-2
4)	UL File Number	13-2
13.2	Compliance with EU Directives	13-3
1)	Conformity verification test	13-3
2)	EMC Installation Requirements	13-4
3)	Precautions for noise filter connection	13-5
13.3	Servo motor outline drawing	13-6
1)	R2 motor, flange size 40mm and 60mm	13-6
2)	R2 motor, flange size 20mm	13-7
3)	Flange size 14mm R2GAD102RM (DC48V)	13-7
4)	Compact cylinder linear motor DE0AC001A03MX00 (DC48V)	13-8
13.4	Servo Motor Data Sheet	13-9
1)	Characteristics table	13-9
2)	Velocity-torque characteristics	13-12
3)	R2GAD102RM velocity-torque characteristics	13-13
4)	DE0AC001A03MX00 velocity—force characteristic	13-13
5)	Overload characteristics	13-14
13.5	Outline drawing of servo amplifier	13-15
13.6	Optional items	13-16
1)	Connector arrangement drawing	13-16
2)	Connector set model number	13-17
3)	Related items of battery for battery backup method absolute encoder	13-18
4)	Fixing bracket for side surface	13-20
5)	Related items for MOTOR setup software and serial communication	13-20
6)	External regenerative resistor	13-21
13.7	Outline drawing of regenerative resistor	13-22

1

1. Preface

1.1	Introduction	1-1
1) 1.1	SANMOTION R ADVANCED MODEL features	1-1
1.2	Instruction Manual	1-3
1) 1.2	Contents	1-3
2) 1.2	Precautions related to these Instructions	1-3
1.3	System Configuration	1-4
1) 1.3	Rotary motor model number (R series)	1-5
2) 1.3	Servo Amplifier Model Number	1-6
1.4	Product Part Names	1-7
1) 1.4	Servo Amplifier	1-7
2) 1.4	Rotary motor	1-8
1.5	Combination	1-9
1) 1.5	Combination motor list	1-9
2) 1.5	Combination encoder list	1-9

1.1 Introduction

The AC Servo amplifier SANMOTION R ADVANCED MODEL multi-axes EtherCAT provides two kinds capacity. The servo motor corresponds to the rotary motor of R series 200W or less and the compact linear motor of DE0AC001A03MX00. For motor encoder, rotary motor can use serial encoder and pulse encoder, linear motor can use pulse encoder. Backup batteries for motor encoder can be supplied via servo amplifier dedicated connector. In addition, connectors for EtherCAT communication, PC connection and encoder are equipped.


1) SANMOTION R ADVANCED MODEL features

- Downsizing/Energy saving

It is appropriate to the system which has limited installation because realizing space saving downsized by 4 axes integration. In addition, it contributes energy saving of system because the motor regenerative power can be used as the power for another motor.
 It is DC power input type (Main circuit: DC48V (24V), Control circuit: 24V) servo amplifier.

- Shortening a settling time (High response position/velocity control)

We have shortened the positioning time to 1/2 the current use, which improves the throughput of the machine using a high-response model following control and using model following vibration suppression control and feed forward vibration suppression control simultaneously.
 Furthermore, external disturbance suppression can be performed at the same time with parallel use of an external disturbance observer, which creates the target value's required response and the external disturbance suppression as well as stabilizes the robust activity necessary to operate the servo realistically at a high level.



- MOTOR setup software


4-axes setup operation via single cable is available.
 Improvement of operation trace function, ability to measure operational properties of the servo motor with virtually the same operability of an oscilloscope, which increases measurement efficiency of machinery properties. Additionally, the creation of a multi-window display allows the operator to change parameters by checking measurement data for servo tuning, allowing for improved tuning efficiency.

■ Safe torque off function

By using hardware equipped with Safe Torque Off function that safely disables motor torque, you can easily incorporate safety functions to the machines.

In this servo system, safe torque off conditions of all 4 axes are changed together depending on single safety input.

Also, failure detection monitor of 4 axes outputs together. (Failure detection is output when any axis has failure condition.)



■ Installation of Power supply device and overcurrent protection device

For power supply of this servo amplifier (Main circuit: DC48V (24V), Control circuit: 24V), use of general AC/DC power device (switching power supply) is supposed. Please prepare an overcurrent protection fuse or breaker etc on power line to the input port of servo amplifier from AC power because fuse is not built in to the main and control power input of servo amplifier. (This servo amplifier is getting UL standards with condition that fuse is installed to input port. Refer to chapter 13, about the standards conformity.)

■ Digital operator

Digital operator which is built into our AC servo amplifier "SANMOTION R" and "SANMOTION R ADVANCED MODEL", is not equipped.

■ Cautions on wiring length

Main circuit power and control power supply are intended to be input from commonly used AC/DC converter. When wiring length from power supply to servo amplifier is relatively long, the voltage might drop due to cable impedance, and this may cause motor torque decrease and control circuit error. Please perform wiring with use of thick cable and minimal-length as much as possible, so as not to let any voltage drops occur.

■ Analog monitor

Analog monitor function which monitors servo amplifier and motor operation condition, is not equipped to the servo amplifier.

1.2 Instruction Manual

This manual outlines the specifications, installation, wiring, operations, functions, maintenance, etc., of the AC servo amplifier SANMOTION R ADVANCED MODEL as follows:

1) Contents

- Chapter 1 Preface
Product outline, model number, names of components.
- Chapter 2 Specifications
Detailed specifications for Servo Motor, Servo Amplifier and Motor Encoder.
- Chapter 3 Installation
Explanation of installation procedure
- Chapter 4 Wiring
Illustrations and explanations of wiring
- Chapter 5 Object Dictionary
Explanation of EtherCAT Interface Object Dictionary
- Chapter 6 Operations
Discussion of operation sequence, test operations and parameters
- Chapter 7 Adjustments
Explanation of auto tuning, manual servo tuning, etc.
- Chapter 8 Showing
Explanation of the LED display
- Chapter 9 Maintenance
Explanation of troubleshooting when alarms occur and inspection
- Chapter 10 Safe Torque Off function
Explanation of safe torque off function and how to use it
- Chapter 11 Linear motor
Explanation of how to use when linear motor connected.
- Chapter 12 Selection
Explanation of selection method for the servo motor as well as regenerative resistance capacity
- Chapter 13 Appendix
Explanation of EtherCAT terminology, servo motor data sheets, dimensions and international standards

2) Precautions related to these Instructions

In order to fully understand the functions of this product, please read this instruction manual thoroughly before using the product. After thoroughly reading the manual, keep it handy for reference.

Carefully and completely follow the safety instructions outlined in this manual.

Note that safety is not guaranteed for usage methods other than those specified in this manual or those methods intended for the original product.

Permission is granted to reproduce or omit a portion of the attached figures (as abstracts) for use.


The contents of this manual may be modified without prior notice as revisions or additions are created regarding the usage method of the product. Modifications are performed as per the revisions of this manual

Although the manufacturer has taken all possible measures to ensure the veracity of the contents of this manual, should you notice any error or omission, please notify your local sales office or the head office of your findings.

Original text of this instruction manual is Japanese. Original text writing has priority if there is difference between original text and the other language writing.


1.3 System Configuration

■ RF2□24A□HA5



Model number structure

1) Rotary motor model number (R series)



Decreasing rating may be needed for the model with oil seal and brake.
Some motor may be the type without oil seal or without brake.
Refer to “Section 2.1 6) Degree of decrease rating for R2□A motor with oil seal/brake”.

■ Motor encoder
Serial encoder


Model	Resolution within 1 rotation	Resolution within multiple rotations	Name	Transmission format
PA035S MLC41A	131072(17bit)	—	Absolute encoder for incremental system	Half-duplex start/stop synchronization 2.5Mbps (standard)
PA035C	131072(17bit)	65536(16bit)	Battery backup method absolute encoder	Half-duplex start/stop synchronization 2.5Mbps (standard)
HA035 RA035	131072(17bit)	65536(16bit)	Battery less absolute encoder	Half-duplex start/stop synchronization 2.5Mbps (standard)
MA018	8192(13bit)	—	Absolute encoder for incremental system	Half-duplex start/stop synchronization 2.5Mbps (standard)

Pulse encoder

Model	Resolution within 1 rotation	Name	Transmission format
PP031T	1000/2000/2048/4096/5000/6000/8192/10000 (P/R)	40mm or over	Wire-saving incremental encoder

Some combinations of motor, sensor, brake etc may not be manufactured. Please contact us before order.

2) Servo Amplifier Model Number




- * Setup values for the servo amplifier are "default values" at the time of shipment from our factory.
- * Adjustments for system parameters according to your equipment specifications as well as for combination of servo amplifier and servo motor are necessary.
- * Must perform appropriate setting to the system which is to be used.
- * See chapter 10 for Safe Torque Off function.

1.4 Product Part Names


1) Servo Amplifier

■ RF2 series amplifier




2) Rotary motor

- Lead wire type
- R2□A04○○○△□◇
- R2□A06○○○△□◇



- R2GAD10○○△□◇
- R2GA02D○○△□◇



1.5 Combination

1) Combination motor list

✓ If there is no Servo motor in the list, Please refer the file: M0011195-Annex 1 "For All of the motor code lists".

■ Rotary motor (DC48V)							
Series	Motor code	Servo motor model number	Input type	Amplifier capacity	Flange size	Output	Maximum speed
R2 Series	0x0261	R2GA04003F	DC48V	40A	□40mm	30W	6,000 min ⁻¹
	0x0262	R2GA04005F	DC48V	40A	□40mm	50W	6,000 min ⁻¹
	0x0263	R2GA04008D	DC48V	40A	□40mm	80W	5,000 min ⁻¹
	0x0264	R2GA06010D	DC48V	40A	□60mm	100W	5,000 min ⁻¹
	0x0265	R2GA06020D	DC48V	40A	□60mm	200W	4,500 min ⁻¹
	0x040C	R2GAD102RM	DC48V	25A	□14mm	2.4W	1,500 min ⁻¹
	0x049B	R2GA02D20F	DC48V	40A	□20mm	20W	6,000 min ⁻¹
	0x0497	R2GA02D30F	DC48V	40A	□20mm	30W	6,000 min ⁻¹

■ Linear motor (DC48V)							
Series	Motor code	Servo motor model number	Input type	Amplifier capacity	Width	Output	Maximum speed
DE Series	0x435A	DE0AC001A03M	DC48V	40A	12mm	5.1W	2m/s

2) Combination encoder list

■ Encoder resolution

Combination amplifier model number	Combination amplifier model number	Combination amplifier model number	Encoder code OD: 0x20FE, 1
Incremental encoder	Absolute encoder	Linear scale encoder	Code
500 P/R	2,048 FMT	5μm (200P/mm)	0x0000
512 P/R	4,096 FMT	2.5μm (400P/mm)	0x0001
1,000 P/R	8,192 FMT	2μm (500P/mm)	0x0002
1,024 P/R	16,384 FMT	1.25μm (800P/mm)	0x0003
1,500 P/R	32,768 FMT	1μm (1,000P/mm)	0x0004
2,000 P/R	65,536 FMT	0.5μm (2,000P/mm)	0x0005
2,048 P/R	131,072 FMT	0.25μm (4,000P/mm)	0x0006
2,500 P/R	262,144 FMT	0.125μm (8,000P/mm)	0x0007
3,000 P/R	524,288 FMT	0.1μm (10,000P/mm)	0x0008
4,000 P/R	1,048,576 FMT	0.05μm (20,000P/mm)	0x0009
4,096 P/R	—	—	0x000A
5,000 P/R	—	—	0x000B
6,000 P/R	—	—	0x000C
8,192 P/R	—	—	0x000D
16,384 P/R	—	—	0x000E
32,768 P/R	—	—	0x000F
10,000 P/R	—	—	0x0010

■ Encoder type (Rotary motor)

Encoder code OD: 0x20FE, 2	Combination encoder	Specification	Encoder type in Amplifier model number	Encoder type in Motor number	Remarks (Description)
0x0000	Incremental encoder (Wire-saving incremental)	4 pairs	0	S	Set when motor encoder is wire-saving incremental encoder.
0x0101	Asynchronous encoder (Incremental system)	2.5MHz Without multi turn output	0	H	Encoder for incremental system, which is serial-output only within rotation, set to use in the same way as incremental encoder. * Use the position at power-on as zero.
0x0201		4.0MHz Without multi turn output			
0x0301	Optical asynchronous encoder	2.5MHz With multi turn output	0	P, R	Encoder normally used in absolute system, set to use in incremental system. No backup lithium battery cell is needed to connect.
0x0401		4.0MHz With multi turn output t			
0x0501	Resolver type asynchronous encoder	2.5MHz With multi turn output t	0	W	Encoder normally used in absolute system, set to use in incremental system. * Use the position at power-on as zero.
0x0601		4.0MHz With multi turn output			
0x0300	Optical asynchronous encoder	2.5MHz With multi turn output	0	P, R	Set to use in absolute system. This is multi turn backup system. For encoder type P, lithium battery connection to motor is required.
0x0400		4.0MHz With multi turn output			
0x0500	Resolver type asynchronous encoder	2.5MHz With multi turn output	0	W	Set to use in absolute system. Multi turn is mechanical backup system, no battery cell is needed to connect.
0x0600		4.0MHz With multi turn output			

■ Encoder type (Linear scale encoder, hall sensor)

Encoder code OD: 0x20FE, 2	Linear scale encoder (Incremental)	Hall sensor	CS-normalization (CS-reset method)	Encoder type in Amplifier model number	Remarks (Description)
0x0850	Phase A, B, Z	No	Software setting (Magnetic pole position estimation)	8	System not using hall sensor. Set to perform magnetic pole position estimation process.
0x0860	Phase A, B, Z	No	Software setting (Forced setting)	8	System not using hall sensor. Set when CS-normalization not performed.

No Text on This Page.

2

2 Specifications

2.1	Servo Motor	2-1
1)	General Specifications	2-1
2)	Exterior Dimensions / Specifications / Weight	2-1
3)	Mechanical Specifications / Mechanical Strength / Working Accuracy	2-1
4)	Oil Seal Type	2-2
5)	Holding Brake	2-3
6)	Degree of decrease rating for R2□A Motor, with Oil Seal and Brake	2-4
2.2	Motor Encoder	2-5
1)	Serial Encoder	2-5
2)	Pulse Encoder Specifications	2-5
2.3	Servo motor rotational and moving direction	2-6
1)	Rotary motor rotational direction	2-6
2)	Battery Specification	2-6
2.4	Servo Amplifier	2-7
1)	General Specifications	2-7
2)	General Input/Output	2-8
2.5	Power Supply, Calorific Value	2-9
1)	Main circuit Power supply capacity, Control Power supply capacity	2-9
2)	Inrush Current, Leakage Current	2-9
3)	Calorific value	2-10
2.6	Operation Pattern	2-11
1)	Time of acceleration and deceleration, Permitted repetition, Loading precaution (For rotary motor)	2-11
2)	Time of acceleration and deceleration, Permitted repetition, Loading precaution (For linear motor)	2-13
2.7	Regeneration Process	2-15
1)	Resistance value of optional regenerative resistor	2-15

2.1 Servo Motor

1) General Specifications

Series name	R2 series servo motor	R2GAD102R
Time rating	Continuous	
Insulation classification	Class F	Class B
Voltage/Dielectric strength	AC1500V, 1 minute	AC600V, 1 minute
Insulation resistance	DC500V, 10MΩ or more	
Protection method	Fully closed, natural cooling type	
	Motor flange size 40 and 60: IP67 (However, except for axial penetration part and cable tip part) Motor flange size 20: IP40	IP4X
Existence of oil sealing	Motor flange size 40 and 60: None (Optionally available) Motor flange size 20: None	None (Installation impossible)
Ambient temperature	0 to +40°C	
Storage temperature	-20 to +65°C	
Ambient humidity	20 to 90% (without condensation)	
Vibration classification	V15	
Excitation method	Permanent magnet type	
Installation method	Flange mount	

2) Exterior Dimensions / Specifications / Weight


Refer to [Servo Motor Dimension (Section 13)]

Refer to [Servo Motor Data Sheet (Section 13)]

3) Mechanical Specifications / Mechanical Strength / Working Accuracy


■ Vibration Resistance

Install the servo motor horizontally (shown in the figure below), so when vibration occurs in any of three (3) directions (up/down, backward/forward, left/right) the motor will withstand vibration acceleration up to 24.5m/s².




■ Vibration Classification

The vibration classification of the servo motor is V15 or less at maximum rotation speed for a single servo motor unit and is measured as indicated in the figure below.



- Shock Resistance**
 Install the shaft of servo motor in a horizontal direction (shown in the figure below). This shaft should withstand shock acceleration up to 98m/s^2 (when shock is applied in an upward/downward direction) for two (2) times. However, since a precision motor encoder is fixed to the counter-load side of the flange, any shock applied to the shaft may cause damage to the motor encoder. Therefore, try to avoid shock to the shaft under any circumstances.



- Mechanical Strength**
 The axis strength of the servo motor can withstand instantaneous maximum torque.
- Working Accuracy**
 The following table shows the accuracy and precision of the servo motor output shaft (Total Indicator Reading) of the parts surrounding the shaft.

Items	T. I. R.	Reference Figure
Vibration of output shaft terminal: α	0.02	
Eccentricity of external mating diameter of flange against output shaft M: β	0.06 (20 to 60)	
	0.02 (14)	
Perpendicularity of flange face against output shaft M: γ	0.04 (20)	
	0.02 (14)	
	0.07 (40 to 60)	

* Values in () are the motor flange size.

4) Oil Seal Type

Oil sealing for output shaft of servo amplifier is available as optional. Contact us for replacing oil sealing.

Servo motor model number	Oil seal type
R2□A04○○○□	Standard: N/A Optional: G-Type
R2□A06○○○□	Standard: N/A Optional: S-Type

* Flange size 14 and 20 motor cannot equip oil sealing.

5) Holding Brake

An optional Holding Brake is available for the servo motor. Since the primary use of this brake is for holding, it should never be used for braking, except in emergency situations.

Turn the brake excitation On or Off using the “holding brake timing signal output”. When using this signal, set the command for brake release time to 0min⁻¹ for the servo amplifier.

To externally control the holding brake, a response time (as in the table below) is required.


When using a motor with the brake, determine a time sequence that accounts for this delay.

Servo motor model number	Static friction torque N·m	Release time msec	Braking delay time msec	
			Varistor	Diode
R2GA04003	0.32	25	15	100
R2GA04005	0.32			
R2GA04008	0.32			
R2GA06010	0.36	30	20	120
R2GA06020	1.37			



✓ Flange size 14 and 20 motor cannot equip holding brake.

■ Brake operating time is measured in the following circuit:

◆ Varistor used circuit



◆ Diode used circuit



* Brake release time and Braking delay time refers to those times mentioned in the above table. The Brake release time is the same for both the varistor and diode.

6) Degree of decrease rating for R2□A Motor, with Oil Seal and Brake

In terms of servomotors with oil-seal and/or brake, the following de-rating ratios have to be applied to the torque characteristic in the continuous speed range.

Condition		Degree of decrease rating
Brake	Oil seal	R2GA04005
No	No	-
Yes	No	
No	Yes	90%
Yes	Yes	

2.2 Motor Encoder

1) Serial Encoder

■ Absolute Encoder for Incremental System

Model	Resolution	Synchronization method	Transmission method	Baud rate
PA035S CLM41A	131,072 division (17bits)	Asynchronous	Half duplex serial communication	2.5Mbps
MA018	8,192division (13bit)			

Model number example: R2-series, square size: 40mm, 30W-model R2AA04003FXH00

■ Battery Backup Method Absolute Encoder

Model	Resolution	Multiple rotations	Synchronization method	Transmission method	Baud rate
PA035C	131,072 division (17bits)	65,536 (16bit)	Asynchronous	Half duplex serial communication	2.5Mbps
	131,072 division (17bits)	65,536 (16bit)	Asynchronous	Half duplex serial communication	4.0Mbps

Model number example: R2-series, square size: 40mm, 50W-model R2GA04005FCP00

■ Battery-less Absolute Encoder

Model	Resolution	Multiple rotations	Synchronization method	Transmission method	Baud rate
RA035C	131,072 division (17bits)	65,536(16bit)	Asynchronous	Half duplex serial communication	2.5Mbps
HA035	131,072 division (17bits)	65,536 (16bit)	Asynchronous	Half duplex serial communication	2.5Mbps
	1,048,578 division (20bits)				4.0Mbps

Model number example: R2-series, square size: 60mm, 80W-model R2GA04008DXR03

- ✓ The motor of flange size 14 can equip only the Absolute Encoder for Incremental System. It cannot select the spec of Battery Backup Method Absolute Encoder, Battery-less Absolute Encoder and Pulse encoder.

2) Pulse Encoder Specifications

■ Wire-saving incremental encoder

Model	Resolution	Applicable flange size
PP031	1000/2000/2048/4096/5000/6000/8192/10000 P/R	40mm, 60mm
PP018T	8192 P/R	20mm

Model number example: R2-series, square size: 20mm, 30W-model R2GA02D30FXS00



- ✓ Pulse encoder may not be able to equip depending on motor type. Please contact us when you are planning to purchase.

2.3 Servo motor rotational and moving direction



1) Rotary motor rotational direction

- Servo motor rotation direction and encoder signal pulses of pulse encoder
Motor rotation direction and motor encoder signal phases are related as follows:

Servo motor rotation direction [CCW]




Servo motor rotation direction [CW]




- * When Z Phase is at high level, both Phases A and B cross the low level once every rotation

- Serial Encoder
Servo motor rotation direction : Counterclockwise rotation from the load side "CCW"
...Note : Position signal output : Increase



- Servo motor rotation direction : Clockwise rotation from the load side "CW"
...Note : Position signal output : Decrease



- * This is the serial encoder output position, and the rotation direction differs in EtherCAT communication.

2) Battery Specification

Model: ER3VLY (produced by TOSHIBA LIFESTYLE PRODUCTS & SERVICES CORPORATION)
Voltage: 3.6V

2.4 Servo Amplifier

1) General Specifications

■ General Specifications

Item		RF2J24A (Small capacity) 20 to 30W, DE0AC001A03M	RF2K24 (Large capacity) 20 to 200W	RF2J14 2.4W For R2GAD102R
Control function		Position/Velocity/Torque control (Switching by parameter)		
Control system		MOS-FET: PWM control, sine wave drive		
Main circuit power supply		DC48V±10% or DC24V±10%		
Control power supply		DC24V±10%		
Environment	Operating ambient temperature	0 to 55°C		
	Operating storage temperature	-20 to +65°C		
	Operating and storage humidity	90%RH or less (No condensation)		
	Height above sea level	1000m or less		
	Vibration	4.9m/s ² , Frequency range: 10 to 55Hz, X, Y and Z direction, each within 2H		
Impact (shock)		19.6m/s ²		
Configuration		Tray shape, external DC power supply		
		Natural air cooling (without fan)	Forced air cooling (built-in fan)	Natural air cooling (without fan)
Lineup model number		RF2J24A0HL5 RF2J24A8HL5	RF2K24A0HL5	RF2J14A0HL5
Rated Input	Control power, Current	DC24V 1.2 A		
	Main power Input, Current	DC24/48V 6.2 A	DC24/48V 11.7 A	DC24/48V 6.2 A
Single axis	Rated output voltage and current	3 φ 0-24/0-48V 6.0Arms		3 φ 0-24/0-48V 2.0Arms
	Instantaneous maximum output voltage and current	3 φ 0-24/0-48V 14.1Arms		3 φ 0-24/0-48V 6.0Arms
	Output limitation	30W or less	200W less	2.4W less
Total 4 axes output limitation		120W less	300W less	9.6W less
Amplifier capacity x controlled axes number		40A x 4 axes		25A x 4 axes
Outline dimension		H200 x W50 x D130mm		
Mass		0.75kg	0.8kg	0.75kg

Note 1) Input power voltage shall be within the scope of this specification.

Note 2) Main circuit power depression decrease torque in the motor momentary range. Select motor with sufficient margin.

Note 3) Fuses are not built in servo amplifier. Place an over current protection (such as fuse) on the line toward DC input part of servo amplifier from AC power through DC power (user to prepare). (Please confirm that fuse is built in the DC power supply you purchase before use.)

Note 4) To use battery for main circuit DC power supply, make sure to install electrolytic capacitor in parallel to protect the servo amplifier. (2,000μF or more-sized capacitor is recommended)

■ Performance

Frequency characteristic	800Hz
Allowable load inertia moment	10 times of motor rotor inertia moment. Note 5)

Note 5) If exceeding the allowable load inertia moment, please consult us.

■ Built-in functions


Protection functions	Over current, Current detection error, Overload, Amplifier overheating, External overheating, Over voltage, Main circuit power low voltage, Control power supply low voltage, Encoder error, Over velocity, Velocity control error, Velocity feedback error, Position deviation excess, Position command pulse error, Built-in memory error, Parameter error
Display (LED)	Control power establishment (Blue), Main circuit charging (Red), Servo condition (Green x4), Servo alarm (Red x4), Port 0/1 linkage (Green x2), Communication RUN (Green), Communication error (Red)
External encoder	Not applicable.
Hall effect sensor	Not applicable.
General I/O	Input: 8 points (4 axes common), Output: 8 points (2 points per axis)
Regeneration process/ Regenerative resistor	Regeneration process: built-in/ Regenerative resistor (14 to 20Ω): external
Dynamic brake circuit	None
Analog monitor	Not applicable.
Safety function	Safe-Torque-Off

■ Refer to chapter 10 for detail of option.

2) General Input/Output

■ General input signals

Sequence input signals	Interactive photo coupler (sink, source connection): × 8 inputs
	External power supply: DC12 to 24V±10%, 100mA or more (DC24V)
	Forward direction limit switch, Reverse direction limit switch, External trip, Forced discharge and Emergency stop.
	Refer to [Index: 0x20F8 General input function selection (chapter 5)].



- * T_H denotes the minimum time that H-level input signal must be held and T_L denotes the minimum time that L-level input signals must be held.
- * Generic input signals will be set depending on the selection of validity conditions of each function. AC characteristics differ depending on set functions.
- * Shows AC characteristics in respective functions.

General input functions	Photo coupler ON Hold time (T_L)	Photo coupler OFF Hold time (T_H)
Emergency stop function (Emergency Stop)	Min. 250μs	Min. 250μs
Forward direction limit switch Reverse direction limit switch Forced discharge input External trip input	Min. 8ms	Min. 8ms

* Generic output is transmitted when the set function has held longer than 125μs inside the servo amplifier.

■ General output signals

Sequence output signals	Photorelay output (SYNC, Source connection): x 8 outputs (2 per axis)
	External power supply voltage: DC12 to 24V±10%, 20mA or more
	Circuit power for output signal: DC12 to 15V±10% / Maximum current value 30mA (per 1 output)
	Circuit power for output signal: DC24 to 15V±10% / Maximum current value 50mA (per 1 output)
	Servo ready, Power ON, Servo ON, Holding brake timing, Torque limiting, Velocity limiting, Low speed, Velocity attainment, Matching speed, Zero speed, Command acceptable, Status of gain switch, Velocity loop proportional control status, Control mode switchover status, Forward/Reverse direction limit, Warning, etc.
Refer to [Index: 0x20F9 (chapter 5)], for all of signal names.	

2.5 Power Supply, Calorific Value

1) Main circuit Power supply capacity, Control Power supply capacity

■ DC48V Input (Rotary motor)

Servo amplifier model number	Rated output (W)	Input current of main circuit power supply (A)	Input current of control power supply (A)
R2GA04003F	30	2.5	0.7
R2GA04005F	50	5.3	
R2GA04008D	80	6.6	
R2GA06010D	100	6.9	
R2GA06020D	200	8.0	
R2GAD102RM	2.4	0.8	
R2GA02D20F	20	1.7	
R2GA02D30F	30	2.5	

- ✓ Input current value of main circuit power is effective value in the case of rated revolution velocity and rated torque. Two to three times of the current value shown in the table may be momentarily carried depending on operating patterns such as start-up or stop.
- ✓ The input current of control power supply above is the mean value. The value may vary depending on operating conditions or the encoder connected to your motor, so select the power supply with a margin of more than 1.5 times.

2) Inrush Current, Leakage Current

■ Inrush Current

Large-capacitance capacitors are not contained in main circuit power and control power input part of this series, so high inrush current is not carried at power-on.

■ Leakage Current

Servo amplifier	Leakage current per motor	Total leakage current of 4 motors
RF2 series	0.8 mA	3.5 mA

- ✓ This is the value in the case of using 2m-length tough rubber sheath cable as a power line. Leakage current increases and decreases depending on cable length, so refer to the value in the above table only as a guide of selection.
- ✓ Grounding of control board is mandatory to prevent occurrence of dangerous level voltage on operating panel in the unlikely event of ground leakage. (Grounding resistance value shall be 100Ω or less.)
- ✓ Leakage current value is the value by measuring filter 700Hz with leak-checker. Use earth leakage breaker supporting inverter loads, which is taken as a measure against the possibility that high-frequency earth leakage current is carried and then this causes error on ground-fault circuit interrupter and earth leakage protective relay placed on power supply conducting path, that are caused by floating earth capacitance of servo motor winding, power cable, and servo amplifier.

3) Calorific value

■ Rotary motor

Servo amplifier	Servo motor model number	Servo amplifier total calorific value (W)
RF2	R2GA04003F	9
	R2GA04005F	15
	R2GA04008D	20
	R2GA06010D	22
	R2GA06020D	26
	R2GAD102RM	5
	R2GA02D20F	7
	R2GA02D30F	9

- ✓ For the value in the table, calorific value of regenerative resistor is not included. So, it is required adding as necessary.
- ✓ For installation, strictly follow the way written in "3.1 Installation".
- ✓ These are the value with rated speed and rated torque.

2.6 Operation Pattern

1) Time of acceleration and deceleration, Permitted repetition, Loading precaution (For rotary motor)

The motor's acceleration time(t_a), and deceleration time(t_b) when under constant load is calculated using the following method:

- Acceleration time : $t_a = (J_M + J_L) \cdot (2\pi/60) \cdot \{(N_2 - N_1) / (0.8 \times T_P - T_L)\}$ [s]
- Deceleration time : $t_b = (J_M + J_L) \cdot (2\pi/60) \cdot \{(N_2 - N_1) / (0.8 \times T_P + T_L)\}$ [s]


- ◆ t_a : Acceleration time (s)
- ◆ t_b : Deceleration time (s)
- ◆ J_M : Motor inertia ($\text{kg} \cdot \text{m}^2$)
- ◆ J_L : Load inertia ($\text{kg} \cdot \text{m}^2$)
- ◆ N_1, N_2 : Rotational speed of motor (min^{-1})
- ◆ T_P : Instantaneous maximum stall torque ($\text{N} \cdot \text{m}$)
- ◆ T_L : Load torque ($\text{N} \cdot \text{m}$)

* These expressions are for the rated speed values but exclude the viscous torque and friction of the motor.

- Loading precaution
There are separate limitations on repetitive operations for both the servo motor and servo amplifier, and the conditions of both must be met simultaneously.
- Frequency of permitted repetitions for the servo amplifier
When Start/Stop sequences are repeated frequently, confirm in advance that the frequency of repetitions are within tolerance range. Allowed repetitions differ depending on the type, capacity, load inertia, adjustable speed current value and motor rotation speed of the motor in use. If the load inertia = motor inertia X m-times, and when the permitted Start/Stop repetitions (up to the maximum rotation speed) exceed the following value, please contact us for assistance, as precise calculation of effective torque and regenerating power is critical.

$$\text{Frequency of repetitions} = \frac{20}{m+1} \text{ times / min}$$

- Frequency of permitted repetitions for the servo motor
Permitted Start/Stop repetitions differ according to the motor usage conditions, such as load condition and operating time.
- When the motor repeats continuous speed status and stop status
In operating status (shown below) the motor should be used at a frequency in which its effective torque is less than the rated torque T_R .



- ◆ If the operating cycle is considered as "t", the usable range can be determined as follows:


$$t \geq \frac{T_a^2 t_a + T_L^2 t_s + T_b^2 t_b}{T_R^2} \quad [\text{s}]$$

- T_a : Acceleration torque T_b : Deceleration torque
- T_L : Load torque T_{rms} : Effective torque
- T_R : Rated torque t_s : constant speed time [s]

- ◆ When the cycle time (t) is predetermined T_a, T_b, t_a, t_b appropriate in the above formula are required.

* When actually determining the system drive mode, it is recommended to calculate the load margin and suppress it to $T_{rms} < 0.9T_R$.


- When the motor repeats acceleration, deceleration and stop status
In operating status (shown below) the value of permitted repetitions n (times/minutes) is found with the following equation:



$$N = 2.86 \times 10^2 \times \frac{1}{N (J_M + J_L)} \times \frac{T_P^2 - T_L^2}{T_P^3} \times T_R^2 \quad [\text{times/min}]$$

T_R : Rated torque

- When the motor repeats acceleration – constant speed operation – deceleration status
For the operating status shown below, the value of permitted repetitions n (times/min) is found in the following equation:



$$n = 2.86 \times 10^2 \times \frac{1}{N (J_M + J_L)} \times \frac{T_R^2 - T_L^2}{T_P} \quad [\text{times / min}]$$

T_R : Rated torque

- Negative load**
The servo amplifier cannot perform continuous operation with a negative load from the servo motor. Please contact us when using the amplifier with a negative load.

Examples:

- Motor drive downward (when there is no center weight).
- Using like a generator, such as the wind-out spindle of a winder.

- Load inertia (J_L)**

When the servo amplifier is used with a load inertia exceeding the allowable load inertia calculated in terms of the motor shaft, “main circuit power over voltage detection” or “regenerative error function” may be issued at the time of the operation.

- ◆ Reduce the torque limit
- ◆ Extend the acceleration and deceleration times (slow down)
- ◆ Reduce the maximum rotation speed
- ◆ Reexamine regenerative resistance

2) Time of acceleration and deceleration, Permitted repetition, Loading precaution (For linear motor)

The motor's acceleration time(t_a), and deceleration time(t_b) when under constant load is calculated using the following method:

- Acceleration time : $t_a = (M_C + M_L) \cdot \{(V_2 - V_1) / (0.8 \times F_P - F_L)\}$ [s]
- Deceleration time : $t_b = (M_C + M_L) \cdot \{(V_2 - V_1) / (0.8 \times F_P - F_L)\}$ [s]


- ◆ t_a : Acceleration time (s)
- ◆ t_b : Deceleration time (s)
- ◆ M_C : Linear motor coil mass (kg)
- ◆ M_L : Load weight (kg)
- ◆ V_1, V_2 : Speed of motor (m/s)
- ◆ F_P : Maximum thrust (N)
- ◆ F_L : Load thrust (N)

* The above are calculation formulas within rated velocity with frictional force and gravity applied to moving part ignored.

- Loading precaution
There are separate limitations on repetitive operations for both the servo motor and servo amplifier, and the conditions of both must be met simultaneously.
- Frequency of permitted repetitions for the servo amplifier
When Start/Stop sequences are repeated frequently, confirm in advance that the frequency of repetitions are within tolerance range. Allowed repetitions differ depending on the type, capacity, and load mass, adjustable speed current value and motor velocity of the motor in use. If the load mass = motor coil mass x m-times, and when the permitted Start/Stop repetitions (up to the maximum rotation speed) exceed the following value, please contact us for assistance, as precise calculation of execution force and regenerating power is critical.

$$\text{Frequency of repetitions} = \frac{20}{m+1} \text{ times / min}$$

- Frequency of permitted repetitions for the servo motor
Permitted Start/Stop repetitions differ according to the motor usage conditions, such as load condition and operating time.
- When the motor repeats continuous speed status and stop status
In operating status (shown below) the motor should be used at a frequency in which its execution force is less than the rated force F_R .



◆ If the operating cycle is considered as "t", the usable range can be determined as follows:


$$t \geq \frac{F_a^2 t_a + F_L^2 t_s + F_b^2 t_b}{F_R^2} \quad [s]$$

- | | | |
|-----------------------------|----------------------------|---------------------------------|
| F_a : Acceleration force | F_b : Deceleration force | F_L : Load force |
| F_{rms} : Effective force | F_R : Rated force | t_s : constant speed time [s] |

◆ When the cycle time (t) is predetermined F_a, F_b, t_a, t_b appropriate in the above formula are required.

* When actually determining the system drive mode, it is recommended to calculate the load margin and suppress it to $F_{rms} < 0.9F_R$.


- When the motor repeats acceleration, deceleration and stop status
In operating status (shown below) the value of permitted repetitions n (times/minutes) is found with the following equation:



$$n = 30 \times \frac{1}{V(M_C+M_L)} \times \frac{F_P^2 - F_L^2}{F_P^3} \times F_R^2 \quad \text{[times/min]}$$

F_R : Rated force

- When the motor repeats acceleration – constant speed operation – deceleration status
For the operating status shown below, the value of permitted repetitions n (times/min) is found in the following equation:



$$n = 30 \times \frac{1}{V(M_C+M_L)} \times \frac{F_R^2 - F_L^2}{F_P} \quad \text{[times/min]}$$

F_R : Rated force

- Negative load**
The servo amplifier cannot perform continuous operation with a negative load from the servo motor. Please contact us when using the amplifier with a negative load.

Examples:

- Motor drive downward (when there is no center weight).
- Using like a generator, such as the wind-out spindle of a winder.

- Load mass (M_L)**
For the intended usage in extremely large load mass (M_L) for coil (moving factor) mass, “overvoltage” or “regenerative overload” alarm may be activated during decelerating. In this case, the following procedures are required. Please contact us for the details.

- Reduce the force limit
- Extend the acceleration and deceleration times (slow down)
- Reduce the maximum speed
- Re-examine regenerative resistance

2.7 Regeneration Process

For this amplifier, built-in regenerative resistor is not equipped. The table below shows tolerable regenerative power of our optional external resistor. Refer to [Capacity Selection of Regenerative Resistor (12.2)] for the selection method of regenerative resistor.

1) Resistance value of optional regenerative resistor

■ Tolerable power of optional regenerative resistor

Optional regenerative resistor	Resistance value	Tolerable regeneration resistance power-external type [PR0]
REGIST-080W50B	50 Ω	10W
REGIST-120W50B	50 Ω	30W
REGIST-220W20B	20 Ω	55W

- ✓ The tolerable effective power of external regenerative resistor is maximum 25% of the rated power under natural air cooling.
- ✓ The tolerable effective power of external regenerative resistor is maximum 50% of the rated power under forced air cooling by fan.

3

3. Installation

3.1	Servo Amplifier	3-1
1)	Servo Amplifier	3-1
2)	Open package	3-2
3)	Mounting direction and location	3-3
4)	Control arrangement within the machine	3-3
3.2	Rotary Motor	3-4
1)	Precautions	3-4
2)	Open package	3-4
3)	Installation	3-4
4)	Mounting method	3-5
5)	Waterproofing and dust proofing	3-5
6)	Protective cover installation	3-6
7)	Gear installation and Integration with the target machinery	3-6
8)	Allowable bearing load	3-8
9)	Cable Installation Considerations	3-8

3.1 Servo Amplifier

1) Servo Amplifier

When installing, please be sure to protect the following precautions.

■ Various precautions

The device should be installed on non-flammable surfaces only. Installation on or near flammable materials can cause fire.

Do not stand, and put heavy items on the servo amplifier.

Operate the device within the specified environmental conditions.

Do not drop the device or subject it to excessive shock.

Make sure no screws or other conductive or flammable materials get inside the servo amplifier.

Do not obstruct the air intake and exhaust vents.

The attachment direction should be observed strictly.

Please contact our office if the amplifier is to be stored for a period of 3 years or longer. The capacity of the electrolytic capacitors decreases during long-term storage.

The thing that damage and mounting parts have damaged should fix by returning to our company immediately.

■ If enclosed in a cabinet

The temperature inside the cabinet can exceed the external temperature depending on the power consumption of the device and the size of the cabinet. Consider the cabinet size, cooling, and placement, and make sure the temperature around the servo amplifier does not exceed 55°C. For longevity and reliability purposes it is recommended to keep the temperature below 40°C.

■ If there is a vibration source nearby

Protect the servo amplifier from vibration by installing it on a base with a shock absorber.

■ If there is a heat generator nearby

If the ambient temperature may increase due to convection or radiation, make sure the temperature near the servo amplifier does not exceed 55°C.

■ If corrosive gas is present

Long-term use may cause contact failure on the connectors and connecting parts. Never use the device where it may be exposed to corrosive gas.

■ If explosive or combustible gas is present

Never use the device where explosive or combustible gas is present. The device's relays and contacts, regenerative resistors and other parts can arc (spark) and can cause fire or explosion.


■ If dust or oil mist is present

The device cannot be used where dust or oil mist is present. If dust or oil mist accumulates on the device, it can cause insulation deterioration or leakage between the conductive parts, and damage the servo amplifier.

■ If a large noise source is present

If inductive noise enters the input signals or the power circuit, it can cause a malfunction. If there is a possibility of noise, inspect the line wiring and take appropriate noise prevention measures. A noise filter should be installed to protect the servo amplifier.



3) Mounting direction and location



* Refer to Appendix, optional parts, for side mounting plate.

4) Control arrangement within the machine

- Leave at least 50 mm space above and below the servo amplifier to ensure unobstructed airflow from the inside of the servo amplifier and the radiator. If heat gets trapped around the servo amplifier, use a cooling fan to create airflow.
- Make sure the temperature around the servo amplifier does not exceed 55°C. For longevity and reliability purposes it is recommended to keep the temperature below 40°C.
- Leave at least 10 mm space on both sides of the servo amplifier to ensure unobstructed airflow from the heat sinks on the side and from the inside of the servo amplifier.
- If the servo amplifier is installed on its side, make sure that the ambient temperature does not exceed 50°C, and mount the back panel to a metal plate. Recommended metal plate thickness is 2mm or more.



3.2 Rotary Motor

1) Precautions

■ Various precautions


The device should be installed on non-flammable surfaces only. Installation on or near flammable materials can cause fire.
Do not stand, and put heavy items on the servo amplifier.
Operate the device within the specified environmental conditions.
Do not drop the device or subject it to excessive shock.
The attachment direction should be observed strictly.
The thing that damage and mounting parts have damaged should fix by returning to our company immediately.

2) Open package

Verify the followings when the product arrives.

If you find any discrepancy, contact your distributor or sales office.

- Verify that the model number of the servo motor is the same as ordered.
The model number is located on the main nameplate, following the word "MODEL".
- Verify that there is no problem in the appearance of servo motor.
- Verify that there are no loose screws on the servo motor.




3) Installation

Please note the following regarding the installation location and mounting method for the servo motor.

The servo motor is designed for indoor use. Make sure to install it indoors.	
Do not use the device in locations where the oil seal lip is continuously exposed to oil, or where the device is exposed to large quantities of water, oil drops, or cutting fluid. The motor is designed to withstand only small amounts of moisture spray.	
Ambient temperature: 0 to 40°C Storage temperature: -20 to 65°C Ambient humidity: 20 to 90%	Good ventilation, no corrosive or explosive gases present. No dust or dirt accumulation in the environment. Easy access for inspection and cleaning.

4) Mounting method

- Mounting in several orientations - horizontal, or with the shaft on top or bottom- is acceptable.
- If the output shaft is used in reduction devices that use grease, oil, or other lubricants, or in mechanisms exposed to liquids, the motor should be installed in a perfectly horizontal or downward position. In some models, there is an oil-seal attached to the output shaft. If the shaft is facing upwards and the seal lip is continuously exposed to oil, oil can enter inside the motor and cause damage, as a result of wear and degradation of the oil seal. In such cases an oil seal should be used on the load-side as well. Contact your distributor or sales office if the device is to be used in such conditions.
- The motor connector and cable outlet should be installed facing downwards, as nearly vertical as possible.
- In vertical installation, create a cable trap to prevent oily water from getting into the motor.




5) Waterproofing and dust proofing

- The protection inside the motor conforms to IEC standards (IEC34-5). However, such protection is suitable only for short-term use. For regular use, additional sealing measures are required. Be sure to handle the connector carefully, as damage to the exterior of the connector (painted surface) can reduce its waterproofing capability.
- The motor waterproofing is of IPX 7 class level, but still requires careful handling. If the motor is continuously wet, due to the respiratory effect of the motor, liquid may penetrate inside the motor.
- Install a protective cover to prevent corrosion of the coating and the sealing material, which can be caused by certain types of coolants (especially water soluble types).
- In the case of a cannon plug type motor, use a waterproofed type plug.


6) Protective cover installation

- Install a protective cover (as described below) for motors continuously subjected to liquids.
- Turn the connectors (lead outlets) downwards within the angle range shown in the picture below.
- Install the cover on the side where the water or oil would drip.
- Install the cover at an angle (for runoff), to prevent water or oil from collecting.
- Make sure that the cable does not get soaked in water or oil.
- Create a sag in the cable outside the cover, to make sure water or oil does not penetrate to the motor.
- If it is not possible to install the connectors (lead outlets) facing downwards, create a sag in the cable to prevent water or oil from entering the motor.




7) Gear installation and Integration with the target machinery

- The oil level of the gear box should be below the oil seal lip, for a slight spraying effect on the lip.
- Create a hole to prevent pressure build-up inside the gear box, as pressure can cause water or oil to penetrate the oil seal and enter inside the motor
- If the motor is used with the shaft facing upwards, an oil seal should be used on the opposite side of the mechanism as well. In addition, install a drain to expel the water or oil that may penetrate through this oil seal.




- Refer to the drawing below for correct centering of the motor shaft and the target machinery. Please note when using a rigid coupling that even a slight mistake in centering can damage the output shaft.


Measured at all 4 locations, the difference between the maximum and the minimum should not exceed 3/100mm (coupling rotates jointly)




- Do not subject the servo motor shaft to shock, as the precision encoder is directly connected to it. If it is absolutely necessary to hit the motor for position adjustment or other reasons, use a rubber or plastic hammer and hit the front flange area.



- If mounting to a machine, create enough mounting holes for smooth coupling of the motor flange rabbet. The mounting surface should be flat, otherwise damage to the shaft or the load may occur.
- Use the screw at the end of the shaft for installing parts such as the gear, pulley, or coupling, to avoid shock.




- Tapered servo motor shafts transmit the torque via the tapered surface. Make sure the key fits without rattling. The tapered surface contact should be no less than 70%.
- Use a special tool for removing the gear, pulley, etc.



8) Allowable bearing load

- The table below shows the allowable bearing load of the servo motors. Do not apply excessive thrust load or radial load. In case of belt driving, make sure that the shaft converted value of belt tension does not exceed the allowable values shown below. The thrust load and radial load tolerance values assume individual application to the shaft.



Series	Servo motor model number	Assembly			Operation		
		Radial load (N)	Thrust load (N)		Radial load (N)	Thrust load (N)	
		FR	F direction	F1 direction	FR	F direction	F1 direction
R2	R2GA04003F	98	78	78	49	29	29
	R2GA04005F	150	98	98	98	29	29
	R2GA04008D	150	98	98	98	29	29
	R2GA06010D	150	98	98	98	29	29
	R2GA06020D	390	200	200	200	68	68
	R2GAD102RM	10	5	5	10	5	5
	R2GA02D20F	20	20	20	20	20	20
	R2GA02D30F	20	20	20	20	20	20

* For specifications on other motor, please contact us.

9) Cable Installation Considerations

- Make sure that no stress is applied to the cable and that it is undamaged.
- If the servo motor is installed in a moving location, make sure that no excessive stress is applied to the cable, by allowing a large bending radius.
- Avoid pulling the cable over sharp objects such as cutting scrap that can damage its exterior. Make sure the cable is not touching any machinery, and that it is out of the path of people and machines.
- Prevent bending or additional weight stress on the cable connection by clamping the cable to the machinery.
In applications where the motor or the cable is moving using a cable bear, the bending radius should be based on the required cable-life and the type of cable used.
- Install the cables of moving parts in a manner that permits easy regular replacement.
Consult with your distributor or sales office for recommendations, if you use cables for moving parts.

No Text on This Page.

4


4. Wiring

4.1	Control power supply, Regeneration resistance, and Wiring protective ground	4-1
1)	Name and its function	4-1
2)	Wire	4-1
3)	Wire diameter - Permissible current	4-1
4)	Wiring Example	4-3
5)	Wiring of control power, main circuit power, regenerative resistor and motor power	4-5
6)	Pin disposition of IN, OUT connector	4-6
7)	CN1 connector disposition	4-7
8)	General input-output connector disposition	4-9
4.2	Wiring of Motor Encoder	4-10
1)	EN1 to 4: connector name and its function	4-10
2)	Servo amplifier side terminal number	4-11
3)	Recommended encoder cable specification	4-12
4)	Encoder cable length	4-12

4. Wiring Control power supply, Regeneration resistance, and Wiring protective ground

4.1 Control power supply, Regeneration resistance, and Wiring protective ground

1) Name and its function

Terminal name	Connector	Terminal symbol	Remarks
Main circuit power	CNA	Pin 4 and 8: P Pin 3 and 7: N	DC48V±10% or DC24V±10%
Control power	CNA	Pin 6: +24V Pin 2: 24G	DC24V±10%
Power ground	CNA	Pin 1 and 5: PE	Connect to power ground.
Servo motor connecting terminal	MOT1 to MOT4	Pin 1: Motor ground Pin 2: Phase W Pin 3: Phase V Pin 4: Phase U	Connect to servo motor.
Protective ground		—	Connect to FG of cabinet.
Regenerative resistor connecting terminal	CNC	Pin 1 and 2	Connect to regenerative resistor if lack a regeneration capacity. Regenerative resistor is not built into this amplifier.

2) Wire

The electric wire used for a servo amplifier main circuit power is shown below.

■ Wire type

Kinds of wires		Conductor allowable temperature [°C]
Code	Name	
PVC	Common vinyl electric wire	—
IV	600V electric wire	60
HIV	Special heat-resistant vinyl wire	75

- ✓ The information in this table is based on rated current flowing through three bundled lead wires in ambient temperature of 40°C.
- ✓ When wires are bundled or put into a wire-duct, such as a hardening vinyl pipe or a metallic conduit, take the allowable current reduction ratio into account.
- ✓ If ambient temperature is high, service life of the wires becomes shorter due to heat-related deterioration. In this case, we recommend using heat-resistant vinyl wires.

3) Wire diameter - Permissible current

AWG sizes	Nominal cross-sectional area [mm ²]	Conductor resistance [Ω/km]	Allowable current over ambient temperature [A]		
			30°C	40°C	55°C
20	0.5	39.5	6.6	5.6	4.2
19	0.75	26.0	8.8	7.0	5.4
18	0.75	24.4	9.0	7.7	5.8
16	1.25	15.6	12.0	11.0	8.3


- ✓ It is a reference value in the case of a special heat-resistant vinyl wire (HIV).
- ✓ The diameter of an electric wire and permissible current in the case of doing the bundle line of the three electric wires are shown.
- ✓ Use it below by the above-mentioned permissible current.

4. Wiring Control power supply, Regeneration resistance, and Wiring protective ground

Recommended Wire Diameter

The recommendation electric wire diameter used for servo amplifiers and rotary motors are shown below.

■ Input voltage DC48V (R-series rotary motor)

Servo motor model No.	Motor power (U · V · W · \oplus)		Servo amplifier to be combined	Main circuit power supply (P, N)		Control power supply (CP, CN)		Regenerative resistor			
	mm ²	AWG No		mm ²	AWG No	mm ²	AWG No	mm ²	AWG No	mm ²	AWG No
R2GA02D20F	0.52	20	RF2□24	0.83	18	0.33	22	0.83	18	0.83	18
R2GA02D30F											
R2GA04003F											
R2GA04005F											
R2GA04008D											
R2GA06010D	0.33	22	RF2K24	0.83	18	0.33	22	0.83	18	0.83	18
R2GAD102RM			RF2J14								

- ✓ "□" is optional number or alphabetical letter.
- ✓ The above values are provided under condition that ambient temperature is 40°C and rated current is applied to 3 lead bands.
- ✓ Consider wire allowable current reduction rate, when you band wires and then insert them into duct such as cured vinyl tube or metal tube.
- ✓ If ambient temperature is relatively high, the lifetime is shortened due to heat deterioration. In this case special heat-resistant vinyl covered wire (HIV) is recommended.
- ✓ For the main circuit power supply, wire diameter less than above table is able to use depending on servo motor capacity.

■ Caution on cable length


- ◆ Control power (24V, 24G)
When control power input part is relatively long, input voltage for servo amplifier can drop due to cable impedance.
Attention necessary especially when multiple servo amplifiers are supplied power from one power supply. Control power input shall be directly applied to encoder, so if the voltage is out of the scope of 24V±10%-specification (for servo amplifier and encoder) due to voltage drop, servo amplifier and encoder cannot operate. Please consider to shorten and thicken the wiring between power and servo amplifier as much as possible, or use wire corresponding to variable output voltage power supply and remote sensing, when wiring.
- ◆ Main circuit power (P, N)
When control power input part is relatively long, 48V<24V> can drop due to cable impedance. Attention necessary especially when multiple servo amplifiers are supplied power from one power supply.
Please be ware that if main circuit power drops, motor generated torque shall drop (momentary range of high-velocity revolution).
- ◆ Motor input (U, V, and W)
When motor input line is relatively long, the voltage can drop due to cable impedance, and then motor generated torque can decrease. (Momentary range of high-velocity revolution.)
To solve this problem, we recommend selecting motor with sufficient margin for acceleration and deceleration torque calculation.

4. Wiring Control power supply, Regeneration resistance, and Wiring protective ground

4) Wiring Example

Even if it turns off power supply, high-pressure voltage may remain in servo amplifier. Completion of electric discharge turns off the lamp of CHARGE. Please do connection check work after checking putting out lights.


■ Recommended wiring for power




- * Use one of the OUT1 - OUT8 outputs, and set either during ALM status output ON or during ALM status output OFF with the selection setting of "Index: 0x20F9 General output function selection".
- * Place electrolytic capacitor between P and N, or CP and CN on amplifier side as required, when wiring from DC power to servo amplifier is relatively long. In this case, inrush current runs into electrolytic capacitor on power-on, so DC power supply needs to respond the inrush current.
- * To use battery for main circuit DC power supply, make sure to install electrolytic capacitor in parallel to protect the servo amplifier. (2,000 μ F or more-sized capacitor is recommended)

4. Wiring Control power supply, Regeneration resistance, and Wiring protective ground

- In case of connecting inductive load (relay) to output
 - ◆ When using + side of OUT1 or OUT2 for power supply (1st axis)
 - ◆ When using + side of OUT3 or OUT4 for power supply (2nd axis)
 - ◆ When using + side of OUT5 or OUT6 for power supply (3rd axis)
 - ◆ When using + side of OUT7 or OUT8 for power supply (4th axis)



- ◆ When using - side of OUT1 or OUT2 for power supply (1st axis)
- ◆ When using - side of OUT3 or OUT4 for power supply (2nd axis)
- ◆ When using - side of OUT5 or OUT6 for power supply (3rd axis)
- ◆ When using - side of OUT7 or OUT8 for power supply (4th axis)




- * Make sure to install diode as a surge absorber when connecting induction load, such as relay, to the output: OUT1 to OUT8. Please carefully install diode so as not to connect polarity of diode. Failure to do this causes servo amplifier malfunction.

4. Wiring Control power supply, Regeneration resistance, and Wiring protective ground

5) Wiring of control power, main circuit power, regenerative resistor and motor power

■ CN A: terminal arrangement of power input connector (see from cable crimping side)

Terminal number	Signal name	Description
1	FG	Frame grounding
2	CN	Control power: Minus
3	N	Main circuit power: Minus
4	P	Main circuit power: Plus
5	FG	Frame grounding
6	CP	Control power: Plus
7	N	Main circuit power: Minus
8	P	Main circuit power: Plus



CNA	Model number	Applicable wire size	Manufacturer
Housing	5557-8R	-	Molex
Contact	5556-TL	AWG18 to AWG24	

■ CNC: terminal arrangement of regenerative resistor connection (see from cable crimping side)


Terminal number	Signal name	Description
1	-	Generative resistor terminal
2	-	Generative resistor terminal



CNC	Model number	Applicable wire size	Manufacturer
Housing	5557-2R	-	Molex
Contact	5556-TL	AWG18 to AWG24	

■ MOT1 to MOT4: terminal arrangement of motor power connection (see from cable crimping side)

Terminal number	Signal name	Description
1		Motor grounding
2	W	W-phase
3	V	V-phase
4	U	U-phase



MOT1 to 4	Model number	Applicable wire size	Manufacturer
Housing	5557-4R	-	Molex
Contact	5556-TL	AWG18 to AWG24	

※For contact crimping, dedicated crimping tool of manufacturer required.

Crimping tool	Model number	Applicable wire size	Manufacturer
Parts No.	57026-5000	AWG18 to AWG24	Molex

Refer the instruction manual #IS-001J, for how to use crimping tool.



6) Pin disposition of IN, OUT connector

■ Pin assignment

For R-ADVANCED EtherCAT amplifier, port IN/ OUT standard Ethernet connection RJ-45 modular connectors are provided for the EtherCAT communication with a higher-level device. The same pin disposition (same signal) is assigned for both connectors and corresponds to the daisy chain topology. Connect IN (Port 0) to the higher-level device and OUT to the next slave.

Use twisted-pair cables that satisfy at least “Category 5e” to connect the cable.


When you make cables using exclusive tools, use STP (Shielded twisted pair cable) and RJ-45 modular plug with shield.

Either straight or crossed cables can be used for the port connection because an automatic crossover function (Automatic discriminating feature for MDI / MDI-X called Auto MDI / MDI-X) is installed.

IN(port0), OUT(port1)	Terminal number	Signal (Ethernet Connection)	Description
	1	TX+	Transmitting signals +
	2	TX-	Transmitting signals -
	3	RX+	Receiving signals +
	4	—	75Ω Connection
	5	—	75Ω Connection
	6	RX-	Receiving signals -
	7	—	75Ω Connection
	8	—	75Ω Connection


* Connect the master cable (from host unit) to low side connector IN (Port 0), and connect the cable from high side connector OUT (Port 1) to the next slave.

■ Wiring diagram




- R-ADVANCED EtherCAT amplifier is twisted-pair cable and daisy-chain topology-compliant model, and port0 (IN) / 1 (OUT) are Ethernet connection.
- Ethernet port-to-port connection can use both straight and cross cable as the model has auto crossover function for slave amplifier. Connecting cable shall be Category 5e shielded twist- pair cable.

- Caution for RJ-45 modular connector selection
- For the modular connector selection and modification, please confirm the standards dimension below (Standards: TIA-968-A).
- Especially, when the connector (ready-made/ modified product) which has out-of-range dimension at C (from top end of connector housing to lower side of terminal) is used, it gives excessive stress to mating connector and may cause a damage of terminal or connector, and a communication error by contact failure.



7) CN1 connector disposition



- 2013595-3 (*The figure below is viewed from connector's soldered side.)



◆ Signal name and its function


Terminal number	Signal name	Description
1	Reserve	Do not use.
2	Reserve	Do not use.
3	HWGOFF1 -	Signal-input1 (-) for safety function
4	HWGOFF1 +	Signal-input1 (+) for safety function
5	HWGOFF2 -	Signal-input1 (-) for safety function
6	HWGOFF2 +	Signal-input1 (+) for safety function
7	EDM -	Monitor (-) for safety function
8	EDM +	Monitor (+) for safety function

◆ Signal names and functions

Signal name	Terminal NO.	Symbol	Description
Reserved	1	Terminal for maintenance	This is a connection terminal when the function is not used.
Reserved	2		Do not use this terminal.
Safety input 1	3	HWGOFF1-	This is an input signal to control Safe-Torque-Off state. Connection circuit Connected to a relay or open collector transistor circuit. Power supply voltage range: DC24V±10% Internal impedance : 2.2kΩ
	4	HWGOFF1+	
Safety input 2	5	HWGOFF2-	
	6	HWGOFF2+	
Error detection monitor	7	EDM-	This is a signal to monitor errors of Safe-Torque-Off function. Connection circuit Connected to a photo coupler or relay circuit. Power supply voltage range (Uext): DC24V±10% Maximum current value: 50mA Output voltage: Uext-0.5 to Uext
	8	EDM+	
			

- * If you do not use this function, please connect the short-circuit plug for safety instrument that is attached to this product.
- * If the short-circuit plug for safety instrument is required additionally, please order "AL-00849548-02", as our model number.
- * If you do not use this function, please make short-circuit within terminal No. group 1/3/5 and within terminal No. group 2/4/6 by connector "2013595-3".

8) General input-output connector disposition



I/O	Model number	Applicable wire size	Manufacturer
Hood (Straight long screw hook)	10336-52A-008	-	3M
Plug (Soldering type)	10136-3000PE	AWG22 to AWG30	

Terminal arrangement of I/O connector (The figure below is viewed from connector's soldered side.)

Terminal number	Signal name	Symbol	Description	
1	CONT1+	General input 1 +	<p>■ General-purpose input circuit shall connect to relay or Open collector transistor circuit.</p> <p>Power-supply voltage range: DC12V to 24V ± 10%</p> <p>Host equipment: 100mA or more (DC24V) Servo amplifier</p> <p>✓ There are 8 general inputs, and sharing by 4 axes.</p>	
2	CONT1-	General input 1 -		
3	CONT2+	General input 2 +		
4	CONT2-	General input 2 -		
5	CONT3+	General input 3 +		
6	CONT3-	General input 3 -		
7	CONT4+	General input 4 +		
8	CONT4-	General input 4 -		
19	CONT5+	General input 5 +		
20	CONT5-	General input 5 -		
21	CONT6+	General input 6 +		
22	CONT6-	General input 6 -		
23	CONT7+	General input 7 +		
24	CONT7-	General input 7 -		
25	CONT8+	General input 8 +		
26	CONT8-	General input 8 -		
11	OUT1+	1st axis, general output 1 (+)		<p>■ General-purpose output circuit shall connect to relay or Open collector transistor circuit.</p> <p>Power-supply: DC12V to 15V ± 10%, Maximum current: 50mA</p> <p>Power-supply: DC24V ± 10%, Maximum current: 50mA</p> <p>Maximum current shall be 20mA or less if the circuit of host equipment is TTL or CMOS input.</p> <p>✓ There are 2 general inputs per axis.</p>
12	OUT1-	1st axis, general output 1 (-)		
13	OUT2+	1st axis, general output 2 (+)		
14	OUT2-	1st axis, general output 2 (-)		
15	OUT3+	2nd axis, general output 1 (+)		
16	OUT3-	2nd axis, general output 1 (-)		
17	OUT4+	2nd axis, general output 2 (+)		
18	OUT4-	2nd axis, general output 2 (-)		
29	OUT5+	3rd axis, general output 1 (+)		<p>■ General-purpose output circuit shall connect to relay or Open collector transistor circuit.</p> <p>Power-supply: DC12V to 15V ± 10%, Maximum current: 50mA</p> <p>Power-supply: DC24V ± 10%, Maximum current: 50mA</p> <p>Maximum current shall be 20mA or less if the circuit of host equipment is TTL or CMOS input.</p> <p>✓ There are 2 general inputs per axis.</p>
30	OUT5-	3rd axis, general output 1 (-)		
31	OUT6+	3rd axis, general output 2 (+)		
32	OUT6-	3rd axis, general output 2 (-)		
33	OUT7+	4th axis, general output 1 (+)		
34	OUT7-	4th axis, general output 1 (-)		
35	OUT8+	4th axis, general output 2 (+)		
36	OUT8-	4th axis, general output 2 (-)		
9	NC	Reserved		
10	NC	Reserved		
27	NC	Reserved		
28	NC	Reserved		

4.2 Wiring of Motor Encoder

1) EN1 to 4: connector name and its function

■ Battery backup absolute encoder

Servo Amplifier EN1 to 4 Terminal No.	Signal name	Servo motor lead color	Description	Remarks
1	5V	9 (Red)	Power supply	Twisted-pair
2	SG	10 (Black)	Power supply common	
3	(NC)	-	Non connection	-
4	(NC)	-		
5	(NC)	-	Non connection	-
6	(NC)	-		
7	ES +	1 (Brown)	Serial data signal	Twisted-pair
8	ES -	2 (Blue)		
9	BAT +	8 (Pink)	Battery	Twisted-pair
10	BAT -	4 (Purple)		
-	Earth	7 (Shield)	Shield	-

- ✓ Use shielded cable and perform twisted-pair wiring.
- ✓ Connect outer-shielded wires of servo amplifier to metal case (earth) of servo amplifier (EN1 to 4). For the servo motor with leads, the outer shielded wire of the servo motor shall be connected to shielded wires of leads, and for the cannon plug-type servo motor, perform wiring very close to servo motor. Encoder and outer shields are not connected inside the servo motor equipped with this encoder.

■ Absolute encoder for incremental system

Servo Amplifier EN1 to 4 Terminal No.	Signal name	Servo motor lead color	Description	Remarks
1	5V	9 (Red)	Power supply	Twisted-pair
2	SG	10 (Black)	Power supply common	
3	(NC)	-	Non connection	-
4	(NC)	-		
5	(NC)	-	Non connection	-
6	(NC)	-		
7	ES +	1 (Brown)	Serial data signal	Twisted-pair
8	ES -	2 (Blue)		
9	(NC)	-	Non connection	-
10	(NC)	-		
-	Earth	7 (Shield)	Shield	-

- ✓ Use shielded cable and perform twisted-pair wiring.
- ✓ Connect outer-shielded wires of servo amplifier to metal case (earth) of servo amplifier (EN1 to 4). For the servo motor with leads, the outer shielded wire of the servo motor shall be connected to shielded wires of leads, and for the cannon plug-type servo motor, perform wiring very close to servo motor. Encoder and outer shields are not connected inside the servo motor equipped with this encoder.

■ Battery less absolute encoder

Servo Amplifier EN1 to 4 Terminal No.	Signal name	Servo motor lead color	Description	Remarks
1	5V	9 (Red)	Power supply	Twisted-pair
2	SG	10 (Black)	Power supply common	
3	(NC)	-	Non connection	-
4	(NC)	-		
5	(NC)	-	Non connection	-
6	(NC)	-		
7	ES +	1 (Brown)	Serial data signal	Twisted-pair
8	ES -	2 (Blue)		
9	(NC)	-	Non connection	-
10	(NC)	-		
-	Earth	7 (Shield)	Shield	-


- ✓ Use shielded cable and perform twisted-pair wiring.
- ✓ Connect the shielded cable to the metal case (ground) on EN1 to 4 sides and connect the ground to the motor encoder side.

■ Pulse encoder

Servo Amplifier EN1 to 4 Terminal No.	Signal name	Servo motor lead color	Description	Remarks
1	5V	9 (Red)	Power supply	Twisted-pair
2	SG	10 (Black)	Power supply common	
3	(NC)	-	Non connection	
4	(NC)	-		
5	B	2 (Green)	B-phase pulse output	Twisted-pair
6	/B	5 (Purple)		
7	A	1 (Blue)	A-phase pulse output	Twisted-pair
8	/A	4 (Brown)		
9	Z	3 (White)	Z-phase pulse output	Twisted-pair
10	/Z	6 (Yellow)		
-	Earth	7 (Shield)	Shield	

- ✓ Use shielded cable and perform twisted-pair wiring.
- ✓ Connect the shielded cable to the metal case (ground) on EN1 to 4 sides and connect the ground to the motor encoder side.

2) Servo amplifier side terminal number



(Soldered side)

* Wirings vary depending on encoders to be connected, so please perform wiring with care.

I/O	Model number	Applicable wire size	Applicable cable outer diameter	Manufacturer
Connector	36210-0100PL	AWG30 to AWG18	-	3M
Shell kit (Soldering type)	36310-3200-008	-	φ7 to φ9	

3) Recommended encoder cable specification

Shielded cables with multiple twisted pairs	
Cable Ratings	80°C 30V
Conductor resistance value	1Ω or less Note1)
Conductor size	AWG26 - AWG18
SQ (mm ²)	0.15 - 0.75

Note 1) The conductor resistance value is recommended with the cable length actually used.

4) Encoder cable length

The maximum cable lengths under the conductor size of the power supply cable (5V, SG).

Conductor size		Conductor resistance Ω/km (20°C)	Battery backup method absolute encoder Absolute encoder for incremental system Pulse encoder	Battery less absolute encoder
			Length (m)	Length (m)
AWG	26	150 or less	4	6
	24	100 or less	6	10
	22	60 or less	10	16
	20	40 or less	15	25
	18	25 or less	25	41
SQ(mm ²)	0.15	150 or less	4	6
	0.2	100 or less	6	10
	0.3	65 or less	10	16
	0.5	40 or less	15	25
	0.75	28 or less	25	41

* The above conductor resistance values are for reference. Cable lengths are calculated according to the above conductor lengths. Please consult manufacturers, as actual conductor resistance values shall be varied by cable specifications.

* When encoder cable is relatively long, place relay connector on wiring between servo amplifier and encoder so as to ground wires in parallel, or use thicker wire diameter-conducting wire sized cable.

No Text on This Page.

5

5. Object Dictionary

5.1	About EtherCAT	5-1
5.2	Object Dictionary summary	5-1
1)	Structure of Object Dictionary	5-1
2)	Access types	5-1
5.3	CoE Communication Area	5-2
1)	Parameter Details of Object Group from 0x1000	5-3
2)	PDO Mapping	5-5
3)	Communication Timing	5-12
4)	Free Run Mode (Free Run:Asynchronous Operation)	5-13
5)	DC Mode (SYNC0 Event Synchronization)	5-14
6)	DC Mode (SYNC1 Event Synchronization)	5-15
5.4	PDS FSA	5-16
1)	Abstract	5-16
2)	FSA (Finite States Automaton)	5-17
3)	Control Word	5-19
4)	Status Word	5-20
5)	Manufacture specific area	5-21
5.5	Profile Area	5-22
1)	Error Code and Error Operation	5-24
2)	Operation Mode	5-27
3)	Function Group "Position" Mode	5-28
4)	Profile Position Mode	5-31
5)	Cycle Synchronization Position Mode	5-37
6)	Interpolated Position Mode	5-39
7)	Function Group "Velocity", "Homing mode"	5-44
8)	Profile Velocity Mode	5-44
9)	Cyclic Synchronous Velocity Mode	5-44
10)	Homing Mode	5-47
11)	Function Group "Torque (force)"	5-57
12)	Profile torque (force) mode	5-57
13)	Cyclic Synchronous torque (force) mode	5-57
14)	Function Group "Touch Probe"	5-60
15)	Operation Mode Parameter (Profile Area)	5-62
5.6	Manufacturer Specific Area	5-85
1)	Object Group (0x2000-)	5-85
2)	Control Command Parameter	5-90
3)	Auto-Tuning Parameter	5-92
4)	Basic Control Parameter	5-94
5)	Feed Forward vibration suppressor control / Notch filter Parameter	5-100
6)	High stabilized control settings	5-101
7)	Observer Parameter	5-102
8)	Model Following Control Settings Parameter	5-103
9)	Amplifier Function Parameter	5-105
10)	System Parameter	5-122
11)	Monitor Parameter	5-137

5.1 About EtherCAT

For the technical specifications for the network communication construction method, physical parameter adjustment method and the function activation method, another technical document is preparing. Please contact us.

Detailed information of EtherCAT can be obtained from the following ETG(EtherCAT Technology Group)website:

<http://www.ethercat.org/>

■ Trademark

EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

5.2 Object Dictionary summary

1) Structure of Object Dictionary

Each object is addressed using a 16-bit index displaying 4 digits hexadecimal, assigned to each group in the object dictionary. RF2 multi axis EtherCAT amplifier accepts the objects of 4 axes by single ESC, so, the numbering of object from 2nd to 4th axis differ from 1st axis.

Structure of the Object Dictionary of CoE (CANopen over EtherCAT) comply with CiA draft standard proposal 402 is shown as below.

Structure of Object Dictionary

Index (Hex)	Index (Hex)	Object
0x0000 to 0x0FFF	Common object	Data Type Area
0x1000 to 0x1FFF	Common object	Communication Profile Area (CoE communication area)
0x2000 to 0x21FF, 0x5000 to 0x51FF	1st object	Manufacturer Specific Profile Area (Manufacturer spec area)
0x2200 to 0x23FF, 0x5200 to 0x53FF	2nd object	
0x2400 to 0x25FF, 0x5400 to 0x55FF	3rd object	
0x2600 to 0x27FF, 0x5600 to 0x57FF	4th object	
0x2800 to 0x4FFF, 0x5800 to 0x57FF	Reserved	
0x6000 to 0x67FF	1st object	Standardized Device Profile Area (Profile area)
0x6800 to 0x6FFF	2nd object	
0x7000 to 0x77FF	3rd object	
0x7800 to 0x7FFF	4th object	
0x8000 to 0x9FFF	Reserved	
0xA000 to 0xFFFF	Reserved	-

2) Access types

The Attribute column defines the access rights for a particular object.

Means of access are access to attribute data objects, and also direction of access is indicated from Master to Slave.

Access Attributes for Data Objects

Attribute	Description
Rw, RW, rw,	Read and write access
Wo, WO, wo	Write only access
Ro, RO, ro	Read only access
Const, CONST	Read only access, value is constant

5.3 CoE Communication Area

CoE communication object list, Object type, Data length, Access (Dir), PDO Mapping, and parameter effective timing (Update). Are shown. The shapes in the Update column stand for effective timing; #=immediately, \$=ESM (EtherCAT State Machine) transition required, &=control power cycle required.

Communication Area


Index	Sub-Index	Object Type	Name	Data length	Dir	PDO Mapping	Update	NVRAM
0x1000	0x00	VAR	Device Type	Unsigned32	RO	No	-	-
0x1001	0x00	VAR	Error Register	Unsigned8	RO	Possible	-	-
0x1008	0x00	VAR	Device Name of Manufacturer	VisibleString	RO	No	-	-
0x1009	0x00	VAR	Hardware Version of Manufacturer	VisibleString	RO	No	-	-
0x100A	0x00	VAR	Software Version of Manufacturer	VisibleString	RO	No	-	-
0x1010	-	ARRAY	Store Parameters	-	-	-	-	-
	0x00	-	Number of entry	Unsigned8	RO	No	-	-
	0x01	-	Save all parameters	Unsigned32	RW	No	#	-
0x1018	-	RECORD	Identity Object	-	-	-	-	-
	0x00	-	Number of Entry	Unsigned8	RO	No	-	-
	0x01	-	Vender ID	Unsigned32	RO	No	-	-
	0x02	-	Product Code	Unsigned32	RO	No	-	-
	0x03	-	Revision Number	Unsigned32	RO	No	-	-
	0x04	-	Not supported [Serial Number]	Unsigned32	RO	No	-	-
0x10F0	-	ARRAY	Backup parameters	-	-	-	-	-
	0x00	-	Number of entry	Unsigned8	RO	No	-	-
	0x01	-	Checksum	Unsigned32	RO	No	-	Yes
0x1400-0x1403	-	RECORD	RxPDO Parameter	-	-	-	-	-
	0x00	-	Number of Entry	Unsigned8	RO	No	-	-
	0x01-0x05	-	Reserved	Unsigned32	RW	No	\$	-
0x1500-0x1503	0x06	-	RxPDO exception PDO	Octet-String	RW	No	\$	-
	0x07	-	RxPDO State	BOOLEAN	RO	Possible	-	-
	0x08	-	RxPDO Control	BOOLEAN	RW	Possible	#	-
0x1600-0x1603	0x09	-	RxPDO Toggle	BOOLEAN	RW	Possible	#	-
	-	RECORD	1 st to 4 th , 257 th to 260 th Reception PDO Mapping	PDO Mapping	-	-	-	-
	0x00	-	Number of Entry to RxPDO	Unsigned8	RW	No	\$	-
0x1700-0x1703	0x01-n	-	Object mapped in the 1st ...	Unsigned32	RW	No	\$	-
	0x01-n	-	Object mapped in the n-th	Unsigned32	RW	No	\$	-
0x1800-0x1803	-	RECORD	TxPDO Parameter	-	-	-	-	-
	0x00	-	Number of Entry	Unsigned8	RO	No	-	-
	0x01-0x05	-	Reserved	Unsigned32	RW	No	\$	-
0x1900-0x1903	0x06	-	TxPDO exception PDO	Octet-String	RW	No	\$	-
	0x07	-	TxPDO State	BOOLEAN	RO	Possible	-	-
	0x08	-	Reserved	BOOLEAN	-	-	-	-
0x1A00-0x1B03	0x09	-	TxPDO Toggle	BOOLEAN	RO	Possible	-	-
	-	RECORD	1 st to 512 th Reception PDO Mapping	PDO Mapping	-	-	-	-
	0x00	-	Number of Entry to TxPDO	Unsigned8	RW	No	\$	-
0x1C00	0x01-n	-	Object mapped in the 1st ...	Unsigned32	RW	No	\$	-
	0x01-n	-	Object mapped in the n-th	Unsigned32	RW	No	\$	-
	-	ARRAY	SM(Sync Manager) Communication Type	-	-	-	-	-
0x1C10-0x1C11	0x00	-	Number of Entry	Unsigned8	RO	No	-	-
	0x01-0x08	-	Communication Type of SM0 ...	Unsigned8	RO	No	\$	-
	0x01-0x08	-	Communication Type of SM7	Unsigned8	RO	No	\$	-
0x1C12-0x1C13	-	ARRAY	PDO Assignment of SM 0 to SM1	-	-	-	-	-
	0x00	-	No. of Objects PDO assigned	Unsigned8	RW(RO)	No	\$	-
0x1C32-0x1C33	-	ARRAY	PDO Assignment of SM 2 to SM3	-	-	-	-	-
	0x00	-	No. of Objects PDO assigned	Unsigned8	RW(RO)	No	\$	-
	0x01-0x07	-	Index of Objects PDO assigned	Unsigned16	RW	No	\$	-
0x1C32-0x1C33	-	RECORD	SM 2 to SM3 Synchronization	-	-	-	-	-
	0x00	-	Number of Synchronous Parameter	Unsigned8	RO	No	-	-
	0x01	-	Synchronous Type	Unsigned16	RW	No	\$	Yes
	0x02	-	Cycle Time	Unsigned32	RW(RO)	No	-	Yes
	0x03	-	Shift Time	Unsigned32	RO	No	-	-
	0x04	-	Synchronous Type Support	Unsigned16	RO	No	-	-
	0x05	-	Minimum Cycle Time	Unsigned32	RO	No	-	-
	0x06	-	Calculate and Copy Time	Unsigned32	RO	No	-	-
	0x07	-	Reserved	-	-	-	-	-
	0x08	-	Get Cycle Time	Unsigned16	RW	No	-	-
	0x09	-	Delay Time	Unsigned32	RO	No	-	-
	0x0A	-	Sync0 Cycle Time	Unsigned32	RW(RO)	No	-	-
	0x0B	-	Cycle Time Too Small	Unsigned16	RO	No	-	-
	0x0C	-	SM-Event Missed	Unsigned16	RO	No	-	-
	0x0D	-	Shift Time Too Short	Unsigned16	RO	No	-	-
	0x0E	-	RxPDO Toggle Failed	Unsigned16	RO	No	-	-
	0x0F-0x1F	-	Reserved	-	-	-	-	-
0x20	-	Sync Error	BOOL	RO	Possible	-	-	

* The index which does not appear in the list among 0x1000 to 0x1FFF is Reserved.

1) Parameter Details of Object Group from 0x1000

0x1000: Device Type

Index	0x1000	Indicates type and profile function of device	Object Code		VAR	
Sub-Idx	Name		Data Type	Access	PDO	Value
0x00	Device Type [DEVICE]	Displays device type for EtherCAT servo drive.	Unsigned32	RO	Possible	0x00020192



0x1001: Error Register

Index	0x1001	Indicates error state of slave. Refer to (Error Field Definition) for the details of error.	Object Code		VAR	
Sub-Idx	Name/Description		Data Type	Access	PDO	Initial Value
0x00	Error Register [ERRREG]		Unsigned8	RO	Possible	0x00
		Bit7:Maker Definition Error Bit6:Reserved Bit5:Device Profile Definition Error Bit4:Communication Error			Bit3:Temperature Error Bit2:Voltage Error Bit1:Current Error Bit0:Generic error	

0x1008: Device Name


Index	0x1008	Indicates product device name.	Object Code		VAR	
Sub-Idx	Name/Description		Data Type	Access	PDO	Value
0x00	Device Name [DEVICE]	Product Device Name (ASCII Code)	Visible String (Unsigned32)	RO	No	Character String (-)
		<u>RF2 K 2 4 A 0 H L 5</u> ✓ Refer to section 1.3, Servo amplifier model number, for model number structure details.				

0x1009: Hardware Version

Index	0x1009	Indicates product hardware version.	Object Code		VAR	
Sub-Idx	Name/Description		Data Type	Access	PDO	Value
0x00	Hardware Version [HARDVER]	Hardware Version of Device	Visible String (Unsigned32)	RO	No	Character String (-)

0x100A: Software Version

Index	0x100A	Indicates product software version.	Object Code		VAR	
Sub-Idx	Name/Description		Data Type	Access	PDO	Value
0x00	Software Version [SOFTVER]	Software Version of Device	Visible String (Unsigned32)	RO	No	Character String (-)
		<u>8 D 0 0 . 0 . 5 5 2 5</u>				



5. Object Dictionary

Object

0x1010:Store Parameters

Index	0x1010	Store current amplifier parameters to non-volatile memory	Object Code		ARRAY													
Sub-Idx	Name/Description		Data Type	Access	PDO	Initial value												
0x00	Number of Entry		Unsigned8	RO	No	0x0C												
0x01	Store all parameters of AX1 [PARASAVE] Store all storable parameters of axis 1, in a lump.		Unsigned32	RW	No	0x0000 0001												
<p>In order to avoid storage of parameters by misstate, storage is only executed when a specific signature is written to the "Sub-index 0x01". The signature is "save".</p> <p>&Write-access Sequence</p> <ol style="list-style-type: none"> 1) Master writes "0x65 76 61 73" (ASCII:s:73, a:61, v:76, e:65) in "Sub-index 01." 2) Slave stores storable parameters in EEPROM of CPU performing servo control when received correct signs. * Slave information connected to ASIC is not the stored EEPROM. 3) Slave responds by SDO sending (download-initiating response) after normal storage completion. If failed to store, slave responds via SDO abort transfer servis (abort code: 0606 0000h). If incorrect sign was written, slave responds via SDO abort transfer service (abort code: 0800 0020h). <p>&Read-access Sequence</p> <p>Slave provides information on parameter storing function in the following formats.</p> <table border="1"> <thead> <tr> <th>Bit</th> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>31-2: Reserved</td> <td>0</td> <td>Reserved</td> </tr> <tr> <td>1: Auto</td> <td>0</td> <td>Slave does not store parameters on an autonomous basis.</td> </tr> <tr> <td>0: Cmd</td> <td>1</td> <td>Slave stores parameters when commanded via the above write -access.</td> </tr> </tbody> </table> <p>✓ If NVRAM is Yes at each area of object list , paramaters will be store by this command.</p>							Bit	Value	Description	31-2: Reserved	0	Reserved	1: Auto	0	Slave does not store parameters on an autonomous basis.	0: Cmd	1	Slave stores parameters when commanded via the above write -access.
Bit	Value	Description																
31-2: Reserved	0	Reserved																
1: Auto	0	Slave does not store parameters on an autonomous basis.																
0: Cmd	1	Slave stores parameters when commanded via the above write -access.																
0x02	Not supported [Save communication parameter]		Unsigned32	RW	No	0x0000 0000												
0x03	Not supported [Save application parameter]		Unsigned32	RW	No	0x0000 0000												
0x04	Store all parameters of AX2 [PARASAVE] Store all storable parameters of axis 2, in a lump. ✓Parameter description is same as Sub-Index 0x01.		Unsigned32	RW	No	0x0000 0001												
0x05	Not supported [Save communication parameter]		Unsigned32	RW	No	0x0000 0000												
0x06	Not supported [Save application parameter]		Unsigned32	RW	No	0x0000 0000												
0x07	Store all parameters of AX [PARASAVE] Store all storable parameters of axis 3, in a lump. ✓Parameter description is same as Sub-Index 0x01.		Unsigned32	RW	No	0x0000 0001												
0x08	Not supported [Save communication parameter]		Unsigned32	RW	No	0x0000 0000												
0x09	Not supported [Save application parameter]		Unsigned32	RW	No	0x0000 0000												
0x0A	Store all parameters of AX4 [PARASAVE] Store all storable parameters of axis 4, in a lump. ✓Parameter description is same as Sub-Index 0x01.		Unsigned32	RW	No	0x0000 0001												
0x0B	Not supported [Save communication parameter]		Unsigned32	RW	No	0x0000 0000												
0x0C	Not supported [Save application parameter]		Unsigned32	RW	No	0x0000 0000												

0x10F0: Back up parameter

Index	0x10F0	Checksum value of XML parameter file	Object Code		RECORD	
Sub-Idx	Number of Entry		Data Type	Access	PDO	Value
0x00	Number of Entry		Unsigned8	RO	No	0x01
0x01	Check Sum [FoEChecksum] Indicate checksum value of XML parameter file. When saved parameter or download XML parameter file by FoE.		Unsigned32	RO	No	-

0x1018:Identity Object

Index	0x1018	Indicates information of salve device.	Object Code		RECORD	
Sub-Idx	Name/Description		Data Type	Access	PDO	Value
0x00	Number of Entry		Unsigned8	RO	No	0x04
0x01	Vender ID [VENDOR] Vender ID registered in ETG		Unsigned32	RO	Possible	0x0000 01B9
0x02	Product Code [PRODUCT] Product Code of Production		Unsigned32	RO	No	0x00000006
0x03	Revision No. [AMPREV] Revision Number of Product (Not used: fixed value 0)		Unsigned32	RO	No	(-)
0x04	Serial No. [SERIAL] Serial Number of Product (Not used: fixed value 3)		Unsigned32	RO	No	(-)

1) Synchronous Setup

The features of time and diagnostic function are described by object 0x1C32, 0x1C33, 0x1C02, 0x1400-0x15FF, and 0x1800-0x19FF in the supported synchronous mode.

The supported synchronous mode is described by the portion in OP mode of device description.

The PDO parameter includes the information on PDO and a PDO mapping object (0x1600-0x17FF and 0x1A00-0x1BFF) is related with PDO parameter object (0x1400-0x15FF, 0x1800-0x19FF), respectively.

Sub-Index 1 to 5 of the PDO parameter object is reserved in order to maintain compatibility with CANopen.

0x1400-0x1403, 1500-1503: RxPDO Parameter 1 to 4, 257 - 260 (rxpdo)

Index	0x1400-0x1403 0x1500-0x1503	The receiving PDO parameters 1 to 4, 257 to 260 show rxpdo setup and state of rxpdo 1 to 4, 257 to 260 corresponded.	Object Code	RECORD		
Sub-Idx	Name/Description		Data Type	Access	PDO	Range (Initial Value)
0x00	Number of Entry		Unsigned8	Ro	No	0x09
0x01	Not supported : COB-ID RxPDO1(-512)		Unsigned32	RW	No	-
0x02	Not supported : Transmission Type		Unsigned8	RW	No	-
0x03	Not supported : Inhibit Time		Unsigned16	RW	No	-
0x04	Reserved		Unsigned8	RO	No	-
0x05	Not supported : Event Timer		Unsigned16	RW	No	-
0x06	Not supported : RxPDO Exclude PDO		Octet-String	RW	No	-
Includes the index of object mapping RxPDO which was not able to assign in this RxPDO.						
0x07	Not supported : RxPDO State		BOOLEAN	RO	Possible	-
When output data of this RxPDO were not arranged to hardware, slave sets it to TRUE =1.						
0x08	Not supported : RxPDO Control		BOOLEAN	RW	Possible	-
When output of this RxPDO does not have an effective value, master sets it to TRUE =1.						
0x09	Not supported : RxPDO Toggle		BOOLEAN	RW	Possible	-
Toggles every update of supporting RxPDO to be written by master.						

2) PDO Mapping

Can always optimize because PDO setting is able to change transfer data between the master and slave freely in the EtheCAT CoE profile.

The change of the RxPDO mapping uses reception of PDO mapping parameter (0x1600 - 0x1603, 0x1700 - 0x1703) with this servo amplifier, and the TxPDO mapping parameter uses transmission of PDO mapping parameter (0x1A00 - 0x1A03, 0x1B00 - 0x1B03).

For mapping, set Index of PDO, Sub-Index, and data length (bit length) to transmit.

Data length must agree with the one in the object dictionary.

Perform mapping in the following procedures.

- Once clear the number of the objects (Set the sub-index to 0.) for mapping to zero.
- Write in setup sequentially from the object (sub-index 1) assigned to the head.
- Write in the number of objects assigned to the number of the objects to map (sub-index 0).

■ Restrictions on PDO-mapping

- BOOLEAN-type object is mappable from the 16-bit-boundary to the next 16-bit-data-field continuously.
- Byte object (8-bit), Half-word object (16-bit), word object (32-bit) are mappable by starting from the boundary of 8-bit, and also can be arranged to either of even/odd address.
- In the case shown below requires that address must start from boundary of 8-bit or 16-bit.
【The case of mapping for Byte object after BOOLEAN-type object】
Fill blank bits by using Padding object (OD:0x0000 SI:0) to reach boundary of 8-bit or 16-bit.
- The number of objects which can be mapped, are maximum 10 objects per axis for RxPDO and TxPDO respectively, and the size of objects are maximum 32 bytes per axis for RxPDO and TxPDO respectively.
If mapping is done exceeding the limit, a malfunction may occur.
- Must set the mapping data size per axis as even-bytes. If the data is odd byte, add 1 bit by using Padding object (OD:0x0000 SI:0) to make an even-byte. If the data is odd byte, sets 1 to the error indicator (0x130.4) of AL status and sets the error code 0x0024 or 0x0025 to AL status code (0x134-0x135).

0x1600 - 0x1603 and 0x1700 - 0x1703 are entry of the RxPDO mapping object dictionary.

0x1600:Reception PDO Mapping 1

Index Ax1	0x1600	Reception PDO Mapping 1	Object Code		RECORD	
Ax2	0x1610		Access	PDO	Range (Initial Value)	
Ax3	0x1620					
Ax4	0x1630					
Sub-Idx	Name/Description					Data Type
0x00	Number of Entry : Number of RxPDO1 Object		Unsigned8	RW	No	0x00 to 0x1F
0x01	Entry 1 Object Mapped in the 1st - RxPDO1		Unsigned32	RW	No	0x60400010
0x02	Entry 2 - Entry-n		Unsigned32	RW	No	0x00000000
- n	Object Mapped in the 2nd to n of - RxPDO1 * "n" is up to 0x1F in maximum.					

5. Object Dictionary

Object

0x1601 - 0x1603,0x1700 - 0x1703:RxPDO Mapping 2 - 4,257 - 260(RxPDO x)

Sub-Idx	Name/Description	Data Type	Access	PDO	Range (Initial Value)
0x00	Number of Entry : "n" Number of RxPDOx Object	Unsigned8	RW	No	0x00 to 0x1F
0x01	Entry 1 - Entry n Object Mapped in the 1st to n of - RxPDOx	Unsigned32	RW	No	0x00000000 - 0xFFFFFFFF

0x1800-0x1803,0x1900-0x1903:TxPDO Parameter 1 - 4,257 - 260(TxPDO)

Sub-Idx	Name/Description	Data Type	Access	PDO	Range (Initial Value)
0x00	Number of Entry	Unsigned8	RO	No	0x09
0x01	Not supported : COB-ID RxPDO1(-512)	Unsigned32	RW	No	0x0000 0000
0x02	Not supported : Transmission Type	Unsigned8	RW	No	-
0x03	Reserved	Unsigned16	RW	No	-
0x04	Reserved	Unsigned8	RO	No	-
0x05	Reserved	Unsigned16	RW	No	-
0x06	Not supported : TxPDO exception PDO Includes the index of object mapping TxPDO which was not able to assign in this RxPDO.	Octet-String	RW	No	-
0x07	Not supported : TxPDO State When output data of this TxPDO were not arranged to hardware, slave sets it to TRUE =1.	BOOLEAN	RO	Possible	-
0x08	Reserved	BOOLEAN	RO	No	-
0x09	Not supported : TxPDO Toggle Toggles every update of supporting TxPDO to be written by master.	BOOLEAN	RO	Possible	-

0x1A00 - 0x1A03 and 0x1B00 - 0x1B03 are entry of the TxPDO mapping object dictionary.

0x1A00: TxPDO Mapping 1 (TxPDO 1)

Sub-Idx	Name/Description	Data Type	Access	PDO	Range (Initial Value)
0x00	Number of Entry : Number of TxPDO1 Object	Unsigned8	RW	No	0x00 - 0x1F
0x01	Entry 1 Object Mapped in the 1st to TxPDO1	Unsigned32	RW	No	0x60410010
0x02	Entry 2 - Entry n Object Mapped in the 2nd to n of - TxPDO1 * "n" is up to 0x1F in maximum.	Unsigned32	RW	No	0x00000000 - 0xFFFFFFFF

0x1A01-0x1A03,0x1B00-0x1B03: TxPDO Mapping 2-4,257-260(TxPDO x)

Sub-Idx	Name/Description	Data Type	Access	PDO	Range (Initial Value)
0x00	Number of Entry : "n" Number of TxPDOx Object	Unsigned8	RW	No	0x00 - 0x1F
0x01	Entry 1 - Entry n Object Mapped in the 1st to n of -TxPDOx * "n" is to 0x1F in maximum.	Unsigned32	RW	No	0x00000000 - 0xFFFFFFFF

5. Object Dictionary

Object

0x1C00:SM (Sync Manager) Communication Type

Index	0x1C00	Indicates Sync Manager communication type.			Object Code		ARRAY
Sub-Idx	Name	Description	Data Type	Access	PDO	Range (Initial Value)	
0x00	Number of Entry	:SM number of channels to be used	Unsigned8	RO	No	0x08	
0x01	Communication Type SM0	1:Mailbox Reception(from master to slave)	Unsigned8	RO	No	0x01	
0x02	Communication Type SM1	2:Mailbox Transmission (from slave to master)	Unsigned8	RO	No	0x02	
0x03	Communication Type SM2	3:PD Output (from master to slave)	Unsigned8	RO	No	0x03	
0x04	Communication Type SM3	4:PD Input (from slave to master)	Unsigned8	RO	No	0x04	
0x05	Communication Type SM4	0:Not used	Unsigned8	RO	No	0x00	
-	...	1:Mailbox Reception					
0x08	Communication Type SM7	2:Mailbox Transmission 3:PD Output 4:PD Inpu					

SM (Sync Manager) PDO Assignment

0x1C10:SM Channel 0(Mailbox Receive)

Index	0x1C10	Indicates the number of the object assigned to SM0 as PDO.		Object Code		ARRAY
Sub-Idx	Description		Data Type	Access	PDO	Value
0x00	Number assigned by PDO		Unsigned8	RO	No	0x00

0x1C11:SM Channel 1(Mailbox Send)

Index	0x1C11	Indicates the number of the object assigned to SM1 as PDO.		Object Code		ARRAY
Sub-Idx	Description		Data Type	Access	PDO	Value
0x00	Number assigned by PDO		Unsigned8	RO	No	0x00

0x1C12:SM Channel 2(Process Data Output)


Index	0x1C12	Indicates the object assigned to SM2 as PDO.			Object Code		ARRAY
Sub-Idx	Description		Data Type	Access	PDO	Range	
0x00	n [several] number of object assigned to RxPDO		Unsigned8	RW	No	0x00 to 0x04	
0x01	Index of the PDO object assigned to RxPDO		Unsigned16	RW	No	0x1600:RxPDO 1	
-						...	
4						0x1603:RxPDO 4 0x1700:RxPDO257 ... 0x1703:RxPDO260	

0x1C13:SM Channel 3(Process Data Input)

Index	0x1C13	Indicates the object assigned to SM3 as PDO.			Object Code		ARRAY
Sub-Idx	Description		Data Type	Access	PDO	Range	
0x00	n [several] number of object assigned to TxPDO		Unsigned8	RW	No	0x00 to 0x04	
0x01	Index of the PDO object assigned to TxPDO		Unsigned16	RW	No	0x1A00:TxPDO 1	
-						...	
4						0x1A03:TxPDO 4 0x1B00:TxPDO257 ... 0x1B03:TxPDO260	

0x1C32:SM2 Synchronization (Output Sync Manager Parameter)



Index	0x1C32	SM2 synchronization setup	Object Code		RECORD																		
Sub-Idx	Name/Description		Access	PDO	Range																		
0x00	Number of synchronization parameter		Unsigned8	RO No	0x20																		
0x01	Synchronization Type [SM2TYP] Sets up synchronous mode.		Unsigned16	RW No	0x0002																		
			Setting Range	0x0000-0x0003																			
<p>0x00:Not Synchronized (Free Run) 0x01:Reserved 0x02:DC Sync0 SYNC0 Event Synchronization (Synchronized with SYNC0 Hardware Signal) 0x03:DC Sync1 SYNC1 Event Synchronization (Synchronized with SYNC1 Hardware Signal)</p> <p>✓ This is the storing parameter into non volatile memory. RF2 multi axes amplifier is controlled with Axis 1 setting, even though 4 axes are there and each axis has this parameter.</p>																							
0x02	Cycle Time : Unit(ns) [SM2SYC] Sets up communication cycle between master and slave. Set Value: When T (ns) =125000x2 ^Y (ns), it is in the range of Y= 1 to 7.		Unsigned32	RW No	0x0007A120 (500µs)																		
			Setting Range	0x0001E848 - 0x00F42400 (0.125 - 16ms)																			
<p>Free Run (Synchronization Type=0x0) : Local Timer Event Cycle of Slave DC SYNC0 (Synchronization Type=0x02) : SYNC0 Cycle Time (0x09A0 - 0x09A3) DC SYNC1 (Synchronization Type=0x03) : SYNC0 Cycle Time (0x09A0 - 0x09A3)</p> <p>Possible Setting Value:T_(ns)</p> <table border="1"> <tr> <td>125us</td> <td>:0x0001E848</td> <td>250us</td> <td>:0x0003D090</td> <td>500us</td> <td>:0x0007A120</td> </tr> <tr> <td>1ms</td> <td>:0x000F4240</td> <td>2ms</td> <td>:0x001E8480</td> <td>4ms</td> <td>:0x003D0900</td> </tr> <tr> <td>8ms</td> <td>:0x007A1200</td> <td>16ms</td> <td>:0x00F42400</td> <td></td> <td></td> </tr> </table> <p>✓ Error is returned when the value is set except the value that can be set as above. ✓ Synchronizes with Interpolation time period (0x60C2) by the setting of Special Function Selection (0x20F7). ✓ This is the storing parameter into non volatile memory. RF2 multi axes amplifier is controlled with Axis 1 setting, even though 4 axes are there and each axis has this parameter.</p>						125us	:0x0001E848	250us	:0x0003D090	500us	:0x0007A120	1ms	:0x000F4240	2ms	:0x001E8480	4ms	:0x003D0900	8ms	:0x007A1200	16ms	:0x00F42400		
125us	:0x0001E848	250us	:0x0003D090	500us	:0x0007A120																		
1ms	:0x000F4240	2ms	:0x001E8480	4ms	:0x003D0900																		
8ms	:0x007A1200	16ms	:0x00F42400																				
0x03	Shift Time : Unit (ns) Time between Hardware Output Effective Operation and Related Event		Unsigned32	RO No	0x0																		
0x04	Synchronization Type Supported		Unsigned16	RO No	0x4007																		



Sub-Idx	Name/Description	Data Type	Access	PDO	Range
0x05	Minimum Cycle Time : Unit(ns) The minimum cycle time is supported by slave. (Maximum time of local cycle)	Unsigned32	RO	No	0x0001E848 (125 μ s)
0x06	Copy and Operation Time (Calc and Copy Time) Unit (ns) Time required of micro controller in order to copy process data to local memory from SyncManager. Operation is processed, if required before data's transmitting to process.	Unsigned32	RO	No	0x0000F424 (62.5 μ s)
0x07	Reserved	Unsigned32	-	-	-
0x08	Get Cycle Time 0:Stops local cycle time measurement. 1:Starts local cycle time measurement. *Measurement value is reset when written into again.	Unsigned16	RW	No	-
0x09	Delay Time It is time during trigger reception of SYNC0 or SYNC1 event to be effective in order to do output drive of the value by the hardware delay time of slave, *Only the synchronous type 0x02, or DC SYNC0/1 of 0x03	Unsigned32	RO	No	0x00007530 (30 μ s)
0x0A	Not supported : Sync0 Cycle Time When SYNC0 fixed cycle time is required of application, it is the time between two Sync0 signals. *Synchronous Time = Only DC SYNC0 of 0x03, and local cycle control	Unsigned32	RW	No	-
0x0B	Cycle Time Too Small This error counter is incremented when cycle time is too short as local cycle cannot be completed or input data cannot prepare by the next SM event.	Unsigned16	RO	No	-
0x0C	SM-Event Missed This error counter is incremented when application demands SM event and cannot receive it. As a result, data may be unable to be copied any more.	Unsigned16	RO	No	-
0x0D	Shift Time Too Short This error counter is incremented when the time interval of SYNC0 trigger and an output is too short, by the fact that shift time or SYNC1 cycle time is too short.	Unsigned16	RO	No	-
0x0E	Not supported : RxPDO Toggle Failed This error counter is incremented when slave supports a RxPDO toggle and then new RxPDO data cannot be received from a master. (When RxPDO toggle is set to TRUE.)	Unsigned16	RO	No	-
0x0F:0x1F	Reserved	-	-	-	-
0x20	Not supported : Sync Error TxPDO mapping is possible at the time of SM-Event Missed or Shift Time Too Short Counter support. <u>0: Not Sync. Error or unsupported Sync.Error</u> <u>1: Sync. Error</u>	BOOL	RO		

0x1C33:SM3 Synchronization (Input SyncManager Parameter)

Index	0x1C33	SM3 Synchronization	Object Code		RECORD	
Sub-Idx	Name/Description		Data Type	Access	PDO	Initial Value
0x00	Number of Synchronization Parameter		Unsigned8	RO	No	0x20
0x01	Synchronization Type [SM3TYP] 0x00:Not synchronized (Free Run) 0x01:Reserved 0x02:DC Sync0 SYNC0 Event Synchronization (Synchronized with SYNC0 Hardware Signal) 0x03:DC Sync1 SYNC1 Event Synchronization (Synchronized with SYNC1 Hardware Signal) 0x04 - 0x21:Reserved 0x22:Synchro SM2 Event Synchronization (When Output is transmitted by Safe-Ope and OP)		Unsigned16	RW	No	0x0002
			Setting Range		0x00, 0x02, 0x03, 0x22	
✓ This is the storing parameter into non volatile memory. RF2 multi axes amplifier is controlled with Axis 1 setting, even though 4 axes are there and each axis has this parameter.						
0x02	Cycle Time : Unit (ns) [SM3CYC]		Unsigned32	RO	No	0x0007A120 (500µs)
Free Run (Synchronous Type=0x00) : Local Timer Event Cycle of Slave DC SYNC0 (Synchronous Type=0x02) : SYNC0 Cycle Time (0x09A0 - 0x09A3) DC SYNC1 (Synchronous Type=0x03) : SYNC0 Cycle Time (0x09A0 - 0x09A3)						
✓ The value shall be the same as Index:0x1C32,Sub-index2.						
0x03	Shift Time : Unit(ns) Time between Input Latch Operation from Hardware and Related Operation		Unsigned32	RO	No	0x0
✓ The value shall be the same as Index:0x1C32,Sub-index2.						
0x04	Synchronous Type Support		Unsigned16	Ro	No	0x4007



Sub-Idx	Name/Description	Data Type	Access	PDO	Range
0x05	Minimum Cycle Time : Unit (ns) The minimum cycle time is supported by slave. (Maximum time of local cycle) ✓ The value shall be the same as Index:0x1C32,Sub-index5.	Unsigned32	RO	No	0x0001E848 (125µs)
0x06	Copy and Operation Time (Calc and Copy Time) Unit (ns) Time required from Input Latch through minimum cycle time.	Unsigned32	RO	No	0x0001E848 (125µs)
0x07	Reserved	-	-	-	-
0x08	Get Cycle Time 0:Stops local cycle time measurement. 1:Starts local cycle time measurement. *Measurement value is reset when written into again.	Unsigned16	RW	No	-
0x09	Delay Time Hardware delay time of a slave, period from trigger reception of SYNC0 or SYNC1 event until latching input value. *Only the synchronous type 0x02, or DC SYNC0/1 of 0x03	Unsigned32	RO	No	-
0x0A	Not supported : Sync0 Cycle Time When SYNC0 fixed cycle time is required of application, it is the time between two Sync0 signals. *Synchronous Time = Only DC SYNC0 of 0x03, and local cycle control	Unsigned32	RW	No	-
0x0B	Cycle Time Too Small This error counter is incremented when cycle time is too short as local cycle cannot be completed or input data cannot prepare by the next SM event.	Unsigned16	RO	No	-
0x0C	SM-Event Missed This error counter is incremented when application demands SM event and cannot receive it. As a result, data may be unable to be copied any more.	Unsigned16	RO	No	-
0x0D	Shift Time Too Short This error counter is incremented when the time interval of SYNC0 trigger and an output is too short, by the fact that shift time or SYNC1 cycle time is too short.	Unsigned16	RO	No	-
0x0E	Not supported : RxPDO Toggle Failed This error counter is incremented when slave supports a RxPDO toggle and then new RxPDO data cannot be received from a master. (When RxPDO toggle is set to TRUE.)	Unsigned16	RO	No	-
0x0F:0x1F	Reserved	-	-	-	-
0x20	Not supported (Sync Error) TxPDO mapping is possible at the time of SM-Event Missed or Shift Time Too Short Counter support. <u>0: Not Sync. Error or unsupported Sync-Error</u> <u>1: Sync. Error</u>	BOOL	RO		

3) Communication Timing

Since application is synchronized with master and slave, data handling of EtherCAT makes a peculiar motion. As for synchronization type, synchronization mode discernment is possible by the combination of 0x1C32 and 0x1C33 of sub index in Object Dictionary. Terms used to Communication Timing are explained below.

Copy and Prepare Outputs

Output data in trigger events, such as local timer event and SM2/3 event and SYNC0/1 event, are read from SyncManager output area. Then, slave operates process using output data, and is outputted to motor. The overview of "Copy and Prepare Output" time is the hardware delay depending on the time and software operating time for copying process data to a local memory from SyncManager, when accurate operation move is required. They follow the value described by SyncManager Object: 0x1C32.

Index	Sub-Index	Time Definition
0x1C32	0x06	Process data copy from SyncManager and accurate operation
0x1C32	0x09	Hardware Delay Time

Get and Copy Inputs

The abstract of "Get and Copy Inputs" time is the delay for copying input process data to hardware reading of a encoder signal and SyncManager 3 area, when accurate operation move is required. They follow the value described by SyncManager Object: 0x1C33. Input can be used in SyncManager 3 area after spending 0x1C32 0x05 "Minimum Cycle Time".

Index	Sub-Index	Time Definition
0x1C33	0x06	Data copy from accurate operation and local memory to SyncManager
0x1C33	0x09	Hardware delay time for input latch preparation

Outputs Valid

"Outputs Valid" in this servo amplifier indicates the time, which added together the following three kinds of time.

- 1) Time until copies process data to local memory from SyncManager by trigger event
- 2) Time until servo loop operation process and the current command to ASIC for servo are written in
- 3) Hardware delay to current loop operation process within ASIC and IGBT gate output

Start Driving Outputs

"Start Driving Outputs" is the timing to write current command in ASIC for servo by micro controller. 0x1C32 0x09 "Hardware Delay Time" indicate between "Start Driving Outputs" and "Outputs Valid".

Start Latch

"Start Latch" is start signal to input latch process.

Between "Start Latch" and "Input Latch", defines as 0x1C33 0x09 "Delay Time" in consideration of hardware delay time and the software operating time mounted in slave.

Input Latch

"Input Latch" in this servo amplifier indicates the real position acquisition timing of motor encoder.

However, when position cannot be received from encoder (serial encoder), data is not copied to SyncManager area.

User Shift Time

"User Shift Time" is value in consideration to the jitter of the master.

SYNC1 Cycle Time

"SYNC1 Cycle Time" may be used for the shift of "Start Input Latch" or "Start Driving Output". "SYNC1 Cycle Time" is defined as a register 0x984 - 0x987 as a shift time between SYNC0 and SYNC1, as long as SYNC0 is a standard signal.

Shift Time

"Shift Time" defines time between the synchronous event such as SM2 event, SYNC0, and SYNC1, and also "Outputs Valid" and "Input Latch". Possible to write if its specifications can shift "Outputs Valid" or "Input Latch".

The synchronous mode supported to this servo amplifier is shown the following.

4) Free Run Mode (Free Run:Asynchronous Operation)

In free run mode, starts by the local timer interrupt of an application controller.


Local cycle moves independently of communication cycle or master cycle.

As an optional feature, slave supports 0x02 of 0x1C32 "Cycle Time". In this case, 0x05 of 0x1C32 "Minimum Cycle Time" is also supported with slave.

Free run mode is set as 0x1C32:0x01=0x00 and 0x1C33:0x00=0x00.

Parameter of Free Run Mode List

Index	Sub-Index	Dir	Name	Remarks
0x1C32	0x01	RW	Synchronization Type	0x00:Free Run Support
	0x02	RO	Cycle Time	Control Cycle Time of Slave
	0x04	RO	Synchronization Type Supported	Bit0=1:FreeRun Support
	0x05	RO	Minimum Cycle Time	RS2-EtherCAT(s) are the same setup to 0x1C32:0x02.
0x1C33	0x01	RW	Synchronization Type	0x00:Free Run Support
	0x02	RO	Cycle Time	Same setup to 0x1C32:0x02
	0x04	RO	Synchronization Type Supported	Same setup to 0x1C32:0x04
	0x05	RO	Minimum Cycle Time	Same setup to 0x1C32:0x05




Communication Timing of Free Run Mode

5) DC Mode (SYNC0 Event Synchronization)

Local cycle of slave is started to SYNC0 event reception.
 Process data frame must complete data reception within slave before the next SYNC0 interruption generating.
 "Calc and Copy Time" contains the minimum time lag between frame reception and SYNC0 event.

Parameter of DC Mode (SYNC0 Event Synchronization)

Index	Sub-Index	Dir	Name	Remarks
0x1C32	0x01	RW	Synchronization Type	Synchronized with 0x02:DC SYNC0
	0x02	RO	Cycle Time	SYNC0 Cycle Time
	0x04	RO	Synchronization Type Supported	Bit4:2=001:DC SYNC0
	0x05	RO	Minimum Cycle Time	
	0x06	RO	Calc and Copy Time	Minimum Time between Frame and SYNC0
	0x08	RW	Cycle Time Acquisition	
	0x09	RO	Delay Time	
	0x0B	RO	Cycle Time Short	
	0x0C	RO	SM Event Missed(Event Omission)	
	0x0E	RO	RxPDO Toggle Failed	
	0x20	RO	Synchronization Error	
	0x1C33	0x01	RW	Synchronization Type
0x02		RO	Cycle Time	Same set to 0x1C32:0x02
0x04		RO	Synchronization Type Support	Same set to 0x1C32:0x04
0x05		RO	Minimum Cycle Time	Same set to 0x1C32:0x05
0x06		RO	Calc and Copy Time	Time between Input Latch and Minimum Cycle Time
0x08		RW	Cycle Time Acquisition	Same set to 0x1C32:0x08
0x0B		RO	Cycle Time Short	Same set to 0x1C32:0x0B
0x0C		RO	SM Event Missed(Event Omission)	Same set to 0x1C32:0x0C
0x0E		RO	RxPDO Toggle Failed	Same set to 0x1C32:0x0E
0x20		RO	Synchronization Error	Same set to 0x1C32:0x20




Communication Timing of DC Synchronization Mode (SYNC0)

6) DC Mode (SYNC1 Event Synchronization)

Local cycle of slave is started to SYNC0 event reception.
 Should receive process data frame before the next SYNC0 interruption generating.
 Since SYNC1 is used for "Output Valid", SYNC1 cycle time defines the time lag between SYNC0 and "Start Driving Output".
 0x1C32: 0x06 (Calc and Copy Time) indicate the allowance time for SYNC1 cycle time, and 0x1C32: 0x09 (Delay Time) define the hardware delay for driving an output.

Parameter of DC Mode (SYNC1 Event Synchronization)

Index	Sub-Index	Dir	Name	Remarks
0x1C32	0x01	RW	Synchronization Type	Synchronized with 0x03:DC SYNC0
	0x02	RO	Cycle Time	SYNC0 Cycle Time
	0x04	RO	Synchronization Type Supported	Bit4:2=010:DC SYNC1
	0x05	RO	Minimum Cycle Time	
	0x06	RO	Calc and Copy Time	Value between SYNC0 and Minimum SYNC1 Cycle Time
	0x08	RW	Cycle Time Acquisition	
	0x09	RO	Delay Time	
	0x0B	RO	Cycle Time Short	
	0x0C	RO	SM Event Missed(Event Omission)	
	0x0E	RO	RxPDO Toggle Failed	
	0x20	RO	Synchronization Error	
0x1C33	0x01	RW	Synchronization Type	Synchronized with 0x03:DC SYNC1
	0x02	RO	Cycle Time	Same set to 0x1C32:0x02
	0x04	RO	Synchronization Type Supported	Same set to 0x1C32:0x04
	0x05	RO	Minimum Cycle Time	Same set to 0x1C32:0x05
	0x06	RO	Calc and Copy Time	Time between Input Latch and Minimum Cycle Time
	0x08	RW	Cycle Time Acquisition	Same set to 0x1C32:0x08
	0x0B	RO	Cycle Time Short	Same set to 0x1C32:0x0B
	0x0C	RO	SM Event Missed(Event Omission)	Same set to 0x1C32:0x0C
	0x0E	RO	RxPDO Toggle Failed	Same set to 0x1C32:0x0E
	0x20	RO	Synchronization Error	Same set to 0x1C32:0x20



Communication Timing of DC Synchronization Mode(SYNC0)


5.4 PDS FSA

1) Abstract

PDS (Power System Device) FSA (Finite States Automaton) of this servo amplifier is an abstract concept which defines the state of the control device stays or passes, operation with the Black Box. It defines the slave's application operating. Slave controls State Device, Mode, and State Change with Object "Control Word (0x6040)" sent via the network.

By "Status word (0x6041)" generated with slave device, the State returns the present state. Besides, PDS and FSA are controlled also by Error Detection Signal.


The slave local and network shows you how to be driving.



2) FSA (Finite States Automaton)

FSA of RS2 EtherCAT slave amplifier determines the sequence of device state and drive control, and operation peculiar to each state is shown.

With this State Machine, what kind of command slave amplifier receives is changed.



FSA of EtherCAT Amplifier

Low Level power Area

: The control source is established and the state can switch on main circuit power supply.

High Level Power Area

: Main circuit power supply is in SwitchOn state. However, motor is in servo-off (torque(force)-off) state, and when the main circuit is not established, Shift 3 is canceled by slave. Target and set point value are invalid.

Torque Area

: After slave completes servo-on (torque(force)-on) preparation, excited by motor with SwitchOn. Motor is operated by target or set point value.

FSA and FSA state describes the state transitions.

FSA State Definition

No.	State	Description
[A]	Not Ready to Switch on	The control source is provided to the slave and established. Slave is performing initialization or self-test.
[B]	Switch on Disabled	Initialization is completed, and slave is in condition to be able to set parameter. However, main circuit power supply is not in the state should be supplied.
[C]	Ready to Switch on	In input permission state about main circuit power supply. Although parameter can be set, function is in invalid state.
[D]	Switch on	Main circuit power supply is provided and in the completion state of Operation enabled preparation. Parameter to slave can be set. This amplifier is able to transit even if main power is OFF.
[E]	Operation Enabled	Fault (alarm) is not generated, where drive function is effective and motor is excited. Parameter to slave can be set.
[F]	Quick Stop Active	In the state where the Quick stop (scram) function is performed. In the state where drive function is effective and motor is excited.
[G]	Fault Reaction Active	In the state where Fault (alarm) occurs with slave and the Quick stop (scram) function is performed. Also, in the state that motor is excited by the drive function effective.
[H]	Fault	In the state which the fault (alarm) generated with the slave and Fault reaction completed. Drive function is invalid, and main circuit power supply is turned on or off by application.

State Shift of FSA

No.	[Before Shift]->[After]	Event / Action
0	[Start] ↓ [Not ready to Switch on]	Event : After control power supply ON or reset application, shifts automatically. Action : Slave performs initialization and self-test.
1	[Not ready to Switch on] ↓ [Switch on Disabled]	Event : Shifts automatically. Action : Communication is permitted.
2	[Switch on Disabled] ↓ [Ready to Switch on]	Event : [Shut down] command (Bit2, 1, 0=1, 1, 0) is received from master. Action : None
3	[Ready to Switch on] ↓ [Switch on]	Event : [Switch On] command (Bit3, 2, 1, 0=0, 1, 1, 1) is received from master. Action : Since in main circuit power supply permission state, provide main circuit power supply.
4	[Switch on] ↓ [Operation enabled]	Event : [Enable operation] command (Bit3, 2, 1, 0=1, 1, 1, 1) is received from master. Action : Slave is Servo-ON and all the internal preset values are cleared.
5	[Operation enabled] ↓ [Switch on]	Event : [Disabled operation] command (Bit3, 2, 1, 0=0, 1, 1, 1) is received from master. Action : Slave is Servo-ON.
6	[Switch on] ↓ [Ready to Switch on]	Event : [Shut down] command (Bit2, 1, 0=1, 1, 0) is received from master. Action : Master should intercept main circuit power supply.
7	[Ready to Switch on] ↓ [Switch on Disabled]	Event : [Quick Stop] command (Bit2, 1=0, 1) or [Disable voltage] command (Bit1=0) is received from master. Action : None
8	[Operation enabled] ↓ [Ready to Switch on]	Event : [Shut down] command (Bit2, 1, 0=1, 1, 0) is received from master. Action : Slave is Servo-Off. Master should intercept main circuit power supply.
9	[Operation enabled] ↓ [Switch on Disabled]	Event : [Disable voltage] command (Bit1=0) is received from master. Action : Slave is Servo-Off. Master should intercept main circuit power supply.
10	[Switch on] ↓ [Switch on Disabled]	Event : [Quick Stop] command (Bit2, 1=0, 1) or [Disable voltage] command (Bit1=0) is received from master. Action : Master should intercept main circuit power supply.
11	[Operation enabled] ↓ [Quick stop active]	Event : [Quick Stop] command (Bit2, 1=0, 1) is received from master. Action : Quick Stop function is performed.
12	[Quick stop active] ↓ [Switch on Disabled]	Event : Shifts automatically when Quick Stop operation is completed or when the "Disable voltage" command (Bit1=0) is received at Quick Stop option code 1-3. Action : Slave is Servo-Off. Master should intercept main circuit power supply.
13	Error occurs ↓ [Fault reaction active]	Event : Fault (Alarm) occurs at slave. Action : Set-up Fault operation function is performed.
14	[Fault reaction active] ↓ [Fault]	Event : Shifts automatically. Action : Slave is Servo-Off. Master should intercept main circuit power supply.
15	[Fault] ↓ [Switch on Disabled]	Event : [Fault reset] command (Bit7=0 -> 1) is received from master. Action : Without slave's Fault factor, Fault reset is performed. Master should clear the "Fault reset" bit (Bit7=1->0) after normal state check.
16	[Quick stop active] ↓ [Operation enabled]	Event : [Enable operation] command (Bit3, 2, 1, 0=1, 1, 1, 1) is received by Quick Stop option code5 to 7. Action : Slave function is permitted.

3) Control Word

Control Word (Object: 0x6040) indicates the command for controlling the FSA state of slave.
 Control Word consists of "FSA Control Bit", "Operation Mode spec. Control Bit", and "Maker Option Control Bit."
 All the operation mode common "FSA Control Bit" allotment and command coding are described below.

Allotment for Each Bit of Control Word

Bit15	Bit14	Bit13	Bit12	Bit11	Bit10	Bit9	Bit8
Manufacturer Specific (Manufacture Specification)					Reserved	Operation mode Specific	Halt
Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
Fault Reset	Operation mode Specific (Operation Mode Specification)			Enable Operation	Quick Stop	Enable Voltage	Switch On

Bit9, 6, 5, and 4 are Operation Mode Specification. Halt functional operation of Bit8 is also Operation Mode Specification. Motion under command is interrupted when Bit8 =1. Slave is defined by Halt option code and operated. Since Bit10 is Reserved, set to "0." Bit15 to 11 are Manufacturer Specification.

0x6040:Control Word (Intersection)

Index Ax1 0x6040 Ax2 0x6840 Ax3 0x7040 Ax4 0x7840	Indicates reception command of FSA (State Machine) that PDS (Power Device System) is controlled.	Object Code	Variable		
Sub-Idx	Description	Data Type	Access	PDO	Initial Value
0x00	Control Word [CWORD] Bit pattern (Bit 7, 3, 2, 1, 0) of Control Word The composition is as follows.	Unsigned16 Display Range	RW	Possible	0x0000 0x0000 - 0xFFFF

MSB

LSB

Manufacturer Specific	Reserved	Operation mode Specific	Halt	Fault reset	Operation mode Specific	Enable operation	Quick stop	Enable voltage	Switch on
15 ... 11	10	9	8	7	6 ... 4	3	2	1	0

Control word bit pattern command

Command	Control Word bit					Transition No.
	bit7	bit3	bit2	bit1	bit0	
Shut down	0	x	1	1	0	2,6,8
Switch On	0	0	1	1	1	3
Switch On+Enable operation	0	1	1	1	1	3+4 *1
Disable voltage	0	x	x	0	x	7,9,10,12
Quick Stop	0	x	0	1	x	7,10,11
Disabled operation	0	0	1	1	1	5
Enable operation	0	1	1	1	1	4,16
Fault reset	0->1	x	x	x	x	15

*1) When Switch On and Enable operation are simultaneously received from master, after performing the "Switch On" function, shifts to "Enable operation" automatically.

4) Status Word

Status Word (Object: 0x6041) provides the status of slave FSA.

Status Word consists of a "Slave FSA Status Bit", "Operation Mode spec. Status Bit", and "Maker Option Status Bit."

"FSA State Bit of Slave" allotment of servo amplifier common portion and command coding are described below.


Allotment for Bit of Status Word

Bit15	Bit14	Bit13	Bit12	Bit11	Bit10	Bit9	Bit8
Reserved (Manufacture Specification)	Reserved (Manufacture Specification)	Reserved (Operation Mode Specification)	Target Value Ignored	Internal Limit Active	Target Reached	Remote	Reserved (Maker Specification)
Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
Warning	Switch On Disabled	Quick Stop	Voltage Enabled	Fault	Operation Enabled	Switched On	Ready to Switch on

Each state will be displayed in the status word bit pattern that indicates the current state.

0x6041:Status Word (Intersection)

Index	Ax1 0x6041 Ax2 0x6841 Ax3 0x7041 Ax4 0x7841	Indicates status of FSA (State Machine) that PDS (Power Device System) is controlled.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Status Word [STSWORD] Bit pattern (Bit 6, 5, 3, 2, 1, 0) of Status Word The composition is as follows.		Unsigned16	RO	Possible	0x0000
			Display Range	0x0000 - 0xFFFF		



Status Word List Bit Pattern(Bit 6,5,3,2,1,0)

No.	FSA State	Bit of Status Word					
		bit6	bit5	bit3	bit2	bit1	bit0
[A]	Not ready to Switch on	0	x	0	0	0	0
[B]	Switch on Disabled	1	x	0	0	0	0
[C]	Ready to Switch on	0	1	0	0	0	1
[D]	Switch on	0	1	0	0	1	1
[E]	Operation enabled	0	1	0	1	1	1
[F]	Quick stop active	0	0	0	1	1	1
[G]	Fault reaction active	0	x	1	1	1	1
[H]	Fault	0	x	1	0	0	0

Bit4 :Voltage Enabled (Main Circuit Bit 14 : Voltage Enabled (Main Circuit Establishment Status)

Means that main circuit power supply is impressed at the time of "1."

Bit5 :Quick Stop (Quick Stop)

Shows that it is under operation by Quick Stop Request at the time of "0"

Bit7 :Warning(Warning Status)

It is set to "1" when warning is occurring in slave. This bit is not cleared even if warning factor is lost.

Bit9 :Remote(Control Word Remote)

Operation through EtherCAT communication enabled at the time of "1".

Operation through EtherCAT communication disabled at the time of "0" although setup software enabled.

Bit10:Target reached

It is set to "1" when an operation mode is changed.

It is set to "1" when Quick stop operation is finished and motor stops with Quick stop Option Code;-2,5 to7

Besides, when Bit10 (Target reached) of status word is "1", Indicates that the motor reached the preset value.

Then cleared to "0" when target position is changed. (Only Profile Position (pp):Reserved)

Bit11:Internal Limit Active

When target position is outside of range, and at invalid, soft limit, and forward/backward side limit, it is set to "1".

Setting range is based on specification.

Bit12:Target value ignored Inposition(csp),Velocity Attainment(csv),Torque (force) Limit(cst)

When Target value ignored bit is in Position (csp), Velocity (csv), and Torque (force) (cst) mode, the update of the command becomes permission "0" with command update permission monitor within servo amplifier. Other than this (when command is prohibited), is set to "1."

* At SOFF -> SON, holding brake operation open time after motor excitation is set up, and it becomes "0"after BOFDYR passes.

Bit13 and 8 are based on operation mode specifications, and Bit15 and 14 are maker specifications.

5) Manufacture specific area

Shared parts with the entire operating mode in manufacture specific area for control words are described below.

Allocation for control words (manufacture specific area)

bit15	bit14	bit13	bit12	bit11
Cseten	Reserved	Reserved	Eclr	Reserved

0x6040: Control words (shared parts with manufacture specific area)

Index	Ax1 0x6040 Ax2 0x6840 Ax3 0x7040 Ax4 0x7840	Indicates status of FSA (State Machine) that PDS (Power Device System) is controlled.	Object code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Control words [CWORD] *For bit 7, 3, 2, 1 and 0, please refer to the list of commands for control word patterns.		Unsigned16 Setting range	RW	Possible	0x0000 0x0000 - 0xFFFF

MSB											LSB	
Cseten	Resrvd	Eclr	Reserved	Reserved	Operation mode Specific	Halt	Fr*	Operation mode Specific	Hs**	qs**	ev**	so**
15	14,13	12	11	10	9	8	7	6...4	3	2	1	0

bit12: Encoder clear enable [ECLR]
Clear absolute encoder battery malfunction or multiple rotating positions.
"0": Encoder clear disable "1": Encoder clear enable


bit15: Magnetic pole position estimation enabled [CSET]
Magnetic pole position estimation command when using linear motor without hall effect sensor input.
"0": Magnetic pole position estimation disabled
"1": Magnetic pole position estimation enabled

Bit 12: Encoder clear enabled

This Bit 12 unsets multi turn position (Multi turn clear) in memory and so do Battery malfunction.

When the position is Position reverse polarity 0x607E: bit7=0, the actual position will be within minus one rotation.

Encoder clear (Reset encoder) sequence is shown below.



Shared parts with the entire operating mode in manufacture specific area for status words are described below.

Layout for control words (manufacture specific area)

bit15	bit14	bit8
Csetfix	Csetpro	Reserved

These words are displayed in the status word bit patterns indicating current state in each state.

0x6041: Status words (Cycle Synchronous Velocity mode: csv, Profile Velocity: pv)

Index	Ax1 0x6041 Ax2 0x6841 Ax3 0x7041 Ax4 0x7841	Indicates status of FSA (State Machine) that PDS (Power Device System) is controlled.	Object code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Status words [STSWORD] *For bit 6, 5, 3, 2, 1 and 0, please refer to the list for status word bit pattern states.		Unsigned16 Display range	RO	Possible	0x0000 0x0000 - 0xFFFF

MSB											LSB				
Csetfix	Csetpro	Operation mode Specific	Target Value Ignored	Internal Limit active	Tr	Rm	Reserved	W	Sod**	Qs**	Ve	F**	Oe**	So**	Rtso**
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0

bit15-14: Magnetic pole position estimation status [CSETSTS]
The following are linear motor magnetic pole position estimation status.
Bit15 14
0 0 :Magnetic pole position estimation disabled
0 1 :Magnetic pole position estimation in process
1 1 :Magnetic pole position estimation completed

5.5 Profile Area

The followings are shown in Table ; profile area of CoE (CANopen over EtherCAT) object list, RS2-EtherCAT Supported / Un-supported, Data length, Access (Dir), PDO Mapping, and parameter effective timing (updating).
 #=immediately, \$=ESM change required, and &=controlpower cycle required.

Profile Area (No.1)

○:Support, ✕:Not Supported, □:Support (Not changeable :Fixed Value), -:None

Index	S-Idx	FP	FV	FT	FH	Name	Data Type	Dir	PDO_M	Update	NVRAM
0x6007	0x00	○	○	✕	○	Abort Connection Option Code	Integer16	RW	No	#	Yes
0x603F	0x00	○	○	○	○	Error Code	Unsigned16	RO	Possible	-	-
0x6040	0x00	○	○	○	○	Control Word	Unsigned16	RW	Possible	#	-
0x6041	0x00	○	○	○	○	Status Word	Unsigned16	RO	Possible	-	-
0x605A	0x00	○	○	○	○	Quick Stop Option Code	Integer16	RW	No	#	Yes
0x605B	0x00	○	○	✕	○	Shutdown Option Code	Integer16	RW	No	#	Yes
0x605C	0x00	○	○	○	✕	Disable Operation Option Code	Integer16	RW	No	#	Yes
0x605D	0x00	○	○	○	○	Halt Option Code	Integer16	RW	No	#	Yes
0x605E	0x00	○	○	□	□	Fault Reaction Option Code	Integer16	RW	No	-	Yes
0x6060	0x00	○	○	○	○	Operation Mode	Integer8	RW	Possible	#	Yes
0x6061	0x00	○	○	○	○	Operation Display	Integer8	RO	Possible	-	-
0x6062	0x00	○	✕	✕	✕	Position Demand Value	Integer32	RO	Possible	-	-
0x6063	0x00	○	○	○	○	Internal Actual Position	Integer32	RO	Possible	-	-
0x6064	0x00	○	○	○	○	Real Position	Integer32	RO	Possible	-	-
0x6065	0x00	○	✕	✕	✕	Excessive Position Deviation Value	Unsigned32	RW	Possible	-	Yes
0x6066	0x00	□	✕	✕	✕	Excessive Position Deviation Time-out	Unsigned16	RW	No	-	-
0x6067	0x00	○	✕	✕	✕	Position Window (Positioning complete range)	Unsigned32	RW	No	#	Yes
0x6068	0x00	□	✕	✕	✕	Position Window Time	Unsigned16	RW	No	-	-
0x6069	0x00	○	○	✕	✕	Real Velocity Sensor Value	Integer32	RO	Possible	-	-
0x606A	0x00	□	□	□	□	Sensor Selection Code	Integer16	RW	Possible	-	-
0x606B	0x00	✕	✕	✕	✕	Velocity Demand Value	-	-	-	-	-
0x606C	0x00	✕	○	✕	✕	Real Velocity Value (Velocity Monitor)	Integer32	RO	Possible	-	-
0x606D	0x00	✕	○	✕	✕	Velocity Window (Velocity matching range)	Unsigned16	RW	Possible	#	-
0x606E	0x00	✕	○	✕	✕	Velocity Window Time	Unsigned16	RW	Possible	#	-
0x606F	0x00	✕	○	✕	✕	Velocity Threshold	Unsigned16	RW	Possible	#	-
0x6070	0x00	✕	○	✕	✕	Velocity Threshold Time	Unsigned16	RW	Possible	#	-
0x6071	0x00	✕	✕	○	✕	Target Torque (force) (Torque (force) Command)	Integer16	RW	Possible	#	-
0x6072	0x00	○	○	○	○	Maximum Torque (force) (Torque (force) Limit)	Unsigned16	RW	Possible	#	-
0x6073	0x00	✕	✕	✕	✕	Maximum Current	-	-	-	-	-
0x6074	0x00	✕	✕	✕	✕	Torque (force) Demand	-	-	-	-	-
0x6075	0x00	✕	✕	✕	✕	Motor Rating Current	-	-	-	-	-
0x6076	0x00	○	○	○	○	Motor Rating Torque (force)	Unsigned32	RO	Possible	-	-
0x6077	0x00	○	○	○	○	Real Torque (force) Value (Torque (force) Monitor)	Integer16	RO	Possible	-	-
0x6078	0x00	○	○	○	○	Real Current Value	Integer16	RO	Possible	-	-
0x6079	0x00	○	○	○	○	DC Link Circuit Voltage	Unsigned32	RO	Possible	-	-
0x607A	0x00	○	✕	✕	✕	Target Position (Position Command)	Integer32	RW	Possible	#	-
0x607B	0x00	-	-	-	-	Position Range Limit	Unsigned8	RO	No	-	-
↑	0x01	○	✕	✕	✕	Mimi nun Position Limit	Integer32	RW	Possible	\$	Yes
↑	0x02	○	✕	✕	✕	Maximum Position Limit	Integer32	RW	Possible	\$	Yes
0x607C	0x00	○	○	○	○	Coordinates Offset (Homing Offset)	Integer32	RW	Possible	#	Yes
0x607D	0x00	-	-	-	-	Software Position Limit	Unsigned8	RO	No	-	-
↑	0x01	○	✕	✕	✕	Software Mimi nun Position Limit	Integer32	RW	Possible	#	Yes
↑	0x02	○	✕	✕	✕	Software Maximum Position Limit	Integer32	RW	Possible	#	Yes
0x607E	0x00	○	○	○	○	Polarity	Unsigned8	RW	Possible	\$	Yes
0x607F	0x00	○	✕	✕	✕	Max. Profile Velocity (Velocity Control Command)	Unsigned32	RW	Possible	#	Yes
0x6080	0x00	✕	✕	✕	✕	Maximum Motor Speed	Unsigned32	RW	Possible	-	-
0x6081	0x00	○	○	✕	✕	Profile Velocity	Unsigned32	RW	Possible	#	-
0x6082	0x00	○	○	✕	✕	End Velocity	Unsigned32	RW	Possible	-	-
0x6083	0x00	○	○	✕	✕	Profile Acceleration (Accelerating Constant)	Unsigned32	RW	Possible	#	Yes
0x6084	0x00	○	○	✕	✕	Profile Deceleration (Decelerating Constant)	Unsigned32	RW	Possible	#	Yes
0x6085	0x00	○	○	○	○	Quick Stop Deceleration	Unsigned32	RW	Possible	#	Yes
0x6086	0x00	○	✕	✕	✕	Motion Profile Type	Integer16	RW	Possible	#	-
0x6087	0x00	✕	✕	○	✕	Torque (force) Slope	Unsigned32	RW	Possible	#	-
0x6088	0x00	✕	✕	□	✕	Torque (force) Profile Type	Integer16	RW	Possible	-	-
0x608F	0x00	-	-	-	-	Position Encoder Resolution (Encoder Resolution)	Unsigned8	RO	No	-	-
↑	0x01	□	✕	✕	✕	Encoder Resolution	Unsigned32	RW	Possible	-	-
↑	0x02	□	✕	✕	✕	Motor Resolution	Unsigned32	RW	Possible	-	-
0x6090	0x00	✕	✕	✕	✕	Velocity Encoder Resolution	-	-	-	-	-

Profile Area (No.2)

Index	S-Idx	FP	FV	FT	FH	Name	Data Type	Dir	PDO M	Update	NVRAM
0x6091	0x00	—	—	—	—	Gear Ratio	Unsigned8	RO	No	-	-
↑	0x01	□	x	x	x	Motor Shaft Resolution	Unsigned32	RW	Possible	-	-
↑	0x02	□	x	x	x	Drive Shaft Resolution	Unsigned32	RW	Possible	-	-
0x6092	0x00	—	—	—	—	Feed Constant	Unsigned8	RO	No	-	-
↑	0x01	□	x	x	x	Feed	Unsigned32	RW	Possible	-	-
↑	0x02	□	x	x	x	Drive Shaft Resolution	Unsigned32	RW	Possible	-	-
0x6098	0x00	x	x	x	○	Homing Method	Integer8	RW	Possible	#	Yes
0x6099	0x00	-	-	-	-	Homing Speed	Unsigned8	RO	No	-	-
↑	0x01	x	x	x	○	Speed during search for switch	Unsigned32	RW	Possible	#	Yes
↑	0x02	x	x	x	○	Speed during search for Zero	Unsigned32	RW	Possible	#	Yes
0x609A	0x00	x	x	x	○	Homing Acceleration	Unsigned32	RW	Possible	#	Yes
0x60A3	0x00	○	x	x	x	Profile Jerk Use	Unsigned 8	RW	No	-	-
0x60A4	0x00	-	-	-	-	Profile Jerk	Unsigned8	RO	No	-	-
↑	0x01	○	x	x	x	Profile Jerk 1	Unsigned32	RW	No	#	-
↑	0x02	○	x	x	x	Profile Jerk 2	Unsigned32	RW	No	#	-
0x60B0	0x00	○	x	x	x	Position Offset (Position Addition)	Integer32	RW	Possible	#	-
0x60B1	0x00	○	○	-	x	Speed Offset (Speed Addition)	Integer32	RW	Possible	#	-
0x60B2	0x00	○	○	○	x	Torque (force) Offset (Torque (force) Addition)	Integer16	RW	Possible	#	-
0x60B8	0x00	x	x	x	○	Touch probe function	Unsigned16	RW	Possible	#	-
0x60B9	0x00	x	x	x	○	Touch probe state	Unsigned16	RO	Possible	#	-
0x60BA	0x00	x	x	x	○	Touch probe1 positive edge position stored	Integer32	RO	Possible	#	-
0x60BB	0x00	x	x	x	○	Touch probe1 negative edge position stored	Integer32	RO	Possible	#	-
0x60BC	0x00	x	x	x	x	Touch probe1 positive edge position stored	Integer32	RO	Possible	#	-
0x60BD	0x00	x	x	x	x	Touch probe1 negative edge position stored	Integer32	RO	Possible	#	-
0x60C0	0x00	○	x	x	x	Interpolation sub mode select	Integer16	RW	No	-	-
0x60C1	0x00	-	-	-	-	Interpolation data record	Unsigned8	RO	No	-	-
↑	0x01	○	x	x	x	Interpolation position target	Integer32	RW	Possible	#	-
↑	0x02	○	x	x	x	Interpolation time	Unsigned8	RW	Possible	#	-
0x60C2	0x00	-	-	-	-	Interpolation time period	Unsigned8	RO	No	-	-
↑	0x01	○	○	○	○	Interpolation time period value	Unsigned8	RW	No	#	-
↑	0x02	○	○	○	○	Interpolation time index	Integer8	RW	No	#	-
0x60C4	0x00	-	-	-	-	Interpolation data configuration	Unsigned8	RO	No	-	-
↑	0x01	○	x	x	x	Maximum buffer size	Unsigned32	RO	No	-	-
↑	0x02	○	x	x	x	Actual buffer size	Unsigned32	RW	Possible	#	-
↑	0x03	○	x	x	x	Buffer format	Unsigned8	RW	Possible	#	-
↑	0x04	○	x	x	x	Point of buffer	Unsigned16	RW	Possible	#	-
↑	0x05	○	x	x	x	Data size of interpolation data record	Unsigned8	RO	No	-	-
↑	0x06	○	x	x	x	Clear buffer	Unsigned8	WO	Possible	#	-
0x60C5	0x00	x	○	x	x	Maximum Acceleration	Unsigned32	RW	Possible	-	Yes
0x60C6	0x00	x	○	x	x	Maximum Deceleration	Unsigned32	RW	Possible	-	Yes
0x60E0	0x00	○	○	○	○	Forward Torque (force) Limit Value	Unsigned16	RW	Possible	#	Yes
0x60E1	0x00	○	○	○	○	Backward Torque (force) Limit Value	Unsigned16	RW	Possible	#	Yes
0x60E3	0x00	-	-	-	-	Support Homing Method	Unsigned8	RO	No	-	-
↑	0x01 ~ 0x25	x	x	x	○	Support Homing Method 1 - 37	Integer8	RO	No	-	-
0x60F2	0x00	○	x	x	x	Position Option Code	Unsigned16	RW	Possible	#	-
0x60F4	0x00	○	x	x	x	Actual Position Deviation (Following Error Actual Value)	Integer32	RO	Possible	-	-
0x60F8	0x00	x	x	x	x	Maximum Deviation (Amount of Max. Gaps)	-	-	-	-	-
0x60FA	0x00	○	x	x	x	Control Effort	Integer32	RO	Possible	-	-
0x60FC	0x00	○	x	x	x	Internal Position Command Value	Integer32	RO	Possible	-	-
0x60FD	0x00	○	○	○	○	Digital Input	Unsigned32	RO	Possible	-	-
0x60FE	0x00	—	—	—	—	Digital Output	Unsigned8	RW	Possible	#	-
↑	0x01	○	○	○	○	Physical Output	Unsigned32	RW	Possible	#	-
↑	0x02	○	○	○	○	Bitmask	Unsigned32	RW	Possible	#	-
0x60FF	0x00	x	○	x	x	Target Velocity (Velocity Command)	Integer32	RW	Possible	#	-
0x6402	0x00	○	○	○	○	Motor Type	Unsigned16	RW	Possible	-	-
0x6403	0x00	○	○	○	○	Motor Catalog No.	VisibleString	RO	No	-	-
0x6404	0x00	○	○	○	○	Motor Manufacture	VisibleString	RO	No	-	-
0x6405	0x00	○	○	○	○	http Motor Catalog Address	VisibleString	RO	No	-	-
0x6406	0x00	x	x	x	x	Motor Calibration date	-	-	-	-	-
0x6407	0x00	x	x	x	x	Motor Service Period	-	-	-	-	-
0x6502	0x00	○	○	○	○	Support Drive Mode	Unsigned32	RO	Possible	-	-
0x6503	0x00	○	○	○	○	Drive Catalog No.	VisibleString	RO	No	-	-
0x6505	0x00	○	○	○	○	http Drive Catalog Address	VisibleString	RO	No	-	-

1) Error Code and Error Operation

0x6007: Abort Connection Option Code

Index	Ax1	0x6007	When an abnormality occurs in the communication system (Ex. communication timeout, Link lost, Crc error etc..), This object indicates how the servo amplifier to behave.	Object Code	Variable	
	Ax2	0x6807				
	Ax3	0x7007				
	Ax4	0x7807				
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Abort Connection Option Code		Integer16	RW	No	0x0001
			Setting Range	0x0000-0x0003		
<p>0 : No Action</p> <p>1 : Fault Signal</p> <p>2 : Desable Voltage Command</p> <p>3 : Even if it is the setting of the Quick Stop Active state, shifts to Switch On Disabled after a stop by Quick Stop Command (quick stop setting (0x605A)).</p>						

0x603F: Error code

Index	Ax1	0x603F	Displays codes of errors occurred in the servo amplifier.	Object code	Variable	
	Ax2	0x683F				
	Ax3	0x703F				
	Ax4	0x783F				
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Error codes [ERRCODE]		Unsigned16	RO	Possible	0x0000
	For the list of error codes, please refer to the list of alarm codes in chapter 11.3.		Display range	0x0000 - 0xFFFF		
<p>✓ Represents the same information as lower 16-bit of Sub-index 0x01 in pre-defined errorfield 0x1003 in CANopen communication method.</p>						

0x605A: Quick Stop Option Code (EMR)

Index	Ax1	0x605A	When quick stop (EMR) command is inputted, it is set up by which action motor is stopped.	Object Code	Variable	
	Ax2	0x685A				
	Ax3	0x705A				
	Ax4	0x785A				
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Quick Stop Option Code [QSTOP]		Integer16	RW	No	0x0002
	By Control mode, treated in the amplifier internally as shown below.		Setting Range	0x0000-0x0007 (0 - 7)		
<p>-128 to -1, 4, 8 to 127 are reserved. Not possible to be set.</p> <p># Profile position (pp), Cyclic sync position (csp), Interpolated Position (ip) mode</p> <p># Cyclic sync velocity mode (csv), Profile velocity (pv), Homing mode (hm)</p> <p>0 : Drive function is Disabled. (To Switch On Disabled after motor stop by dynamic brake operation)</p> <p>1 : To Switch On Disabled after stop at slowdown deceleration (0x6084)</p> <p>2 : To Switch On Disabled after stop at quick stop deceleration (0x6085)</p> <p>3 : To Switch On Disabled after stop by Current Limit</p> <p>5 : Quick Stop Active state after stop at slowdown deceleration (0x6084)</p> <p>6 : Quick Stop Active state after stop at quick stop deceleration (0x6085)</p> <p>7 : Quick Stop Active state after stop by Current Limit</p> <p># Cyclic sync torque (force) mode (cst), Torque (force) profile mode (tq)</p> <p>0 : Drive function is disabled (After a motor stops by dynamic brake operation, Switch On Disabled)</p> <p>1, 2 : Switch On Disabled after Stops by 0x6087 (Torque (force) Slope)</p> <p>3 : To Switch On Disabled after stop by Current Zero</p> <p>5, 6 : Quick Stop Active state after Stops by 0x6087 (Torque (force) Slope)</p> <p>7 : Quick Stop Active state after stop by Current Zero</p> <p>*When Quick Stop Operation, not only Maximum torque (force) (0x6072), Clock wise side torque (force) limit (0x60E0), Counter clockwise torque (force) limit (0x60E1), but also Sequence current limit value (0x201E) are limited. When external EMR signal is input through I/O, it will be "Switch On Disable" even if "Quick Stop Active" is set.</p> <p>*RF2 series servo amplifier does not have dynamic brake circuit. So, it will be Free Run Stop if set value is zero.</p>						

0x605B: Shutdown Option Code

Index	Ax1	0x605B	When shifts from Operation Enabled to the Ready to Switch On State, determined how it operates.	Object Code	Variable		
	Ax2	0x685B					
	Ax3	0x705B					
	Ax4	0x785B					
Sub-Idx	Description			Data Type	Access	PDO	Initial Value
0x00	Shutdown Option Code			Integer16	RW	No	0x0000
				Setting Range	0x0000 - 0x0001 (0 to 1)		
<p># Profile position (pp), Cyclic sync position(csp), Interpolated Position (ip) mode</p> <p># Cyclic sync velocity mode (csv), Profile velocity (pv), Homing mode</p> <p><u>0</u> : Disable Drive: Servo-Off(Switch OFF Drive Power Stage)</p> <p><u>1</u> : Slow down with slow down ramp; Disable of the drive function</p> <p># Cyclic sync torque (force) mode (cst), Torque (force) profile mode (tq)</p> <p><u>0</u> : Disable Drive: Servo-Off(Switch OFF Drive Power Stage)</p> <p><u>1</u> : Stop at 0x6087 Torque (thrust force) slop</p>							

0x605C:Disable Operation Option Code

Index	Ax1	0x605C	When shifts from Operation Enabled to the Switch On State, determined how it operates.	Object Code	Variable		
	Ax2	0x685C					
	Ax3	0x705C					
	Ax4	0x785C					
Sub-Idx	Description			Data Type	Access	PDO	Initial Value
0x00	Disable Operation Option Code [DISOP]			Integer16	RW	No	0x0000
				Setting Range	0x0000 - 0x0001 (0 to 1)		
<p>Set how to stop a motor at shifts from servo-on to servo-off.</p> <p># Profile position (pp), Cyclic sync position(csp), Interpolated Position (ip) mode</p> <p># Cyclic sync velocity mode (csv), Profile velocity (pv), Homing mode</p> <p><u>0</u> : Disable Drive function Switch OFF drive power stage.</p> <p><u>1</u> : Slow down with slow down ramp; disable of drive function</p> <p># Cyclic sync torque (force) mode (cst), Torque (force) profile mode (tq)</p> <p><u>0</u> : Disable Drive: Servo-Off(Switch OFF Drive Power Stage)</p> <p><u>1</u> : Stop at 0x6087 Torque (thrust force) slop</p> <p>✓When main power is shut down, it will be dynamic brake operation regardless of the setting. However, RF2 series servo amplifier does not have dynamic brake circuit. So, it will be Free Run Stop if set value is zero.</p>							

0x605D:Halt option code

Index	Ax1	0x605D	This object shall indicate what action is performed when the Halt function is executed.	Object Code	Variable		
	Ax2	0x685D					
	Ax3	0x705D					
	Ax4	0x785D					
Sub-Idx	Name/Description			Data Type	Access	PDO	Initial Value
0x00	Halt option code			Integer16	RW	No	0x0001
	By Control mode, treated in the amplifier internally as shown below. -128 to -1, 4 to 127 are reserved. Not possible to be set up.			Setting Range	0x0001 - 0x0003(1-3)		
<p># Profile position (pp), Cyclic sync velocity mode (csv), Profile velocity (pv), Homing mode</p> <p><u>1</u> : Operation enabled state after Stop at slowdown deceleration (0x6084).</p> <p><u>2</u> : Operation enabled state after stop at quick stop deceleration (0x6085)</p> <p><u>3</u> : To Switch On Disabled after stop by Current Limit</p> <p># Cyclic sync position mode (csp) .Interpolated Position (ip) mode</p> <p><u>1, 2, 3</u> : Operation enabled state after stop by Current Limit</p> <p># Cyclic sync torque (force) mode (cst), Torque (force) profile mode (tq)</p> <p><u>1, 2</u> : Operation enabled state after Stops by 0x6087(Torque (force) Slope)</p> <p><u>3</u> : Operation enabled state after stop by Current Zero.</p> <p>✓For being servo OFF after stop by halt state, perform servo OFF with the state of setting a halt bit of the control word.</p>							

5. Object Dictionary

Object

0x605E: Fault Reaction Option Code

Index	Ax1	Ax2	Ax3	Ax4	0x605E	0x685E	0x705E	0x785E	When alarm is generated with servo amplifier, determined how it operates.	Object Code	Variable
Sub-Idx	Description					Data Type	Access	PDO	Initial Value		
0x00	Fault Reaction Option Code					Integer16	RW	No	0x0002		
						Setting Range	0x0000~0x0003 (0~3)				
<p># Profile Position (pp) Mode, Interpolated Position Mode (ip), Cycle Synchronous Position Mode (csp) # Profile Velocity (pv) Mode, Homing Mode (hm), Cycle Synchronous Velocity Mode (csv)</p> <p>0 : Drive function is Disabled. (Motor stop by dynamic brake operation) 1 : Stop at slowdown deceleration (0x6084) 2 : Stop at quick stop deceleration (0x6085) 3 : Stop by Current Limit</p> <p># Torque Profile (tq) Mode, Cycle Synchronous Torque Mode (cst)</p> <p>0 : Drive function is Disabled. (Motor stop by dynamic brake operation) 1, 2 : Stop at 0x6087 (Torque (thrust force) slope) 3 : Stop by Current Limit</p> <p>*RF2 series servo amplifier does not have dynamic brake circuit. So, it will be Free Run Stop if set value is zero.</p>											

2) Operation Mode

EtherCAT-CoE specification has modes of operation shown in operation mode list.
Profiles applicable to RS2 EtherCAT-CoE slave amplifier are listed in the following Operation Mode List.
Besides, operation mode supported can check at "Supported Drive Mode:0x6502."

Operation Mode List

Operation Mode	Mark	R-ADVANCED EtherCAT Supported
Profile Position Mode	pp	Yes
Profile Velocity Mode	pv	Yes
Homing Mode	hm	Yes
Interpolated Position Mode	ip	Yes
Torque (force) Mode	tq	Yes
Velocity Mode (ex. Inverter)	vl	No
Cycle Sync. Position Mode	csp	Yes
Cycle Sync. Velocity Mode	csv	Yes
Cycle Sync. Torque (force) Mode	cst	Yes

Shift of an operation mode uses the object "operation mode:0x6060."
Also, the object "operation mode display:0x6061" is used for the present operation mode check.
At each operation mode, the bit assigned to Control Word and Status Word is prepared.

Unique Mode Bit Assigned to Control Word

Operation Mode	bit8	bit6	bit5	bit4
pp Profile Position Mode	Halt	Absolute / Relative Position	Change set immediately	New set point
csp Cycle Sync. Position Mode			Reserved	Reserved
ip Interpolated position		Reserved	Reserved	Interpolation Enable
csv Cycle Sync. Velocity Mode		Reserved	Reserved	Reserved
pv Profile Velocity Mode		Reserved	Reserved	Reserved
cst Cycle Sync. Torque (force) Mode		Reserved	Reserved	Reserved
tq Torque (force) Mode		Reserved	Reserved	Reserved
hm Homing Mode		Homing offset Active	Reserved	Homing Enable

Manufacturer own Bit Assigned to Status Word


Operation Mode	bit13	bit12	bit10
pp Profile Position Mode	Following error	Set-point Acknowledge	Target reached Quick Stop Finished Operation Change Finished Halt Active
csp Cycle Sync. Position Mode	Following error	Target Position ignore	
ip Interpolated position	Reserved	Interpolation active	
csv Cycle Sync. Velocity Mode	Reserved	Target velocity ignore	
pv Profile Velocity Mode	Reserved	Target velocity ignore	
cst Cycle Sync. Torque (force) Mode	Reserved	Target torque (force) ignore	
tq Torque (force) Mode	Reserved	Target torque (force) ignore	
hm Homing Mode	Homing error	Homing attained	

Selection and change of an operation mode use mode:0x6060 of operation, and mode display:0x6061 of operation is used for the check of the operation mode under present operation.


3) Function Group "Position" Mode

Abstract of Function Group "Position" Mode


As for function group "Position" operation mode, "Profile position Mode", "Cyclic Synchronous Position Mode" and "Interpolated Position Mode" are supported. 0x6060: Operate "Profile Position Mode" by setting "1" in operation mode, "Cyclic Synchronous Position Mode" by setting "8" and "Interpolated Position Mode" by setting "7". Here is the main object list for the function group "Profile Position Mode"



Block Diagram of each operation mode when the function group is in "Position" mode



Block Diagram with Function Group [Position] Mode



Block Diagram with Using model following control, Using model following vibration suppressor control of Function Group [Position] mode

5. Object Dictionary

4) Profile Position Mode

0x6060: When Operation Mode is set “1”, “Profile Position Mode” shall be operated.

The master sends “Target Position (0x607A)”, “Profile Velocity (0x6081)”, “Profile Acceleration and Deceleration (0x6083, 0x6084)”.
 The slave (servo amplifier) executes trajectory generation and starts to move to the target position by setting bit4=1: New set-point of Control word 0x6040.

The slave executes all of Position Control, Velocity control, and Torque (force) control.
 Also, Velocity offset and Torque (force) offset can be used as Velocity Additional value and Torque (force) Additional value.

The slave executes all of Position Control, Velocity control, and Torque (force) control.

Also, Velocity offset and Torque (force) offset can be used as Velocity Additional value and Torque (force) Additional value.

The following two different ways to apply to a servo amplifier supported by device profile.


There are two different ways as follows to set target positions to a servo amplifier supported by the device profile.

1. Single set point: [Change set immediately bit(0x6040:Control word bit5) = 1]
 During the set point processing, if a new set-point is set by “New set-point (bit 4)” in Control word, the servo amplifier immediately processes the new set-point.
 For relative position move, new set-point will be as relative move value from processing point. In this case, please make not to exceed maximum value (0x7FFFFFFF) by sum of processing point and new set-point move value.
2. Set of set points: [Change set immediately bit(0x6040:Control word bit5) = 0]
 During the set point processing, if a new set-point is set by “New set-point (bit 4)” in Control word, the servo amplifier immediately processes the new set-point after reaching the target position.

The master controller switches the two modes mentioned above by the timing of the following bits; “New set-point(bit4)”, “Change set immediately(bit5)”, “Change of set-point(bit9)” in the Control Word (0x6040) and “Set-point acknowledge(bit12)” in the Status Word (0x6041).

These bits allow to set up a request response mechanism in order to prepare the next set points while a previous set point still is processed in the servo amplifier.

This minimizes reaction times within a control program on the master.




Sequence Diagram for Profile Position Mode

5. Object Dictionary

& Single set-point

- (1) If the bit "Change set immediately (bit5)" is "1", a single set point is executed by the servo amplifier.
- (2) After a set point is applied to a servo amplifier, the master sets "new set-point (bit4)" in Control word to "1" in order to notify completion of the set point to the slave(servo amplifier).
- (3) A slave(servo amplifier) acknowledges a requested bit and buffers a new set-point, and in order to respond, sets "Set-point acknowledge(bit12)" to "1".
- (4) After the master recognized the new valid data, "New set-point (bit4)" is released to "0".
- (5) Even if the set point that is received at the time point "t0" is being processed, a new set-point will be immediately valid.
- (6) The servo amplifier validates the actual move to the new target position immediately when the second target position as "New set-point" at the time point "t1" is received.




Single set-point (Update a set point immediately)

5. Object Dictionary

& Set of set-points

- (1) If the bit "Change set immediately (bit5)" is "0", the servo amplifier executes settings for the set-point.
- (2) After a set point is applied to a servo amplifier, the master sets "new set-point (bit4)" in Control word to "1" in order to notify completion of the set point to the slave(servo amplifier).
- (3) A slave(servo amplifier) acknowledges a requested bit and buffers a new set-point, and in order to respond, sets "Set-point acknowledge (bit12)" to "1".
- (4) After the master recognized the new valid data, "New set-point (bit4)" is released to "0".
- (5) A new set-point will be valid after completion of a Set-point processing received at the time point "t0".
- (6) The servo amplifier validates the actual move to the new target position "t3" immediately as long as that receives the second target position as "New set-point" before arriving to the first target position "t1".
- (7) When the bit Change of set-point (bit 9) is set to "1", the servo amplifier moves to the next set-point processing without reducing the velocity once to Zero during set-point processing.




Set of set points (Update to the next set point after completion of a set point)

5. Object Dictionary

0x6040:Control Word (Profile Position Mode: pp)

Index	Ax1 0x6040 Ax2 0x6840 Ax3 0x7040 Ax4 0x7840	This object shall indicate Operation Mode Specific bit and Manufacturer specific bit of Profile Position Mode (pp).	Object Code	Variable	
Sub-Idx					
0x00	Control Word [CWORD] * See the Command table for "Control word bit pattern (Bit 7, 3, 2, 1, 0,)	Unsigned16	RW	Possible	Initial value 0x0000
		Range	0x0000-0xFFFF		

MSB													LSB	
Cseten	-	Eclr	-	Change of set-point	Halt	Fr	Abs / Rel	Change set immediately	New Set point	Hs	qs	ev	so	
15	14..13	12	11..10	9	8	7	6	5	4	3	2	1	0	




5. Object Dictionary

0x6041:Status Word (Profile Position Mode: pp)

Index	Ax1 0x6041 Ax2 0x6841 Ax3 0x7041 Ax4 0x7841	This object indicates Operation Mode Specific bit and Manufacturer Specific bit of the Profile Position mode (pp).	Object code	Variable		
Sub-Idx	Discription		Data Type	Access	PDO	Initial value
0x00	Status Word [STSWORD] * See the Pattern Status table for "Status word bit pattern (Bit 6,5, 3,2,1,0,)"		Unsigned16 Range	RO	Possible	0x0000 0x0000-0xFFFF

MSB

LSB




5. Object Dictionary

& Motion Profile

In this servo amplifier, S-shape acceleration/deceleration motion profile can be executed at the time of acceleration or deceleration.

- (1) Motion profile type is selected by 0x6086.
- (2) Combination of S-shape acceleration/deceleration time (A, B, C, D) is set by 0x60A3.
- (3) S-shape acceleration/deceleration time A, B, C, D is set by 0x60A4.



Motion profile operation

V = Profile Velocity
 A,B,C,D = Acceleration(Deceleration) at the jerk slope period time
 ta = Acceleration time (Linear ramp)
 tb = Deceleration time (Linear ramp)
 ta' = Acceleration time (Jerk-limited ramp)
 tb' = Deceleration time (Jerk-limited ramp)

0x6086: Motion Profile Type

Index	Ax1	Ax2	Ax3	Ax4		Object Code	Variable	
	0x6086	0x6886	0x7086	0x7886	Motion Profile Type			
Sub-Idx	Description				Data Type	Access	PDO	Initial Value
0x00	Motion Profile Type				Integer16	RW	Possible	0x0000
	Sets up type of motion profile operation.				Setting Range	0x0000, 0x0003 (0 or 3)		
	0x0000: Linear ramp (trapezoidal profile)							
	0x0003: Jerk-limited ramp							

0x60A3: Profile Jerk Use

Index	Ax1	Ax2	Ax3	Ax4		Object Code	Variable																				
	0x60A3	0x68A3	0x70A3	0x78A3	Profile Jerk Use																						
Sub-Idx	Description				Data Type	Access	PDO	Initial Value																			
0x00	Profile Jerk Use				Unsigned8	RW	No	0x01																			
	Sets up combinations of sub index numbers of profile jerk object (0x60A4) for jerk profile operation.				Setting Range	0x01-0x02 (1 or 2)																					
	<table border="1"> <thead> <tr> <th rowspan="2">Value of 0x60A3</th> <th colspan="4">Jerk assignment Value (Sub Index Number of 0x60A4)</th> </tr> <tr> <th>A</th> <th>B</th> <th>C</th> <th>D</th> </tr> </thead> <tbody> <tr> <td>0x01</td> <td>0x01</td> <td>0x01</td> <td>0x01</td> <td>0x01</td> </tr> <tr> <td>0x02</td> <td>0x01</td> <td>0x01</td> <td>0x02</td> <td>0x02</td> </tr> </tbody> </table>				Value of 0x60A3	Jerk assignment Value (Sub Index Number of 0x60A4)				A	B	C	D	0x01	0x01	0x01	0x01	0x01	0x02	0x01	0x01	0x02	0x02				
Value of 0x60A3	Jerk assignment Value (Sub Index Number of 0x60A4)																										
	A	B	C	D																							
0x01	0x01	0x01	0x01	0x01																							
0x02	0x01	0x01	0x02	0x02																							

5. Object Dictionary

0x60A4: Profile Jerk

Index	Ax1	Ax2	Ax3	Ax4	Profile Jerk	Object Code	Array	
	0x60A4	0x68A4	0x70A4	0x78A4				
Sub-Idx	Description				Data Type	Access	PDO	Initial value
0x00	Number of entry				Unsigned8	RO	No	0x02
0x01	Profile Jerk 1				Unsigned32	RW	No	0xFFFFFFFF
	Sets up value of jerk 1. Sets up variation of the acceleration/deceleration per second.				Setting range	0x00000000-0xFFFFFFFF (0-4294967295 pps ³)		
0x02	Profile Jerk 2				Unsigned32	RW	No	0xFFFFFFFF
	Sets up value of jerk 2. Sets up variation of the acceleration/deceleration per second.				Setting range	0x00000000-0xFFFFFFFF (0-4294967295 pps ³)		

* Refer M0011028 for setting of jerk function.


5) Cycle Synchronization Position Mode

0x6060: When Operation Mode is "8", Servo amplifier is operated by Cycle Synchronization Position Mode.

In "Cycle Synchronization Position control system", the master (Control Device) generate trajectory and transmit the Target position continuously to the slave to make control Position, Velocity and Torque (force).



Velocity offset and Torque (force) offset are used for as Additive velocity value and Additive torque (force) value, then the Position offset function calculates offset value for the new target position.

A command type - Absolute/Relative position - is selectable by 0x6040:Bit 6. (Bit 6 = 0: Absolute position, Bit 6 = 1: Relative position). However, when the master sets Operation enabled state (Bit 0 to 3 = 0x0F), it shall be defined after the amplifier refers it.



0x6040: Control Word (Cyclic Sync. Position Mode: csp)

Index	Ax1	Ax2	Ax3	Ax4	This object indicates Operation Mode Specific bit and Manufacturer Specific bit under the Cyclic Sync. Position mode (csp).	Object code	Variable	
	0x6040	0x6840	0x7040	0x7840				
Sub-Idx	Description				Data Type	Access	PDO	Initial value
0x00	Control Word [CWORD]				Unsigned16	RW	Possible	0x0000
					Range	0x0000-0xFFFF		



5. Object Dictionary


0x6041:Status Word (Cyclic Sync. Position Mode: csp)

Index Ax1	0x6041	This object indicates Operation Mode Specific bit and Manufacturer Specific bit under Cyclic Sync. Position Mode (csp).	Object code	Variable		
Ax2	0x6841					
Ax3	0x7041					
Ax4	0x7841					
Sub-Idx		Description	Data Type	Access	PDO	Initial value
0x00		Status Word [STSWORD] *See the Pattern status table for "Status word bit" (Bit6,5, 3,2,1,0)	Unsigned16 Range	RO	Possible	0x0000 0x0000-0xFFFF

MSB

LSB

Csetfix	Csetpro	Fe	Target Value Ignored	Internal Limit active	Tr	Rm	Res	W	Sod*	Qs*	Ve	F*	Oe*	So*	Rtso*
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0



5. Object Dictionary

6) Interpolated Position Mode

0x6060: When Operation Mode is set "7", "Interpolated Position Mode" shall be operated.

Trajectory generation of Interpolated Position Control depend on master.

The master sends Interpolated Position command.

The slave (Drive device) executes Position Control, Velocity Control, and Torque (force) Control.

Velocity offset and Torque (force) offset can be used as Velocity Additional value and Torque (force) Additional value.

Position offset adds offset to Position command.

There are two kinds of interpolation methods for interpolation position target. Select by using Interpolation sub mode select (0x60C0).

Provided Interpolated Position Command is buffered with 0x60C4 setting.


There are 2 kinds of buffer format, FIFO (first-in-first-out) and Ring. Ring buffers can be used for circular operation.

Domain for 256 buffers is allocated within servo amplifier and Index 0x60C4-2 sets up the number of buffers which will actually be used. When interpolated position command value is received in the situation where there are no empty buffers, the oldest Interpolated position command value is automatically overwritten.

The slave picks up Interpolated Position command from buffer at each every interpolation cycle and uses it to Position command while interpolation allowed (Interpolation active). In the case that the buffer format is FIFO, when there is no Interpolated position command value stored in the buffer, it will cease to read values, and motors will stop at the last read Interpolated position command value. In the case that the buffer format is Ring, after all Interpolated position command values are read, the reading process will restart from the beginning.

Also, Interpolated command is treated as absolute value.

State Change of Interpolated position mode



FSA status and FSAsate change

FSA status definition

Status	Description
[Interpolation inactive]	Amplifier allow inputting data. But, it has no influence.
[Interpolation active]	Amplifier allow inputting data. And, it works.

FSA state change

State change	Event
I	Select Interpolated Position Mode out from Operation Mode.
II	Select other than Interpolated Position Mode out from Operation Mode.
III	Receive "IP mode enable (Controlword: bit4=1)"
IV	Receive "IP mode disable (Controlword: bit4=0)"

5. Object Dictionary

&Interpolation sub mode select (0x60C0)


This servo amplifier corresponds to two kinds of interpolation methods. Select by using interpolation sub mode select (0x60C0).

Interpolation sub mode select	Contents
0	Linear Interpolation (fixation time)
-1	Linear Interpolation (variable Time)

• Linear Interpolation (fixation time)

Reads interpolation position target (0x60C1-1) from buffer at each interpolation time period (0x60C2) and uses it for position control.

Sets interpolation position target (0x60C1-1) and interpolation time period (0x60C2). Interpolation time (0x60C1-2) is not used.




Buffer	
Interpolation Position Target 0x60C1-1	Interpolation Time 0x60C1-2
P0	-
P1	-
P2	-
P3	-

• Linear Interpolation (variable time)

Calculate the linear interpolation between two points of the interpolation position target (0x60C1-1) by interpolation time (0x60C1-2) and use it for position control.

Sets interpolation position target (0x60C1-1) and interpolation time (0x60C1-2). Interpolation time period (0x60C2) is not used.




Buffer	
Interpolation Position Target 0x60C1-1	Interpolation Time 0x60C1-2
P0	T0
P1	T1
P2	T2
P3	T3

5. Object Dictionary

&Usage when buffer format is set to FIFO


- (1) Set communication cycle time on Index 0x1C32-2.
- (2) Set Interpolation sub mode select (0x60C0).
- (3) When setting interpolation sub mode select at 0, set interpolation time period (0x60C2). Interpolation time period is the cycle in which the servo amplifiers read interpolation position target from the buffer. Generally, the same value as the communication cycle time is set. For setting a different value for the communication cycle time, bit0 of the special function selection of Index 0x20F7 should be set at 1.
The setting value will be reflected to internal parameter of servo amplifiers other than when ESM is Operational. When changes are carried out in Operational Mode, it is necessary to temporarily lower ESM to Safe-Operational.
- (4) Change operation mode to 7: Interpolated position mode.
- (5) Set the number of buffer which will actually be used on Index 0x60C4-2 (Actual buffer size). The maximum number of buffers of this servo amplifier is 256.
- (6) Set 0 on Index 0x60C4-3 (Buffer format), and select a FIFO buffer.
- (7) Enable operation.
- (8) Set 1 on Index 0x60C4-6 (Buffer clear), and enable access to buffer. As all buffers are cleared at 0 statuses, the transmitted interpolation position target will be disabled.
- (9) When setting interpolation sub mode select at 0, set interpolation position target (0x60C1-1). Interpolation time (0x60C1-2) does not need to be set. Set interpolation position target on Index 0x60C1. The transmitted interpolation position target will be stored in buffer in the servo amplifier. In the servo amplifier, at each data reception, the buffer write pointer is incremented and stored in buffer.
When setting interpolation sub mode select at -1, set interpolation position target (0x60C1-1) and interpolation time (0x60C1-2). In servo amplifier, increment write pointer of the buffer when storing interpolation time in buffer. After setting interpolation position target, set interpolation time in response to interpolation position target. (Set interpolation position target, interpolation time, interpolation position target and interpolation time, ... in this order.)
- (10) When setting bit4=1 (Enable Interpolation) of Control Word (0x6040), the servo amplifier starts reading interpolation position target and the motor starts running.
- (11) The master transmits interpolation position target and interpolation time (in the case that interpolation sub mode select is -1) at each communication cycle time. In the case that there is no interpolation position target in the buffer while interpolated position mode is permitted, the servo amplifier will stop reading interpolation position target, and the motors will stop at the last read interpolation position target.
- (12) Following are methods to stop the motor:
 - Set bit4=0 of Control Word (0x6040).
 - Set bit8 (halt) =1 of Control Word (0x6040).
 - Stop renewing interpolation position target.
 - Set Interpolation time at 0. (In the case that interpolation sub mode select is -1)



5. Object Dictionary

&Usage when buffer format is set to Ring


- (1) Sets communication cycle time on Index 0x1C32-2.
- (2) Set Interpolation sub mode select (0x60C0).
- (3) When setting interpolation sub mode select at 0, set interpolation time period (0x60C2). Interpolation time period is the cycle in which the servo amplifiers read interpolation position target from the buffer. Generally, the same value as the communication cycle time is set. For setting a different value for the communication cycle time, bit0 of the special function selection of Index 0x20F7 should be set at 1.
The setting value will be reflected to internal parameter of servo amplifiers other than when ESM is Operational. When changes are carried out in Operational Mode, it is necessary to temporarily lower ESM to Safe-Operational.
- (4) Change operation mode to 7: Interpolated position mode.
- (5) Set the number of buffer which will actually be used on Index 0x60C4-2 (Actual buffer size). The maximum number of buffers of this servo amplifier is 256.
- (6) Set 1 on Index 0x60C4-3 (Buffer format), and select a Ring buffer.
- (7) Enable operation.
- (8) Set 1 on Index 0x60C4-6 (Buffer clear), and enable access to buffer. As all buffer are cleared at 0 status, the transmitted interpolation position target will be disabled.
- (9) When setting interpolation sub mode select at 0, set interpolation position target (0x60C1-1). Interpolation time (0x60C1-2) does not need to be set. The transmitted interpolation position target will be stored in buffer in the servo amplifier. In the servo amplifier, at each data reception, the buffer write pointer is incremented and stored in buffer. When setting interpolation sub mode select at -1, set interpolation position target (0x60C1-1) and interpolation time (0x60C1-2). In servo amplifier, increment write pointer of the buffer when storing interpolation time in buffer. After setting interpolation position target, set interpolation time in response to interpolation position target. (Set interpolation position target, interpolation time, interpolation position target and interpolation time, ... in this order.)
Ring buffer mode can be used for circular operation. By setting all interpolation position target for circular operation within the buffer, there is no need to transmit interpolation position target from the master during operation.
- (10) When setting bit4=1 (Enable Interpolation) of Control Word (0x6040), the servo amplifier starts reading interpolation position target and the motor starts running. After reading the last value in the buffer, the reading process will restart from the beginning domain in the buffer.
- (11) Following are methods to stop the motor:
 - Set bit4=0 of Control Word (0x6040).
 - Set bit8 (halt) =1 of Control Word (0x6040).
 - Stop renewing interpolation position target.
 - Set interpolation Time at 0. (In the case that interpolation sub mode select is -1)



5. Object Dictionary


0x6040: Control word (Interpolated Position Mode: ip)

Index Ax1	0x6040	This object indicates operation mode specific bits and manufacturer specific bits of the Interpolated Position Mode (ip)	Object code	Variable		
Ax2	0x6840					
Ax3	0x7040					
Ax4	0x7840					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Control word [CWORD] *For details on Bit 7,3,2,1 and 0, see the table of Control Word Bit Pattern Command.		Unsigned16 Range	RW	Possible	0x0000 0x0000 - 0xFFFF



0x6041: Status word (Interpolated Position Mode: ip)

Index Ax1	0x6041	This object indicates operation mode specific bits and manufacturer specific bits of the Interpolated Position Mode (ip)	Object code	Variable		
Ax2	0x6841					
Ax3	0x7041					
Ax4	0x7841					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Status word [STSWORD] *For details on Bit 6, 5, 3, 2, 1 and 0, see the Status Word List Bit Pattern. (Bit 6,5,3,2,1,0)		Unsigned16 Range	RO	Possible	0x0000 0x0000 - 0xFFFF



5. Object Dictionary

7) Function Group "Velocity", "Homing mode" # Abstract of Function Group "Velocity", "Homing mode"


In Function Group "Velocity" the operation mode, "Profile Velocity mode" and "Cyclic Synchronous Velocity Mode" shall be supported. 0x6060: When the bit is set "3" in Operation Mode it is operated profile Velocity Mode, and when the bit is set "9", it is operated by Cyclic Synchronous Velocity Mode.
And also, when the bit is "6" in Homing mode, the slave performs Returning to the origin position in Velocity mode.

8) Profile Velocity Mode

In this mode, trajectory is generated by the slave.

The master (Control Device) transmits 0x60FF: Target velocity through Cyclic Sync mode or Asynchronous mode, and the slave makes control of velocity and torque (force).

And also, be able to give slope reaching the target velocity by setting 0x6083: Profile Acceleration and 0x6084: Profile deceleration.




9) Cyclic Synchronous Velocity Mode


In this mode, trajectory is generated by the master, not the slave.

The master (Control Device) transmits 0x60FF: Target velocity through Cyclic Sync mode, and the slave makes control of velocity and torque (force).

When the Profile acceleration and deceleration 0x60083, 0x6084 are used, they function only for Halt and Quick stop operations.



Block diagrams of Function Group “Velocity” “Homing” mode are indicated in the following pages.




Block Diagram with Function Group [Velocity] [Homing] Mode

5. Object Dictionary

0x6040:Control Word (Cyclic Sync. Velocity Mode: csv, Profile Velocity Mode: pv)


Index Ax1	0x6040	This object shall indicate the operation mode specific and manufacturer specific bit in Cyclic Sync-position mode (csv), Profile velocity mode (pv)	Object code	Variable		
Ax2	0x6840					
Ax3	0x7040					
Ax4	0x7840					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Control word [CWORD] * See the bit patten command list for the detail on Bit 7, 3, 2, 1, 0		Unsigned16 Range	RW	Possible	0x0000 0x0000-0xFFFF



bit8:HALT [HALT]
0: Acceptpt Velocity Command(Enable bit4)
1:Stop axle with halt option code(0x605D)

0x6041:Status Word (Cyclic Sync. Velocity Mode: csv, Profile Velocity Mode:pv)

Index	0x6041	This object indicates Operation mode specific bits and Manufacturere specific bits in Cyclic Shunc. Mode (csv) and Profile velocity (pv)mode.	Object code	Variable					
Sub-Idx	Description				Data Type	Access	PDO	Initial value	
0x00	Status Word [STSWORD] * See the Status word bit patterns status lists for the details on Bit 6, 5, 3, 2, 1, 0				Unsigned16 Range	RO	Possible	0x0000 0x0000-0xFFFF	



bit4:Voltage Enabled [Voltage Enabled] 0:voltage disenabled 1:voltage enabled
bit7:warning [warning] 0:No warning 1:warning condition
bit9:remote [remote] 0: Control word is not processed 1: Being processed by control word
bit10:Target velocity reached [Target reached] 1: Reached at target velocity Set to "1" when the actual velocity is within constant velocity. Coincident velocity output has two settings, "OD: 0x606D rotational rate setting" and "OD: 0x202A ratio setting," and shall be selected on "OD: 0x20F0. 4 velocity window unit output." Also set to "1" in the halt state, when quick stop operation activated (quick stop option code-2, 5, 6, and 7), and operational mode change completed (for about 1 minute set).
bit11:Internal Limit active [Internal Limit active] 0:nomal operation 1:Software Position limit, CW limit/CCW limit
bit12: Zero-speed status [Speed] 0: Not Zero-speed status 1: Zero-speed status

5. Object Dictionary

10) Homing Mode

This clause describes the method by which a drive seeks the home position (also called, the datum, reference point or zero point)


Input objects are defined as well as the output objects. The user may specify the speed, acceleration and the method of homing. There is a further object home offset, which allows the user to displace zero in the user's coordinate system from the home position.

There is no output data except for those bits in the status word, which return the status or result of the homing process and the demand to the position control loops.

There are two homing speeds; the faster speed is used to find the home switch (Sub-Index 1) and slower speed is used to find the index pulse.

Here is the Objects list in the Homing mode.

List of Homing Mode Object			
Index	Sub-Index	Name	PDO Mapping
0x607C	0x00	Home offset	Possible
0x6098	0x00	Homing method	Possible
0x6099	0x00	Homing speeds	Possible
0x609A	0x00	Homing acceleration	Possible
0x60E3	0x00	Support Homing Method	No
0x60FD	0x00	Digital Input	Possible



By choosing a homing method, the following behavior is determined: the homing signal (positive limit switch, negative limit switch, home switch and touch-probe 1), the direction of actuation and where appropriate, the position of index pulse.

The home position and the zero position are offset by the home offset. (0x607C: See the definition of home offset for how this offset is used.) There are five sources of homing signal available: These are the negative and positive limit switches, the home switch, touch-probe 1 and index pulse from an encoder.

The drive that reached to the limit switch shall move in the other direction to leave the position. In the diagrams of homing sequences shown below, the encoder count increases as the axis position moves to the right. (The left is the minimum position and the right is the maximum position.)

5. Object Dictionary

The below shows the supported Homing Methods list. No.-4 to -1 are manufacturer specific homing methods

Method	Homing Mode	Stop direction
-4	Homing on hard stop (Butt) and index pulse in negative direction	positive
-3	Homing on hard stop (Butt) and index pulse in positive direction	negative
-2	Homing on hard stop (Butt) in positive direction	negative
-1	Homing on hard stop (Butt) in negative direction	positive
0	Undefined homing methods (Homing does not start)	-
1	Homing on negative limit switch and index pulse	positive
2	Homing on positive limit switch and index pulse	negative
3	Homing on positive home switch and index pulse	negative
4	Homing on positive home switch and index pulse	positive
5	Homing on negative home switch and index pulse	positive
6	Homing on negative home switch and index pulse	negative
7	Homing on positive limit switch, homing on positive home switch and index pulse	negative
8	Homing on positive limit switch, homing on positive home switch and index pulse	positive
9	Homing on positive limit switch, homing on negative home switch and index pulse	negative
10	Homing on positive limit switch, homing on negative home switch and index pulse	positive
11	Homing on negative limit switch, homing on positive home switch and index pulse	positive
12	Homing on negative limit switch, homing on positive home switch and index pulse	negative
13	Homing on negative limit switch, homing on negative home switch and index pulse	positive
14	Homing on negative limit switch, homing on negative home switch and index pulse	negative
17	Homing on negative limit switch	positive
18	Homing on positive limit switch	negative
19	Homing on positive home switch	positive
20	Homing on positive home switch	negative
21	Homing on negative home switch	positive
22	Homing on negative home switch	negative
23	Homing on positive limit switch and Homing on positive home switch	negative
24	Homing on positive limit switch and Homing on positive home switch	positive
25	Homing on positive limit switch and Homing on negative home switch	negative
26	Homing on positive limit switch and Homing on negative home switch	positive
27	Homing on negative limit switch and Homing on positive home switch	positive
28	Homing on negative limit switch and Homing on positive home switch	negative
29	Homing on negative limit switch and Homing on negative home switch	positive
30	Homing on negative limit switch and Homing on negative home switch	negative
33	Homing on the index pulse	negative
34	Homing on the index pulse	positive
35	Homing on the current position	-
37	Homing on the current position	-

Object:0x607C Use of the object 0x607C Homing Offset

The set homing offset (0x607C) is used to calculate actual position during homing. Homing offset can be always written, however is used only in the homing mode to re-calculate actual position.


The position actual value (0x6064) is the current software position in the amplifier. It is based on the unprocessed position encoder information (single or multi turn encoder).

For a single turn encoder the single turn information represents the position actual value. For a multi turn encoder the multi turn information represents the position actual value.

Settings of actual position calculation method".


The actual position (0x6064) in home position during homing is as follows:

Without Homing Method 35,37



$$\text{Zero Position} = \text{Home Position} + \text{Home offset (0x607C)}$$

Homing Method 35,37




$$\text{Actual Position (0x6064)} = \text{Home offset (0x607C)}$$

The following figures show sequences in the homing mode of Control word (0x6040), Operation mode (0x6060) and Operation display (0x6061).


5. Object Dictionary

The following sequence shows homing modes corresponding to the Amplifier of Servo Amplifier

1) Start and completion sequence of homing mode



2) Cancel before homing completion



5. Object Dictionary

Definitions of general purpose input signals in the homing mode

- 1) In the homing mode, input allocation and sequence of positive limit switch (CC:OT) and negative limit switch (CCW:OT) are determined by setting of 0x01:Positive limit switch and 0x02:negative limit switch in 0x20F0.
- 2) The home switch in a homing mode is allocated an exclusive use connector CONT1 (Home Switch) automatically. This is dual input both of general-purpose input and exclusive input. Therefore, when you use Home switch input, set 0x20F8 General input function selection as "00: CONT1 Always_OFF".
 - * If CONT1 is allocated to the other operation, a homing may not work normally.
 - * The definition of home switch setting is fixed as follows:
 - Home switch is on: Photocoupler of the amplifier is on
 - Home switch is off: Photocoupler of the amplifier is off
- 3) For the Homing Switch, CONT1 is assigned exclusively. So, the homing using Home Switch is not able to use by multiple axis. For the other axis excepting Home Switch use axis, use the homing without Home Switch.

Homing mode which cannot use with multiple axis

- Homing Method [3][4] :Homing on positive home switch and index Pulse
- Homing Method [5][6] :Homing on positive home switch and index Pulse
- Homing Method [7][8][9][10] :Homing on positive home switch, home switch and index Pulse
- Homing Method [11][12][13][14] :Homing on negative home switch, home switch and index Pulse
- Homing Method [19][20] :Homing on positive home switch
- Homing Method [21][22] :Homing on negative home switch

Operation direction by homing method

Move direction in each homing drawing and rotation direction are depending on 0x607E: Polarity.

Move direction in drawing and motor rotation direction are shown below.

0x607E Polarity	Move to right/ Positive rotation (Actual position increased)	Move to left/ Negative rotation (Actual position decreased)
0x00 (Position polarity Bit7=0)	CW	CCW
0xE0 (Position polarity Bit7=1)	CCW	CW


5. Object Dictionary

Homing Method [1]: Homing on negative limit switch and index Pulse

Homing Method [2]: Homing on positive limit switch and index Pulse

In the method [1], the initial direction of movement shall be leftward (negative rotation) if the negative limit switch is inactive. The home position shall be at the first index pulse to the right of the position (positive side) where the negative limit switch becomes active.

And using the method [2], the initial direction of movement shall be rightward (negative rotation) if the positive limit switch is inactive. The position of home shall be at the first index pulse to the left of the position (negative side) where the positive limit switch becomes inactive.




[1]Homing on negative limit switch and index pulse

[2] Homing on positive limit switch and index pulse

0x6099, 0x01: Speed during search for switch


0x6099, 0x02 : Speed during search for zero



Homing Method [3][4]: Homing on positive home switch and index Pulse

Homing Method [5][6]: Homing on positive home switch and index Pulse

Using these methods as shown in the below figure, the initial direction of movement shall be dependent on the state of the home switch input. In the method [3] and [6], the home position shall be at the left position where the home switch changes state, and in the method [4] and [5], the home position shall be at the initial index pulse to the right of the point where the home switch changes state. If the initial position is situated so that the direction of movement shall reverse during homing, the point at which the reversal takes place is anywhere after a change of state to the home switch.



[3] Homing on positive home switch and index pulse (Neg)


[4] Homing on positive home switch and index pulse (Pos)

[5] Homing on positive home switch and index pulse (Pos)


[6] Homing on positive home switch and index pulse (Neg)

5. Object Dictionary

Homing Method [7][8][9][10]: Homing on positive home switch, home switch and index Pulse



Homing Method [11][12][13][14]: Homing on negative home switch, home switch and index Pulse



5. Object Dictionary


Homing Method [17]: Homing on negative limit switch

Homing Method [18]: Homing on positive limit switch

In the method [17], the initial direction of movement shall be leftward (Negative rotation) if the negative limit switch is inactive. The home position shall be at the position by the negative limit switch becomes active.

And using the method [18], the initial direction of movement shall be rightward (positive rotation) if the positive limit switch is inactive. The position of home shall be at the position by the positive limit switch becomes active.


Positive Limit Switch and Negative Limit Switch used in homing method [17] and [18] cannot be used for the inputs other than the following versatile input: CONT1, CONT2, CONT3. Error occurs when homing is enabled, if set to CONT4, 5, 6, 7 and 8.



Homing Method [19][20]: Homing on positive home switch

[21][22]: Homing on negative home switch

These methods are similar to methods 3 to 6 that the home position is not dependent on the index pulse but only depend on the relevant home or limit switch transitions. The initial move direction depending on state of home switch and the move direction at home switch change are matched as follows: [3]=[19], [4]=[20], [5]=[21], [6]=[22].




5. Object Dictionary

- # Homing Method [33][34]: Homing on index Pulse
- # Homing Method [35][37]: Homing on current position

In homing method [33][34], the home position shall be at the nearest index pulse that is found in the selected direction ([33] is negative direction, [34] is positive direction).

In homing method [35][37], the current position shall be taken to be the home position. This method does not require the drive device to be in operation-enabled state (Servo-ON).

Note) However, the actual position calculation method is only absolute homing.



Note) Homing method [35]: Homing on current position is void at CiA402 Work Draft CANopen Drive and motion control device profile part2 Version: 3.0.1.13 (26 April 2012)

- # Homing Method [-1] [-2]: Homing on hard stop Note
- # Homing Method [-3] [-4]: Homing on hard stop and index pulse Note


Note) Methods [-1] to [-4] are manufacturer-specific methods.

In homing methods [-1] and [-2], the direction of homing is positive or negative respectively.

The home position shall be the mechanical end where the motor stopped.

In homing methods [-3] and [-4], the direction of homing is negative or positive respectively.

The home position shall be the first index pulse after reversing at the mechanical end where the motor stopped.



5. Object Dictionary

& Home position retention function when using absolute system

Execution result of "OD: 0x6098 Homing method 35 (Homing to present position)" can be retained by performing all parameters retention in "OD: 0x1010 Store parameter," and then the origin coordinate shall be retained in "OD: 0x6064: Actual position" even when re-turning on the power next time.

In this regard, however if any encoder clear or battery errors occur, correct origin coordinate shall not be presented, so re-homing is required. Absolute system homing "origin coordinate retention procedure" is shown below:

Step 1 Preparation of homing

OD: 0x6098 Set homing method to "35 (0x23): Homing to present position."
 OD: 0x607C Setting of home offset (When using "0: Absolute homing," set the position you want to set to "detection reference position," when using "1: Relative position homing," set to zero.)
 OD: 0x6060 Change operation mode to "6: Homing mode."

Step 2 Homing start

OD: 0x6040 Set "Control word, Bit4=1 (0x0010): Homing start."

Step 3 Confirmation of reference position detection

OD: 0x6041 Monitor "Status word, Bit12=1: Homing completed."
 When performing "0: Absolute homing," proceed to step 5, when performing "1: Relative homing," proceed to step 4.

Step 4 Setting of home offset

OD: 0x210C Calculate "OD: 0x607C Home offset" value from home index position to set.
Home offset (0x607C) = Origin coordinate after homing completed - Home index (0x210C)

Step 5 Homing completion

Exit "OD: 0x6040 Control word, Bit4 = 0 (0x0000): Homing," and then change the control mode back to the one using "OD: 0x6060 Operation mode."

Step 6 Storage of origin coordinate

Write "0x65766173" in "Sub-Idx01: All parameters storage" of "OD: 0x1010 Parameter storage."



Step 7 Confirmation of storage completion

Storing is completed by turning back to "Sub-Idx01=1" of "OD: 0x1010 Parameter storage."
 (0: Now in storing)

- ✓ In use of absolute system, it is not available except homing method 35 (0x23).
- ✓ To clear stored "origin coordinate after homing completed," perform encoder clear, and then re-perform parameter retention procedure (step 6 and 7).

0x6040:Control Word (Homing Mode: hm)

Index	Ax1	Ax2	Ax3	Ax4	Description	Data Type	Access	PDO	Initial value
0x6040	0x6840	0x7040	0x7840		This object indicates the Operation Mode Specific bit and Manufacturer Specific bit in Homing Mode.				
Sub-Idx	Description					Data Type	Access	PDO	Initial value
0x00	Control Word [CWORD] *For details on Bit 7,3,2,1 and 0, see the table of Control Word Bit Pattern Command.					Unsigned16	RW	Possible	0x0000
						Range	0x0000-0xFFFF		



5. Object Dictionary


0x6041:Status Word(Homing Mode: hm)

Index	Ax1	0x6041	This object indicates Operation Mode Specific bit and Manufacturer Specific bit in Homing Mode.	Object code	Variable		
	Ax2	0x6841					
	Ax3	0x7041					
	Ax4	0x7841					
Sub-Idx	Description			Data Type	Access	PDO	Initial value
0x00	Status Word [STSWORD] *For details on Bit 6, 5, 3, 2, 1 and 0, see the Status Word List Bit Pattern.			Unsigned16 Range	RO	Possible	0x0000
				0x0000-0xFFFF			

MSB

LSB

Csetfix	Csetpro	Homing error	Homing attained	Internal Limit active	Target reached	Rm	Res	W	Sod*	Qs*	Ve	F*	Oe*	So*	Rtso*
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0



bit13	bit12	bit10	Description
0	0	0	Homing procedure is in progress
0	0	1	Homing procedure is interrupted or not started
0	1	0	Homing is attained, but target is not reached
0	1	1	Homing procedure is completed successfully
1	0	0	Homing error occurred, velocity is not 0
1	0	1	Homing error occurred, velocity is 0 (ZV)
1	1	X	Reserved

5. Object Dictionary

11) Function Group "Torque (force)"

Abstract of Function Group "Torque (force)"

As for function group "Torque (force)" Mode, "Profile Torque (force) Mode" and "Cyclic Synchronous Torque (force) Mode" are supported.


0x6060: If Operation Mode is set "4", it is operated by Profile torque (force) mode. If it is set "10", Cyclic synchronous torque (force) mode is operated. The below list indicates the main Objects as for function group "Torque (force)".

12) Profile torque (force) mode

In this mode, trajectory is generated by the slave.

The master (Control Device) transmits 0x6071: Target torque (force) through Cyclic Sync mode or Asynchronous mode, and the slave makes control of velocity and torque (force).

And also, be able to give slope reaching the target torque (force) by setting 0x6087: Torque Slope.




13) Cyclic Synchronous torque (force) mode


In this mode, trajectory is generated by the master, not the slave.

The master (Control Device) transmits 0x6071: Target torque (force) through Cyclic Sync mode, and the slave makes control of torque (force).

0x6087 Torque (force) slope functions only in Holt or Quick stop operation.



Block diagrams of Function Group "Torque" mode are indicated in the following pages.





Block Diagram with Function Torque Mode

5. Object Dictionary



0x6040:Control word (Cyclic synchronous torque (force) mode: cst, Profile torque (force) mode:tq)

Index	Ax1 0x6040 Ax2 0x6840 Ax3 0x7040 Ax4 0x7840	This object indicates operation mode specific bits and manufacturer specific bits of the Cyclic synchronous torque (force) mode (cst) and Profile torque (force) mode (tq)	Object code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Control word [CWORD] * See the Command table for "Control word bit pattern (Bit 7, 3, 2,1, 0,) command		Unsigned16 Range	RW	Possible	0x0000 0x0000-0xFFFF



0x6041:Status word (Cycle synchronous torque (force) mode: cst, Profile torque (force) mode: tq)

Index	Ax1 0x6041 Ax2 0x6841 Ax3 0x7041 Ax4 0x7841	This object indicates Operation modes specific and Manufacturer specific bits of Cycle synchronous torque (force) mode: cst, Profile torque (force) mode: tq	Object code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Status word [STSWORD] * See the Pattern Status table for "Status word bit pattern (Bit 6,5, 3,2,1,0,)		Unsigned16 Range	RO	Possible	0x0000 0x0000-0xFFFF



14) Function Group “Touch Probe”

Abstract of Touch Probe


“Touch Probe function” is a latching function to latch the edge-triggered encoder position by digital input.
 “Touch Probe in the event” is independent from NC cycle time function since it latches the sensor position in the hardware of the slave, therefore, it enables capture it more precisely.
 This amplifier provides two of channels - Touch Probe 1 (CONT1), Touch Probe 2 (CONT2) - for inputting “Touch Probe function”.
 Set all of selections of General input functions in 0x20F8 to [00:Always function disabled] before using “Touch Probe function”, since the input channels are provided for dual-purpose input.
 The objects used for “Touch Probe” are indicated in the following list.

Object Lists of Touch Probe

Index	Sub-Index	Name	PDO Mapping
0x60B8	0x00	Touch Probe Function	Possible
0x60B9	0x00	Touch Probe Status	Possible
0x60BA	0x00	Touch probe pos 1 pos value (positive edge)	Possible
0x60BB	0x00	Touch probe pos 1 neg value (negative edge)	Possible
0x60BC	0x00	Touch probe pos 2 pos value (positive edge)	Possible
0x60BD	0x00	Touch probe pos 2 neg value (negative edge)	Possible

- Touch prove 1 (CONT1) signal can be triggered with “touch prove 1 input or position encoder index pulse ^{Note 1}” by “0x60B8, bit 2: Trigger selection.”
- Touch prove 2 (CONT2) signal can be triggered with “touch prove 2 input or position encoder index pulse ^{Note 1}” by “0x60B8, bit 10: Trigger selection.”

Note1) When setting trigger with position encoder index pulse, if you use incremental encoder Z-phase is used, if you use absolute encoder, “the position that absolute data within single turn is zero” is used as index.
 The sequence of Touch Probe Function is indicated as follows.



The position value of positive edge latched at Touch Probe 1 (position encoder index pulse) is stored in 0x60BA
 The position value of negative edge latched at Touch Probe 1 (position encoder index pulse) is stored in 0x60BB
 The position value of positive edge latched at Touch Probe 2 (position encoder index pulse) is stored in 0x60BC
 The position value of negative edge latched at Touch Probe 2 (position encoder index pulse) is stored in 0x60BD


The position value latched by Touch Probe function

5. Object Dictionary

& Master-led homing (Touch probe homing method): Homing with touch-probe (without Limit Switch)


EtherCAT-support is recommended for touch probe homing to support correct and fast homing.

Touch probe events can be accurately captured as the events function separately inside slave hardware, unlike master/ slave sampling frequency. Examples of homing using touch probe function are shown below:



Master-based homing using touch probe

*A) shows machine axis position, the red line shows velocity, B) shows motor position chart, and C) shows motor velocity chart.



Example of touch probe homing procedure

5. Object Dictionary

15) Operation Mode Parameter (Profile Area)

0x6060: Operation Mode

Index Ax1 0x6060 Ax2 0x6860 Ax3 0x7060 Ax4 0x7860	Indicates requested operation mode.	Object Code	Variable		
Sub-Idx	Description	Data Type	Access	PDO	Initial Value
0x00	Operation Mode [OPMODE]	Integer8	RW	Possible	0x00
	0 : No Mode/Mode is not assigned. 1 : (pp) Profile Position Mode 2 : Reserved 3 : (pv) Profile Velocity Mode 4 : (tp) Torque (force) Profile Mode 5 : Reserved 6 : (hm) Homing Mode 7 : (ip) Interpolated position mode 8 : (csp) Cycle Sync. Position Mode 9 : (csv) Cycle Sync. Velocity Mode 10 : (cst) Cycle Sync. Torque (force) Mode	Setting Range		0x00 - 0x0A (0 to 10)	

* When this parameter is read, setup "operation mode" is read out.

Operation mode under actual operation serves as "Operation Mode Display" (0x6061).

* Make sure to change at the time of the main power supply OFF, Servo-off, or motor stop.


* Changing mode while motor rotating is dangerous. Make sure to change at the time of the main power supply OFF, Servo-off, or motor stop.

* Servo ON is not available when operation Mode is set "0".

0x6061: Operation Mode Display

Index Ax1 0x6061 Ax2 0x6861 Ax3 0x7061 Ax4 0x7861	Indicates actual operation mode. Definition is the same as 0x6060: Operation Mode.	Object Code	Variable		
Sub-Idx	Description	Data Type	Access	PDO	Initial Value
0x00	Operation Mode Display [OPDISP]	Integer8	RO	Possible	0x00
	0 : No Mode/Mode is not assigned. 1 : (pp) Profile position Mode 2 : Reserved 3 : (pv) Profile Velocity Mode 4 : (tp) Torque (force) Profile Mode 5 : Reserved 6 : (hm) Homing Mode 7 : (ip) Interpolated position mode 8 : (csp) Cycle Sync. Position Mode 9 : (csv) Cycle Sync. Velocity Mode 10 : (cst) Cycle Sync. Torque (force) Mode	Display Range		0x00 - 0x0A (0 to 10)	

Operation modes changed at the time of motor rotation will be valid after the motor stops completely.



5. Object Dictionary

0x6062: Position Demand Value

Index	Ax1 0x6062 Ax2 0x6862 Ax3 0x7062 Ax4 0x7862	Indicates the internal target position.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Target position [PositionDemandValue] Indicates the internal command when position control mode is in profile position mode This command position update by the servo control cycle 125us.		Integer32	RO	Possible	-
			Display Range	0x80000000 ~ 0x7FFFFFFF (-2147483648 ~ 2147483647 Pulse)		
			Unit	Pulse		

0x6063: Internal Actual Position

Index	Ax1 0x6063 Ax2 0x6863 Ax3 0x7063 Ax4 0x7863	Indicates real position of motor encoder.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Internal Actual Position [IACPMON] Internal actual position data update by the servo control cycle 125us. Monitor unit indicates the resolution of motor encoder to be used. *Encoder combination: In the case of Absolute encoder Effective bit length=Multiply 1 rotation resolution by multiple-rotation bit, effective bit length become "x" unfixed. * Encoder combination: In the case of Incremental encoder When the voltage enabled, define the position as zero, and the value of 32-bit that quadruplicate the A/B signal, which rise/down on "the free run counter" is displayed. * If the 0x607E position polarity(bit7) = 1, this data is inverted. Therefore, From an anterior view of the motor the value increases in the direction of Counter-Clockwise rotation (CCW).。		Integer32	RO	Possible	-
			Display Range	0x80000000 - 0x7FFFFFFF (-2147483648 to 2147483647 Pulse)		
			Unit	1 pulse		

0x6064: Position Actual Value

Index	Ax1 0x6064 Ax2 0x6864 Ax3 0x7064 Ax4 0x7864	Indicates after offset process or the actual position of motor encoder.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Position Actual Value [APMON] Position Actual Value indicates present position In case of synchronization by distributed clock (0x1C32-01 is DC Sync0 or DC Sync1), position data that is latched by SYNC signal will reply. In case of non-synchronization system, latest present position (Same as 0x6063) will reply. * Encoder combination: In the case of Incremental encoder When the voltage enabled, define the position as zero, and the value of 32-bit that quadruplicate the A/B signal, which rise/down on "the free run counter" is displayed. From an anterior view of the motor the value increases in the direction of Counter-Clockwise rotation (CCW). *When the position polarity of 0x607E is reversed, the value increases in the CW direction.		Integer32	RO	Possible	-
			Display Range	0x80000000 - 0x7FFFFFFF (-2147483648 to 2147483647 Pulse)		
			Unit	Pulse		

0x6065: Position Deviation Window (Position Deviation Counter Overflow Value)

Index	Ax1 0x6065 Ax2 0x6865 Ax3 0x7065 Ax4 0x7865	Permissible position range is set as a position request value relatively to.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Position Deviation Window [OFLV] When position actual value crosses position deviation window, becomes Excessive position deviation alarm. Position Actual Value Deviation >= Set Value		Unsigned32	RW	Possible	0x4C4B40 (5000000Pulse)
			Setting Range	0x00000001 - 0x7FFFFFFF (1 to 2147483647 Pulse))		
			Unit	Pulse		

0x6066: Position Deviation Time-out

Index	Ax1 0x6066 Ax2 0x6866 Ax3 0x7066 Ax4 0x7866	Setting time to be the position deviation excessive alarm state after Bit13 of the status word is set to 1. Operating reaction when excessive position deviation occurs is peculiar to a maker.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Position Deviation Time-out Unit is "ms" and stops immediately after alarm occurring.		Unsigned16	RW	No	0x0000
			Setting Range	0x0000 - 0x0000		
			Unit	ms		

5. Object Dictionary

0x6067:Position Window (Input Position Window)

Index	Ax1 0x6067 Ax2 0x6867 Ax3 0x7067 Ax4 0x7867	Sets up the range permissible as target position attainment. When position actual value of position encoder is in Position Window, means arriving at target position.	Object Code	Variable
Sub-Idx	0x00	Position Window [INP] When position deviation counter value is below this preset value, outputs IN-Position signal (INP). When Position Actual Value Deviation ≤ Set Value, outputs Position Window Monitor (INP monitor).	Data Type: Unsigned32 Access: RW PDO: No Initial Value: 0x64 (100Pulse)	Setting Range: 0x00000000 - 0x7FFFFFFF (0 to 2147483647 Pulse) Unit: pulse
<p>*In the case of incremental encoder, 4 times of the number of encoder pulses are standard. *In the case of absolute encoder (except for incremental output), absolute value is standard.</p>				

0x6068:Position Window Time

Index	Ax1 0x6068 Ax2 0x6868 Ax3 0x7068 Ax4 0x7868	Sets up time until outputs to INP monitor after arriving in Position Window.	Object Code	Variable
Sub-Idx	0x00	Position Window Time RS2-EtherCAT slave amplifier is outputted immediately after arriving in setting range.	Data Type: Unsigned16 Access: RW PDO: No Initial Value: 0x0000	Setting Range: 0x0000 - 0x0000 Unit: ms

0x6069:Actual Sensor Velocity

Index	Ax1 0x6069 Ax2 0x6869 Ax3 0x7069 Ax4 0x7869	Indicates actual value of velocity sensor.	Object Code	Variable
Sub-Idx	0x00	Actual Value of Velocity Sensor Indicates actual velocity calculated by motor encoder.	Data Type: Integer32 Access: RO PDO: Possible Initial value: —	Setting Range: 0x80000000~0xFFFFFFFF (-2147483648 to 2147483647 pps) Unit: Pulse/Sec

0x606A:Sensor Selection Code

Index	Ax1 0x606A Ax2 0x686A Ax3 0x706A Ax4 0x786A	With the object provide the source of velocity sensor actual value. It determines whether a differentiated position signal or the signal from a separate velocity sensor evaluated.	Object Code	Variable
Sub-Idx	0x00	Sensor Selection Code 0:Actual velocity from position encoder 1:Actual velocity from velocity encoder Position encoder and velocity encoder use the same encoder.	Data Type: Integer16 Access: RW PDO: Possible Initial Value: 0x0000	Setting Range: 0x0000 - 0x0001

5. Object Dictionary

0x606C: Velocity Actual Value

Index	Ax1 0x606C Ax2 0x686C Ax3 0x706C Ax4 0x786C	Has actual velocity value calculated from position encoder. Value shall be given in the velocity unit of user definition.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Velocity Actual Value [ACVMON] *Filter is processed to data, and cutoff frequency is 250Hz.		Integer32	RO	Possible	-
			Display Range	0x80000000 - 0x7FFFFFFF (-2147483648-2147483647 pps)		
			Unit	Pulse/sec		

0x606D: Velocity Window (Velocity Matching: Rotation Speed Setup)

Index	Ax1 0x606D Ax2 0x686D Ax3 0x706D Ax4 0x786D	Sets the range regarded as Velocity matching range by the unit [min-1]. Use this setting when "Velocity Matching Unit Selection" is "0x00_min-1".	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Velocity Window When the actual velocity remains within the range of the target velocity during the time period set in velocity window time shown in 0x605E, the status word "TargetReached" is set. This is enabled in profile velocity mode.		Unsigned16	RW	No	0x32 (50 min ⁻¹)
			Display Range	0x0000~0xFFFF (0~65535min ⁻¹)		
			Unit	min ⁻¹		
<p>✓The velocity matching output is switched by the setting of rotation speed (min-1) and ratio (%) at Velocity matching unit output selection (0x20F0.4). At selection of rotation speed setup, the condition under this setting value can be monitored with the status word (0x6040) bit 10: Target matching monitor.</p>						

0x606E: Velocity Window Time

Index	Ax1 0x606E Ax2 0x686E Ax3 0x706E Ax4 0x786E	After velocity attainment, sets up time (timer) until the status word "TargetReached" is set.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Velocity Window Time This servo amplifier sets the status word Bit 10: Target matching monitor when the velocity reaches the setting range and remains within the range for a time longer than the setting.		Unsigned16	RW	No	0x0001
			Display Range	0x0001 ~ 0x1388 (1~5000)		
			Unit	ms		

0x606F: Velocity Threshold (Speed Zero Setting)

Index	Ax1 0x606F Ax2 0x686F Ax3 0x706F Ax4 0x786F	Sets the range regarded as speed zero by the unit [min-1].	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Speed Zero Window When the actual velocity falls below this setting value, the status word "Speed zero detection" is set. This is enabled only in profile velocity mode.		Unsigned16	RW	No	0x0032 (50 min ⁻¹)
			Display Range	0x0005 to 0x01F4 (5 to 500min ⁻¹)		
			Unit	min ⁻¹		

0x6070: Velocity Threshold Time

Index	Ax1 0x6070 Ax2 0x6870 Ax3 0x7070 Ax4 0x7870	Sets up time (timer) until the status word "Speed zero detection" is canceled.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Velocity Threshold Time When the actual velocity is higher than the threshold velocity for a time longer than the setting, the status word bit 12: Speed zero detection is canceled. This is enabled only in profile velocity mode.		Unsigned16	RW	No	0x0001
			Display Range	0x0001 to 0x1388 (1 to 5000)		
			Unit	ms		

5. Object Dictionary

0x6071: Target Torque (force)

Index	Ax1	0x6071	Torque (force) command value set to torque (force) controls in Function Torque (force) Mode.	Object Code	Variable	
	Ax2	0x6871				
	Ax3	0x7071				
	Ax4	0x7871				
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Target Torque (force) [TATRQ] Setting units are 0.1% LSB in 1/1000 unit of rated torque (force). However, it is limited by max torque (force) for the value that exceeds the max torque (force) of the motor.		Integer16	RW	Possible	0x0000
			Display Range	0x8000 to 0x7FFF (-3276.8 to 3276.7%)		
			Unit	0.1 %		

0x6072: Maximum Torque (force)

Index	Ax1	0x6072	Indicates maximum set value of the torque (force) permitted to the motor.	Object Code	Variable	
	Ax2	0x6872				
	Ax3	0x7072				
	Ax4	0x7872				
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Maximum Torque (force) [MAXTRQ] Setting units are 0.1% / LSB in 1/1000 unit of rated torque (force). However, it is limited by max torque (force) for the value that exceeds the max torque (force) of the motor.		Unsigned16	RW	Possible	0x1388 (500.0%)
			Setting Range	0x0000 - 0x1388 (0 to 500.0%)		
			Unit	0.1%		

0x6076: Rated torque

Index	Ax1	0x6076	Indicates rated torque of selected motor.	Object Code	Variable	
	Ax2	0x6876				
	Ax3	0x7076				
	Ax4	0x7876				
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Rated torque Indicates rated torque of selected motor. Only the Sanyo Denki R series motor is accepted.		Unsigned32	RO	Possible	-
			Setting range	0x00000000 to 0xFFFFFFFF		
			Unit	m N·m		

6077: Actual Torque (force) Value

Index	Ax1	0x6077	Indicates actual torque (force) value of motor.	Object Code	Variable	
	Ax2	0x6877				
	Ax3	0x7077				
	Ax4	0x7877				
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Real Torque (force) Value [ACTMON] Setting units are 1% / LSB in 1/1000 unit of rated torque (force).		Integer16	RO	Possible	-
			Display Range	0x8000 - 0x7FFF (-3276.8 to 3276.7%)		
			Unit	0.1%		

0x6078: Actual Current Value

Index	Ax1	0x6078	Indicates actual current value of motor.	Object Code	Variable	
	Ax2	0x6878				
	Ax3	0x7078				
	Ax4	0x7878				
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Actual Current Value Monitor unit is 1/1000 unit of the rated current, and is 0.1%/LSB.		Integer16	RO	Possible	-
			Setting range	0x8000-0x7FFF (-3276.8-3276.7%)		
			Unit	0.1 %		

5. Object Dictionary

0x6079: DC link circuit voltage

Index	Ax1 0x6079 Ax2 0x6879 Ax3 0x7079 Ax4 0x7879	This object shall provide the instantaneous DC link current voltage at the drive device. The value shall be given in mV.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	DC link circuit voltage ✓For AC100V, AC200V DC24V, DC48V Rotary, Linear , Direct Drive Motor (RS2E TypeH, RS2A TypeH, RS2J TypeH, RS2K TypeH)		Unsigned32	RO	Possible	—
			Display Range	0x00000000~0xFFFFFFFF		
			Unit	mV		
<p>This monitor is simplified. This shows 280,000mV at 200VAC input, 140,000mV at 100VAC input, 48,000mV at 48VDC input, 24,000mV at 24VDC input and 0V at POFF state.</p> <p>✓For AC400V Rotary, Linear , Direct Drive, Induction Motor AC200V input type (SS1A typeH, RS2C typeH) It displays the actual DC voltage by detected internal circuit.</p>						

0x607A:Target Position

Index	Ax1 0x607A Ax2 0x687A Ax3 0x707A Ax4 0x787A	Command position of drive moved by setup of motion control parameters, such as velocity, acceleration, deceleration, and motion profile type.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Target Position [TAPOS] Sets up absolute position command for every communication cycle.		Integer32	RW	Possible	0
			Display Range	0x80000000 - 0xFFFFFFFF		
			Unit	pulse		

5. Object Dictionary

0x607B:Position range Limit (Modulo value)

Index	Ax1 0x607B Ax2 0x687B Ax3 0x707B Ax4 0x787B	At position command type motion mode, set the range of position coordinates able to be set (able to be assigned). Both controller (position command) and driver (actual position) communicate position data within the range of position coordinates set here.	Object Code Array			
Sub-Idx	Name/Description		Data Type	Access	PDO	Range (Initial Value)
0x00	Number of Entry		-	RO	No	0x2
0x01	Min position range limit	[MINPLIM]	Unsigned8	RW	Possible	0x80000000
			Setting value	0x80000000-0x7FFFFFFF		
0x02	Max position range limit	[MAXPLIM]	Integer32	RW	Possible	0x7FFFFFFF
			Setting value	0x80000000-0x7FFFFFFF		
Refer to the next page for details.						

< About Setting Value >

- Unit is the same user definition as target position, and in this servo amplifier, the unit is 1 Pulse/LSB.
- When minimum position range limit = 0x00000000 and maximum position range limit = 0x00000000 are set, or when minimum position range limit = 0x80000000 and maximum position range limit = 0x7FFFFFFF are set, the position coordinate is recognized as "Linear coordinate".
- When setting is other than the above, position coordinate indicates "Modulo coordinate". In this case, although the setting value can be any value, set actual range of motion at no more than the positive maximum value (0x7FFFFFFF) of 32bit
("maximum position range limit - "minimum position range limit" ≤ 2147483647 (0x7FFFFFFF))

< Linear coordinate(Straight Axis) >


- The limit value of coordinates is the lower limit = 0x80000000, and upper limit = 0x7FFFFFFF. However for PP mode, wraparound exceeding position range limit is available if 0 is set to Min/Max position range limit.
For CSP mode, wraparound at any range limit is available.
To set limits on the range of motion within position range limit, set the appropriate software position limits (0x607D).

< Modulo Coordinate (Rotation Axis) >

- When the current position reaches the maximum position range limit in the direction of coordinate increase, the following coordinate value will indicate the setting value of minimum position range limit.
- In the opposite situation, when the current position reaches the minimum position range limit in the direction of coordinate decrease, the following coordinate value will indicate the setting value of maximum position range limit.
- Except for the motion modes listed below in brackets, all position information set by the controllers should be modulo coordinates.
(In the following case, in the setting of "Standard positioning same as straight axis," for example, if you wish to move from current position by a value of 90°, the following commands are possible:
"positioning to absolute displacement 630° = 360° (1 revolution) + 270° (in this case, relative displacement of 540°",
"positioning to relative displacement 500° = 360° (1 revolution) + relative displacement of 140 (in the result, positioning to 230°)"

In this case, the current position information always indicates modulo calculated value by 360°.

- In modulo mode, the parameter to set rotation direction in the profile position mode is 0x60F2 bit7, 6.
Modulo coordinate image, in the case that minimum position range limit = 0, and maximum position range limit = 359 is set, is shown below.





Example of Positioning at Rotation Axis

< Regarding timing in which the setting parameter is reflected to coordinate >

- In the case that the previously set position range limit value has been written in the nonvolatile memory of the servo amplifier
⇒ Immediately after control power is On, the setting value of the position range limit will be reflected on position information.
- In the case that setting of position range limit is changed when ESM is in Pre-Operational status.
⇒ The changed setting value will be reflected when ESM is shifted from Pre-Operational to Safe-Operational.
- In the case that ESM changes setting of position range limit in another status than that of Pre-Operational
⇒ Because the changed setting value will be reflected when ESM is shifted from Pre-Operational to Safe-Operational, temporarily lower ESM to Pre-Operational and increase ESM again.

5. Object Dictionary

0x607C: Home offset (homing mode)





Index Ax1 0x607C Ax2 0x687C Ax3 0x707C Ax4 0x787C	Normalizes homing position (mechanical origin) detected in homing mode by homing offset value.	Object code	Variable		
Sub-Idx	Description	Data Type	Access	PDO	Initial Value
0x00	<p>Home offset [HOFFSET]</p> <p>&The set homing offset (0x607C) is used to calculate actual position.</p> <p>✓ Homing offset can be always written, however, is used to re-calculate only in homing mode.</p> <p>The actual position (0x6064) using homing position during homing is calculated as follows:</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>Without Homing Method 35,37</p>  <p>Zero Position = Home Position + Home offset (0x607C)</p> </div> <div style="text-align: center;"> <p>Homing Method 35,37</p>  <p>Actual Position(0x6064) = Home offset (0x607C)</p> </div> </div> <p>✓If not Homing Method 35 or 37 and ZeroPosition=Home Offset Homing need to sets 0x20F6-1 = 1.</p>	Integer32	RW	Possible	0x00000000 (0 pulse)
		Setting Range	0x80000000-0x7FFFFFFF (-2147483648-2147483647 Pulse)		
		Unit	Pulse		

0x607D: Software Position Limit

Index Ax1 0x607D Ax2 0x687D Ax3 0x707D Ax4 0x787D	Consists of the Maximum / Minimum software position limits. Position command and actual position are calculated by target position (0x607A) and position offset (0x60B0) to be limited in absolute position.	Object Code Array			
Sub-Idx	Name/Description	Data Type	Access	PDO	Range (Initial Value)
0x00	Number of Entry	-	RO	No	0x2
0x01	<p>Minimum Position Limit [SMINLIM]</p> <p>Unit is 1 pulse/LSB with RS2EtherCAT amplifier in the same user definition as a target position.</p>	Integer32	RW	Possible	0x80000000 - 0x7FFFFFFF (0)
0x02	<p>Maximum Position Limit [SMAXLIM]</p> <p>Unit is 1 pulse/LSB with RS2EtherCAT amplifier in the same user definition as a target position.</p>	Integer32	RW	Possible	0x80000000 - 0x7FFFFFFF (0)
<p>Since the actually used limit value includes Home Offset (0x607C), it is normalized internally before being compared with target position.</p> <p>Minimum Position Limit for Normalization = Minimum Position Limit - Home Offset Maximum Position Limit for Normalization = Maximum Position Limit - Home Offset *Function is invalid when the Minimum Position Limit >= Maximum Position Limit.</p>					

5. Object Dictionary

0x607E: Polarity (Position, Velocity, Torque (force) Command/Offset Input Polarity)

Index	Ax1	Ax2	Ax3	Ax4		Object Code	Variable	
	0x607E	0x687E	0x707E	0x787E	Sets command for input polarity. When Bit=1, the command value is multiplied by -1, and it serves as a reverse command.			
Sub-Idx	Description				Data Type	Access	PDO	Initial Value
0x00	Polarity [CMDPOL]				Unsigned8	RW	Possible	0x00
	Selects the combination of each command polarity over position command, velocity command, torque (force) command input, position offset, velocity offset (velocity addition), and torque (force) offset (torque (force) addition) from the following contents.				Setting Range	0x00 - 0xE0		
<p>Bit7 : Position Polarity "0": Command is multiplied by +1. "1": Multiplied by -1. (only csp,ip enable)</p> <ul style="list-style-type: none"> Valid only in Cycle sync. position mode (csp) , Interpolated position mode (ip) , 0x607A Target position and 0x60B0 Position offset input value are multiplied by -1 with "1", and then command polarity is reversed. <p>Bit6 : Velocity Polarity "0": Command is multiplied by +1. "1": Multiplied by -1.</p> <ul style="list-style-type: none"> In Cycle sync. position mode (csp), Interpolated position mode (ip), "1" 0x60B0 Velocity offset input value as velocity compensation is multiplied by -1 with "1", and then compensation polarity is reversed. In Cycle sync. position mode (csv), 0x60FF Target velocity and 0x60B1 Velocity offset input value are multiplied by -1 with "1", and then command polarity is reversed. <p>Bit5 : Torque (force) Polarity "0": Command is multiplied by +1. "1": Multiplied by -1.</p> <ul style="list-style-type: none"> In Cycle sync. position mode (csp) , Interpolated position mode (ip) and Cycle sync. velocity mode(csv),0x60B2 Torque (force) offset input value as torque (force) compensation is multiplied by -1 with "1", and then compensation command polarity is reversed. In Cycle sync. torque (force) mode(cst), 0x6071 Target torque and 0x6082 Torque offset input value are multiplied by -1 with "1", and then command polarity is reversed. <p>Bit4 - 0: Reserved</p> <p>*Direction with positive (+) polarity command supply according to the setting value is shown below.</p> <p>*When command input polarity is standard set value "Bit7=0, Bit6=0, Bit5=0", rotates to positive direction (CCW)by command polarity + / to negative direction (CW) by -.</p> <div style="display: flex; justify-content: space-around;">   </div> <p>*When command input polarity is standard set value "Bit7=1, Bit6=1, Bit5=1", rotates to negative direction (CW) by command polarity + / to positive direction (CCW) by -.</p> <div style="display: flex; justify-content: space-around;">   </div> <p>Note) Change will be impossible if ESM of this parameter is Operational. Make sure to change after servo-off and shift to Pre-Operational.</p> <ul style="list-style-type: none"> ✓Refer to section 13, Linear motor control parameter list for the description of linear motor polarity. ✓When OT is used, set 0x00 or 0xE0. 								

0x607F: Maximum Profile Velocity (Velocity Limit Command)

Index	Ax1	Ax2	Ax3	Ax4		Object Code	Variable	
	0x607F	0x687F	0x707F	0x787F	Sets permissible velocity to Velocity command.			
Sub-Idx	Description				Data Type	Access	PDO	Initial Value
0x00	Maximum Profile Velocity [VCLM] Limit maximal allowed profile velocity (0x6081) during a profiled position (pp) motion. *The unit is in user definition as same as 0x6081				Unsigned32	RW	Possible	0xFFFFFFFF
					Setting Range	0x00000001 - 0xFFFFFFFF (1 - 4294967295 pps)		
					Unit	Pulse/sec		

5. Object Dictionary

0x6080: Maximum motor velocity

Index	Ax1	0x6080	Sets the selected motor's maximum velocity.	Object Code	Variable		
	Ax2	0x6880					
	Ax3	0x7080					
	Ax4	0x7880					
Sub-Idx	Description			Data Type	Access	PDO	Initial value
0x00	Maximum motor velocity Sets the selected motor's maximum velocity. When the Sanyo Denki R series motor is selected, it is automatically set at the time of amplifier power input.			Unsigned32	RW	Possible	0x00000000
				Setting range	0x00000000-0xFFFFFFFF (0-4294967295 min-1)		
				Unit	min-1		


0x6081: Profile Velocity

Index	Ax1	0x6081	This object shall indicate the configured velocity normally attained at the end of the acceleration ramp during a profile position mode motion.	Object code	Variable		
	Ax2	0x6881					
	Ax3	0x7081					
	Ax4	0x7881					
Sub-Idx	Description			Data Type	Access	PDO	Initial value
0x00	Profile velocity [PROVEL] The value is effective for both of CW and CCW.			Unsigned32	RW	Possible	0xFFFFFFFF
				Display range	0x00000000-0xFFFFFFFF (0-4294967295 pps)		
				unit	Pulse/sec		

0x6082: End velocity

Index	Ax1	0x6082	Sets end velocity.	Object Code	Variable		
	Ax2	0x6882					
	Ax3	0x7082					
	Ax4	0x7882					
Sub-Idx	Description			Data Type	Access	PDO	Initial value
0x00	End velocity Sets the end velocity in position mode at the time of reaching the target. This servo amplifier does not support this function.			Unsigned32	RW	Possible	0x00000000
				Setting range	0x00000000-0xFFFFFFFF		
				Unit	Pulse/sec		

0x6083: Profile acceleration

Index	Ax1	0x6083	Parameters to decide the gradient at the time of motor acceleration during Profile position, Function velocity mode.	Object Code	Variable		
	Ax2	0x6883					
	Ax3	0x7083					
	Ax4	0x7883					
Sub-Idx	Description			Data Type	Access	PDO	Initial value
0x00	Profile acceleration [TVCACC] The parameters to give acceleration incline against preset velocity command, and set the rate of velocity per second.			Unsigned32	RW	Possible	0xFFFFFFFF
				Setting Range	0x00000000-0xFFFFFFFF (0-4294967295 pps ²) *		
				Unit	Pulse/sec ²		
<p>Note) This parameter is effective only against Profile position mode (pp), Profile velocity mode (pv).</p>  <p>Note) If value is set to "0", the amplifier proceeds it as "1." * At the pv mode, upper limit value will be kept at 16,000msec if the value exceeding 16,000msec is set with conversion per 1,000min-1.</p>							

5. Object Dictionary

0x6084: Profile Deceleration

Index	Ax1 0x6084 Ax2 0x6884 Ax3 0x7084 Ax4 0x7884	Parameters to decide the gradient at the time of motor deceleration.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Profile Deceleration [TVCDEC] The parameters to give deceleration incline against preset velocity command, and set the rate of velocity per second. *This parameter is effective only against Profile position mode (pp), Profile velocity mode (pv).		Unsigned32	RW	Possible	0xFFFFFFFF
			Setting Range	0x00000000-0xFFFFFFFF (0-4294967295 pps2) *		
			Unit	Pulse/sec2		
<p>Note) If value is set to "0", the amplifier proceeds it as "1." * At the pv mode, upper limit value will be kept at 16,000msec if the value exceeding 16,000msec is set with conversion per 1,000min-1.</p>						

0x6085: Quick Stop Deceleration

Index	Ax1 0x6085 Ax2 0x6885 Ax3 0x7085 Ax4 0x7885	Slowdown parameter used for motor stop when quick stop function is active and "2" or "6" is set to quick stop code object (0x605A). Used also when Fault reaction code object (0x605E) and the Halt option code object (0x605D) are "2."	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Quick Stop Deceleration [QSDEC] Value serves as the same unit as a Profile acceleration object (0x6083). Note) If value is set to "0", the amplifier proceeds it as "1."		Unsigned32	RW	Possible	0xFFFFFFFF
			Setting Range	0x00000000-0xFFFFFFFF (0-4294967295 pps2)		
			Unit	Pulse/sec2		

0x6087: Torque (force) slope

Index	Ax1 0x6087 Ax2 0x6887 Ax3 0x7087 Ax4 0x7887	This object shall give incline to torque (force) command in Torque (force) profile mode (tq)	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Torque (force) slope [TSLOPE] Setting units are 0.1% / sec. Even Torque (force) slope is set the value more than maximum current of the motor, it will be limited to Maximum current.		Unsigned32	RW	Possible	0xFFFFFFFF
			Setting range	0x00000001~0xFFFFFFFF		
			Unit	0.1%/sec		

0x6088: Torque Profile Type

Index	Ax1 0x6088 Ax2 0x6888 Ax3 0x7088 Ax4 0x7888	This is a parameter to set the Torque (force) Profile Type in torque (force) profile mode(tq).	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Torque (force) Profile Type Setting unit is 0 (Linear ramp) fixed.		Integer16	RW	Possible	0x0000
			Setting Range	0x0000~0x0000		

0x608F: Position Encoder Resolution

Index	Ax1 0x608F Ax2 0x688F Ax3 0x708F Ax4 0x788F	Sets the resolution of the output shaft encoder.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Number of entry		Unsigned8	RO	No	0x02
0x01	Sets the number of pulses of position encoder. Indicates resolution of the connected encoder.		Unsigned32	RW	Possible	0x01
			Setting Range	0x00000001~0xFFFFFFFF		
			Unit	Pulse		
0x02	Sets the rotation speed of the motor shaft. Since this servo amplifier is not compatible with this function, values other than 1 cannot be set.		Unsigned32	RW	Possible	0x01
			Setting Range	0x01~0x01		
			Unit			

5. Object Dictionary

0x6091: Gear Ratio

Index	Ax1 0x6091 Ax2 0x6891 Ax3 0x7091 Ax4 0x7891	Sets the gear ratio of the motor shaft and the output shaft.	Object Code		Variable
Sub-Idx	Description	Data Type	Access	PDO	Initial Value
0x00	Number of entry	Unsigned8	RO	No	0x02
0x01	Sets the rotation speed of the motor shaft. With this servo amplifier, the rotation speed of the motor shaft is fixed to 1.	Unsigned32	RW	Possible	0x01
		Setting Range	0x01~0x01		
		Unit			
0x02	Sets the rotation speed of the output shaft. With this servo amplifier, the rotation speed of the output shaft is fixed to 1.	Unsigned32	RW	Possible	0x01
		Setting Range	0x01~0x01		
		Unit			

0x6092: Feed Constant

Index	Ax1 0x6092 Ax2 0x6892 Ax3 0x7092 Ax4 0x7892	Sets the travel distance in one rotation of the output shaft.	Object Code		Variable
Sub-Idx	Description	Data Type	Access	PDO	Initial Value
0x00	Number of entry	Unsigned8	RO	No	0x02
0x00	Sets the travel distance. Since this servo amplifier is not compatible with this function, values other than 1 cannot be set.	Unsigned32	RW	Possible	0x01
		Setting Range	0x01~0x01		
		Unit			
0x01	Sets the rotation speed of the motor shaft. With this servo amplifier, the rotation speed of the motor shaft is fixed to 1.	Unsigned32	RW	Possible	0x01
		Setting Range	0x01~0x01		
		Unit			

0x6098: Homing method

Index	Ax1 0x6098 Ax2 0x6898 Ax3 0x7098 Ax4 0x7898	This object shall set the homing method that shall be used.	Object code		Variable
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Homing method [HOMETYP] Configured homing method (Origin return method)	Integer8	RW	Possible	0x23 (35)
		Setting range	0xFC~0x25 (-4~37)		
<p> <u>-4 (0xFC) : Homing on positive hard stop and index pulse</u> <u>-3 (0xFD) : Homing on negative hard stop and index pulse</u> <u>-2 (0xFE) : Homing on negative hard stop</u> <u>-1 (0xFF) : Homing on positive hard stop</u> <u>0 (0x00) : No Homing method</u> <u>1 (0x01) : Homing on negative limit and index pulse</u> <u>2 (0x02) : Homing on positive limit and index pulse</u> <u>3 (0x03) : Homing on positive home switch and index pulse</u> <u>4 (0x04) : Homing on positive home switch and index pulse</u> <u>5 (0x05) : Homing on negative home switch and index pulse</u> <u>6 (0x06) : Homing on negative home switch and index pulse</u> <u>7 (0x07) : Homing on positive limit switch, homing on positive home switch and index pulse</u> <u>8 (0x08) : Homing on positive limit switch, homing on positive home switch and index pulse</u> <u>9 (0x09) : Homing on positive limit switch, homing on negative home switch and index pulse</u> <u>10 (0x0A) : Homing on positive limit switch, homing on negative home switch and index pulse</u> <u>11 (0x0B) : Homing on negative limit switch, homing on positive home switch and index pulse</u> <u>12 (0x0C) : Homing on negative limit switch, homing on positive home switch and index pulse</u> <u>13 (0x0D) : Homing on negative limit switch, homing on negative home switch and index pulse</u> <u>14 (0x0E) : Homing on negative limit switch, homing on negative home switch and index pulse</u> <u>17 (0x11) : Homing on negative limit switch</u> <u>18 (0x12) : Homing on positive limit switch</u> <u>19 (0x13) : Homing on positive home switch</u> <u>20 (0x14) : Homing on positive home switch</u> <u>21 (0x15) : Homing on negative home switch</u> <u>22 (0x16) : Homing on negative home switch</u> <u>33 (0x21) : Homing on negative index pulse</u> <u>34 (0x22) : Homing on positive index pulse</u> <u>35 (0x23) : Homing on the current position</u> <u>37 (0x25) : Homing on the current position</u> <u>-5 to -128(0xFB-0x80), 15(0x0F), 16(0x10) 23~32(0x17-0x20), 36(0x24), 38~127(0x26-0x7F) :Reserved</u> </p>					

5. Object Dictionary

0x6099: Homing Velocity

Index	Ax1 0x6099 Ax2 0x6899 Ax3 0x7099 Ax4 0x7899	Homing velocity is used during the procedure command "Homing operation"	Object code	ARRAY	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Number of entry	Unsigned8	RO	No	0x02
0x01	Switch search speed [SSVCMD] Set the motor speed during search for a end position switch on homing mode	Unsigned32	RW	Possible	0x000A0000
		Setting range	0x0-0xFFFFFFFF (0-4294967295 pps)		
		Unit	Pulse/sec		
0x02	Zero phase search speed [ZSVCMD] Assign the motor speed during search for the index pulse (zero) detection	Unsigned32	RW	Possible	0x00080000
		Setting range	0x0-0xFFFFFFFF (0-4294967295 pps)		
		Unit	Pulse/sec		

0x609A: Homing acceleration and deceleration

Index	Ax1 0x609A Ax2 0x689A Ax3 0x709A Ax4 0x789A	This object is the parameters that define the velocity slope of the acceleration and deceleration ramp on homing mode.	Object code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Homing acceleration ad deceleration [HOMEACC] The parameters to Homing velocity that restrain velocity slope of the acceleration and deceleration ramp during acceleration, zero speed, direction change Note) This parameter is effective only during Homing mode (hm)	Unsigned32	RW	Possible	0xFFFFFFFF
		Setting range	0x00000000-0xFFFFFFFF (0-4294967295 pps ²) *		
		Unit	Pulse/sec ²		
<p>Note) If value is set "0", the amplifier proceeds it as "1."</p> <p>* At the hm mode, upper limit value will be kept at 16,000msec if the value exceeding 16,000msec is set with conversion per 1,000min-1.</p>					

0x60B0: Position Offset

Index	Ax1 0x60B0 Ax2 0x68B0 Ax3 0x70B0 Ax4 0x78B0	Provides Target position with Offset.	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial Value
0x00	Position Offset [POSOFF] Offset value is added to Target position. If this value is not zero, Target position and Actual position shift for the amount of position offset value when motor stop.	Integer32	RW	Possible	0x00000000 (0 pulse)
		Display Range	0x80000000 - 0x7FFFFFFF		
		Unit	1pulse/lsb		

0x60B1: Velocity Offset (Velocity Compensation Value)

Index	Ax1 0x60B1 Ax2 0x68B1 Ax3 0x70B1 Ax4 0x78B1	Offset is given to Velocity command.	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial Value
0x00	Velocity Offset (Velocity Compensation Value) [VCOMPC] In Cycle sync. Position mode (csp) and Interpolated Position mode (ip), added to Preset Velocity Command and valid with Velocity compensation enable bit set. In Cycle sync. Velocity mode (csv), gives Offset to Velocity demand value.	Integer32	RW	Possible	0
		Display Range	0x80000000 - 0x7FFFFFFF (-2147483648-2147483647 pps)		
		Unit	Pulse/sec		

5. Object Dictionary

0x60B9:Touch probe status

Index	Ax1	Ax2	Ax3	Ax4	Description	Data Type	Access	PDO	Initial Value
	0x60B9	0x68B9	0x70B9	0x78B9	Displays the status of the touch probe				
Sub-Idx	Description				Data Type	Access	PDO	Initial Value	
0x00	Touch probe status [TPSTS] Displays the status of the touch probe				Unsigned16	RO	Possible	0x0000	
					Setting Range	0x0000-0xFFFF			
<u>bit0: Touch probe 1 switch enable monitor</u> 0:Touch probe 1 is switched off 1:Touch probe 1 is enabled <u>bit1: Touch probe 1 positive edge value stored monitor</u> 0:Touch probe 1 no positive edge value stored 1:Touch probe 1 positive edge position stored <u>bit2: Touch probe 1 negative edge value stored monitor</u> 0:Touch probe 1 no negative edge value stored 1:Touch probe 1 negative edge position stored <u>bit6: Touch probe 1 Trigger selection monitor (User-defined : for testing)</u> 0:Trigger with touch probe 1 input mode 1:Position encoder index pulse trigger mode <u>bit7: Touch probe 1input monitor (User-defined : for testing)</u> 0:Photocoupler is off (CONT1:OFF) 1:Photocoupler is on (CONT1:ON) <u>bit8: Touch probe 2 switch enable monitor</u> 0:Touch probe 2 is switched off 1:Touch probe 2 is enabled <u>bit9: Touch probe 2 positive edge value stored monitor</u> 0:Touch probe 2 no positive edge value stored 1:Touch probe 2 positive edge position stored <u>bit10: Touch probe 2 negative edge value stored monitor</u> 0:Touch probe 2 no negative edge value stored 1:Touch probe 2 negative edge position stored <u>bit14: Touch probe 2 Trigger selection monitor (User-defined: for testing)</u> 0:Trigger with touch probe 1 input mode 1:Position encoder index pulse trigger mode <u>bit15: Touch probe 2input monitor (User-defined : for testing)</u> 0:Photocoupler is off (CONT2:OFF) 1:Photocoupler is on (CONT2:ON) bit13~11, 5~3: Reserved									

Note) If using pulse encoder, Index pulse is Z-phase signal (C-phase signal).
If using Absolute encoder, it is the position of zero data in one rotation.

0x60BA:Touch probe pos 1 pos value (positive edge)

Index	Ax1	Ax2	Ax3	Ax4	Description	Data Type	Access	PDO	Initial Value
	0x60BA	0x68BA	0x70BA	0x78BA	Position value of the touch probe 1 at positive edge.				
Sub-Idx	Description				Data Type	Access	PDO	Initial Value	
0x00	Touch probe pos1 pos value [TP1PPOS]				Integer32	RO	Possible	-	
					Display Range	0x80000000-0x7FFFFFFF (-2147483648-2147483647 Pulse)			
					Unit	1 Pulse			

0x60BB:Touch probe pos1 neg value (negative edge)

Index	Ax1	Ax2	Ax3	Ax4	Description	Data Type	Access	PDO	Initial Value
	0x60BB	0x68BB	0x70BB	0x78BB	Position value of the touch probe 1 at negative edge.				
Sub-Idx	Description				Data Type	Access	PDO	Initial Value	
0x00	Touch probe pos1 neg value [TP1NPOS]				Integer32	RO	Possible	-	
					Display Range	0x80000000-0x7FFFFFFF (-2147483648-2147483647 Pulse)			
					Unit	1 Pulse			

0x60BC:Touch probe pos2 pos value (positive edge)

Index	Ax1	Ax2	Ax3	Ax4	Description	Data Type	Access	PDO	Initial Value
	0x60BC	0x68BC	0x70BC	0x78BC	Position value of the touch probe 2 at positive edge.				
Sub-Idx	Description				Data Type	Access	PDO	Initial Value	
0x00	Touch probe pos2 pos value [TP2PPOS]				Integer32	RO	Possible	-	
					Display Range	0x80000000-0x7FFFFFFF (-2147483648-2147483647 Pulse)			
					Unit	1 Pulse			

5. Object Dictionary

0x60BD: Touch probe pos 2 neg value (negative edge)

Index	Ax1 0x60BD Ax2 0x68BD Ax3 0x70BD Ax4 0x78BD	Position value of the touch probe 2 at negative edge.	Object Code		Variable	
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Touch probe pos 2 neg value [TP2NPOS]		Integer32	RO	Possible	-
			Display Range	0x80000000-0x7FFFFFFF (-2147483648-2147483647 Pulse)		
			Unit	1 Pulse		

0x60C0: Interpolation sub mode select

Index	Ax1 0x60C0 Ax2 0x68C0 Ax3 0x70C0 Ax4 0x78C0	Select algorithm of interpolation	Object code		Variable	
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Interpolation algorithm selection [IPSUBM] 0: Linear interpolation(fixation time) -1: Linear interpolation(Variable time)		Integer16	RW	No	0x0000
			Display Range	0xFFFF - 0x0000 (-1 - 0)		

0x60C1: Interpolation data record

Index	Ax1 0x60C1 Ax2 0x68C1 Ax3 0x70C1 Ax4 0x78C1	Interpolation position target in interpolation algorithm. It is buffered with format in 0x60C4.	Object code		ARRAY	
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Number of entry		Unsigned8	RO	No	0x02
0x01	Interpolation position target [IPPOS]		Integer32	RW	Possible	0x00000000
			Setting Range	0x80000000 - 0x7FFFFFFF (-2147483648 - 214783647Pulse)		
			Unit	Pulse		
0x02	Interpolation time [IPTIME]		Unsigned8	RW	Possible	0x00
			Setting Range	0x00 - 0xFF (0 - 255ms)		
			Unit	ms		

5. Object Dictionary

0x60C2: Interpolation time period

Index Ax1 0x60C2 Ax2 0x68C2 Ax3 0x70C2 Ax4 0x78C2	Set the interpolation time period value (sub-index 01) in seconds. Then set the interpolation time index (sub-index 02) as exponential in decimal.	Object Code	RECORD		
Sub-Idx	Name/Description	Data Type	Access	PDO	Range (Initial Value)
0x00	Number of Entry	Unsigned8	RO	No	0x02
0x01	Interpolation time period value Indicates the value of the time interval used for interpolation. Value makes a degree decision by $10^{\wedge}(\text{interpolation time index})$ sec of S-Idx:0x02.	Unsigned8	RW	No	0x1 - 0xFA (1 - 250)
0x02	Interpolation time index Indicates the degree (what multiplies) of interpolation time. Example: Setting value 0xFC(-4) means 100μsec.	Integer8	RW	No	0xFA - 0xFD (10^{-6} - 10^{-3})
It will be synchronized with SM2 cycle time (0x1C32.2) by the setting of special function selection (0x20F7).					

Setting Example:

Interpolation time period	Interpolation time period value (Index 0x60C2, Sub-Index 01)	Interpolation time index (Index 0x60C2, Sub-Index 02)	In the case of synchronizing SM2 cycle time (0x1C32.2)	
			Dir	Cycle Time (Index 0x1C32, Sub-Index 02)
125us	125(0x7D)	-6(0xFA)	←→	0x0001E848 (125μs)
250us	250(0xFA)	-6(0xFA)	→	0x0003D090 (250μs)
	25(0x19)	-5(0xFB)	←→	
500us	50(0x32)	-5(0xFB)	→	0x0007A120 (500μs)
	5(0x05)	-4(0xFC)	←→	
1ms	1(0x01)	-3(0xFD)	←→	0x000F4240 (1ms)
	10(0x0A)	-4(0xFD)	→	
	100(0x64)	-5(0xFD)	→	
2ms	2(0x02)	-3(0xFD)	←→	0x001E8480 (2ms)
	20(0x14)	-4(0xFD)	→	
	200(0xC8)	-5(0xFD)	→	
4ms	4(0x04)	-3(0xFD)	←→	0x003D0900 (4ms)
	40(0x28)	-4(0xFC)	→	
8ms	8(0x08)	-3(0xFD)	←→	0x007A01200 (8ms)
	80(0x50)	-4(0xFC)	→	
16ms	16(0x10)	-3(0xFD)	←→	0x00F42400 (16ms)
	160(0xA0)	-4(0xFC)	→	

0x60C4: Interpolation data configuration

Index Ax1 0x60C4 Ax2 0x68C4 Ax3 0x70C4 Ax4 0x78C4	The format of interpolation data.	Object code	RECORD		
Sub-Idx	Description	Data Type	Access	PDO	Initial Value
0x00	Number of entry	Unsigned8	RO	No	0x06
0x01	Maximum buffer size [MAXSIZE] Show the size of allowable buffer.	Unsigned32	RO	No	0x00000100
		Value	0x00000100		
0x02	Actual buffer size [BUFFSIZE] Set the buffer size.	Unsigned32	RW	Possible	0x00000000
		Setting Range	0x00000000 - 0x00000100		
0x03	Buffer format [BUFSTR] 0x00: FIFO 0x01: Ring	Unsigned8	RW	Possible	0x00
		Setting Range	0x00 - 0x01		
0x04	Point of buffer [BUFPOS] Empty buffer point for next interpolation data record.	Unsigned16	RW	Possible	0x0000
		Setting Range	0x0000 - 0x00FF		
0x05	Data size of interpolation data record [RECSIZE] Show the size of each data in Interpolated position mode.	Unsigned8	RO	No	0x04
		Value	0x04 - 0x05		
		Unit	byte		
0x06	Clear buffer [BUFCLR] 0x00: Clear all record in buffer and disable data access. 0x01: Enable data access to buffer. Interpolation data record come from upper controller into buffer.	Unsigned8	WO	Possible	0x00
		Setting Range	0x00 - 0x01		

5. Object Dictionary

0x60C5: Maximum deceleration

Index	Ax1	0x60C5	Sets the limit value of deceleration	Object Code	Variable		
	Ax2	0x68C5					
	Ax3	0x70C5					
	Ax4	0x78C5					
Sub-Idx	Description			Data Type	Access	PDO	Initial Value
0x00	Deceleration limit value Limits the deceleration set value by this parameter if the deceleration setting of 0x6084 exceeds this value. Invalid when the set value is 0. ✓Valid for PV mode only.			Unsigned32	RW	Possible	0xFFFFFFFF
				Setting Range	0x00000000 to 0xFFFFFFFF (0 to 4294967295 pps ²)		
				Unit	Pulse/sec ²		

0x60C6: Maximum acceleration

Index	Ax1	0x60C6	Sets the limit value of acceleration	Object Code	Variable		
	Ax2	0x68C6					
	Ax3	0x70C6					
	Ax4	0x78C6					
Sub-Idx	Description			Data Type	Access	PDO	Initial Value
0x00	Acceleration limit value Limits the acceleration set value by this parameter if the acceleration setting of 0x6083 exceeds this value. Invalid when the set value is 0. ✓Valid for PV mode only.			Unsigned32	RW	Possible	0xFFFFFFFF
				Setting Range	0x00000000 to 0xFFFFFFFF (0 to 4294967295 pps ²)		
				Unit	Pulse/sec ²		

0x60E0: Forward Direction Torque (force) Limit Value

Index	Ax1	0x60E0	Sets limit value of motor forward direction max. torque (force).	Object Code	Variable		
	Ax2	0x68E0					
	Ax3	0x70E0					
	Ax4	0x78E0					
Sub-Idx	Description			Data Type	Access	PDO	Initial Value
0x00	Forward Direction Torque (force) Limit Value [TCLM-F] Setting units are 1% / LSB in 1/1000 unit of rated torque (force). However, it is limited by max torque (force) for the value that exceeds the max torque (force) of the motor. *Set up in consideration of Acceleration / Deceleration time. If setting value is too low, Acceleration / Deceleration torque (force) will be insufficient and normal control cannot be performed.			Unsigned16	RW	Possible	0x1388 (500.0%)
				Setting Range	0x0000 - 0x1388 (0 - 500.0%)		
				Unit	0.1%		

0x60E1: Reverse Direction Torque (force) Limit Value

Index	Ax1	0x60E1	Sets limit value of motor reverse direction max. torque (force).	Object Code	Variable		
	Ax2	0x68E1					
	Ax3	0x70E1					
	Ax4	0x78E1					
Sub-Idx	Description			Data Type	Access	PDO	Initial Value
0x00	Reverse Direction Torque (force) Limit Value [TCLM-R] Setting units are 1% / LSB in 1/1000 unit of rated torque (force). However, it is limited by max torque (force) for the value that exceeds the max torque (force) of the motor. *Set up in consideration of Acceleration / Deceleration time. If setting value is too low, Acceleration / Deceleration torque (force) will be insufficient and normal control cannot be performed.			Unsigned16	RW	Possible	0x1388 (500.0%)
				Setting Range	0x0000 - 0x1388 (0 - 500.0 %)		
				Unit	0.1%		

5. Object Dictionary

0x60E3: Support homing method

Index	Ax1	Ax2	Ax3	Ax4	0x60E3	0x68E3	0x70E3	0x78E3	Specifies the value definition of homing method supported	Object code	ARRAY	
Sub-Idx	Description								Data Type	Access	PDO	Value
0x00	Number of Entry								Unsigned8	RO	No	0x1C
0x01	Support homing method 1 [HSUP01] Supports Homing method 1 "Homing on negative limit switch and index pulse"								Unsigned16	RO	No	0x0001
0x02	Support homing method 2 [HSUP02] Supports Homing method 2" Homing on positive limit switch and negative index pulse"								Unsigned16	RO	No	0x0002
0x03	Support homing method 3 [HSUP03] Supports Homing method 3" Homing on positive home switch and negative index pulse"								Unsigned16	RO	No	0x0003
0x04	Support homing method 4 [HSUP04] Supports Homing method 4" Homing on positive home switch and positive index pulse"								Unsigned16	RO	No	0x0004
0x05	Support homing method 5 [HSUP05] Supports Homing method 5" Homing on negative home switch and positive index pulse"								Unsigned16	RO	No	0x0005
0x06	Support homing method 6 [HSUP06] Supports Homing method 6" Homing on negative home switch and negative index pulse"								Unsigned16	RO	No	0x0006
0x07	Support homing method 7 [HSUP07] Supports Homing method 7 "Homing on positive limit switch, homing on positive home switch and negative index pulse"								Unsigned16	RO	No	0x0007
0x08	Support homing method 8 [HSUP08] Supports Homing method 8 "Homing on positive limit switch, homing on positive home switch and positive index pulse"								Unsigned16	RO	No	0x0008
0x09	Support homing method 9 [HSUP09] Supports Homing method 9 "Homing on positive limit switch, homing on negative home switch and negative index pulse"								Unsigned16	RO	No	0x0009
0x0A	Support homing method 10 [HSUP0A] Supports Homing method 10 "Homing on positive limit switch, homing on negative home switch and positive index pulse"								Unsigned16	RO	No	0x000A
0x0B	Support homing method 11 [HSUP0B] Supports Homing method 11" Homing on negative limit switch, homing on positive home switch and positive index pulse"								Unsigned16	RO	No	0x000B
0x0C	Support homing method 12 [HSUP0C] Supports Homing method 12 " Homing on negative limit switch, homing on positive home switch and negative index pulse"								Unsigned16	RO	No	0x000C
0x0D	Support homing method 13 [HSUP0D] Supports Homing method 13 " Homing on negative limit switch, homing on negative home switch and positive index pulse"								Unsigned16	RO	No	0x000D
0x0E	Support homing method 14 [HSUP0E] Supports Homing method 14 " Homing on negative limit switch, homing on negative home switch and negative index pulse"								Unsigned16	RO	No	0x000E
0x0F	Support homing method 15 [HSUP0F] Supports Homing method 17" Homing on negative limit switch."								Unsigned16	RO	No	0x0011
0x10	Support homing method 16 [HSUP10] Supports Homing method 18 "Homing on positive limit switch."								Unsigned16	RO	No	0x0012
0x11	Support homing method 17 [HSUP11] Supports Homing method 19" Homing on home switch (positive logic), stop in positive direction."								Unsigned16	RO	No	0x0013
0x12	Support homing method 18 [HSUP12] Supports Homing method 20" Homing on home switch (positive logic), stop in negative direction."								Unsigned16	RO	No	0x0014
0x13	Support homing method 19 [HSUP13] Supports Homing method 21 "Homing on home switch (negative logic), stop in positive direction."								Unsigned16	RW	No	0x0015
0x14	Support homing method 20 [HSUP14] Supports Homing method 22 " Homing on home switch (negative logic), stop in negative direction."								Unsigned16	RW	No	0x0016
0x15	Support homing method 21 [HSUP15] Supports Homing method 33 " Homing on index pulse in negative direction."								Unsigned16	RO	No	0x0021
0x16	Support homing method 22 [HSUP16] Supports Homing method 34 " Homing on index pulse in positive direction."								Unsigned16	RO	No	0x0022
0x17	Support homing method 23 [HSUP17] Support Homing method 35 "Homing position on actual position"								Unsigned16	RO	No	0x0023
0x18	Support homing method 24 [HSUP18] Supports homing method 37 "Homing on actual position or homing position"								Unsigned16	RO	No	0x0025
0x19	Support homing method 25 [HSUP19] Supports homing method -1 "Homing on hard stop (Butt) to the Positive direction"								Unsigned16	RO	No	0x00FF
0x1A	Support homing method 26 [HSUP1A] Supports homing method -2 "Homing on hard stop (Butt) to the Negative direction"								Unsigned16	RO	No	0x00FE
0x1B	Support homing method 27 [HSUP1B] Supports homing method -3 "Homing on Negative side hard stop (Butt) and index pulse in Positive direction"								Unsigned16	RO	No	0x00FD
0x1C	Support homing method 28 [HSUP1C] Supports homing method -4 "Homing on Positive side hard stop (Butt) and index pulse in Negative direction"								Unsigned16	RO	No	0x00FC


MSB		LSB	
Reserved	Reserved	Reserved	Supported homing method
15...10	9	8	7...0

Bit7-0: Supported homing method Index 6098 corresponding to that indicated on Homing methods number

5. Object Dictionary


0x60F2: Positioning option code

Index	Ax1 0x60F2 Ax2 0x68F2 Ax3 0x70F2 Ax4 0x78F2	Set the behavior of positioning.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Positioning option code [POSOP] See table below for definition of bit 7 and 6. Set 0 except bit 7 and 6.		Unsigned16	RW	Possible	0x0000
			Setting Range	0x0000-0xFFFF		



bit7	bit6	Rotation direction definition on rotation axis
0	0	Standard positioning same as straight axis: When position reached limit value, position value goes wraparound to the other side. Positioning at absolute value and relative value is allowable.
0	1	Positioning at negative rotation direction: Move to target through minimum limit of position range, even though target position is bigger than actual position.
1	0	Positioning at positive rotation direction: Move to target through maximum limit of position range, even though target position is smaller than actual position.
1	1	Positioning at shortcut: Automatically decide shortcut direction, and move. When target position and actual position are just opposite, rotation direction is decided to positive.

Modulo coordinate image at minimum position range limit=0, maximum position range limit = 359



0x60F4: Actual Position Deviation (Following error actual value)

Index	Ax1 0x60F4 Ax2 0x68F4 Ax3 0x70F4 Ax4 0x78F4	This object shall provide the actual value of the following error.	Object code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Actual Position Deviation [PMON] Unit is 1 pulse/LSB with RS2EtherCAT amplifier in the user definition. In incremental encoder, the value that quadruplicate the A/B signal is provided.		Integer32	RO	Possible	0x00000000
			Setting range	0x80000000-0x7FFFFFFF (-2147483648-2147483647 Pulse)		
			Unit	Pulse		

0x60FA: Control effort

Index	Ax1 0x60FA Ax2 0x68FA Ax3 0x70FA Ax4 0x78FA	Indication of the target value after positioning.	Object code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Indicate velocity command value after positioning. This object indicate value at Profile position and Cycle position mode only.		Integer32	RO	Possible	0x00000000
			Setting range	0x80000000-0x7FFFFFFF (-2147483648-2147483647 Pulse)		
			Unit	PPS		

5. Object Dictionary

0x60FC: Position Demand Internal Value

Index	Ax1	0x60FC	Indicates the internal target position.	Object Code	Variable		
	Ax2	0x68FC					
	Ax3	0x70FC					
	Ax4	0x78FC					
Sub-Idx	Description			Data Type	Access	PDO	Initial Value
0x00	Internal Target Position Displays internal target position command in profile position mode. This value same as Position Demand Value(0x6062) as measured by the control cycle unit(125µs). ✓Other modes Values are not displayed. (always displayed as 0)			Integer32	RO	Possible	-
				Display Range	0x80000000-0x7FFFFFFF (-2147483648-2147483647 Pulse)		
				Unit	Pulse		

0x60FD: Digital inputs

Index	Ax1	0x60FD	This object shall monitor the status of general-purpose input, output and hardware gate off.	Object code	Record								
	Ax2	0x68FD											
	Ax3	0x70FD											
	Ax4	0x78FD											
Sub-Idx	Description			Data Type	Access	PDO	Initial value						
0x00	Digital input monitor [DINPUT] Monitor the state of general input: CONT1 to 8. 1: Photocoupler is on. * For hardware detection, digital input has about 4msec delay.			Unsigned32	RO	Possible	-						
				Display range	0x00000000-0xFFFFFFFF								
MSB							LSB						
Res	CONT8	CONT7	CONT6	CONT5	CONT4	CONT3	CONT2	CONT1	Res	EMR	Home	Positive limit	Negative limit
31..24	23	22	21	20	19	18	17	16	15..4	3	2	1	0

0x60FE: Digital output

Index	Ax1	0x60FE	This object sets output of holding brake timing output monitor and general-purpose output OUT1 and OUT2	Object Code	Record		
	Ax2	0x68FE					
	Ax3	0x70FE					
	Ax4	0x78FE					
Sub-Idx	Description			Data Type	Access	PDO	Initial Value
0x00	Number of entry			Unsigned8	RO	No	0x0
0x01	Physical output [DOUTPUT] Bit 0: Monitoring Holding brake output timing Bit17-16: Enables control output OUT1 and OUT2 when it is set 0x42 through 0x45 for "Controls by EtherCAT communication". * For hardware detection, digital output has about 4msec delay.			Unsigned32	RW	Possible	-
				Display range	0x000000-0xFFFFFFFF		
MSB							LSB
Reserved		FOUT2	FOUT1	Reserved	Set brake		
31 - 18		17	16	15...3	0		
0x02	Bit mask bit0: Disabled bit17-16 mask the bits corresponding to physical output When the setting of General Purpose Output setting is set by any of "Controls by EtherCAT communication", if the mask of the setting bit is set, output of OUT1.2 will be disabled. When the bit mask is set to "1", it is Enable OUTPUT and the bit mask is set to "0", it is Disable OUTPUT.			Unsigned32	RW	Possible	0xFFFFFFFF
				Setting Range	0x000000~0xFFFFFFFF		

5. Object Dictionary

0x60FF: Target Velocity

Index	Ax1 0x60FF Ax2 0x68FF Ax3 0x70FF Ax4 0x78FF	Indicates to set Target velocity, and used for inputting trajectory generator.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Target Velocity (Velocity command) [TAVEL] Velocity command input for Cyclic Sync. Velocity (csv), Profile velocity (pv)		Integer32	RW	Possible	-
			Display range	0x80000000-0x7FFFFFFF (-2147483648-2147483647 pps)		
			Unit	Pulse/sec		

0x6402: Motor Type

Index	Ax1 0x6402 Ax2 0x6C02 Ax3 0x7402 Ax4 0x7C02	Select running motor type.	Object Code	VAR		
Sub-Idx	Name/Description		Data Type	Access	PDO	Value
0x00	Motor Type This product does not support any motor other than AC motor.		Unsigned16	RW	Possible	0x000C

0x6403: Motor Catalog Number

Index	Ax1 0x6403 Ax2 0x6C03 Ax3 0x7403 Ax4 0x7C03	Indicates setting motor model number.	Object Code	VAR		
Sub-Idx	Name/Description		Data Type	Access	PDO	Value
0x00	Motor Model Number Setting Motor Model Number (ASCII Code)		Visible String	RO	No	Character String (-)
<u>R</u> <u>2</u> <u>G</u> <u>A</u> <u>0</u> <u>4</u> <u>0</u> <u>0</u> <u>3</u> <u>F</u> ✓ Please refer to chapter 1.4 "Motor model number" for the detail of motor model number. ※ Only the Sanyo Denki R series are supported. Non supported motors are indicated as Not Supported.						

0x6404: Motor Manufacture

Index	Ax1 0x6404 Ax2 0x6C04 Ax3 0x7404 Ax4 0x7C04	Indicates manufacturer of setting motor.	Object Code	VAR		
Sub-Idx	Name/Description		Data Type	Access	PDO	Value
0x00	Manufacturer Manufacturer of setting motor (ASCII code)		Visible String	RO	No	Character String (-)
※ It is indicated as SANYO DENKI Co., LTD because Sanyo Denki motors are recommended.						



5. Object Dictionary

0x6405: Motor Catalog Address of our Home Page

Index	Ax1 0x6405 Ax2 0x6C05 Ax3 0x7405 Ax4 0x7C05	Indicates catalog address of selected motor.	Object Code	VAR		
Sub-Idx	Name/Description		Data Type	Access	PDO	Value
0x00	Home Page Address Home Page Address of setting motor (ASCII Code)		Visible String	RO	No	Character String (-)
※ SANYO DENKI's home page address is indicated because Sanyo Denki motors are recommended.						

0x6502: Supported Drive mode

Index	Ax1 0x6502 Ax2 0x6D02 Ax3 0x7502 Ax4 0x7D02	This object shall provide information on the supported drive modes by the servo amplifier.	Object code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Support drive mode [SUPMODE] 0: Not supported 1: Supported		Unsigned32 Display range	RO	Possible	0x03ED 0x03ED~0x03ED



0x6503: Drive Catalog No.

Index	Ax1 0x6503 Ax2 0x6D03 Ax3 0x7503 Ax4 0x7D03	Indicates Catalog No. of this product.	Object Code	VAR		
Sub-Idx	Name/Description		Data Type	Access	PDO	Value
0x00	Catalog No. The Catalog No. of this product is indicated.		Visible String	RO	No	Character String (-)
Indicates the bookbinding Catalog No. of this product (944-1 or 946-2)						

0x6505: http Drive Catalog Address

Index	0x6505	Indicates the website address of the catalog for this product.	Object Code	VAR		
Sub-Idx	Name/Description		Data Type	Access	PDO	Value
0x00	Website address The address of the website catalog for this Product. (ASCII Code)		Visible String	RO	No	Character String (-)
※Indicates the address of the catalog of servo amplifiers on the Sanyo Denki website.						

5. Object Dictionary

5.6 Manufacturer Specific Area

1) Object Group (0x2000-)

The followings are shown in Table; Manufacturer area of CoE (CANopen over EtherCAT) object list, RS2-EtherCAT Supported / Un-supported, Data length, Access (Dir), PDO Mapping, and parameter effective timing (updating).
 #=immediately, \$=ESM change required, and &=control-power-source re-input.

Manufacturer Specific Area (No.1)

Index	S-Idx	FP	FV	FT	FH	Name	Data Type	Dir	PDO Mapping	Update	NVRAM
0x2000	0x00	○	○	○	○	Control Word 1	Unsigned16	RW	Possible	#	Yes
0x2001	0x00	○	○	○	○	Parameter Select	Unsigned16	RW	Possible	#	-
0x2002	0x00	-	-	-	-	Auto-tuning settings	Unsigned8	RO	No	-	-
↑	0x01	○	○	○	○	Auto-Tuning Mode	Unsigned8	RW	No	#	Yes
↑	0x02	○	○	○	○	Auto-Tuning Characteristic	Unsigned8	RW	No	#	Yes
↑	0x03	○	○	○	○	Auto-Tuning Response	Unsigned8	RW	No	#	Yes
↑	0x04	○	○	○	○	Running tune	Unsigned8	RW	No	-	-
↑	0x05	○	○	○	○	Monitoring on tune	Unsigned8	RO	No	-	-
↑	0x06	○	○	○	○	Tune result saving parameter selection	Unsigned8	RW	No	-	-
0x2003	0x00	○	x	x	x	Position Command Smoothing Constant	Unsigned16	RW	Possible	#	Yes
0x2004	0x00	○	x	x	x	Position Command Filter	Unsigned16	RW	No	#	Yes
0x2005	0x00	-	-	-	-	Position Loop Proportional Gain	Unsigned8	RO	No	-	-
↑	0x01	○	x	x	x	Position Loop Proportional Gain 1	Unsigned16	RW	Possible	#	Yes
↑	0x02-0x04	○	x	x	x	Position Loop Proportional Gain 2 - 4	Unsigned16	RW	No	#	Yes
0x2006	0x00	-	-	-	-	Position Integral Time Constant	Unsigned8	RO	No	-	-
↑	0x01	○	x	x	x	Position Integral Time Constant 1	Unsigned16	RW	Possible	#	Yes
↑	0x02-0x04	○	x	x	x	Position Integral Time Constant 2 - 4	Unsigned16	RW	No	#	Yes
0x2007	0x00	○	x	x	x	Higher Tracking Control Position Compensation Gain	Unsigned16	RW	No	#	Yes
0x2008	0x00	-	-	-	-	Feed forward compensation parameter	Unsigned8	RO	No	-	-
↑	0x01	○	x	x	x	Feed Forward Gain	Unsigned16	RW	Possible	#	Yes
↑	0x02	○	x	x	x	Feed Forward Filter	Unsigned16	RW	No	#	Yes
0x2009	0x00	-	-	-	-	Velocity Command Filter Settings	Unsigned8	RO	No	-	Yes
0x200A	0x00	○	○	x	○	Velocity Feedback Filter	Unsigned16	RW	No	#	Yes
0x200B	0x00	-	-	-	-	Velocity Loop Proportional Gain	Unsigned8	RO	No	-	-
↑	0x01	○	○	x	○	Velocity Loop Proportional Gain 1	Unsigned16	RW	Possible	#	Yes
↑	0x02-0x04	○	○	x	○	Velocity Loop Proportional Gain 2 - 4	Unsigned16	RW	No	#	Yes
0x200C	0x00	-	-	-	-	Velocity Loop Integral Time Constant	Unsigned8	RO	No	-	-
↑	0x01	○	○	x	○	Velocity Loop Integral Time Constant 1	Unsigned16	RW	Possible	#	Yes
↑	0x02-0x04	○	○	x	○	Velocity Loop Integral Time Constant 2 - 4	Unsigned16	RW	No	#	Yes
0x200D	0x00	-	-	-	-	Load Inertia Moment Ratio	Unsigned8	RO	No	-	-
↑	0x01	○	○	○	○	Load Inertia Moment Ratio 1	Unsigned16	RW	Possible	#	Yes
↑	0x02-0x04	○	○	○	○	Load Inertia Moment Ratio 2 - 4	Unsigned16	RW	No	#	Yes
0x200E	0x00	○	○	x	○	Higher Tracking Control Velocity Compensation Gain	Unsigned16	RW	No	#	Yes
0x200F	0x00	-	-	-	-	Acceleration Feedback Compensation	Unsigned8	RO	No	-	-
↑	0x01	○	○	x	○	Acceleration Feedback Gain	Integer16	RW	No	#	Yes
↑	0x02	○	○	x	○	Acceleration Feedback Filter	Unsigned16	RW	No	#	Yes
0x2011	0x00	-	-	-	-	Command Filter	Unsigned8	RO	No	-	-
↑	0x01	○	○	○	○	Torque (force) Command Filter 1	Unsigned16	RW	Possible	#	Yes
↑	0x02-0x04	○	○	○	○	Torque (force) Command Filter 2 - 4	Unsigned16	RW	Possible	#	Yes
0x2012	0x00	-	-	-	-	FF Vibration Suppressor Frequency	Unsigned8	RO	No	-	-
↑	0x01	○	x	x	x	FF Vibration Suppressor Frequency 1	Unsigned16	RW	Possible	#	Yes
↑	0x02-0x04	○	x	x	x	FF Vibration Suppressor Frequency 2 - 4	Unsigned16	RW	No	#	Yes
0x2015	0x00	-	-	-	-	High setting control settings	Unsigned8	RO	No	-	-
↑	0x01	○	x	x	x	Acceleration Compensation	Integer16	RW	No	#	Yes
↑	0x02	○	x	x	x	Deceleration Compensation	Integer16	RW	No	#	Yes
↑	0x03	○	x	x	x	Command Velocity Low-pass Filter	Unsigned16	RW	No	#	Yes
↑	0x04	○	x	x	x	Command Velocity Threshold	Unsigned16	RW	No	#	Yes

○: Supported, x: Not supported

FP: Function Group "Position"

FV: Function Group "Velocity"

FT: Function Group "Torque (force)"

FH: Function Group "Homing mode"

5. Object Dictionary

Manufacturer Specific Area (No.2)

Index	S-Idx	FP	FV	FT	FH	Name	Data Type	Dir	PDO Mapping	Update	NVRAM
0x2016	0x00	-	-	-	-	Observer Parameter	Unsigned8	RO	No	-	-
↑	0x01	○	○	×	○	Observer Characteristic	Unsigned8	RW	No	#	Yes
↑	0x02	○	○	×	○	Observer Compensation Gain	Unsigned16	RW	No	#	Yes
↑	0x03	○	○	×	○	Observer Output Filter	Unsigned16	RW	No	#	Yes
↑	0x04	○	○	×	○	Observer Notch Filter	Unsigned16	RW	No	#	Yes
↑	0x05	○	○	×	○	Observer Load Inertia Ratio	Unsigned16	RW	No	#	Yes
↑	0x06	○	○	×	○	Observer Loop Proportional Gain	Unsigned16	RW	No	#	Yes
↑	0x07	○	○	×	○	Observer Load Torque (force) Filter	Unsigned16	RW	No	#	Yes
0x2017	0x00	-	-	-	-	Model Control Gain	Unsigned8	RO	No	-	-
↑	0x01	○	×	×	×	Model Control Gain 1	Unsigned16	RW	Possible	#	Yes
↑	0x02-0x04	○	×	×	×	Model Control Gain 2 - 4	Unsigned16	RW	No	#	Yes
0x2018	0x00	○	×	×	×	Overshoot Suppressor Filter	Unsigned16	RW	No	#	Yes
0x2019	0x00	-	-	-	-	Model Control Antiresonance Frequency	Unsigned8	RO	No	-	-
↑	0x01	○	×	×	×	Model Control Antiresonance Frequency 1	Unsigned16	RW	Possible	#	Yes
↑	0x02-0x04	○	×	×	×	Model Control Antiresonance Frequency 2 - 4	Unsigned16	RW	No	#	Yes
0x201A	0x00	-	-	-	-	Model Control Resonance Frequency	Unsigned8	RO	No	-	-
↑	0x01	○	×	×	×	Model Control Resonance Frequency 1	Unsigned16	RW	Possible	#	Yes
↑	0x02-0x04	○	×	×	×	Model Control Resonance Frequency 2 - 4	Unsigned16	RW	No	#	Yes
0x201B	0x00	○	○	×	○	Gain Switching Filter	Unsigned16	RW	No	#	Yes
0x201C	0x00	○	○	×	○	Internal Velocity Command limit	Unsigned16	RW	No	#	Yes
0x201D	0x00	○	×	×	×	Position Command error 1 level	Unsigned32	RW	No	#	Yes
0x201E	0x00	○	○	×	○	Sequence Operation Torque (force) Limit Value	Unsigned16	RW	No	#	Yes
0x201F	0x00	○	×	×	×	Near Range	Unsigned32	RW	No	#	Yes
0x2020	0x00	○	○	×	○	Speed Zero Range	Unsigned16	RW	No	#	Yes
0x2021	0x00	○	○	×	○	Low Speed Range	Unsigned16	RW	No	#	Yes
0x2022	0x00	○	○	×	○	Speed Attainment Setting (high-speed setting)	Unsigned16	RW	No	#	Yes
0x2023	0x00	-	-	-	-	Analog Monitor Select Output	Unsigned8	RO	No	-	-
↑	0x01,0x02	○	○	○	○	Analog Monitor Select Output 1 ,2	Unsigned8	RW	No	#	Yes
↑	0x03	○	○	○	○	Analog Monitor Output Polarity	Unsigned8	RW	No	#	Yes
0x2024	0x00	○	○	○	○	Delay Time of Engaging Holding Brake (Holding Brake Holding Delay Time)	Unsigned16	RW	Possible	#	Yes
0x2025	0x00	○	○	○	○	Delay Time of Releasing Holding Brake (Holding Brake Release Delay Time)	Unsigned16	RW	No	#	Yes
0x2026	0x00	○	○	○	○	Brake Operation Beginning Time	Unsigned16	RW	Possible	#	Yes
0x2027	0x00	○	○	○	○	Power Failure Detection Delay Time	Unsigned16	RW	No	#	Yes
0x2028	0x00	○	×	×	×	Excessive Deviation Warning Level	Unsigned32	RW	No	#	Yes
0x2029	0x00	○	○	○	○	Overload Warning Level	Unsigned16	RW	No	#	Yes
0x202A	0x00	○	○	○	○	Speed Matching Width	Unsigned16	RW	No	#	Yes
0x202B	0x00	○	○	○	○	Torque (force)Command Filter Characteristic	Unsigned8	RW	No	#	Yes
0x202C	0x00	○	×	×	×	Feed Forward Filter, Depth Selection	Unsigned8	RW	No	#	Yes
0x202E	0x00	○	○	○	○	Torque attainment setting	Unsigned16	RW	No	#	Yes
0x202F	0x00	○	○	○	○	Brake Activation Speed	Unsigned16	RW	Possible	#	Yes
0x2030	0x00	○	○	○	×	Position Loop Integral Gain Limit	Unsigned16	RW	Possible	#	Yes
0x2031	0x00	×	○	○	×	Velocity Control Integral Gain Limit	Unsigned16	RW	Possible	#	Yes
0x2032	0x00	×	×	○	×	Torque (force) Control Proportional Gain	Unsigned8	RW	Possible	#	Yes
0x2034	0x00	-	-	-	-	Command Filter off Speed	Unsigned8	RO	No	#	
↑	0x01	○	○	○	○	Position / Velocity Command Filter off Speed selection	Unsigned8	RW	Possible	#	Yes
↑	0x02	○	○	○	○	Position / Velocity Command Filter off Speed	Unsigned16	RW	Possible	#	Yes
0x2035	0x00	-	-	-	-	Assist-Function Parameter	Unsigned8	RO	No	-	-
↑	0x01	○	-	-	-	Correction Proportional Gain	Unsigned8	RW	No	-	Yes
↑	0x02	○	-	-	-	Correction Integral Time Constant	Unsigned16	RW	No	-	Yes
↑	0x03	○	-	-	-	Correction Low-pass Filter	Unsigned16	RW	No	-	Yes
↑	0x04	○	-	-	-	Excessive Position Synchronization Deviation Level	Unsigned32	RW	No	-	Yes
↑	0x05	○	-	-	-	Position Synchronization Deviation Warning Level	Unsigned32	RW	No	-	Yes
↑	0x06	○	-	-	-	Position Deviation Polarity Selection	Unsigned8	RW	No	-	Yes
↑	0x07	○	○	○	-	Assist-target axis address	Unsigned8	RW	No	#	Yes
↑	0x08	○	○	○	-	Assist-function selection	Unsigned8	RW	No	#	Yes
↑	0x09	-	-	○	-	Torque assisting rate	Unsigned16	RW	Possible	-	Yes
0x2036	0x00	-	-	-	-	Position Differential Gain setting	Unsigned8	RO	No	-	-
↑	0x01	○	×	×	×	Position differential time constant	Unsigned16	RW	Possible	#	Yes
↑	0x02	○	×	×	×	Position differential filter	Unsigned16	RW	Possible	#	Yes
0x2037	0x00	○	×	×	×	Position Drain Ratio	Unsigned32	RW	Possible	#	Yes
0x2038	0x00	○	×	×	×	Velocity Control Bypass Setting	Unsigned16	RW	Possible	#	Yes
0x2039	0x00	○	○	×	×	Verifications Drain Ratio	Unsigned16	RW	Possible	#	Yes
0x203A	0x00	○	○	○	○	Torque (force) Control Integral Gain Setting	Unsigned8	RW	Possible	#	Yes
0x203B	0x00	○	○	○	○	Torque (force) Control Integral Gain Limit Setting	Unsigned8	RW	Possible	#	Yes
0x203C	0x00	○	×	×	×	Software Deceleration Limit	Unsigned32	RW	No	#	Yes
0x203D	0x00	-	-	-	-	Amplifier temperature warning level	Unsigned8	RO	No	-	-
↑	0x01	○	○	○	○	Amplifier temperature warning high level setting	Integer16	RW	No	#	Yes
↑	0x02	○	○	○	○	Amplifier temperature warning low level setting	Integer16	RW	No	#	Yes

○: Supported, ×: Not supported

5. Object Dictionary

Manufacturer Specific Area (No.3)

Index	S-Idx	FP	FV	FT	FH	Name	Data Type	Dir	PDO Mapping	Update	NVRAM
0x2040	0x00	—	—	—	—	Command Filter Setting	Unsigned8	RO	No	—	-
↑	0x01	○	○	×	○	Velocity Command Filter	Unsigned8	RW	Possible	#	Yes
↑	0x02	○	○	○	○	Torque (force) Command Filter	Unsigned8	RW	Possible	#	Yes
0x2041 0x2042- 0x2045	0x00	—	—	—	—	Velocity Command Filter Setting Torque (force) Command Filter1 – 4 Setting	Unsigned8	-	-	-	Yes
↑	0x01	○	○	×	○	Filter ON/OFF	Integer8	RW	Possible	#	Yes
↑	0x02	○	○	×	○	Filter Type	Integer8	RW	Possible	#	Yes
↑	0x03	○	○	×	○	Low Pass Filter Cutoff frequency	Unsigned16	RW	Possible	#	Yes
↑	0x04	○	○	×	○	High Pass Filter Cutoff frequency	Unsigned16	RW	Possible	#	Yes
↑	0x05	○	○	×	○	Band PassFilter Cutoff frequency	Unsigned16	RW	Possible	#	Yes
↑	0x06	○	○	×	○	Band width of Band Pass Filter	Unsigned16	RW	Possible	#	Yes
↑	0x07	○	○	×	○	Center frequency of Notch Filter	Unsigned16	RW	Possible	#	Yes
↑	0x08	○	○	×	○	Band width of Notch Filter	Unsigned16	RW	Possible	#	Yes
↑	0x09	○	○	×	○	Bi-quad Filter a1	Float32	RW	Possible	#	Yes
↑	0x0A	○	○	×	○	Bi-quad Filter a2	Float32	RW	Possible	#	Yes
↑	0x0B	○	○	×	○	Bi-quad Filter b0	Float32	RW	Possible	#	Yes
↑	0x0C	○	○	×	○	Bi-quad Filter b1	Float32	RW	Possible	#	Yes
↑	0x0D	○	○	×	○	Bi-quad Filter b2	Float32	RW	Possible	#	Yes
0x2050	0x00	—	—	—	—	Quadrant Glitch Compensation function	Unsigned8	RO	No	—	—
↑	0x01	○	○	○	○	Effective condition selection	Unsigned8	RW	Possible	#	Yes
↑	0x02	○	○	○	○	Effective velocity	Unsigned16	RW	Possible	#	Yes
↑	0x03	○	○	○	○	Keeping time	Unsigned16	RW	Possible	#	Yes
↑	0x04	○	○	○	○	Velocity Loop Integral Time Constant	Unsigned16	RW	Possible	#	Yes
0x2051	0x00	○	○	○	○	Micro Vibration Suppression function	Unsigned8	RW	Possible	#	Yes
0x5080	0x00	○	-	-	-	Correction Table Control	Unsigned8	RW	No	#	Yes
0x5081	0x00	○	-	-	-	Correction Table Interpolation Method	Unsigned8	RW	No	#	Yes
0x5082	0x00	○	-	-	-	Correction Table Extrapolation Method	Unsigned8	RW	No	#	Yes
0x5083	0x00	-	-	-	-	Correction Table, Number of Entry	Unsigned8	RW	No	&	Yes
↑	0x01-0x40	○	-	-	-	Correction Position	Unsigned32	RW	No	#	Yes
0x5084	0x00	-	-	-	-	Correction Table, Number of Entry	Unsigned8	RW	No	&	Yes
↑	0x01-0x40	○	-	-	-	Offset	Integer32	RW	No	#	Yes
0x5090	0x00	○	×	×	×	Selection of Backlash Correction Function	Unsigned8	RW	No	#	Yes
0x5091	0x00	○	×	×	×	Correction amount of Backlash	Unsigned32	RW	No	#	Yes
0x5092	0x00	○	×	×	×	Correction direction of Backlash	Unsigned8	RW	No	#	Yes

○: Supported, ×: Not supported

5. Object Dictionary

Manufacturer Specific Area (No.4)

Index	S-Idx	FP	FV	FT	FH	Name	Data Type	Dir	PDO Mapping	Update	NVRAM
0x20F0	0x00	-	-	-	-	Amplifier Function Selection	Unsigned8	RO	No	-	-
↑	0x01	○	○	○	○	Limit behavior	Unsigned8	RW	No	#	Yes
↑	0x02	○	×	×	×	Positioning Method	Unsigned8	RW	No	&	Yes
↑	0x03	○	×	×	×	In position / Position deviation monitor	Unsigned8	RW	No	#	Yes
↑	0x04	○	○	○	○	Velocity Window Unit Output	Unsigned8	RW	No	#	Yes
↑	0x05	○	×	×	×	Deviation Clear	Unsigned8	RW	No	#	Yes
↑	0x06	○	○	○	○	Torque (force) attainment function selection	Unsigned8	RW	No	#	Yes
0x20F1	0x00	-	-	-	-	Encoder Function Selection	Unsigned8	RO	No	-	-
↑	0x01	○	○	○	○	Serial Encoder Clear Function	Unsigned8	RW	No	#	Yes
↑	0x02	○	○	○	○	Incremental Encoder, Digital Filter	Unsigned8	RW	No	#	Yes
↑	0x03	○	×	×	×	External Pulse Encoder, Digital Filter	Unsigned8	RW	No	#	Yes
↑	0x04	○	×	×	×	External Pulse Encoder Polarity	Unsigned8	RW	No	&	Yes
↑	0x05	○	○	○	○	CS offset nonlinear encoder	Unsigned16	RW	No	&	Yes
↑	0x06	○	○	○	○	CS normalization offset of phase Z on linear encoder	Unsigned16	RW	No	&	Yes
↑	0x07	○	○	○	○	Polarity selection on linear encoder	Unsigned8	RW	No	&	Yes
↑	0x08	○	○	○	○	Magnetic pole position detecting frequency	Unsigned16	RW	No	&	Yes
↑	0x09	○	○	○	○	Magnetic Pole Position Estimation Mode Selection	Unsigned8	RW	No	&	Yes
0x20F2	0x00	-	-	-	-	Amplifier Alarm Detect Selection	Unsigned8	RO	No	-	-
↑	0x01	○	○	○	○	Main Circuit Under-voltage Detection	Unsigned8	RW	No	#	Yes
↑	0x02	○	○	○	○	Velocity Control Alarm Detection	Unsigned8	RW	No	#	Yes
↑	0x03	○	○	○	○	Velocity Feedback Alarm Detection	Unsigned8	RW	No	#	Yes
↑	0x04	○	○	○	○	Communication Frame Error Detection	Unsigned8	RW	No	#	Yes
↑	0x05	○	○	○	○	Communication Timeout Detection	Unsigned8	RW	No	#	Yes
0x20F3	0x00	-	-	-	-	Position Control Selection	Unsigned8	RO	No	-	-
↑	0x01	○	×	×	×	Model Control Characteristic	Unsigned8	RW	No	&	Yes
↑	0x02	○	×	×	×	Position Loop Encoder Selection	Unsigned8	RW	No	&	Yes
0x20F4	0x00	○	○	○	○	Servo Loop Delay Time	Unsigned8	RW	No	&	Yes
0x20F5	0x00	○	○	○	○	Torque (force) Limit at Power Supply Shortage	Unsigned8	RW	No	#	Yes
0x20F6	0x00	-	-	-	-	Manufacturer Homing Function Selection	Unsigned8	RO	No	-	-
↑	0x01	×	×	×	○	Actual Position Calculation Method	Unsigned8	RW	No	#	Yes
↑	0x02	×	×	×	○	Hard Stop Torque Limit	Unsigned16	RW	No	#	Yes
↑	0x03	×	×	×	○	Hard Stop Detection Time	Unsigned16	RW	No	#	Yes
0x20F7	0x00	○	○	○	○	Amplifier special setting	Unsigned16	RW	No	#	Yes
0x20F8	0x00	-	-	-	-	General Purpose Input Setting	Unsigned8	RO	No	-	-
↑	0x01	○	○	○	○	Positive Limit Switch Function (Positive Over-Travel)	Unsigned8	RW	No	#	Yes
↑	0x02	○	○	○	○	Negative Limit Switch Function (Negative Over-Travel)	Unsigned8	RW	No	#	Yes
↑	0x03	○	○	○	○	External Error Input Function	Unsigned8	RW	No	#	Yes
↑	0x04	○	○	○	○	Main Power Discharge Function	Unsigned8	RW	No	#	Yes
↑	0x05	○	○	○	○	Emergency Sop Function	Unsigned8	RW	No	#	Yes
↑	0x06	○	○	○	○	Detection function of magnetic pole position	Unsigned8	RW	No	#	Yes
0x20F9	0x00	-	-	-	-	General Purpose Output Setting	Unsigned8	RO	No	-	-
↑	0x01 0x02	○	○	○	○	General Purpose Output 1 – 2	Unsigned8	RW	No	#	Yes
0x20FA	0x00	-	-	-	-	Extend Station Alias	Unsigned8	RO	No	-	-
↑	0x01	○	○	○	○	Extended Alias Number	Unsigned8	RW	No	#	Yes
↑	0x02	○	○	○	○	Station Alias Selection	Unsigned8	RW	No	#	Yes
0x20FD	0x00	-	-	-	-	Amplifier System Selection	Unsigned8	RO	No	-	-
↑	0x01	○	○	○	○	Main power input type	Unsigned8	RW	No	&	Yes
↑	0x02	○	○	○	○	Regenerative Resistor Selection	Unsigned8	RW	No	&	Yes
↑	0x03	○	○	○	○	Setup Communication Baud Rate	Unsigned8	RW	No	&	Yes
↑	0x04	○	○	○	○	Main circuit power input voltage	Unsigned8	RW	No	&	Yes
0x20FE	0x00	○	○	○	○	Combination Motor Code	Unsigned16	RW	No	&	Yes
0x20FF	0x00	○	○	○	○	Combination Encoder Selection	Unsigned8	RO	No	-	-
↑	0x01	○	○	○	○	Encoder Resolution Setting	Unsigned16	RW	No	&	Yes
↑	0x02	○	○	○	○	Encoder Type	Unsigned16	RW	No	&	Yes
↑	0x03	○	×	×	×	External Encoder Resolution	Unsigned32	RW	No	&	Yes

○: Supported, ×: Not supported

5. Object Dictionary

Manufacturer Specific Area (No.5)

Index	S-Idx	FP	FV	FT	FH	Name	Data Type	Dir	PDO Mapping	Update	NVRAM
0x2100	0x00	○	○	○	○	Status Word 1	Unsigned16	RO	Possible	-	-
0x2101	0x00	-	-	-	-	Amplifier error field	Unsigned8	RO	No	-	-
↑	0x01-0x04	○	○	○	○	Alarm actual 1 – 4	Unsigned8	RO	Possible	-	-
0x2102	0x00	-	-	-	-	Description of Alarm Trace	Unsigned8	RO	No	-	-
↑	0x01	○	○	○	○	Now Status	Unsigned32	RO	Possible	-	-
↑	0x02-0x08	○	○	○	○	1 st - 7 th Latest Alarm	Unsigned16	RO	Possible	-	-
0x2103	0x00	-	-	-	-	Warning Status	Unsigned8	RO	No	-	-
↑	0x01	○	○	○	○	Warning Monitor	Unsigned16	RO	Possible	-	-
↑	0x02	○	○	○	○	Warning mask Selection	Unsigned16	RW	No	#	Yes
0x2104	0x00	-	-	-	-	Actual Gain Value Monitor	Unsigned8	RO	No	-	-
↑	0x01	○	-	-	-	Actual Position Loop Proportional Gain	Unsigned16	RO	Possible	-	-
↑	0x02	○	-	-	-	Actual Position Integral Time Constant	Unsigned16	RO	Possible	-	-
↑	0x03	○	○	○	○	Actual Velocity Loop Proportional Gain	Unsigned16	RO	Possible	-	-
↑	0x04	○	○	-	○	Actual Velocity Loop Integral Time Constant 1	Unsigned16	RO	Possible	-	-
↑	0x05	○	○	-	○	Actual Load Inertia Moment Ratio	Unsigned16	RO	Possible	-	-
↑	0x06	○	○	○	○	Actual Torque (force) Command Filter	Unsigned16	RO	Possible	-	-
↑	0x07	-	-	-	-	Actual Model Control Gain	Unsigned16	RO	Possible	-	-
0x2105	0x00	○	○	○	○	Z-phase Signal Base Actual Position	Unsigned32	RO	Possible	-	-
0x2106	0x00	○	○	×	○	Internal Velocity Command Monitor	Integer32	RO	Possible	-	-
0x2107	0x00	○	○	○	○	Internal Torque (force) Command Monitor	Integer16	RO	Possible	-	-
0x2108	0x00	-	-	-	-	Effective Torque (force) Monitor	Unsigned8	RO	No	-	-
↑	0x01	○	○	○	○	Effective Torque (force) Estimated Value	Unsigned16	RO	Possible	-	-
↑	0x02	○	○	○	○	Fast Effective Torque (force) Estimate Value	Unsigned16	RO	Possible	-	-
0x2109	0x00	○	○	○	○	Temperature inside the servo amplifier	Integer16	RO	Possible	-	-
0x210A	0x00	○	○	○	○	Regenerative Resistor Operation Percentage Monitor	Unsigned16	RO	Possible	-	-
0x210B	0x00	○	○	○	○	Encoder Temperature Monitor	Integer16	RO	Possible	-	-
0x210C	0x00	○	○	○	○	Home Index Position Detection Value	Integer32	RO	Possible	-	-
0x210D	0x00	○	—	—	—	Position Synchronization Deviation Monitor	Integer32	RO	Possible	—	-
0x2110	0x00	-	-	-	-	Internal Control Cycle Position Actual Value	Unsigned8	RO	No	-	-
↑	0x01-0x07	○	○	○	○	Internal Control Cycle Actual Position 1 – 7 (125us Latest)	Integer32	RO	Possible	-	-
0x2111	0x00	-	-	-	-	Internal Control Cycle Actual Velocity	Unsigned8	RO	No	-	-
↑	0x01-0x07	○	○	○	○	Internal Control Cycle Actual Velocity 1 – 7 (125us Latest)	Integer32	RO	Possible	-	-
0x2112	0x00	-	-	-	-	Internal Control Cycle Actual Torque (force)	Unsigned8	RO	No	-	-
↑	0x01-0x07	○	○	○	○	Internal Control Cycle Actual Torque (force) 1 – 7 (125us Latest)	Integer16	RO	Possible	-	-
0x2116	0x00	○	○	○	○	Actual Velocity Value (Velocity Monitor) 2	Integer32	RO	Possible	—	-
0x2117	0x00	○	○	○	○	Actual Position Value (Position Monitor) 2	Integer32	RO	Possible	—	-
0x2120	0x00	—	—	—	—	Amplifier Parameter	Unsigned8	RO	—	—	-
↑	0x01	○	○	○	○	Alarm Mask monitor	Unsigned32	RO	Possible	—	-
↑	0x02	○	○	○	○	Amplifier Control Status	Unsigned8	RW	—	#	-
↑	0x03	○	○	○	○	Amplifier Operation Time	Unsigned32	RO	—	—	-
↑	0x04	○	○	○	○	External Regenerative Resistor Value	Unsigned32	RW	Possible	#	-
0x2151	0x00	○	○	○	○	Error Register	Unsigned8	RO	Possible	—	-
0x2152	0x00	○	○	○	○	Device Name	Visible String	RO	No	—	-
0x2153	0x00	○	○	○	○	FPGA Hardware Version	Visible String	RO	No	—	-
0x2154	0x00	○	○	○	○	Communication Software Version	Visible String	RO	No	—	-
0x2155	0x00	○	○	○	○	Servo Software Version	Visible String	RO	No	—	-
0x2156	0x00	—	—	—	—	Alarm Estimation Cause code	Unsigned8	RO	No	—	-
↑	0x01-0x08	○	○	○	○	Alarm cause estimation code 1-8	Unsigned16	RO	No	—	-
0x2157	0x00	○	○	○	○	FPGA Initialization error	Unsigned16	RO	No	—	-
0x5010	0x00	—	—	—	—	Motor Data	Unsigned8	RO	No	-	-
↑	0x01	○	○	○	○	Number of motor pole	Unsigned8	RO	Possible	-	-
↑	0x02	○	○	○	○	Phase resistance	Unsigned16	RO	Possible	-	-
↑	0x03	○	○	○	○	Phase inductance	Unsigned16	RO	Possible	-	-
↑	0x04	○	○	○	○	Moment of inertia	Unsigned32	RO	Possible	-	-
↑	0x05	○	○	○	○	Voltage constant for each phase	Unsigned32	RO	Possible	-	-
↑	0x06	○	○	○	○	Rated torque	Unsigned16	RO	Possible	-	-
0x5040 0x5041 0x5042	0x00	—	—	—	—	Position Unit System Acceleration Unit System Acceleration Unit System	Unsigned8	RO	No	-	-
↑	0x01	○	○	○	○	100% Full-scale Software Resolution	Unsigned8	RO	Possible	-	-
↑	0x02	○	○	○	○	Full-scale Unit	Unsigned16	RO	Possible	-	-
↑	0x03	○	○	○	○	Full-scale Data Type	Unsigned16	RO	Possible	-	-
↑	0x04	○	○	○	○	Full-scale Value	Unsigned32	RO	Possible	-	-



○: Supported, ×: Not supported

5. Object Dictionary

2) Control Command Parameter

0x2000: Control Word 1


Index Ax1 0x2000 Ax2 0x2200 Ax3 0x2400 Ax4 0x2600	Manufacturer-specific object for the servo amplifier control.	Object Code	Variable		
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Control Word1 [CWORD1] Enables various functions. 0:disabled 1:enabled	Unsigned16	RW	Possible	-



5. Object Dictionary

0x2001: Parameter Select


Index Ax1 Ax2 Ax3 Ax4	0x2001 0x2201 0x2401 0x2601	Controls the selection of various parameters.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Parameter Select [PARSEL] Enables various functions.		Unsigned16	RW	Possible	-



<p>bit1-0: model suppression frequency switch selection *1 [MDLFSSEL] Under the model control, resonance/anti-resonance frequency 1-4 to be used is selected. Use the setting: bit1, 0=0, 0 frequency 1 Sub-Index:0x01. Use the setting: bit1, 0=0, 1 frequency 2 Sub-Index:0x02. Use the setting: bit1, 0=1, 0 frequency 3 Sub-Index:0x02. Use the setting: bit1, 0=1, 1 frequency 4 Sub-Index:0x04.</p>
<p>bit3-2: FF suppression frequency selection [SUPFSEL] The suppression frequency value to be used is selected from sub-Index 1-4. Use the setting: bit3, 2=0, 0 frequency 1 Sub-Index:0x01. Use the setting: bit3, 2=0, 1 frequency 2 Sub-Index:0x02. Use the setting: bit3, 2=1, 0 frequency 3 Sub-Index:0x02. Use the setting: bit3, 2=1, 1 frequency 4 Sub-Index:0x04.</p>
<p>bit5-4: Gain change selection *2 [GC] The value to be used is selected by various gain settings from Sub-Index 1-4. Use the setting bit5, 4=0, 0 gain1 Sub-Index:0x01. Use the setting bit5, 4=0, 1 gain2 Sub-Index:0x02. Use the setting bit5, 4=1, 0 gain3 Sub-Index:0x03. Use the setting bit5, 4=1, 1 gain4 Sub-Index:0x04.</p>
<p>bit7-6: Reserved</p>

*1 Model control gains 1-4 are switched by bit5-4: gain switching selection, and bit1-0 is a parameter to switch model control anti-resonance frequency 1-4 and model control resonance frequency 1-4.

*2 The parameter of switching by the Gain change selection is below.
Position loop proportional gain (0x2005), Position integral time constant (0x2006), Velocity loop proportional gain (0x200B), Velocity loop integral time constant (0x200C), Load inertia moment ratio (0x200D), Command filter (0x2011)
Also, for use of this function, please enable Torque low pass filter setting at the Special Function Selection Setting.



<p>bit15-8: Reserved</p>

5. Object Dictionary

3) Auto-Tuning Parameter

0x2002: Auto-tuning

Sub-Idx	Description	Data Type	Access	PDO	Initial value
Index Ax1 Ax2 Ax3 Ax4	0x2002 0x2202 0x2402 0x2602	Auto-tuning settings		Object Code	Array
0x00	Number of entry	Unsigned8	RO	No	0x06
0x01	Auto-tuning Mode [TUNEMODE] Set the validity, invalidity of Auto-tuning, and Load inertia moment rate estimation.	Unsigned8 Setting range	RW	No	0x02
<p><u>0x00: AutoTun (Automatic Tuning)</u> <u>0x01: AutoTun JRAT-Fix (Automatic Tuning JRAT Manual Setting)</u> <u>0x02: ManualTun (Manual Tuning)</u></p> <p>*Under the following operating conditions, Load inertia rate is not estimated properly: operation at low velocity, at low acceleration and at low acceleration/deceleration torque (force). *Load inertia moment ratio of machines applied large disturbance torque (force), machine with major backlash, and machine whose moving part vibrate partially can not correctly estimated. *If you use model following vibration suppressor control, set "02: Manual tuning." *If 00: AutoTun is selected, vibration suppressor control will be disabled though state feedback model following vibration suppressor control (base vibration suppressor) is selected.</p>					
0x02	Auto-Tuning Characteristic [ATCHA] Selects the tuning characteristic.	Unsigned8 Setting range	RW	No	0x00
<p><u>0x00: Positioning1 Positioning Control 1 (General Purpose)</u> <u>0x01: Positioning2 Positioning Control 2 (High Response)</u> <u>0x02: Positioning3 Positioning Control 3 (High Response, FFGN Manual Setting)</u> <u>0x03: Positioning4 Positioning Control 4 (High Response, Horizontal Axis Limited)</u> <u>0x04: Positioning5 Positioning Control 5 (High Response, Horizontal Axis Limited)</u> <u>0x05: Trajectory1 Trajectory Control 1</u> <u>0x06: Trajectory2 Trajectory Control 2 (KP,FFGN Manual Setting)</u></p> <p>*[Positioning Control 1] * For general-purpose positioning like fast forward operations. *[Positioning Control 2] * For high-response positioning like fast forward operations (gravity axis or external force axis.) Shocks could occur to the machine in "Positioning Control 4, 5." *[Positioning Control 3] * For further adjusting FFGN. *[Positioning Control 4] * When "Tuning mode" is set at "Automatic Tuning [JRAT Manual Setting]" in a machine in which JRAT is fixed by "Automatic Tuning [JRAT Manual Setting]" but the actual load inertia vary during the operation. * When the estimation accuracy of the Load Inertia moment ratio is low or cannot be obtained due to operation patterns or machine characteristics. *[Positioning Control 5] * When you want to adjust forward gain in case of the horizontal axis without external forces. *[Trajectory Control 1] * When there is no need to follow position commands and coordination with other axes (such as in cutting operations.) *[Trajectory Control 2] * For coordination with other axes (please adjust KPPGIN.) * For following position commands. Do not use at "model following vibration suppressor control." At Model following vibration suppressor control, trajectory will be out of alignment.</p> <p>*When "Tuning mode" is set at "02 manual tuning," the set value will not be reflected. *According to the characteristics selected, parameters will be set automatically. Position Loop Proportional Control Switch Function, Proportional Control Switch Function, Low Speed Setting, Higher Tracking Velocity Compensation Gain, Feed Forward Gain, as well as Higher Tracking Position, Acceleration Feedback, and Gain Parameter (regardless of selected conditions) are regarded as 0[%] internally.</p>					
0x03	Sets the Auto-Tuning Response [ATRES] *The larger the set value, the higher the response. *Caution, if the response is set too high, the machine may oscillate. *Make the setting suitable for rigidity of the device.	Unsigned8 Setting range	RW	No	0x05
<p>0x01-0x1E (1-30)</p>					



5. Object Dictionary

0x04	<p>Save Notch/FF Vibration Suppression frequency/ Auto-Tuning data</p> <p>◆Result of above tuning data can save by EtherCAT communication network.</p> <p>◆Selects the command <u>0x00: Disable tuning</u> <u>0x01: Execute Auto- Notch Filter tuning</u> <u>0x02: Execute Auto FF Vibration Suppression tuning</u> <u>0x03: Save result of Auto-tuning</u> <u>0x04: Stop Auto Notch Filter tuning / Auto FF Vibration Suppression tuning</u> <u>0x05: Stop save result of Auto-tuning</u></p> <p>◆Make sure of motor stop before start to Auto-tuning. Auto-tuning will get wrong value when it runs with rotating motor. When Auto-tuning is working, command relate to motor operation and the other tuning will not be accept. When motor is rotating, Auto-tuning command from master will not be accepted. Command will ignored and terminated abnormally.</p> <p>◆Master will not able to run Auto-tuning while run by Setup software. ◆Setup software will not able to run Auto-tuning while run by master.</p> <p>◆When Auto-tuning is working, master can be stop Auto-tuning. ◆Slave could receive a execute command then slave will continue to Auto-tuning even if communication error by some reason. If alarm occur by communication error then slave will stop Auto-tuning.</p> <p>◆Auto Notch Filter tuning When Auto Notch Filter tuning is working, need to follow below. >>Don't change 0x2040.2, 0x2042.1 and 0x2042.2. >>Tuning result need to save Torque Command Notch Filter frequency.</p> <p>◆Tuning result of Auto FF Vibration Suppression need to save 0x2012.</p> <p>◆When execute Auto-tuning result save, save parameter will follow selected sub index (0x06). ◦ There are 6 kind of save parameter., Each save parameter has 5 sub index (0x06) >>Load inertia 1(0x200D.1) >>Position Loop Proportional Gain 1(0x2005.1) >>Velocity Loop Proportional Gain 1(0x200B.1) >>Velocity Loop Integral Time Constant 1(0x200C.1) >>Torque Command Filter 1(0x2011.1) Don't change 0x20F7 bit1. >>ModelFollowing Control Gain 1(0x2017.1)</p> <p>◆Result of Auto Notch filter tuning and Auto FF Vibration Suppression tuning can not save at the same time.</p>	Unsigned8 Setting range	RW	No 0x00~0x05 (0~5)	0x00																																										
0x05	<p>Notch /FF Vibration Suppression frequency/ Monitor of save tuning result.</p> <p>◆Indicate state of Notch Filter,FF Vibration Suppression frequency and tuning result.</p> <p><u>0x00: Running tuning</u> <u>0x01: Completion</u> <u>0x02: Abnormal termination</u> If finish tuning, 0x01 or 0x02 will indicate.</p>	Unsigned8 Setting range	RO	No 0x00~0x02 (0~2)	0x01																																										
0x06	<p>Parameter setting of save Auto-tuning result</p> <p>◆Setting of save parameter</p> <p>◆Description</p> <table border="1" data-bbox="352 1653 1339 1872"> <thead> <tr> <th>Setting value</th> <th>Load inertia</th> <th>Position Proportional Gain</th> <th>Velocity Proportional Gain</th> <th>Velocity Integral Constant</th> <th>Torque Command Filter</th> <th>Model Control Gain</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> </tr> <tr> <td>1</td> <td>○</td> <td>×</td> <td>○</td> <td>○</td> <td>○</td> <td>×</td> </tr> <tr> <td>2</td> <td>○</td> <td>×</td> <td>×</td> <td>×</td> <td>×</td> <td>×</td> </tr> <tr> <td>3</td> <td>×</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> </tr> <tr> <td>4</td> <td>×</td> <td>×</td> <td>○</td> <td>○</td> <td>○</td> <td>×</td> </tr> </tbody> </table>	Setting value	Load inertia	Position Proportional Gain	Velocity Proportional Gain	Velocity Integral Constant	Torque Command Filter	Model Control Gain	0	○	○	○	○	○	○	1	○	×	○	○	○	×	2	○	×	×	×	×	×	3	×	○	○	○	○	○	4	×	×	○	○	○	×	Unsigned8 Setting range	RW	No 0x00-0x04 (0-5)	0x00
Setting value	Load inertia	Position Proportional Gain	Velocity Proportional Gain	Velocity Integral Constant	Torque Command Filter	Model Control Gain																																									
0	○	○	○	○	○	○																																									
1	○	×	○	○	○	×																																									
2	○	×	×	×	×	×																																									
3	×	○	○	○	○	○																																									
4	×	×	○	○	○	×																																									


5. Object Dictionary

4) Basic Control Parameter

0x2003: Position Command Smoothing Constant

Index Ax1 Ax2 Ax3 Ax4	0x2003 0x2203 0x2403 0x2603	This moving low-pass filter smooths the position command pulse. Sets time constants.	Object Code		Variable	
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Position Command Smoothing Constant [PCSMT] *Applies gradient to the step condition positioning pulse. *Applies S curve to the ramp condition position command pulse. *When position command differences in each communication cycle are large, position command will be smoothed. (This may decrease the operating noise of the servo motor.) *When this moving-average filter is used, the value is set at "0.3ms and higher". *When the set value is "0.0ms-0.2ms", this filter is invalid. *Set in increments of 0.5ms. (Under the set value "0.4ms and less", there may be cases where the set value cannot be applied to the operation.)		Unsigned16	RW	Possible	0x0005 (0.5 ms)
			Setting range	0x0000-0x1388 (0.0-500.0 ms)		
			Unit	0.1 ms		
* Position command pulse with step condition applied  * Position command pulse with ramp condition applied. 						

0x2004: Position Command Filter

Index Ax1 Ax2 Ax3 Ax4	0x2004 0x2204 0x2404 0x2604	This low-pass filter suppresses any sudden change of the position control pulse. Sets time constants.	Object Code		Variable	
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Position Command Filter [PCFIL] Time constant for the filter will be set. Filter will be invalid at the set value 0.0 ms. Does not influence Feed Forward.		Unsigned16	RW	No	0x0000 (0.0 ms)
			Setting range	0x0000-0x4E20 (0.0-2000.0 ms)		
			Unit	0.1 ms		
*This parameter setting is valid when the value of Higher Tracking Control Position Compensation Gain is set at 0%. *When Higher Tracking Control Position Compensation Gain is 0%, value is set at 0.0ms, the filter becomes invalid. *This filter can suppress overshoot caused by the rise of the feed forward compensation gain.						
						

5. Object Dictionary

0x2005: Position Loop Gain

Index Ax1 Ax2 Ax3 Ax4	0x2005 0x2205 0x2405 0x2605	Proportional gain for position controller. By setting bit5, 4 gain change selection (GC) in the parameter selection (0x2001), the position loop proportional gain to be used is selected.	Object Code		Array	
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x04
0x01	Position Loop Gain 1	[KP1]	Unsigned16	RW	Possible	0x001E (30 /s)
		*Automatically saved by Auto-tuning result saving. *When Auto-tuning function is valid, this setting value is not applied. *When gain 1(bit5, 4=0, 0) is selected, in the Gain Switching function, it operates at this setting value.				
0x02	Position Loop Gain 2	[KP2]	Unsigned16	RW	No	0x001E (30 /s)
		* When gain 2(bit5, 4=0, 1) is selected, in the Gain Switching function, it operates at this setting value.				
0x03	Position Loop Gain 3	[KP3]	Unsigned16	RW	No	0x001E (30 /s)
		* When gain 3(bit5, 4=1, 0) is selected, in the Gain Switching function, it operates at this setting value.				
0x04	Position Loop Gain 4	[KP4]	Unsigned16	RW	No	0x001E (30 /s)
		* When gain 4(bit5, 4=1, 1) is selected, in the Gain Switching function, it operates at this setting value.				
Setting range			0x0001-0x0BB8 (1-3000 /s)			
Unit			1/s			

0x2006: Position Integral Time Constant 1

Index Ax1 Ax2 Ax3 Ax4	0x2006 0x2206 0x2406 0x2606	Integral time constant for position controller. By setting bit5, 4, gain change selection (GC), in parameter selection (0x2001), the position integral time constant to be used is selected.	Object Code		Array	
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x04
0x01	Position Integral Time Constant 1	[TPI1]	Unsigned16	RW	Possible	0x2710 (1000ms) proportional control
		* Automatically saved by Auto-tuning result saving. * When Auto-tuning function is valid, this setting value is not applied. *When gain 1(bit5, 4=0, 0) is selected, in the Gain Switching function, it operates at this setting value.				
0x02	Position Integral Time Constant 2	[TPI2]	Unsigned16	RW	No	0x2710 (1000ms) proportional control
		*When gain 2(bit5, 4=0, 1) is selected, in the Gain Switching function, it operates at this setting value.				
0x03	Position Integral Time Constant 3	[TPI3]	Unsigned16	RW	No	0x2710 (1000ms) proportional control
		*When gain 3(bit5, 4=1, 0) is selected, in the Gain Switching function, it operates at this setting value.				
0x04	Position Integral Time Constant 4	[TPI4]	Unsigned16	RW	No	0x2710 (1000ms) proportional control
		*When gain 4(bit5, 4=1, 1) is selected, in the Gain Switching function, it operates at this setting value.				
Setting range			0x0003-0x2710 (0.3-1000 ms)			
Unit			0.1ms			

5. Object Dictionary

0x2007: Higher Tracking Control Position Compensation Gain

Index Ax1	0x2007	Improves the Command Tractability using Compensation Gain Parameter to the position system. The larger value can raise command tracking performance.	Object Code		Variable	
Ax2	0x2207					
Ax3	0x2407					
Ax4	0x2607					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Higher Tracking Control Position Compensation Gain [TRCPGN]		Unsigned16	RW	No	0x0000 (0 %)
	When higher tracking control position compensation bit is enabled, Feed Forward Gain (FFGN), Position Command Filter Time Constant (PCFIL) will be automatically set to the intended proportion. KFGN [%] = 0.9 × Setting value [%]		Setting range	0x0000-0x0064 (0-100 %)		
	PCFIL [Hz] = Velocity Loop Proportional Gain / Setting value [%] / 100 When the value is greater, Command Track ability will be improved. ■ When a value other than 0% is set, Position Command Filter and Feed Forward Gain are automatically set in the servo amplifier. ■ When Auto-tuning function is valid, this setting value not applied.		Unit	1 %		

0x2008: Feed Forward compensation parameter

Index Ax1	0x2008	Sets parameters regarding Feed Forward compensation functions.	Object Code		Array	
Ax2	0x2208					
Ax3	0x2408					
Ax4	0x2608					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x0002
0x01	Feed Forward Gain [FFGN] Sets feed forward compensation gain to position control system. Model control system compensates for feed forward to Model following system when Position Control Selection is at Model following control.		Unsigned16	RW	Possible	0x0000 (0 %)
	*Valid when Higher Tracking Control Position Compensation Gain is set at 0%. *The setting value is not applied when using the Auto-Tuning Characteristics listed below.		Setting range	0x0000-0x0064 (0-100 %)		
	<u>Positioning1</u> <u>Positioning Control 1 (General Purpose)</u> <u>Positioning2</u> <u>Positioning Control 2 (High Response)</u> <u>Positioning4</u> <u>Positioning Control 4 (High Response, Horizontal Axis Limited)</u> <u>Trajectory1</u> <u>Trajectory Control 1</u>		Unit	1 %		
0x02	Feed Forward Filter [FFFIL] First low-pass filter to eliminate pulsed ripple caused by the position command pulse included in the feed forward command. Sets the cutoff frequency. * Sets values to disable the filter differ according to the setting of "position control selection."		Unsigned16	RW	No	0x0FA0 (4000Hz) Invalid
	Position Control Selection		Setting range	0x0001-0x0FA0 (1-4000Hz)		
	00:Standard Standard		Unit	1 Hz		
	01:Model1 Model 1 Model Following Control		Value when the filter is invalid			
	02:Model2 Model 2 Model Flowing Vibration Suppress Control		2000Hz or more			
			500Hz or more			

0x2009: Command Filter Settings

Index Ax1	0x2009	Sets primary low pass filter regarding velocity command.	Object Code		Variable	
Ax2	0x2209					
Ax3	0x2409					
Ax4	0x2609					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Velocity Command Filter [VCFIL] This primary low pass filter to suppress the sudden changes of the velocity command. Sets the cutoff frequency. When sets over 2000Hz(0x07D0) then setting become disable.		Unsigned16	RW	No	0x0FA0 (4000 Hz) Invalid
			Setting Range	0x0001~0x0FA0 (1~4000 Hz)		
			Unit	1 Hz		

5. Object Dictionary

0x200A: Velocity Feedback Filter

Index Ax1 Ax2 Ax3 Ax4	0x200A 0x220A 0x240A 0x260A	Parameter to switch on the primary low-pass filter in response to velocity feedback.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Velocity Feedback Filter [VDFIL] First low-pass filter to eliminate ripples caused by encoder pulse included in the velocity control system feedback. Sets the cutoff frequency. Setting value: the filter will be disabled at 2000Hz(0x07D0) or greater.		Unsigned16	RW	No	0x05DC (1500 Hz)
			Setting range	0x0001-0x0FA0 (1-4000 Hz)		
			Unit	1 Hz		
*When the encoder resolution is low, lowering the setting value and suppressor the ripples can suppress motor drive noise. In addition, when the encoder resolution is high, raising the setting value may improve the response of the velocity control system. For general use, set at the Standard value.						

0x200B: Velocity Loop Proportional Gain

Index Ax1 Ax2 Ax3 Ax4	0x200B 0x220B 0x240B 0x260B	Proportional gain of velocity controller. By setting bit5, 4, gain change selection (GC), in the parameter selection (0x2001), the Position Loop Proportional Gain to be used is selected.	Object Code	Array		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x04
0x01	Velocity Loop Proportional Gain 1 [KVP1] *Automatically saved by Auto-tuning result saving.		Unsigned16	RW	Possible	0x0032 (50Hz)
*When Auto-tuning function is valid, this setting value is not applied. *When the Gain switching function is valid, select gain 1 and this setting value is applied. *When gain 1(bit5, 4=0, 0) is selected, in the Gain Switching function, it operates at this setting value.						
0x02	Velocity Loop Proportional Gain 2 [KVP2] *When gain 2(bit5, 4=0, 1) is selected, in the Gain Switching function, it operates at this setting value.		Unsigned16	RW	No	0x0032 (50Hz)
0x03	Velocity Loop Proportional Gain 3 [KVP3] *When gain 3(bit5, 4=1, 0) is selected, in the Gain Switching function, it operates at this setting value.		Unsigned16	RW	No	0x0032 (50Hz)
0x04	Velocity Loop Proportional Gain 4 [KVP4] *When gain 4(bit5, 4=1, 1) is selected, in the Gain Switching function, it operates at this setting value.		Unsigned16	RW	No	0x0032 (50Hz)
			Setting range	0x0001-0x07D0 (1-2000 Hz)		
			Unit	1Hz		

0x200C: Velocity Loop Integral Time Constant

Index Ax1 Ax2 Ax3 Ax4	0x200C 0x220C 0x240C 0x260C	Integral time constant of velocity controller. Selects Velocity Loop Integral Time Constant to use by Gain change selection (GC) (Parameter Select: 0x2001 bit5, 4). Integral term is invalid (proportional control) with the setting value of 1000ms (0x2710).	Object Code	Array		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x04
0x01	Velocity Loop Integral Time Constant 1 [TVI1] *Automatically saved by Auto-tuning result saving.		Unsigned16	RW	Possible	0x00C8 (20ms)
*When Auto-tuning function is valid, this setting value is not applied. *When Gain switching function is valid, select gain 1 and this setting value is applied. *When gain 1(bit5, 4=0, 0) is selected, in the Gain Switching function, it operates at this setting value.						
0x02	Velocity Loop Integral Time Constant 2 [TVI2] * When gain 2(bit5, 4=0, 1) is selected, in the Gain Switching function, it operates at this setting value.		Unsigned16	RW	No	0x00C8 (20ms)
0x03	Velocity Loop Integral Time Constant 3 [TVI3] * When gain 3(bit5, 4=1, 0) is selected, in the Gain Switching function, it operates at this setting value.		Unsigned16	RW	No	0x00C8 (20ms)
0x04	Velocity Loop Integral Time Constant 4 [TVI4] * When gain 4(bit5, 4=1, 1) is selected, in the Gain Switching function, it operates at this setting value.		Unsigned16	RW	No	0x00C8 (20ms)
			Setting range	0x0003-0x2710 (0.3-1000 ms)		
			Unit	0.1ms		

5. Object Dictionary

0x200D: Load Inertia Moment Ratio

Index Ax1 Ax2 Ax3 Ax4	0x200D 0x220D 0x240D 0x260D	Sets inertia moment of the loading device to the servo motor roter inertia. Setting value= $J_L/J_M \times 100\%$ (J_L : Load inertia, J_M : Motor roter inertia) By setting bit5, 4, gain change selection (GC) in the parameter selection (0x2001), the Load Inertia Moment Ratio to be used is selected.	Object Code	Array	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Number of entry	Unsigned8	RO	No	0x04
0x01	Load Inertia Moment Ratio 1 [JRAT1] *For velocity control parameters. *Automatically saved by Auto-tuning result saving. *When Auto-tuning function is valid, this setting value not applied. *When Gain switching function is valid, select gain 1 and this setting value is applied. *When gain 1 (bit5, 4=0, 0) is selected, in the Gain Switching function, it operates at this setting value.	Unsigned16	RW	Possible	0x0064 (100%)
0x02	Load Inertia Moment Ratio 2 [JRAT2] *When gain 2 (bit5, 4=0, 1) is selected, in the Gain Switching function, it operates at this setting value.	Unsigned16	RW	No	0x0064 (100%)
0x03	Load Inertia Moment Ratio 3 [JRAT3] *When gain 3 (bit5, 4=1, 0) is selected, in the Gain Switching function, it operates at this setting value.	Unsigned16	RW	No	0x0064 (100%)
0x04	Load Inertia Moment Ratio 4 [JRAT4] *When gain 4 (bit5, 4=1, 1) is selected, in the Gain Switching function, it operates at this setting value.	Unsigned16	RW	No	0x0064 (100%)
Setting range		0x0000-0x3A98 (0-15000%)			
Unit		1%			

0x200E: Higher Tracking Control Velocity Compensation Gain

Index Ax1 Ax2 Ax3 Ax4	0x200E 0x220E 0x240E 0x260E	Parameter to adjust command following performance of velocity control.	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Higher Tracking Control Velocity Compensation Gain [TRCVGN] *The higher the value, the more improved command following performance. *When using Velocity Loop Proportional Control Switching Function, set it to 0%. *When synchronizing with other axes, set it to 0%. *When corresponding with Q series servo amplifier, set it to 100%. *When auto-tuning enabled, this setting value is not reflected. *The setting value is invalid with Model following control or Model following vibration suppressor control.	Unsigned16	RW	No	0x0000
Setting range		0x0000 - 0x0064 (0-100 %)			
Unit		1%			

0x200F: Acceleration Feedback Compensation

Index Ax1 Ax2 Ax3 Ax4	0x200F 0x220F 0x240F 0x260F	Sets acceleration feedback compensation gain to make the velocity loop stable. Sets the cutoff frequency.	Object Code	Array	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Number of entry	Unsigned8	RO	No	0x02
0x01	Acceleration Feedback Gain [AFBK] Multiply this gain with the detected acceleration to compensate torque (force) command. ■When Auto-tuning function is valid, this setting value not applied. ■If the value is too large, the motor may oscillate. Set within range $\pm 15.0\%$ for general use.	Integer16	RW	No	0x0000 (0.0 %)
Setting range		0xFC18-0x03E8 (-100.0-+100.0%)			
Unit		0.1 %			
0x02	Acceleration Feedback Filter [AFBFIL] First low-pass filter to eliminate ripples caused by encoder pulse included in acceleration feedback compensation. Sets the cutoff frequency. ■Lower this setting value when the encoder resolution is low. ■Setting value: the filter will be disabled at 2000Hz(0x07D0) or greater.	Unsigned16	RW	No	0x01F4 (500Hz)
Setting range		0x0001-0x0FA0 (1-4000Hz)			
Unit		Hz			

5. Object Dictionary

0x2011: Torque Command Filter

Index Ax1	0x2011	Low-pass filter to eliminate high frequency component included in the torque (force) command. Sets cutoff frequency. By setting bit5, 4 gain, change selection (GC) in the parameter selection (0x2001), the Torque (force) Command Filter to be used is selected.	Object Code		Array	
Ax2	0x2211					
Ax3	0x2411					
Ax4	0x2611					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x04
0x01	Torque(force) command filter 1 [TCFIL1] * This setting update when save Auto-Tuning data. * When Auto-Tuning activate , this setting invalid. * When Auto-Tuning activate and System analysis activate, this setting valid. * When Gain Switching activate and select gain 1 (bit5,4=0,0), this setting enable.		Unsigned16	RW	Possible	0x0258 (600Hz)
0x02	Torque (force) Command Filter 2 [TCFIL2] *When the gain permission is enabled and gain 2 (bit5,4 = 0,1) is selected in the Gain Switching function, it operates at this setting value.		Unsigned16	RW	No	0x0258 (600Hz)
0x03	Torque (force) Command Filter 3 [TCFIL3] * When the gain permission is enabled and gain 3 (bit5,4 = 1,0) is selected in the Gain Switching function, it operates at this setting value.		Unsigned16	RW	No	0x0258 (600Hz)
0x04	Torque (force) Command Filter 4 [TCFIL4] * When the gain permission is enabled and gain 4 (bit5,4 = 1,1) is selected in the Gain Switching function, it operates at this setting value.		Unsigned16	RW	No	0x0258 (600Hz)
			Setting value	0x0001 - 0x0FA0 (1 - 4000 Hz)		
			Unit	Hz		

5. Object Dictionary

5) Feed Forward vibration suppressor control / Notch filter Parameter

0x2012: FF Vibration Suppressor Frequency

Index Ax1 0x2012 Ax2 0x2212 Ax3 0x2412 Ax4 0x2612	<p>Sets the frequency of the machine vibration to be suppressed by FF vibration suppressor function. Change this while the servo motor is OFF.</p> <p>Shows the center frequency of the notch filter in response to the position command and set the frequency of the resonance to be constrained (anti-resonance frequency).</p> <p>By setting bit3, 2 FF Vibration Suppressor Frequency switch selection (supfsel) in parameter selection (0x2001), the notch filter to be used is selected.</p>		Object Code		Array
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Number of entry	Unsigned8	RO	No	0x04
0x01	<p>FF Vibration Suppressor Frequency 1 [SUPFRQ1]</p> <p>*This parameter is automatically saved by executing FF vibration suppressor frequency tuning.</p> <p>*Tuning result will be automatically saved in this parameter.</p> <p>*When frequency 2 (bit 3, 2=0, 1) is selected in the vibration suppressor frequency selection function, it will operate at this setting value.</p>	Unsigned16	RW	Possible	0x01F4 (500 Hz) proportional control
0x02	<p>FF Vibration Suppressor Frequency 2 [SUPFRQ2]</p> <p>*When frequency 2 (bit 3, 2=0, 1) is selected in the vibration suppressor frequency selection function, it will operate at this setting value.</p>	Unsigned16	RW	No	0x01F4 (500 Hz) proportional control
0x03	<p>FF Vibration Suppressor Frequency 3 [SUPFRQ3]</p> <p>*When frequency 3 (bit 3, 2=1, 0) is selected in the vibration suppressor frequency selection function, it will operate at this setting value.</p>	Unsigned16	RW	No	0x01F4 (500 Hz) proportional control
0x04	<p>FF Vibration Suppressor Frequency 4 [SUPFRQ4]</p> <p>*When frequency 4 (bit 3, 2=1, 1) is selected in the vibration suppressor frequency selection function, it will operate at this setting value.</p>	Unsigned16	RW	No	0x01F4 (500 Hz) proportional control
	<p>*Setting value can be input by 1Hz; inside the servo amplifier, the units listed below are used.</p> <p>Setting range Unit value inside servo amplifier</p> <p>5-99Hz Valid by 1Hz 100-499Hz Valid by 5Hz and drop less than 5</p> <p>*Setting value: FF vibration suppressor control is invalid</p> <p>*Do not use while synchronizing with other axis such as controlling XY table trajectory for cutting operation.</p>	Setting range	0x0005-0x01F4 (5-500Hz)		
		Unit	Hz		

5. Object Dictionary

6) High stabilized control settings

0x2015: High stabilized control settings

Sub-Idx	Description	Data Type	Access	PDO	Initial value
Index Ax1 0x2015 Ax2 0x2215 Ax3 0x2415 Ax4 0x2615	Parameter setting to implement high setting control by adding position deviation to Acceleration and Deceleration Compensation Values.				
Object Code					Array
0x00	Number of entry	Unsigned8	RO	No	0x04
0x01	Acceleration Compensation [ACCC0] Sets the Acceleration Compensation Value using high-stabilized control. * Set with the Position Deviation Pulse unit (in case of the pulse encoder, with the quadruple encoder resolution unit.) * Compensation is provided in response to position deviation. * Greater setting values result in increased compensation. * Greater accelerations converted from the Position Command Pulse result in increased compensation. * Greater Load inertia result in increased compensation. * High Stabilized Control results in Position Deviation. * In case of model following control or model following anti-resonance control, this setting value is not reflected.	Indeger16	RW	No	0x0 (0 Pulse)
		Setting range	0xD8F1-0x270F (-9999-+9999×50 Pulse)		
		Unit	×50 Pulse		
0x02	Deceleration Compensation [DECC0] Sets the Deceleration Compensation Value with High Stabilized Control. ✓ Setting is in unit of position deviation pulse (for pulse encoder, unit of 4-multiplied encoder resolution). ✓ Compensation shall be performed for position deviation. ✓ The higher the set value, the more the compensation increases. ✓ The higher the acceleration converted from position command pulse, the more the compensation increases. ✓ The higher the load inertia value, the more the compensation increases. ✓ Position deviation decreases by high-stabilized control. * In case of model following control or model following anti-resonance control, this setting value is not reflected.	Indeger16	RW	No	0x0 (0 Pulse)
		Setting range	0xD8F1-0x270F (-9999-+9999×50 Pulse)		
		Unit	×50 Pulse		
0x03	Command Velocity Low-pass Filter [CVFIL] Sets the cutoff frequency of the primary low-pass filter to eliminate high-frequency component (ripples etc.) included in the Velocity (Command Velocity) calculated from the position command inside the higher established control. * When the encoder resolution is low, lower the cutoff frequency. * The filter is disabled by setting value 2000Hz or more.	Unsigned16	RW	No	0x03E8 (1000Hz)
		Setting range	0x001-0x0FA0 (1-4000Hz)		
		Unit	Hz		
0x04	Command Velocity Threshold [CVTH] Sets the Velocity Threshold to validate the Acceleration and Deceleration Compensation Values in the higher established control. * When the velocity (command velocity) converted from the Position Command is higher than this velocity, implement the Acceleration or Deceleration Compensations. ⚠ The rotary motor differs from linear motor in unit.	Unsigned16	RW	No	0x0014 (20 min ⁻¹) [20mm/s]
		Setting range	0x0000-0xFFFF (0-65536)		
		Unit	Rotary : min ⁻¹ [Linear : mm/s]		

5. Object Dictionary

7) Observer Parameter

0x2016: Observer Parameter

Index Ax1 Ax2 Ax3 Ax4	0x2016 0x2216 0x2416 0x2616	Sets various parameters in the disturbance suppression observer. Observer compensation operates with control word 1 (0x2000) bit 11: disturbance Observer compensation enable [OBCON]="1"	Object Code	Record	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Number of entry	Unsigned8	RO	No	0x07
0x01	Observer Characteristic [OBCHA]	Unsigned8	RW	No	0x00
	Setting range	0x00-0x02			
	0x00: Low For Low Frequency 0x01: Middle For Middle Frequency 0x02: High For High Frequency 0x03-0xFF: Reserved				
	*Select "00 Low, Low Frequency Disturbance Observer Suppressor" for Load torque (force) monitor (estimate value). *Select 02 High, High Frequency Disturbance Observer Suppressor, when the encoder resolution is over 1048576P/R (20bit).				
0x02	Compensation gain for Disturbance Observer.[OBG] Observer Compensation gain in response to the Torque (force)command. *The larger the value, the higher the suppression performance. By making this too large to oscillate, the disturbance suppression characteristics improve.	Unsigned16	RW	No	0x0000 (0 %)
	Setting range	0x0000-0x0064 (0-100 %)			
	Unit	1 %			
0x03	Observer Output Filter [OBLPF] First low-pass filter to eliminate high frequency elements included in the observer compensation. Sets the cutoff frequency. *Filter is invalid at the setting value more than 2000Hz.	Unsigned16	RW	No	0x032 (50 Hz)
	Setting range	0x0001-0x0FA0 (1-4000 Hz)			
	Unit	Hz			
	*The larger the value is, the faster the response of disturbance observer suppression. However, it may cause a louder driving sound depending on the ripple components included in disturbance observer output. *Filter is invalid when observer characteristic is set to [01 Middle, For Middle Frequency], or [02 High, For High Frequency].				
0x04	Observer Notch Filter [OBNFIL] Notch filter to eliminate arbitrarily selected frequency from observer compensation. Set the center frequency of the filter. *When resonance appears in disturbance observer output, such as sympathetic vibration with the mechanical system, this notch filter sometimes suppresses the vibration. *Setting value can be input by 1Hz; inside the servo amplifier, the units listed below are applied. Setting value Unit value inside servo amplifier 100-1999Hz Valid by 10Hz and drop less than 10 2000-4000Hz Filter invalid	Unsigned16	RW	No	0x0FA0 (4000 Hz)
	Setting range	0x0001-0x0FA0 (1-4000 Hz)			
	Unit	Hz			
	<p style="text-align: center;">Resonant frequency f_n</p>				
0x05	Observer Load Inertia Ratio [OBLJLM] Sets the Inertia moment (Load Inertia) of the loading device for the motor inertia moment at the disturbance suppression observer. Setting value= $JL/JM \times 100\%$ (JL: Load inertia, JM: Motor rotor inertia) * Selection of disturbance suppression observer characteristics: JRAT 1-4 are used when frequency setting is made.	Unsigned16	RW	No	0x0064 (100%)
	Setting range	0x0000-0x1388 (0-5000%)			
	Unit	%			
0x06	Observer Loop Proportional Gain [OBPGIN] Proportional gain of the observer control.	Unsigned16	RW	No	0x012C (300Hz)
	Setting range	0x0001-0x07D0 (1-2000Hz)			
	Unit	Hz			
0x07	Load Torque (force) Filter [TESLPF] After the disturbance suppression observer output low-pass filter, set the cutoff frequency of the primary low-pass filter against the Load torque (force) estimate. Sets the cutoff frequency. Setting value: the filter will be disabled at 2000Hz(0x07D0) or greater.	Unsigned16	RW	No	0x0032 (50 Hz)
	Setting range	0x0001-0x07D0 (1-2000Hz)			
	Unit	Hz			

5. Object Dictionary

8) Model Following Control Settings Parameter

A note of caution in using Model Following Control

- * If oscillation is restrained when using Model Following Vibration Suppressor Control, the vibration suppression effect disappears when the alarm occurs.
- * When the Gain Switching Function is used, please stop the servo motor.
- * When the Model Vibration Suppressor Frequency switching is used, please stop the servo motor.
- * If the alarm "AL.C5 Model Following Vibration Suppressor Control trouble" occurs during the operation, please lower the "KM Model Control Gain" or change the operation pattern so that the acceleration and deceleration will be slowed.
- * In the JOG operation, Model Following Vibration Suppressor Control function does not operate.

0x2017: Model Control Gain

Index Ax1 Ax2 Ax3 Ax4	0x2017 0x2217 0x2417 0x2617	Proportional gain of the Model Following Control Position Controller.	Object Code		Array	
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x04
0x01	Model Control Gain 1 [KM1] *Automatically saved by Auto-tuning result saving. *When gain 1(bit5, 4=0, 0) is selected, in the Gain Switching function, it operates at this setting value.		Unsigned16	RW	Possible	0x001E (30 /s)
0x02	Model Control Gain 2 [KM2] *When gain 2(bit5, 4=0, 1) is selected, in the Gain Switching function, it operates at this setting value.		Unsigned16	RW	No	0x001E (30 /s)
0x03	Model Control Gain 3 [KM3] *When gain 3(bit5, 4=1, 0) is selected, in the Gain Switching function, it operates at this setting value.		Unsigned16	RW	No	0x001E (30 /s)
0x04	Model Control Gain 4 [KM4] *When gain 4(bit5, 4=1, 1) is selected, in the Gain Switching function, it operates at this setting value.		Unsigned16	RW	No	0x001E (30 /s)
		Depends on the setting value of Position control selection (0x20F3:01), the range is different. 01: Model Following Control 0x0001-0x0BB8 (1-3000 /s) 02: Condition Feedback Model Following Vibration Suppress Control 0x000F-0x013B (15-315 /s) * In case of operating at Model following anti-resonance control, use in the range of 15 - 315/s. * Change value while the servo motor is OFF.	Setting range	0x0001-0x0BB8 (1-3000 /s)		
			Unit	1/s		

0x2018: Overshoot Suppressor Filter

Index Ax1 Ax2 Ax3 Ax4	0x2018 0x2218 0x2418 0x2618	Filter to suppress overshoot with Model following control or Model following vibration suppressor control. Sets cutoff frequency.	Object Code		Variable	
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Overshoot Suppressor Filter [OSSFIL] Cutoff frequency of primary low-pass filter in response the velocity integral feedback. *If any overshoots occur on position deviation, lower the setting value. *Filter is invalid at the setting value more than 2000Hz.		Unsigned16	RW	No	0x05DC (1500 Hz)
			Setting range	0x0001-0x0FA0 (1-4000 Hz)		
			Unit	Hz		

5. Object Dictionary

0x2019: Model Control Antiresonance Frequency

Index Ax1	0x2019	Sets antiresonance frequency to the mechanical device with Model following vibration suppressor control. Sets actual antiresonance frequency value of the mechanical system by using System Analysis function of the Software Setup.	Object Code		Array	
Ax2	0x2219					
Ax3	0x2419					
Ax4	0x2619					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x04
0x01	Model Control Antiresonance Frequency 1 [ANRFRQ1] *When frequency 1(bit1, 0=0, 0) is selected in the model anti-resonance frequency switch at 0x2001, it operates at this setting value.		Unsigned16	RW	Possible	0x0320 (80.0 Hz) proportional control
0x02	Model Control Antiresonance Frequency 2 [ANRFRQ2] *When frequency 2(bit1, 0=0, 1) is selected in the model anti-resonance frequency switch at 0x2001, it operates at this setting value.		Unsigned16	RW	No	0x0320 (80.0 Hz) proportional control
0x03	Model Control Antiresonance Frequency 3 [ANRFRQ3] *When frequency 3(bit1, 0=1, 0) is selected in the model anti-resonance frequency switch at 0x2001, it operates at this setting value.		Unsigned16	RW	No	0x0320 (80.0 Hz) proportional control
0x04	Model Control Antiresonance Frequency 4 [ANRFRQ4] *When frequency 4(bit1, 0=1, 1) is selected in the model anti-resonance frequency switch at 0x2001, it operates at this setting value.		Unsigned16	RW	No	0x0320 (80.0 Hz) proportional control
<ul style="list-style-type: none"> ■ Setting value is invalid with following control. ■ If the sitting value is over the Model Control Resonance Frequency, vibration suppressor control is invalid. ■ If "Model Control Anti-resonance Frequency 2-4" are selected in the "Model vibration suppressor frequency switching function", it operates at this setting value. ■ Change value while the servo motor is OFF. 				Setting range	0x0064-0x0320 (10.0-80.0 Hz)	
				Unit	0.1 Hz	

0x201A: Model Control Resonance Frequency

Index Ax1	0x201A	Sets resonance frequency of the mechanical device with Model following vibration suppressor control. Sets actual resonance frequency value of the mechanical system by using System Analysis function of the Software Setup.	Object Code		Array	
Ax2	0x221A					
Ax3	0x241A					
Ax4	0x261A					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x04
0x01	Model Control Resonance Frequency 1 [RESFRQ1] *When frequency 1(bit1, 0=0, 0) is selected in the model anti-resonance frequency switch at 0x2001, it operates at this setting value.		Unsigned16	RW	Possible	0x0320 (80.0 Hz) proportional control
0x02	Model Control Resonance Frequency 2 [RESFRQ2] *When frequency 2(bit1, 0=0, 1) is selected in the model anti-resonance frequency switch at 0x2001, it operates at this setting value.		Unsigned16	RW	No	0x0320 (80.0 Hz) proportional control
0x03	Model Control Resonance Frequency 3 [RESFRQ3] *When frequency 3(bit1, 0=1, 0) is selected in the model anti-resonance frequency switch at 0x2001, it operates at this setting value.		Unsigned16	RW	No	0x0320 (80.0 Hz) proportional control
0x04	Model Control Resonance Frequency 4 [RESFRQ4] *When frequency 1(bit1, 0=1, 1) is selected in the model anti-resonance frequency switch at 0x2001, it operates at this setting value.		Unsigned16	RW	No	0x0320 (80.0 Hz) proportional control
<ul style="list-style-type: none"> * Setting value is invalid with Model following control. * The filter is disabled by setting value 0x320(80Hz) or more. * If Model Control Antiresonance Frequency 2-4 selected in Model vibration suppressor frequency switching setting, it works in this setting. * Change value while the servo motor is OFF. 			Setting range	0x0064-0x0320 (10.0-80.0 Hz)		
			Unit	0.1 Hz		

0x201B: Gain Switching Filter

Index Ax1	0x201B	Low-pass filter to change gain moderately when switching. Sets time constant.	Object Code		Variable	
Ax2	0x221B					
Ax3	0x241B					
Ax4	0x261B					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Gain Switching Filter [GCFIL] By setting bit5, 4, gain change selection (GC) in the parameter selection (0x2001), the time constant at the parameter switching is set. * The larger the value, the gentler the gain changes. * The filter is disabled at the setting value 0ms. * When the mechanical system is shocked by the change of gain resulted from gain switching, making a moderate gain change will modify the shock.		Unsigned16	RW	No	0x0000 (0 ms)
			Setting range	0x0000-0x064 (0-100ms)		
			Setting Unit	ms		

5. Object Dictionary

9) Amplifier Function Parameter

0x201C: Internal Velocity Command limit

Index Ax1 Ax2 Ax3 Ax4	0x201C 0x221C 0x241C 0x261C	Sets the allowable velocity in response to the Internal Velocity Command.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	<p>Internal Velocity Command limit [VCMMAX]</p> <p>In the cycle synchronous position (csp) or the profile position (pp) mode, Interpolated position (ip) the internal velocity command is limited.</p> <p>In the cycle synchronous velocity (csv) or the profile velocity (pv) mode, it is clamped at the setting value in response to the velocity command. Moreover, when</p> <p style="text-align: center;">Setting value = Velocity Command </p> <p>velocity-limit warning bit is set.</p> <p>■ When the setting value is 0 min⁻¹, or 50000 min⁻¹ or more, 0 min⁻¹ it is limited at 1.1 fold the highest rotation velocity of the motor (combining the velocity commands).</p> <p>* It works at the state that bit3 of control word (0x2000) is valid.</p>		Unsigned16	RW	No	0xFFFF (65535min ⁻¹) [65535mm/s]
			Setting range	0x0000 - 0xFFFF (0 - 65535min ⁻¹) [0 - 65535mm/s]		
			Unit	Rotary : min ⁻¹ [Linear : mm/s]		
		<p>⚠ The rotary motor differs from linear motor in unit.</p>				

0x201D: Position Command error 1 level

Index Ax1 Ax2 Ax3 Ax4	0x201D 0x221D 0x241D 0x261D	Position Command error 1 alarm detection level is set.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	<p>Position Command error 1 level [OVFSET]</p> <p>* Profile Position mode (pp)</p> <p>When the velocity-converted value of trajectory generation distance exceeds the setting value, alarm "D2" is detected.</p> <p>* Cycle synchronous position mode (csp), Interpolated position mode (ip)</p> <p>When the velocity-converted value of position command variation (the previous target position – the target position) exceeds the setting value, alarm "D2" is detected.</p> <p>* The weight treated inside the amplifier is set by the servo control cycle 125μs steps; therefore, please set it according to the following equation indicating the resulting value: Internal Unit [LSB] = 480000+1 rotary resolution [Pulse/sec]</p>		Unsigned32	RW	No	0xFFFFFFFF
			Setting range	0x1-0xFFFFFFFF (1 - 4294967295 p/s)		
			Unit	Pulse/sec		

0x201E: Sequence Operation Torque (force) Limit Value

Index Ax1 Ax2 Ax3 Ax4	0x201E 0x221E 0x241E 0x261E	Parameter to set the output torque (force) in Sequence Operation.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	<p>Sequence Operation Torque (force) Limit Value [SQTCML]</p> <p>This is Torque (force) Limit Value for the following sequence controls.</p> <p>* Sequence Operation Torque (force) Limit is adapted with "Quick stop operation," "Emergency Stop operation," as well as "Servo-braking operation," "JOG operation," "Forward/Reverse limit operations" at alarm occurrence, and "holding brake down time" when the servomotor is on.</p> <p>Moreover, when power lowering torque (force) limit selection (0x20F5) is "0x01," electric current is limited including this setting value.</p> <p>* Sets the limiting torque (force) by the ratio of rated output torque (force). (100.0%=rated torque (force))</p> <p>* When the value is set exceeding the Maximum instant stall torque (force) (T_P) of the combining servo motor, it is limited by the Maximum instant stall torque (force) (T_P) of the combining servo motor.</p> <p>* When overload 1 alarm occurs, it is limited to 120% in case a value of more than 120% is set.</p>		Unsigned16	RW	No	0x04B0 (120.0 %)
			Setting range	0x0064-0x1388 (10.0-500.0 %)		
			Unit	0.1 %		

5. Object Dictionary

0x201F: Near Range

Index Ax1 Ax2 Ax3 Ax4	0x201F 0x221F 0x241F 0x261F	A position range variation counter for positioning completion/ near range completion monitoring.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Near Range [NEAR] * Outputs Near range signal when the Position deviation counter is set lower than this set value. * Sets at the resolution of the encoder pulse Following Error Actual Value <= Setting value		Unsigned32	RW	No	0x01F4 (500 pulse)
			Setting range	0x00000000-0x7FFFFFFF (0-2147483647 Pulse)		
			Unit	1 Pulse		
When the actual position variation is greater than the setting value, it is output from near range completion monitor (NEAR monitor.)						

0x2020: Speed Zero Range

Index Ax1 Ax2 Ax3 Ax4	0x2020 0x2220 0x2420 0x2620	Setting value for detecting Zero-speed status (motor stop). Sets the allowable range at Zero-speed.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Speed Zero Range [ZV] Actual Velocity <= Setting value		Unsigned16	RW	No	0x0032 (50min ⁻¹) [50mm/s]
	When the Actual Velocity condition below the Setting value is continuously detected for 1ms or more, zero velocity monitor (ZV) is output. ⚠ The rotary motor differs from linear motor in unit.		Setting range	0x0005 - 0x01F4 (5 - 500min ⁻¹) [5 - 500mm/s]		
			Unit	Rotary : min ⁻¹ [Linear : mm/s]		

0x2021: Low Speed Range

Index Ax1 Ax2 Ax3 Ax4	0x2021 0x2221 0x2421 0x2621	Sets the acceptable Low Speed Range of the motor rotation speed.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Low Speed Range [LOWV] When the speed is lower than this value, Low speed range is output. Actual Velocity <= Setting value then LTG flag is set.		Unsigned16	RW	No	0x0032 (50min ⁻¹) [50mm/s]
			Setting range	0x0000 - 0xFFFF (0 - 65535min ⁻¹) [0 - 65535mm/s]		
			Unit	Rotary : min ⁻¹ [Linear : mm/s]		
<p style="text-align: center;"> speed ↑ ↓ "Low speed Range" setting value LTGDAT 1 0 1 </p> <p> ■ If Auto Tuning Mode setting is 0x01 and Auto Tuning Characteristics setting is 0x02, 50min⁻¹ will be set automatically. ⚠ The rotary motor differs from linear motor in unit. </p>						

5. Object Dictionary

0x2022: Speed Attainment Setting (High Speed Range)

Index Ax1 Ax2 Ax3 Ax4	0x2022 0x2222 0x2422 0x2622	Sets the speed attainment level of the motor rotation speed.	Object Code	Variable		
Sub-Idx 0x00	Speed Attainment Setting [VA] Used as arrival confirmation in response to a high-speed rotation command; When the speed exceeds this setting value, Speed attainment is output. Actual Velocity >= Setting value then VA flag is set.	Description	Data Type Unsigned16	Access RW	PDO No	Initial value 0x03E8 (1000min ⁻¹) [1000mm/s]
			Setting range	0x0000 - 0xFFFF (0 - 65535min ⁻¹) [0 - 65535mm/s]		
			Unit	Rotary : min ⁻¹ [Linear : mm/s]		
<p>■ While operating with torque (force) control mode, simple velocity control is exercised by this parameter. *when Motor speed exceeds this setting value, as the velocity sets at zero, control of unstable velocity cannot be exercised. Avoid the use of such status to continue. ⚠ The rotary motor differs from linear motor in unit.</p>						

5. Object Dictionary

0x2023: Analog Monitor Select Output

Index	Object Name	Description	Data Type	Access	PDO	Initial value
0x2023	0x2023	Selects the output selection and the polarization character of Analog Monitor 1, 2.				
0x00	Number of entry		Unsigned8	RO	No	0x03
0x01	Analog Monitor Select Output 1 [MON1] Select data to output from Analog Monitor 1.		Unsigned8	RW	No	0x05
		Setting range	0x01-0x24			
		<p>& Rotary motor</p> <p>0x00: Reserved (For maintenance by manufacturer)</p> <p>0x01: Torque (force) monitor 2V/ratedTorque (force)</p> <p>0x02: Torque (force) command monitor 2V/ratedTorque (force)</p> <p>0x03: Velocity monitor 0.2mV/min⁻¹</p> <p>0x04: Velocity monitor 1mV/min⁻¹</p> <p>0x05: Velocity monitor 2mV/min⁻¹</p> <p>0x06: Velocity monitor 3mV/min⁻¹</p> <p>0x07: Velocity command monitor 0.2mV/min⁻¹</p> <p>0x08: Velocity command monitor 1mV/min⁻¹</p> <p>0x09: Velocity command monitor 2mV/min⁻¹</p> <p>0x0A: Velocity command monitor 3mV/min⁻¹</p> <p>0x0B: Position deviation monitor 0.01mV/Pulse</p> <p>0x0C: Position deviation monitor 0.1mV/Pulse</p> <p>0x0D: Position deviation monitor 1mV/Pulse</p> <p>0x0E: Position deviation monitor 10mV/Pulse</p> <p>0x0F: Position deviation monitor 20mV/Pulse</p> <p>0x10: Position deviation monitor 50mV/Pulse</p> <p>0x11: Position command monitor1 2mV/kPulse/sec</p> <p>0x12: Position command monitor1 10mV/kPulse/s</p> <p>0x13: Position command monitor2 0.05mV/kPulse/s</p> <p>0x14: Position command monitor2 0.5mV/kPulse/s</p> <p>0x15: Position command monitor2 2mV/kPulse/s</p> <p>0x16: Position command monitor2 10mV/kPulse/s</p> <p>0x17: Load Torque (force) monitor 2V/ratedTorque (force)</p> <p>0x18: Phase U electrical angle monitor 8Vpeak</p> <p>0x19: Position command monitor1 0.05mV/kPulse/sec</p> <p>0x1A: Position command monitor1 0.5mV/kPulse/sec</p> <p>0x1B: Acceleration monitor 0.01mV/rad/sec²</p> <p>0x1C: Acceleration monitor 0.1mV/rad/sec²</p> <p>0x1D: Acceleration monitor 1mV/rad/sec²</p> <p>0x1E: Acceleration monitor 10mV/rad/sec²</p> <p>0x1F to 0xFF: reserved</p> <p>0x1F: Position Synchronization Deviation Monitor 0.01mV/Pulse</p> <p>0x20: Position Synchronization Deviation Monitor 0.1mV/Pulse</p> <p>0x21: Position Synchronization Deviation Monitor 1mV/Pulse</p> <p>0x22: Position Synchronization Deviation Monitor 10mV/Pulse</p> <p>0x23: Position Synchronization Deviation Monitor 20mV/Pulse</p> <p>0x24: Position Synchronization Deviation Monitor 50mV/Pulse</p> <p>0x25~0xFF: Reserved</p> <p>◆Position command monitor1 monitors position command pulse before position smoothing passing.</p> <p>◆Position command monitor2 monitors position command pulse after position smoothing passing.</p> <p>✓Position command pulse frequency monitor1 and 2 are output in the form of pulse when command pulse frequency is 10kHz or less.</p> <p>Average the frequency when converging to position command frequency.</p> <p>◆Torque(force)monitor, velocity monitor, and load torque monitor are placed the following low-path filters.</p> <p>Torque (force) monitor 250Hz, Velocity monitor 250Hz, Load torque monitor 20Hz</p>	<p>& Linear motor</p> <p>0x00: Reserved (For maintenance by manufacturer)</p> <p>0x01: Torque (force) monitor 2V/ratedTorque (force)</p> <p>0x02: Torque (force) monitor 2V/ratedTorque (force)</p> <p>0x03: Velocity monitor 0.2mV/mm/sec</p> <p>0x04: Velocity monitor 1mV/mm/sec</p> <p>0x05: Velocity monitor 2mV/mm/sec</p> <p>0x06: Velocity monitor 3mV/mm/sec</p> <p>0x07: Velocity command monitor 0.2mV/mm/sec</p> <p>0x08: Velocity command monitor 1mV/mm/sec</p> <p>0x09: Velocity command monitor 2mV/mm/sec</p> <p>0x0A: Velocity command monitor 3mV/mm/sec</p> <p>0x0B: Position deviation monitor 0.01mV/Pulse</p> <p>0x0C: Position deviation monitor 0.1mV/Pulse</p> <p>0x0D: Position deviation monitor 1mV/Pulse</p> <p>0x0E: Position deviation monitor 10mV/Pulse</p> <p>0x0F: Position deviation monitor 20mV/Pulse</p> <p>0x10: Position deviation monitor 50mV/Pulse</p> <p>0x11: Position command monitor1 2mV/kPulse/sec</p> <p>0x12: Position command monitor1 10mV/kPulse/s</p> <p>0x13: Position command monitor2 0.05mV/kPulse/s</p> <p>0x14: Position command monitor2 0.5mV/kPulse/s</p> <p>0x15: Position command monitor2 2mV/kPulse/s</p> <p>0x16: Position command monitor2 10mV/kPulse/s</p> <p>0x17: Load Torque (force) monitor 2V/ratedTorque (force)</p> <p>0x18: Phase U electrical angle monitor 8Vpeak</p> <p>0x19: Position command monitor1 0.05mV/kPulse/sec</p> <p>0x1A: Position command monitor1 0.5mV/kPulse/sec</p> <p>0x1B: Acceleration monitor 0.01mV/mm/sec²</p> <p>0x1C: Acceleration monitor 0.1mV/mm/sec²</p> <p>0x1D: Acceleration monitor 1mV/mm/sec²</p> <p>0x1E: Acceleration monitor 10mV/mm/sec²</p> <p>0x1F to 0xFF: reserved</p> <p>0x1F: Position Synchronization Deviation Monitor 0.01mV/Pulse</p> <p>0x20: Position Synchronization Deviation Monitor 0.1mV/Pulse</p> <p>0x21: Position Synchronization Deviation Monitor 1mV/Pulse</p> <p>0x22: Position Synchronization Deviation Monitor 10mV/Pulse</p> <p>0x23: Position Synchronization Deviation Monitor 20mV/Pulse</p> <p>0x24: Position Synchronization Deviation Monitor 50mV/Pulse</p> <p>0x25~0xFF: Reserved</p>			
0x02	Analog Monitor Select Output 2 [MON2] Selects the data to output from Analog Monitor 2. The setting value is the same as in Analog Monitor output selection 1.		Unsigned8	RW	No	0x02
		Setting range	0x01~0x24 (Rotary) 0x01~0x1E (Linear)			
0x03	Analog Monitor Output Polarity Selection [MONPOL] Selects the output polarity of analog monitor 1/2.		Unsigned8	RW	No	0x00
		Setting range	0x00-0x08			
<p>*For both MON1 and MON2, set from any of the followings: +No Polarity Rotation, - Polarity Rotation, ABS Absolute Value Output</p> <p>0x00:AMON1/AMON2 at positive rotation+voltage output/at positive rotation+output</p> <p>0x01:AMON1/AMON2 at positive rotation-voltage output/at positive rotation+output</p> <p>0x02:AMON1/AMON2 at positive rotation+voltage output/at positive rotation-output</p> <p>0x03:AMON1/AMON2 at positive rotation-voltage output/at positive rotation-output</p> <p>0x04:AMON1/AMON2 at positive/reverse rotations+voltage output (absolute value)/at positive rotation+output</p> <p>0x05:AMON1/AMON2 at positive/reverse rotations+voltage output (absolute value)/at positive rotation-output</p> <p>0x06:AMON1/AMON2 at positive rotation+output/at positive/reverse rotations+voltage output (absolute value)</p> <p>0x07:AMON1/AMON2 at positive rotation-output/at positive/reverse rotations+voltage output (absolute value)</p> <p>0x08:AMON1/AMON2 at positive/reverse rotations+voltage output (absolute value)/at positive/reverse rotations+voltage output (absolute value)</p> <p>0x09-0xFF:Reserved</p>						



5. Object Dictionary

About Holding Brake

Servo motor with Holding brake function is usually used with an axis that is always affected by gravity and external forces in order to avoid movable parts falling off from its position when main circuit power is OFF, or servo OFF.

Holding brake is to support the movable parts against gravity and other external force when at rest. Do not use it to stop a moving machine.

Holding brake ->



0x2024: Delay Time of Engaging Holding Brake

Index	Ax1	Ax2	Ax3	Ax4	Description	Object Code	Variable	
	0x2024	0x2224	0x2424	0x2624	Sets holding-brake-activation delay time from when power distribution to holding brake stopped till when holding torque generated.			
Sub-Idx	Description				Data Type	Access	PDO	Initial value
0x00	Delay Time of Engaging Holding Brake [BONDLY]				Unsigned16	RW	Possible	0x01C2 (300ms)
	* While shifting from servo ON to servo OFF, during the setting time, Excitation command 0 is given to servo motor. (Even when servo is turned OFF, power is supplied to the motor until the setting time is over.)				Setting range	0x0000-0x03E8 (0-1000ms)		
					Unit	ms		
By this, until Holding brake functions, servo motor generates Holding torque (force). * This is valid when servo brake operation at servo OFF condition is set in the "dynamic brake operation setting" (This does not function in the dynamic brake operation and the free-run operation.) * When the setting value is 0ms, after servo OFF, command is invalid (command 0) for approximately 4ms. * Because the setting unit is valid in 4ms steps, the remainder, divided by 4, is cut off inside the amplifier. * RF2 series servo amplifier does not have dynamic brake circuit. So, it will be Free Run Stop if dynamic brake operation is set.								

0x2025: Delay Time of Releasing Holding Brake (Holding Brake Releasing Delay time)

Index	Ax1	Ax2	Ax3	Ax4	Description	Object Code	Variable	
	0x2025	0x2225	0x2425	0x2625	Sets holding-brake-release delay time from when power distribution to holding brake started till when holding torque disappeared.			
Sub-Idx	Description				Data Type	Access	PDO	Initial value
0x00	Delay Time of Releasing Holding Brake [BOFFDLY]				Unsigned16	RW	No	0x01C2 (300ms)
	* While shifting from servo OFF to servo ON, during the setting time, Excitation command 0 is given to servo motor.				Setting range	0x0000-0x03E8 (0-1000ms)		
					Unit	ms		
(Even when servo is turned ON, command is not accepted until the setting time is complete.) * Therefore, until Holding brake is released, servo motor does not operate. * When the setting value is 0ms, after servo ON, command is invalid (command 0) for approximately 4ms. * Because the setting unit is valid in 4ms steps, the remainder, divided by 4, is cut off inside the amplifier.								

5. Object Dictionary

0x2026: BRAKE OPERATION BEGINNING TIME

Index Ax1 Ax2 Ax3 Ax4	0x2026 0x2226 0x2426 0x2626	Parameter to compulsorily set the time to operate the Dynamic brake and the Holding brake when motor does not stop at Servo OFF and EMR upon entry.	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Brake Operation Beginning Time [BONBGN] Sets permissible time from servo OFF until servo motor stop. * At the time of Quick Stop operation, Emergency Stop (EMR), Servo brake stop alarm occurrence, if motor velocity does not reach less than 50min ⁻¹ , it signals the Dynamic brake operation and the Holding brake operation that are then output and motor excitation is discharged. * This is the limit when, if the speed is not zero at the setting time after the transition from servo ON to servo OFF (ex. when the motor does not stop after servo OFF at the gravity axis etc.,) the Holding brake and the Dynamic brake operate and compulsorily brake. * If the servo motor velocity reaches below 0x202F Brake Activation Speed within the set time, this function does not operate. * When forced to stop by Holding brake, the Holding brake may possibly be broken. Be cautious about device specifications and sequence when using this function. * RF2 series servo amplifier does not have dynamic brake circuit. So, it will be Free Run Stop during dynamic brake operation.	Unsigned16	RW	Possible	0x2710 (10sec)
		Setting range	0x0000-0xFFFF (0-65535ms)		
		Unit	ms		

0x2027: Power Failure Detection Delay Time

Index Ax1 Ax2 Ax3 Ax4	0x2027 0x2227 0x2427 0x2627	Sets the delay time from Control power OFF to Control power error detection.	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Power Failure Detection Delay Time [PFDDL] * By making the setting value greater, delay in alarm detection time is possible. However, this does not guarantee the retention of Control power until the setting time. * When power source of the control logic expires, it operates the same as when Control power is interrupted. When the Main circuit power reaches a lower point than Control power, other alarms may occur. * In case of power failure of Internal logic circuit, operation is same as when Control power is turned ON again. In case of energy shortage of Main circuit power, other errors such as Main circuit power loss may be detected. * In this setting, actual detection delay time varies by -12ms - +6ms.	Unsigned16	RW	No	0x0020 (32ms)
		Setting range	0x0014-0x03E8 (20-1000ms)		
		Unit	ms		

0x2028: Excessive Deviation Warning Level

Index Ax1 Ax2 Ax3 Ax4	0x2028 0x2228 0x2428 0x2628	Sets Warning output level before Excessive position deviation alarm is output.	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Excessive Deviation Warning Level [OFWL] When the actual deviation exceeds the setting value, within the range relatively regarded as warning against the position, Excessive Deviation Warning engages. Following Error Actual Value >= Setting value	Unsigned32	RW	No	0x7FFFFFFF (2147483647Pulse)
		Setting range	0x00000001~0x7FFFFFFF (1-2147483647 Pulse)		
		Unit	Pulse		

Positioning completion range -> See Position Deviation Window (0x6065 of the function group "position".)

0x2029: Overload Warning Level

Index Ax1 Ax2 Ax3 Ax4	0x2029 0x2229 0x2429 0x2629	Parameter to output Warning before detecting the Overload warning.	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Overload Warning Level [OLWL] * the allowable setting Level range is as follows (the Overload warning level =100%;) Setting value < 20% or 100% >= Setting value When set to 100%, Overload warning and Overload alarm are output at one time. * Overload detection is assumed and set as 75%, of a rated load when Control power is turned ON (hot start). This is to prevent motor damage due to the estimation value reset by power re-closing and operation resumption immediately after the occurrence of Overload alarm when it is set at 0%. Therefore, when Overload warning level is set at 75% or less, Overload warning may be output when Control power is turned ON.	Unsigned16	RW	No	0x005A (90%)
		Setting range	0x0014-0x0064 (20-100 %)		
		Unit	%		

5. Object Dictionary

0x202A: Speed Matching Width (Velocity matching range rate)

Index Ax1 Ax2 Ax3 Ax4	0x202A 0x222A 0x242A 0x262A	Sets the ratio [%] of the range regarded as velocity matching against velocity commands. This value setting is used when "Speed Matching unit selection" is "0x01_Percent."	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Speed Matching Width [VCMPR] Velocity matching is output when the Velocity deviation (difference between the velocity command and actual velocity) is within this setting range. Actual Velocity <= Setting value then VCMP monitor is set.	Unsigned16	RW	No	0x0032 (5.0 %)
		Setting range	0x0000-0x03E8 (0-100%)		
		Unit	0.1 %		
<p>*The Velocity matching output is switched by the setting of rotation speed (min^{-1}) and ratio (%) at Velocity matching unit output selection (0x20F0.4). At ratio selection, the condition under this setting value can be monitored with the status word 1(0x2100) bit 10: Velocity matching monitor.</p>					

0x202B: Torque (force) Command Filter Characteristic

Index Ax1 Ax2 Ax3 Ax4	0x202B 0x222B 0x242B 0x262B	The filter order is set at Torque (force)command filter	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Torque (force) Command Filter Characteristic [TCFILOR] If the cutoff frequency of the torque (force) order filter is switched with the gain switch, the order is fixed at this setting value.	Unsigned8	RW	No	0x02
		Setting range	0x01-0x03		
<p>0x01: <u>primary Filter</u> 0x02: <u>secondary Filter</u> 0x03: <u>tertiary Filter</u> 0x00, 0x04-0xFF: <u>Reserved</u></p>					

0x202C: Feed Forward Filter, Depth Selection (FF Vibration Suppressor Level Selection)

Index Ax1 Ax2 Ax3 Ax4	0x202C 0x222C 0x242C 0x262C	Sets the characteristics of 0x2012 Feed Forward vibration suppressor frequency in operation.	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Feed Forward Filter, Depth Selection [SUPLV] Parameter to set the magnitude of the vibration suppressor frequency effect.	Unsigned8	RW	No	0x00
		Setting range	0x00-0x03		
<p>* Change while servo motor is OFF. * The smaller the value, the greater the effect will be. * FF vibration suppressor frequency switching function does not affect this.</p> <p>0x00: <u>-∞</u> 0x01: <u>-30dB</u> 0x02: <u>-20dB</u> 0x03: <u>-10dB</u> 0x04-0xFF: <u>Reserved</u></p>					

5. Object Dictionary

0x202E: Torque (force) attainment setting

Index Ax1	0x202E	Sets detection level of torque attainment monitor (a function to detect that commanded internal torque value exceeds set value).	Object Code	Variable		
Ax2	0x222E					
Ax3	0x242E					
Ax4	0x262E					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Torque (force) attainment setting [TA] Sets the ratio of torque (force) attainment. Data subjected to the ratio set by this parameter vary depending on torque (force) attainment function selection (0x20F4.6). Sets flag TA (bit11 of 0x2100) in the following case: Torque (force) command >= Set value ✓ Torque (force) attainment output switches between maximum motor torque ratio and limited torque ratio depending on function selection of torque (force) attainment (0x20F0.6). ◆ Function selection of torque (force) attainment (0x20F0.6): In the case of 0x00 Sets the ratio of torque (force) attainment level by using the ratio to motor rated torque (force). "100.0% = rated torque (force)" Torque (force) attainment level is the same value in both forward and reverse direction. Bit 11, output at torque (force) attainment OD:2100 is set to "1" when torque (force) command exceeds torque (force) attainment level.		Unsigned16	RW	No	0x03E8 (100%)
			Setting range	0x0000 - 0x1388 (0.0 - 500.0%)		
			Unit	0.1 %		
		◆ Function selection of torque (force) attainment (0x20F0.6): In the case of 0x01 Sets the ratio of torque (force) attainment level by using the ratio to limited torque (force) value. "100.0% = rated torque (force)" Torque (force) attainment level is also independently calculated for both forward and reverse direction respectively in amplifier, as limited torque (force) value is independent in both directions respectively. $\text{Forward torque (force) attainment level} = \text{Limited forward torque (force) value} \times \text{set value} / 100.0 \text{ [%]}$ $\text{Reverse torque (force) attainment level} = \text{Limited reverse torque (force) value} \times \text{set value} / 100.0 \text{ [%]}$				
		Detection shall be independently performed in both forward and reverse direction, and if the first one commanded torque (force) value in either direction exceeds torque (force) attainment level, Bit11, output at torque (force) attainment OD:2100, is set to "1."				

5. Object Dictionary

0x202F: Brake activation speed

Index Ax1	0x202F	Set the brake activation speed when decelerating motor. It works while running servo-brake.	Object Code		Variable	
Ax2	0x222F					
Ax3	0x242F					
Ax4	0x262F					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Brake activation speed [ZVDAT] Motor brake works at lower rotation speed than set value with condition below. Quick Stop, Alarm, Emergency Stop. Motor stop will detect when relation below continued 1 msec or more. Absolute value of actual speed \leq Set value Holding brake signal will provide after detecting motor stop. ✓ DDM (Direct Drive Motor) has different setting range conversion below. 0x000A~0x01F4 --> 1 to 50.0min ⁻¹ (0.1min ⁻¹ /lsb)		Unsigned16	RW	Possible	0x32 (50min ⁻¹)
			Setting range	0x000A~0x01F4 (10~500min ⁻¹)		
			Unit	min ⁻¹		

0x2030: Position Loop Integral Gain Limit

Index Ax1	0x2030	Set the limit of Position Loop Integral Gain	Object Code		Variable	
Ax2	0x2230					
Ax3	0x2430					
Ax4	0x2630					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Limit value of position integral time constant 1 (TPI1). If setting value of position integral time constant is lower than this setting value. Position integral time constant use this setting value.		Unsigned16	RW	Possible	0x2710
			Setting range	0x0003~0x2710 (0.3~1000)		
			Unit	0.1ms		

0x2031: Velocity Control Integral Gain Limit

Index Ax1	0x2031	Set the Velocity Control Integral Gain Limit.	Object Code		Variable	
Ax2	0x2231					
Ax3	0x2431					
Ax4	0x2631					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Limit value of velocity integral time constant 1 (TVI1). If setting value of velocity integral time constant is lower than this setting value. Velocity integral time constant use this setting value.		Unsigned16	RW	Possible	0x0003
			Setting range	0x0003~0x2710 (0.3~1000)		
			Unit	0.1ms		

0x2032: Torque (force) control proportional gain

Index Ax1	0x2032	Set the Torque (force) control proportional gain.	Object Code		Variable	
Ax2	0x2232					
Ax3	0x2432					
Ax4	0x2632					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Proportional gain of Torque (force) control mode. Torque (force) control proportional gain is set from desired percentage of default torque gain. Setting range is from 50 to 140%, and higher the set value increase the proportional gain.		Unsigned8	RW	No	0x64
			Setting range	0x32~0x8C (50 ~ 140)		
			Unit	%		

0x2034: Low Pass Filter OFF Velocity for Position loop / Velocity loop command.

Index Ax1	0x2034	Set the Low Pass Filter OFF Velocity.	Object Code		Array	
Ax2	0x2234					
Ax3	0x2434					
Ax4	0x2634					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x02
0x01	Switch ON / OFF of the object. This object become active by setting 1 to Sub-Idx :0x01.		Unsigned8	RW	Possible	0x00
			Setting range	0x00-0x01		
0x02	Low Pass Filter OFF Velocity Disable low pass filter at less than this velocity. Setting range is from 0 to 50 rpm.		Unsigned16	RW	Possible	0x0000
			Setting range	0x0000-0x0032		
			Unit	min ⁻¹		
Disable low pass filter for Position/ Velocity command at less than the value set at Sub-Idx2. Cutting off is performed with the value in 0x2004 or 0x2009, while position/velocity command low pass filter is effective.						

5. Object Dictionary

0x2035: Assist-Function Parameter

Sub-Idx	Description	Data Type	Access	PDO	Initial value
Index Ax1 0x2035 Ax2 0x2235 Ax3 0x2435 Ax4 0x2635	The parameter which sets for use of assist function between amplifier 1 to 4.		Object Code		Record
0x00	Number of entry	Unsigned8	RO	No	0x06
0x01	Correction Proportional Gain [KSCP] When the position-assist correction is enabled and the set value is 100%, add the same value as assist deviation value (error pulse volume) to the position command. Correction will be invalid at the set value 0%. ✔If the value is too large, a vibration may occur.	Unsigned8	RW	No	0x0064 (100%)
		Setting Range	0x0000~0x03E8 (0-1000%)		
		Unit	%		
0x02	Correction Integral Time Constant [TSCI] Sets integral time constant of position-assist controller. When the set value is 1000.0ms, the proportional control (without integral compensation) is activated. ✔If the value is too small, a vibration may occur. ✔When 2 sets of amplifiers are mutually corrected their synchronizations, set correction integral time constant at 1000ms (invalid).	Unsigned16	RW	No	0x2710 (1000ms) Proportional Control
		Setting Range	0x0005-0x2710 (0.5-1000.0ms)		
		Unit	0.1ms		
0x03	Correction Low-pass Filter [PSYNLPPF] Sets time constant of the first low-pass filter which suppresses any sudden change in the correction command pulses. Filter will be invalid at the set value 0.0 ms.	Unsigned16	RW	No	0x0000(0.0 ms) Invalid Filter
		Setting Range	0x0000-0x2710 (0.0-1000.0 ms)		
		Unit	0.1 ms		
0x04	Excessive Position-assist Deviation Level [PSDEVAL] Sets acceptable error range for error pulse quantity (synchronization deviation) of 2 amplifiers. When the actual synchronization position deviation exceeds the set value, a position synchronization deviation alarm is issued. Setup Value \leq Synchronization Error Pulse Quantity	Unsigned32	RW	No	0x7FFFFFFF(2147483647)
		Setting Range	0x00000001-0x7FFFFFFF (1-2147483647 Pulse)		
		Unit	Pulse		
0x05	Position-assist Deviation Warning Level [PSDEVWN] Sets Warning output level before Excessive position-assist deviation alarm is issued. When the actual synchronization position deviation exceeds the set value, position synchronization deviation warning is issued. Setup Value \leq Synchronization Error Pulse Quantity	Unsigned32	RW	No	0x7FFFFFFF (2147483647)
		Setting Range	0x00000001-0x7FFFFFFF (1-2147483647 Pulse)		
		Unit	Pulse		
0x06	Position Deviation Polarity Slection [SDEVPOR] Selects polarity of position deviation signal which is sent to another amplifier for position-assist. ✔Regarding command polarity and motor installation angle, set position deviation polarity selection in order to have the same output deviation polarity. ⚡It will be valid with control-power-source re-input.	Unsigned8	RW	No	0x00
		Setting Range	0x00-0x01 0:Without Position Deviation Polarity Reversal 1:With Position Deviation Polarity Reversal		
0x07	Assist-target axis address [MSTERID] Set the address of target axis if sync compensation function is used. ⚡It will be valid with control-power-source re-input.	Unsigned16	RW	No	0x0001
		Setting Range	0x0001-0x0004		
0x08	Assist-function selection [ASSEL] 0x00: Without sync. 0x01: Mutual assisting correction mode, Master mode 0x02: Mutual assisting correction mode, Slave mode 0x03: Master amplifier mode 0x04: Slave amplifier mode 0x05: Master amplifier mode 0x06: Slave amplifier mode (Position-assist function : Position control) (Position-assist function : Position control) (Position-assist function, Master : Position control) (Position-assist function, Slave : Position control) (Torque-assist function : Position control, Velocity control) (Torque-assist function : Torque control)	Unsigned8	RW	No	0x00
		Setting Range	0x00-0x06		
		Unit	-		
0x09	Torque assisting rate [TSCP] When the torque-assist function is enabled and the set value is 100%, add the same value of torque command. Torque-assist will be invalid at the set value 0%.	Unsigned16	RW	Possible	0x0064 (100%)
		Setting Range	0x0000-0x0064 (0-100%)		
		Unit	%		

5. Object Dictionary

0x2036: Position Differential Gain

Index Ax1	0x2036	Sets the differential time constant of the position controller.	Object Code	Variable	
Ax2	0x2236				
Ax3	0x2436				
Ax4	0x2636				
Sub-Idx	Description				Data Type
0x00	Number of entry	Unsigned8	RO	No	0x02
0x01	Position Controller Differential Time Constant The position control characteristic is improved by multiplying the difference of the position differential by the gain equivalent to the derivation time constant. This function will be disabled during auto-tuning.	Unsigned16	RW	Possible	0x0000 (0)
		Setting Range	0x0000 to 0x2710 (0.0 to 1000.0)		
		Unit	0.1ms		
0x02	Position Controller Derivative Compensation LPF LPF to be applied to the command value after setting the position differential time constant. Improves the position differential command value. This function will be disabled during auto-tuning.	Unsigned16	RW	Possible	0x0FA0 (4000)
		Setting Range	0x0001 to 0x0FA0 (1 to 4000)		
		Unit	Hz		

0x2037: Position Integral Time Constant Limit

Index Ax1	0x2037	Sets the velocity to limit the integral output of the position controller.	Object Code	Variable	
Ax2	0x2237				
Ax3	0x2437				
Ax4	0x2637				
Sub-Idx	Description				Data Type
0x00	Output limit of the position controller Disables the integral time constant of the position controller. When the motor velocity exceeds the setting value, it disables the position integral time constant. This function will be disabled during auto-tuning.	Unsigned32	RW	Possible	0x3FFFFFFF (1073741823)
		Setting range	0x00000000 to 0x7FFFFFFF (0 to 2147483647)		
		Unit	pulse		

0x2038: Velocity Control Bypass Setting

Index Ax1	0x2038	Bypasses the velocity controller during position control.	Object Code	Variable	
Ax2	0x2238				
Ax3	0x2438				
Ax4	0x2638				
Sub-Idx	Description				Data Type
0x00	Bypass of Velocity Controller Transmits the command from the position controller to the torque (force) control without the velocity controller. The setting value 0 disables the function. The setting value 1 enables the function.	Unsigned8	RW	Possible	0x00
		Setting range	0x00-0x01		

0x2039: Velocity Integral Time Constant Limit

Index Ax1	0x2039	Sets the torque (force) to limit the integral output of the velocity controller.	Object Code	Variable	
Ax2	0x2239				
Ax3	0x2439				
Ax4	0x2639				
Sub-Idx	Description				Data Type
0x00	Output limit of the velocity controller Disables the integral time constant of the velocity controller. When the motor torque (force) exceeds the setting value or more, it disables the position integral time constant. This function will be disabled during auto-tuning.	Unsigned16	RW	Possible	0xFFFF (65535)
		Setting range	0x0000~0xFFFF (0 ~ 65535)		
		Unit	min-1		

0x203A: Torque (force) Integral Gain

Index Ax1	0x203A	Sets the integral gain of the torque (force) controller.	Object Code	Variable	
Ax2	0x223A				
Ax3	0x243A				
Ax4	0x263A				
Sub-Idx	Description				Data Type
0x00	Torque (force) Control Integral Gain Sets the integral gain of the torque (force) control by using the ratio. Against the integral gain output by each motors is 100%, it can be adjusted within the range of 50% - 200%. This function will be disabled during auto-tuning.	Unsigned8	RW	Possible	0x64
		Setting range	0x32~0xC8 (50 ~ 200)		
		Unit	%		

5. Object Dictionary

0x203B: Torque (force) Integral Gain limit

Index Ax1 Ax2 Ax3 Ax4	0x203B 0x223B 0x243B 0x263B	Sets the limit value of the integral gain of the torque (force) controller.	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Torque (force) Control Integral Gain Limit Limits the setting of gain within the range of 50% - 200% against the value of the object 0x203A. Cuts the large value of the setting by the limit value.	Unsigned8	RW	Possible	0xC8 (200)
		Setting range	0x32~0xC8 (50 ~ 200)		
		Unit	%		

0x203C: Software limit Deceleration

Index Ax1 Ax2 Ax3 Ax4	0x203C 0x223C 0x243C 0x263C	Sets the deceleration in the case that it reaches the software limit switch in CSP, IP mode.	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Software Limit Deceleration [SLTDEC] When it reaches the software position limit of 0x607D, the motor will perform a deceleration stop. This parameter sets the deceleration.	Unsigned32	RW	No	0xFFFFFFFF
		Setting range	0x00000000~0xFFFFFFFF		

0x203D: Amplifier temperature warning level

Index Ax1 Ax2 Ax3 Ax4	0x203D 0x223D 0x243D 0x263D	Sets the warning output level which is issuing before the amplifier temperature error.	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x01	Amplifier temperature warning high level setting [DEGWHL] Sets high level of the amplifier temperature warning detection. When this set value is more than the object 0x2109 "Temperature inside the servo amplifier", sets Bit0 (tpw)=1 "Temperature warning bit" to the object 0x2103. And, when Bit0=1 is set to the object 0x2103-02 "Warning mask selection", also Bit7 "Warning status" of the object 0x6041 "Status word" is set. 0x203D-01 "Amplifier temperature warning high level setting" \leq 0x2109 "Temperature inside the servo amplifier" ✓Temperature warning will be set even if internal temperature value is less than this set value, when condition of 0x203D-02 is satisfied. ✓When this parameter sets to 95°C, amplifier temperature warning will issue at same timing of amplifier temperature error.	Signed16	RW	No	0x4B(75°C)
		Display range	0x038 to 0x005F (56 to 95°C)		
		Unit	°C		
0x02	Amplifier temperature warning low level setting [DEGWLL] Sets low level of the amplifier temperature warning detection. When this set value is less than the object 0x2109 "Temperature inside the servo amplifier", sets Bit0 (tpw)=1 "Temperature warning bit" to the object 0x2103. And, when Bit0=1 is set to the object 0x2103-02 "Warning mask selection", also Bit7 "Warning status" of the object 0x6041 "Status word" is set. 0x203D-01 "Amplifier temperature warning low level setting" \geq 0x2109 "Temperature inside the servo amplifier" ✓Temperature warning will be set even if internal temperature value is more than this set value, when condition of 0x203D-01 is satisfied. ✓When this parameter sets to -15°C, amplifier temperature warning will issue at same timing of amplifier temperature error.	Signed16	RW	No	0xFFF6(-10°C)
		Display range	0xFFFF to 0xFFF1(-1 to -15°C)		
		Unit	°C		

5. Object Dictionary


0x2040 Command Filter Setting

Index Ax1 0x2040 Ax2 0x2240 Ax3 0x2440 Ax4 0x2640		Sets Velocity Command Filter and Torque(force) Command Filter1~4 functions.	Object Code		Variable	
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x02
0x01	Sets Velocity Command Filter Sets Velocity Command Filter object 0x2041 valid or invalid. When valid filter work by 0x2041 setting.		Unsigned8	RW	Possible	0x00
			Setting range	0x00~0x01		
		<u>0: Velocity Command Filter disabled</u> <u>1: Velocity Command Filter enabled</u>				
0x02	Torque(force) Command Filter Sets Torque(force) Command Filter object 0x2042~0x2045 valid or invalid. When valid filter work by 0x2041~0x2045 setting.		Unsigned8	RW	Possible	0x01
			Setting range	0x00~0x01		
		<u>0: Torque(force) Command Filter1~4 disabled</u> <u>1: Torque(force) Command Filter1~4 enabled</u>				

0x2041: Velocity Command Filter Setting, 0x2042-0x2045: Torque(force) Command Filter1 – 4 Setting

Index Ax1 0x2040-0x2045 Ax2 0x2240-0x2245 Ax3 0x2440-0x2445 Ax4 0x2640-0x2645		Sets Velocity Command Filter [VCNFIL], Torque (force) Command Filter.	Object Code		Array	
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x10
0x01	Filter ON/OFF Sets filter ON or OFF. The initial value of 0x2045 is effective.		Integer8	RW	Possible	0x00 (0x01)
			Setting range	0x00-0x01		
0x02	FilterType Sets type of filter The initial value of 0x2045 is 0x01:Low Pass Filter.		Integer8	RW	Possible	0x04 (0x01)
			Setting range	0x01-0x05		
		<u>0x01:Low Pass Filter</u> <u>0x04:Notch Filter</u> <u>0x02:High Pass Filter</u> <u>0x05:Bi-quad Filter</u> <u>0x03:Band Pass Filter</u> <u>0x06-0xFF:Reserved</u>				
0x03	Low Pass Filter cutoff frequency When filter type (Sub-Idx2) sets Low Pass Filter (0x01), Low Pass Filter work by this cutoff frequency. ✔When sets over 2000Hz (0x07D0) then setting become disable.		Unsigned16	RW	Possible	0x0258 (600Hz)
			Setting range	0x000A-0x07D0 (10-2000Hz)		
0x04	High Pass Filter cutoff frequency When filter type (Sub-Idx2) sets High Pass Filter (0x02), High Pass Filter work by this cutoff frequency. ✔When sets over 2000Hz (0x07D0) then setting become disable.		Unsigned16	RW	Possible	0x07D0 (invalid)
			Setting range	0x000A-0x07D0 (10-2000Hz)		
0x05	Center frequency of Band Pass Filter When filter type (Sub-Idx2) sets Band Pass Filter (0x03), Band Pass Filter work by this center frequency. When sets over 2000Hz (0x07D0) then setting become disable.		Unsigned16	RW	Possible	0x07D0 (2000Hz)
			Setting range	0x000A-0x07D0 (10-2000Hz)		
0x06	Band width of Band Pass Filter When filter type (Sub-Idx2) sets Band Pass Filter (0x03), Band Pass Filter work by this band width. Setting value small become band width narrow. Gain [dB]		Unsigned16	RW	Possible	0x0005
			Setting Range	0x0001~0x01F4 (0.1-50)		
		Example of setting value vs band width. Magnification from center frequency(fn)				

5. Object Dictionary

0x07	Center frequency of Notch Filter When filter type (Sub-Idx2) sets Notch Filter(0x04), Notch Filter work by this center frequency.. ✓When sets over 2000Hz(0x07D0), then setting become invalid.	Unsigned16	RW	Possible	0x07D0 (2000Hz)
		Setting range	0x000A-0x07D0 (10-2000Hz)		
0x08	Band width of Notch Filter When filter type (Sub-Idx2) sets Notch Filter(0x04), Notch Filter work by this Band width. Setting value small become band width narrow. 	Unsigned16	RW	Possible	0x0010
		Setting range	0x0001-0x01F4 (0.1-50) 0.1 / LSB		
		Setting value	f1	f2	
		0.1	$fn \times 0.95$	$fn \times 1.05$	
		0.2	$fn \times 0.90$	$fn \times 1.11$	
		0.4	$fn \times 0.82$	$fn \times 1.22$	
		0.6	$fn \times 0.74$	$fn \times 1.35$	
		0.8	$fn \times 0.67$	$fn \times 1.49$	
		1.0	$fn \times 0.62$	$fn \times 1.63$	
		1.2	$fn \times 0.57$	$fn \times 1.77$	
		1.4	$fn \times 0.52$	$fn \times 1.94$	
		1.6	$fn \times 0.48$	$fn \times 2.08$	
		1.8	$fn \times 0.44$	$fn \times 2.25$	
		2.0	$fn \times 0.41$	$fn \times 2.42$	
		5.0	$fn \times 0.19$	$fn \times 5.18$	
		10.0	$fn \times 0.098$	$fn \times 9.66$	
		20.0	$fn \times 0.050$	$fn \times 17.1$	
30.0	$fn \times 0.033$	$fn \times 22.2$			
40.0	$fn \times 0.025$	$fn \times 25.6$			
50.0	$fn \times 0.020$	$fn \times 28.1$			
Example of setting value vs band width. Magnification from center frequency(fn)					
0x09	Bi-quad Filter a1 When filter type (Sub-Idx2) sets Bi-quad Filter(0x05), Bi-quad Filter work by this a1.	Float32	RW	Possible	0.0
		Setting range	-3.402823e38 to 3.402823e38		
0x0A	Bi-quad Filter a2 When filter type (Sub-Idx2) sets Bi-quad Filter(0x05), Bi-quad Filter work by this a2.	Float32	RW	Possible	0.187561
		Setting range	-3.402823e38 to 3.402823e38		
0x0B	Bi-quad Filter b0 When filter type (Sub-Idx2) sets Bi-quad Filter(0x05), Bi-quad Filter work by this b0.	Float32	RW	Possible	0.296890
		Setting range	-3.402823e38 to 3.402823e38		
0x0C	Bi-quad Filter b1 When filter type (Sub-Idx2) sets Bi-quad Filter(0x05), Bi-quad Filter work by this b1.	Float32	RW	Possible	0.593780
		Setting range	-3.402823e38 to 3.402823e38		
0x0D	Bi-quad Filter b2 When filter type (Sub-Idx2) sets Bi-quad Filter(0x05), Bi-quad Filter work by this b2.	Float32	RW	Possible	0.296890
		Setting range	-3.402823e38 to 3.402823e38		

5. Object Dictionary

0x2050 Stick Motion compensation

Index Ax1 Ax2 Ax3 Ax4	0x2050 0x2250 0x2450 0x2650	Setting of Stick Motion compensation	Object Code		Variable	
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Number of entry		Unsigned8	RO	No	0x04
0x01	Set the validity of Stick Motion compensation [STC] <ul style="list-style-type: none"> ◆ Setting validity condition of Stick Motion compensation Stick Motion compensation is enable when STC is enable. ◆ Setting range of Stick Motion compensation will follow 0x00~0x27. 		Unsigned8	RW	Possible	0x00
			Setting range	0x00-0x27		
0x02	Valid speed of Stick Motion compensation [STV] <ul style="list-style-type: none"> ◆ Stick Motion compensation will work when setting value is less than internal velocity command. 		Unsigned16	RW	Possible	10.0
			Setting range	0.1-128.0		
			Unit	min ⁻¹		
0x03	Valid time of Stick Motion compensation [STHLD] <ul style="list-style-type: none"> ◆ Stick Motion compensation will work until this setting time, even if internal velocity command is over speed. ◆ If velocity loop response is low , set the this time longer. 		Unsigned16	RW	Possible	20
			Setting range	1-500		
			Unit	ms		
0x04	Set the integral constant of Stick Motion compensation [STTVI] <ul style="list-style-type: none"> ◆ Vaild velocity loop integral constant when Stick Motion compensation is activating. ◆ Velocity loop integral constant of Stick Motion compensation should set lower than normal setting. If set higher than normal value, efficiency will low. ◆ Stick Motion compensation will disable when velocity loop is proportional control. 		Unsigned16	RW	Possible	0.3
			Setting range	0.3-1000.0		
			Unit	ms		

0x2051: Micro Vibration Suppression

Index Ax1 Ax2 Ax3 Ax4	0x2051 0x2251 0x2451 0x2651	Suppress mechanical micro vibration by moving encoder pulse when motor stop.	Object Code		Variable	
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Set the validity of Micro Vibration Suppression [FBHYST] <ul style="list-style-type: none"> ◆ Suppress mechanical micro vibration when motor stop and encoder pulse moving ± 1 pulse ◆ Micro Vibration Suppression will valid when FBHYST is valid. ◆ Setting range of Micro Vibration Suppression will follow 0x00 to 0x27. 		Unsigned8	RW	No	0x00
			Setting range	0x00-0x27		

5. Object Dictionary

0x5080: Correction Table Control

Index Ax1 Ax2 Ax3 Ax4	0x5080 0x5280 0x5480 0x5680	Enables/disables the correction table function.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Correction Table Control [COTBLEN] Enables/disables the correction table function.		Unsigned8	RW	No	0x00
			Setting range	0x00-0x01		
	<u>0x00: Disabled</u> <u>0x01: Enabled</u> <u>0x02 - 0xFF: Reserved</u>					

0x5081: Correction Table Interpolation Method

Index Ax1 Ax2 Ax3 Ax4	0x5081 0x5281 0x5481 0x5681	Sets the interpolation method of the correction table.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Correction Table Interpolation Method [COTBLINTP] Sets the interpolation method of the correction table.		Unsigned8	RW	No	0x00
			Setting range	0x00-0x02		
	<u>0x00: Linear</u> <u>0x01: Polynomial</u> <u>0x02: Spline</u> <u>0x03 - 0xFF: Reserved</u>					

0x5082: Correction Table Extrapolation Method

Index Ax1 Ax2 Ax3 Ax4	0x5082 0x5282 0x5482 0x5682	Sets the extrapolation method of the correction table.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Correction Table Extrapolation Method [COTBLEXP] Sets the extrapolation method of the correction table.		Unsigned8	RW	No	0x00
			Setting range	0x00-0x02		
	<u>0x00: Linear</u> <u>0x01: Polynomial</u> <u>0x02: Spline</u> <u>0x03 - 0xFF: Reserved</u>					

0x5083: Correction Table Position

Index Ax1 Ax2 Ax3 Ax4	0x5083 0x5283 0x5483 0x5683	Correction Table Position	Object Code	Record		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RW	No	0x00
	✓This becomes valid by re-closing the control source.		Setting range	0x00-0x40		
0x01	Entry 1 Correction Position 1		Unsigned32	RW	No	0x00000000
			Setting range	0x00000000-0xFFFFFFFF		
			Unit	Pulse		
	<ul style="list-style-type: none"> ✓ If correction position over the coordinate axes (-1⇔0), 0x5083 correction position 1 and 0x5084 No1 offset value need to set 0. Caution, if not 0, the machine may oscillate at the correction position over the coordinate axes. ✓This becomes valid by re-closing the control source. 					
0x02 ~ n	Entry 2 to n Correction Position 2 to n		Unsigned32	RW	No	0x00000000
			Setting range	0x00000000-0xFFFFFFFF		
			Unit	Pulse		
	<ul style="list-style-type: none"> ✓"n" is up to 0x40 in maximum. ✓Please set so as to ensure that the correction position n-1 < the correction position n. (n=2-64) If not correction position n-1 < correction position n at the power on and initial state then it indicates warning of 0x2013, Bit9. Correction position need to correction and then re-turn on control power. ✓ If correction position over the coordinate axes (0x7FFFFFFF⇔0x80000000), 0x5083 correction position n=0x7FFFFFFF and 0x5084 Number n offset value need to set 0. Caution, if not 0, the machine may oscillate at the correction position over the coordinate axes. ✓This becomes valid by re-closing the control source. 					
	<ul style="list-style-type: none"> ✓ When the symbol of the actual position (0x6064) is negative, it refers to the table after translating the actual position to the absolute value. After reversing the plus and minus signs of the offset retrieved from the table, use for control. 					

5. Object Dictionary

0x5084: Correction Table Offset

Index Ax1 Ax2 Ax3 Ax4	0x5084 0x5284 0x5484 0x5684	Correction Table Offset	Object Code	Record	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Number of entry ✓This becomes valid by re-closing the control source.	Unsigned8 Setting range	RW	No	0x00 0x00~0x40
0x01	Entry 1 Offset 1 ✓ If correction position over the coordinate axes (-1⇔0), 0x5083 correction position 1 and 0x5084 No1 offset value need to set 0. Caution, if not 0, the machine may oscillate at the correction position over the coordinate axes.	Integer32 Setting range Unit	RW	No	0x00000000 0x80000000-0x7FFFFFFF Pulse
0x02 ~ n	Entry 2 - Entry n Offset 2 - Offset n ✓"n" is up to 0x40 in maximum. ✓ If correction position over the coordinate axes (0x7FFFFFFF⇔0x80000000), 0x5083 correction position n=0x7FFFFFFF and 0x5084 Number n offset value need to set 0. Caution, if not 0, the machine may oscillate at the correction position over the coordinate axes.	Integer32 Setting range Unit	RW	No	0x00000000 0x80000000-0x7FFFFFFF Pulse

0x5090: Backlash correction function selection

Index Ax1 Ax2 Ax3 Ax4	0x5090 0x5290 0x5490 0x5690	Set the Backlash correction function on / off.	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Backlash correction function [BLCEN] Set the Backlash correction function on / off. 0x00: Disabled 0x01: Enabled 0x02 - 0xFF: Reserved	Unsigned8 Setting range	RW	No	0x00 0x00-0x01

0x5091: Backlash correction value

Index Ax1 Ax2 Ax3 Ax4	0x5091 0x5291 0x5491 0x5691	Set the backlash correction value.	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Backlash correction value. [BLCVAL] Set the Backlash correction value. ◆0 is set to bit 6 of Control Word. (Target position is treated as absolute value.) Backlash correction value is incremented from target position when position command had increased target position. Backlash correction value is not incremented from target position when position command had decreased target position. ◆1 is set to bit 6 of Control Word. (Target position is treated as relative value.) Backlash correction value is decremented from target position when target position polarity had changed from positive to negative. Backlash correction value is incremented from target position when target position polarity had changed from negative to positive.	Unsigned32 Setting range Unit	RW	No	0x00000000 0x00000000-0x7FFFFFFF (0 - 2147483647) Pulse

0x5092: Correction direction of Backlash

Index Ax1 Ax2 Ax3 Ax4	0x5092 0x5292 0x5492 0x5692	Sets the correction direction of Backlash	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Correction direction of Backlash [BLCDIR] Sets the command direction of Backlash correction. 0x00: Positive direction 0x01: Negative direction 0x02-0xFF: Reserved	Unsigned8 Setting range	RW	No	0x00 0x00-0x01

5. Object Dictionary

10) System Parameter

0x20F0: Amplifier Function Selection

Sub-Idx	Description	Data Type	Access	PDO	Initial value
Index Ax1 0x20F0 Ax2 0x22F0 Ax3 0x24F0 Ax4 0x26F0	Set the Sequence function.			Object Code	Record
0x00	Number of entry	Unsigned8	RO	No	0x06
0x01	Limit behavior Selection [ACTOT] Selects the operation when the positive direction limit switch (normal rotation over travel) or the negative direction limit switch (reverse rotation over travel) is on.	Unsigned8 Setting range	RW	No	0x06 0x00-0x06
<p>* Profile Position (PP), Profile Velocity (PV), Cycle synchronous position (CSP), Interpolated position (ip), Cycle synchronous velocity (CSV) <u>0x00:Command entry disabled, after the motor stops with the servo brake, servo ON *1</u> <u>0x01:Command entry disabled, after the motor stops with the dynamic brake, servo ON</u> <u>0x02:Command entry disabled, after the motor stops with free run, servo ON</u> <u>0x03:Command entry disabled, after the motor stops with the servo brake, servo OFF *1</u> <u>0x04:Command entry disabled, after the motor stops with the dynamic brake, servo OFF</u> <u>0x05:Command entry disabled, after the motor stops with free run, servo OFF</u> <u>0x06:Command entry enabled, after servo motor stops without internal velocity limit command, servo ON</u> <u>0x07-0xFF:Reserved</u></p> <p>* Profile torque (force) (TQ), Cycle synchronous torque (force) (CST) <u>0x00 - 0x02, 0x06: Limit the Torque (force) command with Sequence Torque (force) limit (servo ON) *1, *2</u> <u>0x03, 0x04: After servo Off, the motor stops with dynamic brake (servo Off)</u> <u>0x05: After servo Off, the motor stops with free run (servo Off)</u> <u>0x07-0xFF:Reserved</u></p> <p>*1 The Sequence Operational Torque(force) limit value(0x201E) is valid with power running direction. *2 When the Torque (force) Command is smaller than sequence operational torque limit value, it is limited by the Target Torque (force). * RF2 series servo amplifier does not have dynamic brake circuit. So, it will be Free Run Stop during dynamic brake operation.</p>					
0x02	Positioning Methods selection [EDGEPOS] Select the Encoder pulse positioning.	Unsigned8 Setting range	RW	No	0x00 0x00-0x01
<p><u>0x00:Specify Pulse Interval</u> <u>0x01:Specify Pulse Edge</u> <u>0x02-0xFF:Reserved</u></p> <p>■Positioning accuracy is improved by selecting Edge positioning when the encoder resolution is coarse. However, this may cause the driving sound of the mechanical system to increase as this edge is always the center of vibration. ■Select standard value for usual operation. *The function becomes valid through control source re-closing.</p> <div style="text-align: center;"> <p>The diagram shows two waveforms, Phase A and Phase B. For Pulse interval positioning, a horizontal double-headed arrow indicates the width of a pulse. For Edge positioning, a vertical dashed line marks the rising edge of a pulse, and a horizontal double-headed arrow indicates the time interval centered on this edge.</p> </div>					


5. Object Dictionary

Sub-Idx	Description	Data Type	Access	PDO	Initial value																				
0x03	In-Position Signal/ Position Deviation Monitor [PDEVMON] Select in-position signal (INP) and Position deviation monitor output before and after passing through the Position Command Filter. <u>0x00:After Filter</u> Compare Position command value with Feedback value after passing through the filter. <u>0x01:Before Filter</u> Compare Position command value with Feedback value before passing through the filter. ■For 00 After_Filter, use the Position deviation value of the Position controller. ■For 01 Before_Filter, use the Position deviation value based on Position command before FF vibration suppressor control. ■With system parameter ID0A Position Control Selection at 01 Model 1 Model Following Control, or 02 Model 2 Model Following Vibration Suppress Control, 01:Before_Filter always operates no matter the selection.	Unsigned8	RW	No	0x00																				
		Setting range	0x00-0x01																						
0x04	Velocity Window Unit Output Selection [VCMPUS] Sets the comparison method of the Velocity matching output. <u>0x00:min-1</u> 0x606D(rotation frequency setting:min ⁻¹)compare with setting value. <u>0x01:percent</u> 0x202A(proportion setting:%)compare with setting value. *The function becomes valid through control source re-closing.	Unsigned8	RW	No	0x00																				
		Setting range	0x00-0x01																						
0x05	Deviation Clear Selection [CLR] Sets ON/OFF of position deviation clear during servo OFF, and deviation clear signal treatment. * Selects operation during servo OFF. Deviation clear/ Deviation NOT clear. * Selects deviation signal treatment. Level detection /Edge detection. * Select proper setting corresponding to above combination from the list below.	Unsigned8	RW	No	0x00																				
		Setting range	0x00-0x03																						
<table border="1"> <thead> <tr> <th colspan="2">Selection</th> <th colspan="2">Contents</th> </tr> </thead> <tbody> <tr> <td>0x00</td> <td>Type1</td> <td>When Servo OFF -> Clear Deviation Deviation Clear Input =Level Detection</td> <td>During servo OFF, Deviation clear is always executed. While Deviation clear input is ON, Deviation clear is always executed.</td> </tr> <tr> <td>0x01</td> <td>Type2</td> <td>When Servo OFF -> Clear Deviation Deviation Clear Input =Edge Detection</td> <td>At the edge of OFF->ON of Deviation clear input, Deviation clear is executed.</td> </tr> <tr> <td>0x02</td> <td>Type3</td> <td>When Servo OFF -> NOT Clear Deviation Deviation Clear Input =Level Detection</td> <td>During servo OFF, Deviation clear is not executed. (After servo ON, the motor may operate suddenly.)</td> </tr> <tr> <td>0x03</td> <td>Type4</td> <td>When Servo OFF -> NOT Clear Deviation Deviation Clear Input =Edge Detection</td> <td>During servo OFF, Deviation clear is not executed. (After servo ON, the motor may operate suddenly.)</td> </tr> </tbody> </table>						Selection		Contents		0x00	Type1	When Servo OFF -> Clear Deviation Deviation Clear Input =Level Detection	During servo OFF, Deviation clear is always executed. While Deviation clear input is ON, Deviation clear is always executed.	0x01	Type2	When Servo OFF -> Clear Deviation Deviation Clear Input =Edge Detection	At the edge of OFF->ON of Deviation clear input, Deviation clear is executed.	0x02	Type3	When Servo OFF -> NOT Clear Deviation Deviation Clear Input =Level Detection	During servo OFF, Deviation clear is not executed. (After servo ON, the motor may operate suddenly.)	0x03	Type4	When Servo OFF -> NOT Clear Deviation Deviation Clear Input =Edge Detection	During servo OFF, Deviation clear is not executed. (After servo ON, the motor may operate suddenly.)
Selection		Contents																							
0x00	Type1	When Servo OFF -> Clear Deviation Deviation Clear Input =Level Detection	During servo OFF, Deviation clear is always executed. While Deviation clear input is ON, Deviation clear is always executed.																						
0x01	Type2	When Servo OFF -> Clear Deviation Deviation Clear Input =Edge Detection	At the edge of OFF->ON of Deviation clear input, Deviation clear is executed.																						
0x02	Type3	When Servo OFF -> NOT Clear Deviation Deviation Clear Input =Level Detection	During servo OFF, Deviation clear is not executed. (After servo ON, the motor may operate suddenly.)																						
0x03	Type4	When Servo OFF -> NOT Clear Deviation Deviation Clear Input =Edge Detection	During servo OFF, Deviation clear is not executed. (After servo ON, the motor may operate suddenly.)																						
* Used, for example, to force the position variation counter inside the servo amplifier to zero from higher-level devices.																									
0x06	Torque (force) attainment function selection [TASEL] Sets detection method of torque (force) attainment setting (0X202E).	Unsigned8	RW	No	0x00																				
		Setting range	0x00 - 0x01																						
<table border="1"> <thead> <tr> <th colspan="2">Selection</th> <th colspan="2">Contents</th> </tr> </thead> <tbody> <tr> <td>00</td> <td>TA/TZR</td> <td colspan="2">Sets by using the ratio of rated torque (force) of the motor. (100%= rated torque (force))</td> </tr> <tr> <td>01</td> <td>TA/TCOM</td> <td colspan="2">Sets by using the ratio of limit value of torque(force). (100%=limit value of torque (force))</td> </tr> </tbody> </table>						Selection		Contents		00	TA/TZR	Sets by using the ratio of rated torque (force) of the motor. (100%= rated torque (force))		01	TA/TCOM	Sets by using the ratio of limit value of torque(force). (100%=limit value of torque (force))									
Selection		Contents																							
00	TA/TZR	Sets by using the ratio of rated torque (force) of the motor. (100%= rated torque (force))																							
01	TA/TCOM	Sets by using the ratio of limit value of torque(force). (100%=limit value of torque (force))																							

5. Object Dictionary

0x20F1: Encoder Function Selection

Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Number of entry	Unsigned8	RO	No	0x09
0x01	Serial encoder Clear Function Selection [ECLRFUNC] Selects the encoder clear method. * Use to clear Serial encoder warning when the warning is not automatically restored. * Valid when using with Battery Backup Method Absolute Encoder and Battery-less Absolute Encoder. * When used with Absolute Encoder for Incremental System, even 01: _Status_MultiTurn is selected; it works as the selection, Clear only encoder status. <u>0x00: Clear Encoder Status (Alarm and Warning) and Multi Turn Data</u> <u>0x01: Clear Only Encoder Status (Alarm and Warning)</u> * Parameter set when amplifier hardware matches to Serial Encoder. * Valid when Battery backup system absolute encoder, or Battery less absolute encoder is used.	Unsigned8 Setting range	RW	No	0x00 0x00-0x01
0x02	Encoder Digital Filter selection [ENFIL] This parameter can be set only when using pulse encoder. This sets digital filter of motor pulse encoder. * It is possible to set the value of incremental pulse digital filter for using incremental encoder. Pulse lower than the set value is eliminated as noise when noise superposition occurs in Incremental encoder signals. * Consider Encoder resolution and Maximum rotation velocity of the servo motor in operation when selecting value. Set the value roughly less than 1/4 of the Encoder pulse width at Maximum rotation velocity. <u>0x00: Minimum Pulse Width=110ns (Minimum pulse Phase Difference 37.5ns)</u> <u>0x01: Minimum Pulse Width=220ns (Minimum pulse Phase Difference 75ns)</u> <u>0x02: Minimum Pulse Width=440ns (Minimum pulse Phase Difference 150ns)</u> <u>0x03: Minimum Pulse Width=880ns (Minimum pulse Phase Difference 300ns)</u> <u>0x04: Minimum Pulse Width= 75ns (Minimum pulse Phase Difference 37.5ns)</u> <u>0x05: Minimum Pulse Width=150ns (Minimum pulse Phase Difference 75ns)</u> <u>0x06: Minimum Pulse Width=300ns (Minimum pulse Phase Difference 150ns)</u> <u>0x07: Minimum Pulse Width=600ns (Minimum pulse Phase Difference 300ns)</u> <u>0x08-0x0F: Reserved</u> * This parameter can be set when amplifier hardware supports Pulse encoder.	Unsigned8 Setting range	RW	No	0x01 0x00-0x07
0x03	Reserved [ENPOL]	Unsigned8 Setting range			
0x04	Reserved [ENPOL]	Unsigned8 Setting range			



5. Object Dictionary

0x05	CS offset [CSOF] Sets electrical degree of the motor. For rotary motor use Must set it 0 degree.	Unsigned16	RW	No	0x0000 (0deg)
		Setting range	0x0000 - 0x0167 (0 - 359deg)		
[Linear]	<p>For linear motor and Direct Drive Motor use In case with hall effect sensor, sets an offset value with electrical angle conversion between 0 degree of U phase electrical angle and hall sensor output signal edge of U phase.</p> <p>✓ This parameter is settable only under condition that amplifier hardware can support hall effect sensor input option.</p> <p>⚡ This function becomes effective after re-turning the control power supply on.</p>				
0x06	CS normalization offset of phase Z [ZPHOF] Sets offset of phase Z signal to electrical degree of the motor. For rotary motor use Must set it 0 degree.	Unsigned16	RW	No	0x0000 (0deg)
		Setting range	0x0000 - 0x0167 (0 - 359deg)		
[Linear]	<p>For linear motor and Direct Drive Motor use This function is valid when performing CS normalization with use of phase Z signal. Sets an offset value with electrical angle conversion between 0 degree of U phase electrical angle and Z phase signal output position.</p> <p>⚡ This function becomes effective after re-turning the control power supply on.</p>				
0x07	Polarity selection on linear encoder [ENCDIR] Select linear encoder signal polarity EN1. You can select phase A and B signal polarity. Phase U and V signal polarity shall not be changed in case of omitted wiring incremental encoder.)	Unsigned8	RW	No	0x00
		Setting range	0x00 - 0x01		
[Linear]	<p>⚡ This function becomes effective after re-turning the control power supply on.</p>				
0x08	Magnetic pole position estimation frequency [EMPFREQ] Sets frequency for torque (force) command that is applied to estimate magnetic pole position. ✓ Change excitation frequency if amplifier hardware magnetic pole position estimation cannot be normally completed due to resonance of equipment. ⚡ This function becomes effective after re-turning the control power supply on.	Unsigned16	RW	No	0x0032 (50Hz)
		Setting range	0x05 - 0x0064 (5 - 100Hz)		
[Linear]					
0x09	Magnetic pole position estimation selection [CSETMD] Select the Magnetic pole position estimation mode. ✓ This object is valid when 0x0850 is set to 0x20FF_0x02.	Unsigned8	RW	No	0x00
		Setting range	0x00 ~ 0x01		
[Linear]	<p>0x00: Follow the setting of 0x20F8. 6. 0x01: Magnetic pole position estimation will run at once only after turn on main power. ⚡ Change is valid after control power-cycle.</p>				

5. Object Dictionary

0x20F2: Amplifier Alarm Detect Selection

Index Ax1 Ax2 Ax3 Ax4	0x20F2 0x22F2 0x24F2 0x26F2	Sets the Sequence function.	Object Code			Record
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x05
0x01	Main Circuit Under-voltage (ALM_62) Detection [MPESEL]		Unsigned8	RW	No	0x01
	When DC input power specification is selected, select whether the Main Circuit Under-voltage alarm should be detected or not. <u>0x00: Do not detect the Main Circuit Under-voltage Alarm.</u> <u>0x01: Detect the Main Circuit Under-voltage Alarm.</u>		Setting range	0x00-0x01		
0x02	Velocity Control Alarm (ALM_C2) Detection [VCALM] Select valid / invalid from the velocity control trouble detection. Trouble can be detected in operation patterns where the motor results in overshooting in response to commands; in these systems, please set as "invalid." <u>0x00: invalid</u> <u>0x01: valid</u>		Unsigned8	RW	No	0x00
			Setting range	0x00-0x01		
0x03	Velocity Feedback Alarm (ALM_C3) Detection [FBKEEN] <u>0x00:invalid</u> <u>0x01:valid</u> Select valid / invalid for the velocity feedback trouble detection.		Unsigned8	RW	No	0x01
			Setting range	0x00-0x01		
0x04	Communication Frame Error (ALM_10-15) Detection [CRCSET] <u>0x00-0x02:invalid</u> <u>0x03: valid (error detected three times in row)</u> <u>0x04: valid (error detected four times in row) ... 0x08: valid (error detected eight times in row)</u>		Unsigned8	RW	No	0x00
	Monitor the following communication error registers at each communication cycle and set as valid / invalid for each alarm and for the detection filter. Reg:0x300 Port 0 Rx invalid frame error (AL_10) Reg:0x301 Port0 RxCRC error (AL_12) Reg:0x302 Port 1 Rx invalid frame error (AL_11) Reg:0x302 Port1 RxCRC error (AL_13) Reg:0x308 Port0 Tx error (AL_14) Reg:0x309 Port1 Tx error (AL_15)		Setting range	0x00-0x08		
0x05	Communication Timeout (ALM_1A) Detection [COTOUT] <u>0x00, 0x01: invalid</u> <u>0x02: valid (not received twice in row)</u> <u>0x03: valid (not received three times in row) ... 0xFF: valid (not received 255 times in row)</u>		Unsigned8	RW	No	0x00
	Monitor SM2 event (command receipt) at each communication cycle and set as valid / invalid for AL_1A and the detection filter.		Setting range	0x00-0xFF		

0x20F3: Position Control Selection

Index Ax1 Ax2 Ax3 Ax4	0x20F3 0x22F3 0x24F3 0x26F3	Selects Position control Compensation and encoder to use to control the position loop in PP, CSP, IP modes.	Object Code			Record
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x02
0x01	Position Control Selection [PCNTSEL]		Unsigned8	RW	No	0x00
	Selects the model following control form and presence/absence. <u>0x00: Normal Control (Model Following Position Control detached)</u> <u>0x01: Model Following Position Control (rigid body model)</u> <u>0x02: Model Following Position Control (base vibration model)</u> <u>0x03 - 0xFF: Reserved</u> *The setting value is switched by re-closing. *The function becomes valid through control source re-closing.		Setting range	0x00-0x02		
0x02	Position Loop Control, Encoder Selection [PLMODE] Selects the encoder that the servo amplifier uses for Position Loop Control. <u>0x00: Semi-closed Control (motor encoder used)</u> <u>0x01: Full-closed Control (external encoder used)</u> *The function becomes valid through control source re-closing.		Unsigned8	RW	No	0x00
			Setting range	0x00-0x01		

5. Object Dictionary

0x20F4: Servo Loop Delay Time

Index Ax1 Ax2 Ax3 Ax4	0x20F4 0x22F4 0x24F4 0x26F4	In SM2 SYNC, set the delay time from IRQ interruption to the beginning of the computation of the servo amplifier control loop.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Servo Loop Delay Time [SLPDLY] In SM2 event SYNC, each axis reaches misalignment because of cable impedance and processing delay caused by the occurrence of IRQ signals in frame transmission. This parameter can adjust the time from the IRQ signal occurrence to the beginning of the amplifier location loop computation. Delay Time (usec) = (Setting value + 1) / 2 "Example : 62.5us = 62.5 * 2 - 1 = 124 =Setting value:0x7C" *Adjust to the last slave axis.		Unsigned8	RW	No	0xEF (120µs)
			Setting range	0x00-0xEF (0.5-120µs)		
			Unit	0.5µs		

0x20F5: Torque (force) Limit at Power Supply Shortage

Index Ax1 Ax2 Ax3 Ax4	0x20F5 0x22F5 0x24F5 0x26F5	When a power supply shortage is detected, select whether the normal limit value or the sequence operation torque (force) limit of the motor output current is used. Provided as a SEMI F47 support function.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Torque (force) Limit at Power Supply Shortage [CPETLSEL] For torque (force) limit upon detection of Power Supply Shortage, select whether the sequence operation torque (force) Limit (0x201E) should be included in addition to the maximum torque (0x6072), positive direction Torque limit (0x60E0), and negative direction Torque limit (0x60E1). <u>0x00: Limit to minimum value of 0x6072, 0x60E0, 0x60E1(By normal torque limit method)</u> <u>0x01: 0x201E:Limit to minimum value of the Sequence Torque Operation Torque limit and the minimum value of 0x6072, 0x60E0, and 0x60E1.</u>		Unsigned8	RW	No	0x00
			Setting range	0x00-0x01		
*For the operation sequence, see chapter 8, "SEMI F47 support function."						

0x20F6: Manufacturer Homing Parameter

Index Ax1 Ax2 Ax3 Ax4	0x20F6 0x22F6 0x24F6 0x26F6	In the homing mode (hm), set the parameter that maker decided.	Object Code	Record		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x03
0x01	Actual position calculation method [HMPSEL] At homing process, define calculation of actual position (0x6064). 0x20F6-1=0 : Calculation method 1 0x20F6 - 1 = 1 : Calculation method 2 Zero Position for the application Home Position (Index Pulse) ← Home offset (0x607C) → Zero Position (Index Pulse) ← Home offset (0x607C) → Except for homing method 35,37. Zero Position = Home Position + Home offset (0x606C) Homing Method 35,37 Actual Position(0x6064) = Home offset (0x606C) ✓ When homing method 35 or 37 and 0x20F6-1=0 ,calculation is calculation method 2.		Unsigned8	RW	No	0x00
			Setting range	0x00~0x01		
0x02	Hard stop torque (force) limit [HSTRQ] In the Hard stop homing (0x6098:from -4 to -1), this value is torque (force) limitation when reaching hard stop. Hard stop is detected with this value.		Unsigned16	RW	No	0x03E8 (100.0%)
			Setting range	0x0000~0x1388 (0~500.0%)		
			Unit	0.1 %		
0x03	Hard stop detection time [HSTIM] In the Hard stop homing (0x6098:from -4 to -1), hard stop is detected after spending this time with torque value beyond above. After hard stop detection, state will change by homing method as below. Homing method (0x6098) -1, -2 --> Home position detected. (Finished homing.) -3, -4 --> Go reverse to find index position. (Continuing homing.)		Unsigned16	RW	No	0x000A (10ms)
			Setting range	0x000A~0xFFFF (10~65535ms)		
			Unit	ms		

5. Object Dictionary

0x20F7: Special Function Selection Setting

Index Ax1	0x20F7	Sets whether or not the special function of the servo amplifier is usable.	Object Code		Variable	
Ax2	0x22F7					
Ax3	0x24F7					
Ax4	0x26F7					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Bit0: Independent setting of SM2 synchronization and interpolated synchronization Sets whether or not the synchronized time in the interpolation mode is synchronized. The interpolation synchronized time is synchronized to SM2 synchronization at the setting value 0. The interpolation synchronized time is independently set from SM2 synchronization at the setting value 1. ✓ When using the SANMotionC, please make sure to use it under the conditions synchronizing to SM2 synchronization.		Unsigned16	RW	No	0x0000
			Setting Range			0x0000-0xFFFF
	Bit1: Torque low pass filter setting Sets torque command filter (0x2011). 0: Torque command filter (0x2011) disable. 1: Torque command filter (0x2011) enable.					
	Bit2: Reserved					
	Bit3: Reserved					
	Bit4: Shutdown command state selection In the FSA status transition, selects the amplifier state at the time of shutdown command inputting. Emergency stop state can set every time at the time of shutdown command inputting. 0: Not to be an emergency stop state at the time of shutdown command inputting. However, transition from Operation state, it is to be an emergency stop state. 1: To be an emergency stop state at the time of shutdown command inputting.					
	Bit5 to 15: Reserved					

5. Object Dictionary

0x20F8: General Purpose Input Setting

Index Ax1 Ax2 Ax3 Ax4	0x20F8 0x22F8 0x24F8 0x26F8	Select the function of General Purpose input 1, 2(CONT1, CONT2). Input time until all the function become enabled is 8ms.	Object Code		Record
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Number of entry	Unsigned8	RO	No	0x06
0x01	Positive Limit Switch Function [PLIMSW] Select the valid condition of the positive direction limit switch function.	Unsigned8	RW	No	0x00
		Setting range	0x00~0x11		
<u>00: Always Disable Always function disabled.</u> <u>01: Always Enable Always function enabled.</u> <u>02: CONT1 ON Function enabled when versatile input CONT1 is ON.</u> <u>03: CONT1 OFF Function enabled when versatile input CONT1 is OFF.</u> <u>04: CONT2 ON Function enabled when versatile input CONT2 is ON.</u> <u>05: CONT2 OFF Function enabled when versatile input CONT2 is OFF.</u> <u>06: CONT3 ON Function enabled when versatile input CONT3 is ON.</u> <u>07: CONT3 OFF Function enabled when versatile input CONT3 is OFF.</u> <u>08: CONT4 ON Function enabled when versatile input CONT4 is ON.</u> <u>09: CONT4 OFF Function enabled when versatile input CONT4 is OFF.</u> <u>0A: CONT5 ON Function enabled when versatile input CONT5 is ON.</u> <u>0B: CONT5 OFF Function enabled when versatile input CONT5 is OFF.</u> <u>0C: CONT6 ON Function enabled when versatile input CONT6 is ON.</u> <u>0D: CONT6 OFF Function enabled when versatile input CONT6 is OFF.</u> <u>0E: CONT7 ON Function enabled when versatile input CONT7 is ON.</u> <u>0F: CONT7 OFF Function enabled when versatile input CONT7 is OFF.</u> <u>10: CONT8 ON Function enabled when versatile input CONT8 is ON.</u> <u>11: CONT8 OFF Function enabled when versatile input CONT8 is OFF.</u>					
0x02	Negative Limit Switch Function [NLIMSW] Select the valid condition of the negative direction limit switch function	Unsigned8	RW	No	0x00
		Setting range	0x00-0x11		
The same as Sub Index:01(positive direction limit switch function.)					
0x03	External Trip Input Function [EXT-E] Sets the trip valid condition the same as the trip input of the external regenerative resistance. The same as Sub Index:01(positive direction limit switch function.)	Unsigned8	RW	No	0x00
		Setting range	0x00-0x11		
0x04	Main Power Discharge Function [DISCHRG] Sets the valid condition of the discharge function in case of main circuit power shutdown. The same as Sub Index:01(positive direction limit switch function.)	Unsigned8	RW	No	0x00
		Setting range	0x00-0x11		
0x05	Emergency Stop Function [EMR] Sets the valid condition of the input function in case of emergency stop. The same as Sub Index:01(positive direction limit switch function.)	Unsigned8	RW	No	0x00
		Setting range	0x00-0x11		
0x06 [Linear]	Detetion function of magnetic pole position [CSET] Sets valid condition for inputting fixed excitation operation on the linear motor without hall efect sensor output. Sets valid condition for inputting fixed magnetic pole position estimation function on the linear motor without hall efect sensor output. This selection functions the same way as SubIndex:01 (limit switch function in positive direction).	Unsigned8	RW	No	0x00
		Setting range	0x00~0x11		

5. Object Dictionary

0x20F9: General Purpose Output Setting

Index Ax1	0x20F9	Selects General Output 1, 2(OUT1, OUT2) function	Object Code		Record
Ax2	0x22F9				
Ax3	0x24F9				
Ax4	0x26F9				
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Number of entry	Unsigned8	RO	No	0x02
0x01	General Purpose Output 1 [OUT1] Selects the Output signal for General Purpose Output 1. For a detailed list, see the General Purpose Output Parameters list.	Unsigned8	RW	No	0x42
		Setting range	0x00-0x5F (Initial value: 42:FOUT1_ON)		
0x02	General Purpose Output 2 [OUT2] Selects the Output signal for General Purpose Output 2. For a detailed list, see the General Purpose Output Parameters list.	Unsigned8	RW	No	0x44
		Setting range	0x00-0x55 (Initial value: 44: FOUT2_ON)		

■ To control from EtherCAT communication

Physical output 0x60FE, 0x01:bit16 setting	42:FOUT1_ON	43:FOUT1_OFF
Physical output 0x60FE, 0x01:bit17 setting	44:FOUT2_ON	45:FOUT2_OFF

■ When Generic input signal status it to be Output.

General Input, CONT1 is ON	3A:CONT1_ON	3B:CONT1_OFF
General Input, CONT2 is ON	3C:CONT2_ON	3D:CONT2_OFF
General Input, CONT3 is ON	3E:CONT3_ON	3F:CONT3_OFF
General Input, CONT4 is ON	40:CONT4_ON	41:CONT4_OFF

■ When Servo amplifier Preset status is to be output.

While Servo Ready Complete	02:S-RDY_ON	03:S-RDY_OFF
	50:S-RDY2_ON	51:S-RDY2_OFF
While Power Supply ON	04:P-ON_ON	05:P-ON_OFF
While Power Supply ON Permission	06:A-RDY_ON	07:A-RDY_OFF
While Motor Excitation	08:S-ON_ON	09:S-ON_OFF
While Holding Brake Excitation Signal Output	0A:MBR-ON_ON	0B:MBR-ON_OFF
While Torque (force) Limiting	0C:TLC_ON	0D:TLC_OFF
While Velocity Limiting	0E:VLC_ON	0F:VLC_OFF
While Low Speed Status	10:LOWV_ON	11:LOWV_OFF
While Speed Attainment Status	12:VA_ON	13:VA_OFF
While Speed Matching Status	14:VCMP_ON	15:VCMP_OFF
While Speed Zero Status	16:ZV_ON	17:ZV_OFF
While Command Acceptance Permission Status	1C:CMD-ACK_ON	1D:CMD-ACK_OFF
While Gain Switching Status	1E:GC-ACK_ON	1F:GC-ACK_OFF
While Velocity Loop Proportional Control Switching Status	20:PCON-ACK_ON	21:PCON-ACK_OFF
While Control Mode Switching Status	24:MS-ACK_ON	25:MS-ACK_OFF
While in positive direction limit condition	26:F-OT_ON	27:F-OT_OFF
While in negative direction limit condition	28:R-OT_ON	29:R-OT_OFF
While Main Circuit Power Supply Charging	4A:CHARGE_ON	4B:CHARGE_OFF
While Dynamic Braking	4C:DB_OFF	4D:DB_ON
While in Alarm Status	38:ALM_ON	39:ALM_OFF

■ When Positioning signal is to be output

While In-Position Status	18:INP_ON	19:INP_OFF
While Near Range Status	1A:NEAR_ON	1B:NEAR_OFF
While In-Position with Position Command 0 Status	52:INPZ_ON	53:INPZ_OFF

*All codes not on the list are Reserved and indeterminate.

* RF2 series servo amplifier does not have dynamic brake circuit.
So, it will be Free Run Stop during dynamic brake operation.

5. Object Dictionary

■ General output parameter list

Item	Setting value	Item	Setting value
The output is always OFF.	00:Always_OFF	The output is always ON.	01:Always_ON
The output is ON during Servo Ready complete.	02:S-RDY_ON	The output is OFF during Servo Ready complete.	03:S-RDY_OFF
The output is ON while the main power supply is turned on.	04:P-ON_ON	The output is OFF while the main power supply is turned on.	05:P-ON_OFF
The output is ON during the main power supply ON permission.	06:A-RDY_ON	The output is OFF during the main power supply ON permission.	07:A-RDY_OFF
The output is ON during motor excitation.	08:S-ON_ON	The output is OFF during motor excitation.	09:S-ON_OFF
The output is ON while holding brake excitation signal outputs.	0A:MBR-ON_ON	The output is OFF while holding brake excitation signal outputs.	0B:MBR-ON_OFF
The output is ON during torque (force) limiting.	0C:TLC_ON	The output is OFF during torque (force) limiting.	0D:TLC_OFF
The output is ON during velocity limiting.	0E:VLC_ON	The output is OFF during velocity limiting.	0F:VLC_OFF
The output is ON during low speed status.	10:LOWV_ON	The output is OFF during low speed status.	11:LOWV_OFF
The output is ON during speed attainment status.	12:VA_ON	The output is OFF during speed attainment status.	13:VA_OFF
The output is ON during speed matching status.	14:VCMP_ON	The output is OFF during speed matching status.	15:VCMP_OFF
The output is ON during zero speed status.	16:ZV_ON	The output is OFF during zero speed status.	17:ZV_OFF
The output is ON during In-Position status.	18:INP_ON	The output is OFF during In-Position status.	19:INP_OFF
The output is ON during In-Position Near status.	1A:NEAR_ON	The output is OFF during In-Position Near status.	1B:NEAR_OFF
The output is ON while command can be accepted.	1C:CMD-ACK_ON	The output is OFF while command can be accepted.	1D:CMD-ACK_OFF
The output is ON during gain switching.	1E:GC-ACK_ON	The output is OFF during gain switching.	1F:GC-ACK_OFF
The output is ON during velocity loop proportional control switching.	20:PCON-ACK_ON	The output is OFF during velocity loop proportional control switching.	21:PCON-ACK_OFF
The output is ON during control mode switching.	24:MS-ACK_ON	The output is OFF during control mode switching.	25:MS-ACK_OFF
The output is ON during positive over-travel status.	26:F-OT_ON	The output is OFF during positive over-travel status.	27:F-OT_OFF
The output is ON during negative over-travel status.	28:R-OT_ON	The output is OFF during negative over-travel status.	29:R-OT_OFF
The output is ON during excessive deviation warning status.	2A:WNG-OFW_ON	The output is OFF during excessive deviation warning status.	2B:WNG-OFW_OFF
The output is ON during over-load warning status.	2C:WNG-OLW_ON	The output is OFF during over-load warning status.	2D:WNG-OLW_OFF
The output is ON during regenerative over-load warning status.	2E:WNG-ROLW_ON	The output is OFF during regenerative over-load warning status.	2F:WNG-ROLW_OFF
The output is ON during battery warning.	30:WNG-BAT_ON	The output is OFF during battery warning.	31:WNG-BAT_OFF
The output is alarm Code Bit 5 (positive logic).	32:ALM5_ON	The output is alarm Code Bit 5 (negative logic).	33:ALM5_OFF
The output is alarm Code Bit 6 (positive logic).	34:ALM6_ON	The output is alarm Code Bit 6 (negative logic).	35:ALM6_OFF
The output is alarm Code Bit 7 (positive logic).	36:ALM7_ON	The output is alarm Code Bit 7 (negative logic).	37:ALM7_OFF
The output is ON during alarm status.	38:ALM_ON	The output is OFF during alarm status.	39:ALM_OFF
The output is ON during generic input CONT1 is ON.	3A:CONT1_ON	The output is OFF during generic input CONT1 is ON.	3B:CONT1_OFF
The output is ON during generic input CONT2 is ON.	3C:CONT2_ON	The output is OFF during generic input CONT2 is ON.	3D:CONT2_OFF
The output is ON during generic input CONT3 is ON.	3E:CONT3_ON	The output is OFF during generic input CONT3 is ON.	3F:CONT3_OFF
The output is ON during generic input CONT4 is ON.	40:CONT4_ON	The output is OFF during generic input CONT4 is ON.	41:CONT4_OFF
The output is ON during physical output is "0x60FE, 1:bit16=1".	42:FOUT1_ON	The output is OFF during physical output is "0x60FE, 1:bit16=1".	43:FOUT1_OFF
The output is ON during physical output is "0x60FE, 1:bit17=1".	44:FOUT2_ON	The output is OFF during physical output is "0x60FE, 1:bit17=1".	45:FOUT2_OFF
The output is always OFF.	46:Always_OFF	The output is always OFF.	47:Always_OFF
The output is always OFF.	48:Always_OFF	The output is always OFF.	48:Always_OFF
The output is ON during main circuit power is charging.	4A:CHARGE_ON	The output is OFF during main circuit power is charging.	4B:CHARGE_OFF
The output is OFF during dynamic brake is operating.	4C:DB_OFF	The output is ON during dynamic brake is operating.	4D:DB_ON
The output is ON during magnetic pole position estimation is finished.	4E:CRDY_ON	The output is OFF during magnetic pole position estimation is finished.	4F:CRDY_OFF
The output is ON during Servo Ready 2 complete.	50:S-RDY2_ON	The output is OFF during Servo Ready 2 complete.	51:S-RDY2_OFF
The output is ON during PCMD=0 and In-position Status.	52:INPZ_ON	The output is OFF during PCMD=0 and In-position Status.	53:INPZ_OFF
The output is ON during power supply shortage warning.	54:PEWNG_ON	The output is OFF during power supply shortage warning.	55:PEWNG_OFF
The output is ON in during detecting torque (force) attainment.	56:TA_ON	The output is OFF in during detecting torque (force) attainment.	57:TA_OFF
When versatile input CONT5 is ON, output is ON	58:CONT5_ON	When versatile input CONT5 is ON, output is OFF	59:CONT5_OFF
When versatile input CONT6 is ON, output is ON	5A:CONT6_ON	When versatile input CONT6 is ON, output is OFF	5B:CONT6_OFF
When versatile input CONT7 is ON, output is ON	5C:CONT7_ON	When versatile input CONT7 is ON, output is OFF	5D:CONT7_OFF
When versatile input CONT8 is ON, output is ON	5E:CONT8_ON	When versatile input CONT8 is ON, output is OFF	5F:CONT8_OFF
Reserved	FF:RESERVE	-	-

✓RF2 series servo amplifier does not have dynamic brake circuit. So, dynamic brake operation monitor will be Free Run operation monitor.

5. Object Dictionary

0x20FA: Extend Station Alias

Index	0x20FA	Sets the rotary switch for Station of Alias to use more than 0 to 256 points rotary switch. This amplifier has single ESC. So, this is single object, also.	Object Code			Variable
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Number of entry		Unsigned8	RO	No	0x02
0x01	Extended Alias Number [EXALIAS] Sets the Inherent Slave address (Station Alias Reg : 0x0012, 0x0013) to bit15-8 bit7-0 Rotary switch of amplifier front panel ,bit15-8 This setting value at initialization If 0x20FA.02=0x00 then logical add will write to station alias Reg : 0x0012,0x0013 *The function becomes valid through control source re-closing.		Unsigned8	RW	No	0x00
			Setting range	0x00~0xFF		
0x02	Station Alias Selection [ALIASSEL] Sets the station alias Reg : 0x0012,0x0013 0x00: Use value of rotary switch of amplifier front panel (bit7-0) and extended alias number(bit15-8) 0x01: Use value of EEPROM address 0x04 *The function becomes valid through control source re-closing.		Unsigned8	RW	No	0x00
			Setting range	0x00~0x01		

5. Object Dictionary

0x20FD: Amplifier System Selection

Index Ax1	0x20FD	Selects the system configuration of the servo amplifier.	Object Code			Record
Ax2	0x22FD					
Ax3	0x24FD					
Ax4	0x26FD					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x03
0x01	Main power input type [MPWRIN] Selects the main circuit mode to actually be wired. <u>0x00:3φAC(three-phase AC input)</u> <u>0x01:1φAC(single phase AC input)</u> <u>0x02:DC (DC power source input) supplied from the power supply unit</u> <u>0x03 - 0xFF:Reserved</u> <u>*The function becomes valid through control source re-closing.</u>		Unsigned8	RW	No	0x02
			Setting range	0x00-0x02		
0x02	Regenerative Resistor Selection [RGKIND] Selects the presence/absence of regenerative resistance and the connection forms. <u>0x00:regenerative resistance disconnected</u> <u>0x01:embedded regenerative resistance used</u> <u>0x02:external regenerative resistance used</u> <u>0x03 - 0xFF:Reserved</u> <u>*The function becomes valid through control source re-closing.</u>		Unsigned8	RW	No	0x02
			Setting range	0x00-0x02		
0x03	Setup Communication Baud Rate [COMBAUD] Selects the baud rate when PC communication is performed by the setup software. <u>0x03 : 9600bps</u> <u>0x04 : 19200bps</u> <u>0x05 : 38400bps</u> <u>0x06 : 57600bps</u> <u>0x00-0x02,0x07-0xFF:Reserved</u> <u>*The function becomes valid through control source re-closing.</u>		Unsigned8	RW	No	0x05
			Setting range	0x03-0x06		
0x04	Main circuit power input voltage [MPWRVL] Selects a main circuit power input voltage. <u>0x00 to 0x02: Reserved</u> <u>0x03:DC48V</u> <u>0x04:DC24V</u> <u>0x05 to 0xFF: Reserved</u> <u>*The function becomes valid through control source re-closing.</u>		Unsigned8	RW	No	0x03
			Setting range	0x03-0x04		

5. Object Dictionary

0x20FE: Motor code

Index Ax1 Ax2 Ax3 Ax4	0x20FE 0x22FE 0x24FE 0x26FE	Sets the code of the drive motor.	Object Code	Variable		
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Combination Motor code [MOCODE] Sets the combination motor code. The motor code list can be set via communication. ✓ If there is no Servo motor in the list, Please refer the Annex File "M0011195-Annex 1". (For All of the motor code lists).		Unsigned16	RW	No	0xFFFF
			Setting range	0x0000-0xFFFF		

■ Rotary motor (48V)							
Series	Motor code	Servo motor model number	Input type	Amplifier capacity	Flange size	Output	Maximum speed
R2 Series	0x0261	R2GA04003F	DC48V	40A	□40mm	30W	6,000 min ⁻¹
	0x0262	R2GA04005F	DC48V	40A	□40mm	50W	6,000 min ⁻¹
	0x0263	R2GA04008D	DC48V	40A	□40mm	80W	5,000 min ⁻¹
	0x0264	R2GA06010D	DC48V	40A	□60mm	100W	5,000 min ⁻¹
	0x0265	R2GA06020D	DC48V	40A	□60mm	200W	4,500 min ⁻¹
	0x040C	R2GAD102RM	DC48V	25A	□14mm	2.4W	1,500 min ⁻¹
	0x049B	R2GA02D20F	DC48V	40A	□20mm	20W	6,000 min ⁻¹
	0x0497	R2GA02D30F	DC48V	40A	□20mm	30W	6,000 min ⁻¹

■ Linear motor							
Series	Motor code	Servo motor model number	Input type	Amplifier capacity	Width	Output	Maximum speed
DE Series	0x435A	DE0AC001A03M	DC48V	40A	30mm	5.1N	2.0m/s

■ Specific setting		
	Motor code	Contents
—	0x8000	Auto setting of motor parameter (When connected to applicable motor)
	0xFFFF	R ADVANCED – Based on motor setting (EEPROM setting value) set by setup software.

	<ul style="list-style-type: none"> ☞ Please contact our sales for the other motor above. ☞ To be Initialized by motor code set on EEPROM at power-on. When the motor code whose set parameter is different from EEPROM value, function becomes enabled when control power is re-turned on. Re-turn on control power since alarm "DE: parameter change completed" becomes active after new value is set to EEPROM. ☞ Automatic setting of motor parameter is performed when re-turning on the power supply after 0x8000 is set to any of motor code (0x20FE: 0x00), encoder division number code (0x20FF: 0x01), or encoder type code (0x20FF: 0x02). After that the three values are updated automatically.
--	--

5. Object Dictionary

0x20FF: Combination Encoder Selection

Index Ax1 Ax2 Ax3 Ax4	0x20FF 0x22FF 0x24FF 0x26FF	Selects the motor encoder specifications and functions driven by combination. * Reactivate the control power after changing the setting this will reset the setting.	Object Code	Record	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Number of entry	Unsigned8	RO	No	0x03
0x01	Encoder Resolution setting [ENCODE] Sets the division number of the motor encoder.	Unsigned16 Setting range	RW	No	0xFFFF
<ul style="list-style-type: none"> ■ When the incremental encoder is used 0x0000 : 500P/R 0x0001 : 512P/R 0x0002 : 1,000P/R 0x0003 : 1,024P/R 0x0004 : 1,500P/R 0x0005 : 2,000P/R 0x0006 : 2,048P/R 0x0007 : 2,500P/R 0x0008 : 3,000P/R 0x0009 : 4,000P/R 0x000A : 4,096P/R 0x000B : 5,000P/R 0x000C : 6,000P/R 0x000D : 8,192P/R 0x000E : 16,384P/R 0x000F : 32,768P/R 0x0010 : 10,000P/R 		<ul style="list-style-type: none"> ■ When the absolute encoder is used 0x0000 : 2,048FMT 0x0001 : 4,096FMT 0x0002 : 8,192FMT 0x0003 : 16,384FMT 0x0004 : 32,768FMT 0x0005 : 65,536FMT 0x0006 : 131,072FMT 0x0007 : 262,144FMT 0x0008 : 524,288FMT 0x0009 : 1,048,576FMT 		<ul style="list-style-type: none"> ■ when linear scale encoder is used. 0x0000 : 5μm [200P/mm] 0x0001 : 2.5μm [400P/mm] 0x0002 : 2μm [500P/mm] 0x0003 : 1.25μm [800P/mm] 0x0004 : 1μm [1,000P/mm] 0x0005 : 0.5μm [2,000P/mm] 0x0006 : 0.25μm [4,000P/mm] 0x0007 : 0.125μm [8,000P/mm] 0x0008 : 0.1μm [10,000P/mm] 0x0009 : 0.05μm [20,000P/mm] 	
<p><u>0x8000: Auto setting of motor parameter (When connected to applicable motor.)</u> <u>0xFFFF: Depends on division number setting (EEPROM setting value) of the MOTOR Setup software.</u></p> <p># Initialized by the encoder resolution number set in EEPROM at the turn-on state. When the encoder resolution number set parameter is different from the EEPROM value set, the function will be enabled by control source re-closing. After the new value is set in EEPROM, alarm "DE: parameter change completed" occurs, then re-close control source.</p> <p>☞ Automatic setting of motor parameter is performed when re-turning on the power supply after 0x8000 is set to any of motor code (0x20FE: 0x00), encoder division number code (0x20FF: 0x01), or encoder type code (0x20FF: 0x02). After that the three values are updated automatically.</p>					

■ Automatic setting of motor parameter

There are two ways to perform automatic setting of motor parameter.

- (1) 0x8000 is set to any of motor code (0x20FE: 0x00), encoder division number code (0x20FF: 0x01), or encoder type code (0x20FF: 0x02). After that all the three values are read out automatically from encoder on re-turning on the control power.
 - (2) When using automatic setting button on parameter setting display of MOTOR setup software, the procedure is as follow:
 - (a) Click automatic setting button on parameter setting display.
 - (b) Click OK-button if normally completed.
 - (c) Set motor code of system parameter tab to 0xFFFF.
 - (d) Re-turn on the control power.
- ✓ Refer to separate document, M0010842 for the details.

In the following cases, automatic setting of motor parameter function is not available.

- ✓ When alarm activated, in servo-on state, when encode-clear being performed.
- ✓ Connected to the motor which is not supported by automatic setting.
- ✓ Connected to the motor which is improper combination with the amplifier (motor size, encoder baud rate).

5. Object Dictionary



0x02	Encoder type [ENTYPE] Selects the type of motor encoder.	Unsigned16	RW	No	0xFFFF
		Setting range	0x0000-0xFFFF		
<p>■ Incremental system (Wire-saving incremental encoder: 4pairs) <u>0x0000: Wire-saving incremental encoder</u> <u>0x0002: Incremental encoder: CS normalization/ software setting (Magnetic pole position estimation)</u></p> <p>■ Incremental System (Absolute encoder for incremental system) <u>0x0101: asynchronous encoder 2.5MHz(without multiple rotation output)</u> <u>0x0201: asynchronous encoder 4.0MHz(without multiple rotation output)</u> *Used when the position at the turn-on state is zero.</p> <p>■ absolute system (multiple rotation backup system) <u>0x0300: optical asynchronous encoder 2.5MHz(with multiple rotation output)</u> <u>0x0400: optical asynchronous encoder 4.0MHz(with multiple rotation output)</u> <u>0x0600: resolver asynchronous encoder 2.5MHz(with multiple rotation output)</u> <u>0x0600: resolver asynchronous encoder 4.0MHz(with multiple rotation output)</u></p> <p>■ Incremental system (multiple rotation output system) <u>0x0301: optical asynchronous encoder 2.5MHz(with multiple rotation output)</u> <u>0x0401: optical asynchronous encoder 4.0MHz(with multiple rotation output)</u> <u>0x0501: resolver asynchronous encoder 2.5MHz(with multiple rotation output)</u> <u>0x0601: resolver asynchronous encoder 4.0MHz(with multiple rotation output)</u> *When the absolute encoder is used in the Incremental system, it is used when the turn-on state position is zero. In this setting, battery trouble and battery warnings are not detected.</p> <p>■ Incremental system (Clearing multiple rotation at initialization: +/- 1 turn or less) <u>0x0302: optical asynchronous encoder 2.5MHz(with multiple rotation output. +/- 1 turn or less at initialization)</u> <u>0x0402: optical asynchronous encoder 4.0MHz(with multiple rotation output. +/- 1 turn or less at initialization)</u> <u>0x0502: resolver asynchronous encoder 2.5MHz(with multiple rotation output. +/- 1 turn or less at initialization)</u> <u>0x0602: resolver asynchronous encoder 4.0MHz(with multiple rotation output. +/- 1 turn or less at initialization)</u> *Performing encoder clearing by initialization when power turns on. In this setting, battery trouble and battery warnings are not detected.</p> <p>■ Linear scale encoder (Only when using linear motor) <u>0x0850: signal/ limited to A,B, and Z :CS normalization/ software setting</u> <u>(Magnetic pole position estimation)</u> <u>0x0860: signal/ limited to A,B, and Z :CS normalization/ software setting (forced setting)</u></p> <p>■ Setting with the Setup software configuration <u>0x8000: Auto setting of motor parameter (When connected to applicable motor.)</u> <u>0xFFFF: R ADVANCED – with the encoder setting (EEPROM setting value) set in Setup software</u></p> <p>☞ Initialized by the encoder variety code set in EEPROM at the turn-on state. When the encoder variety set parameter is different from the EEPROM value set, the function will be enabled by control source re-closing. After the new value is set in EEPROM, alarm "DE: parameter change completed" occurs, then re-close control source.</p> <p>☞ Automatic setting of motor parameter is performed when re-turning on the power supply after 0x8000 is set to any of motor code (0x20FE: 0x00), encoder division number code (0x20FF: 0x01), or encoder type code (0x20FF: 0x02). After that the three values are updated automatically.</p>					

5. Object Dictionary

11) Monitor Parameter

0x2100: Status Word 1


Index Ax1 0x2100 Ax2 0x2300 Ax3 0x2500 Ax4 0x2700	Indicates servo amplifier status.	Object Code	Variable		
Sub-Idx 0x00	Description Status Word 1 Indicates various internal statuses of the amplifier.	Data Type Unsigned16	Access RO	PDO Possible	Initial value -



5. Object Dictionary

0x2101: Amplifier Error Field


Index Ax1	0x2101	Indicates the alarm occurring in the servo amplifier. Sub-Index 0x00 indicates the number of alarms that are currently occurring, and Sub-Index 0x01-0x04 indicates the contents of alarms and Amplifier Status when the alarms occur up to four. Resets the alarm by setting Alarm reset in Control Word (0x6040.7).	Object Code Array			
Ax2	0x2301					
Ax3	0x2501					
Ax4	0x2701					
Sub-Idx	Name	Description	Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x04
0x01	Error 1	: Alarm 1 [ALMACT1]	Unsigned8	RO	Possible	0x00
0x02	Error 2	: Alarm 2 [ALMACT2]	Unsigned8	RO	Possible	0x00
0x03	Error 3	: Alarm 3 [ALMACT3]	Unsigned8	RO	Possible	0x00
0x04	Error 4	: Alarm 4 [ALMACT4]	Unsigned8	RO	Possible	0x00



bit7-0: Alarm Code defined by this servo amplifier
See the Alarm Code list.

0x2102: Description of Alarm Trace

Index Ax1	0x2102	Indicates the Alarm history of the servo amplifier occurring now or previously.	Object Code	Array		
Ax2	0x2302					
Ax3	0x2502					
Ax4	0x2702					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x08
0x01	Now Status [NOWALM] *When the Alarm doesn't occur, it becomes 0x0000.		Unsigned32	RO	Possible	0x00000000
0x02	1 st Latest Alarm	[LASTAL1]	Unsigned32	RO	Possible	0x00000000
0x03	2 nd Latest Alarm	[LASTAL2]	Unsigned32	RO	Possible	0x00000000
0x04	3 rd Latest Alarm	[LASTAL3]	Unsigned32	RO	Possible	0x00000000
0x05	4 th Latest Alarm	[LASTAL4]	Unsigned32	RO	Possible	0x00000000
0x06	5 th Latest Alarm	[LASTAL5]	Unsigned32	RO	Possible	0x00000000
0x07	6 th Latest Alarm	[LASTAL6]	Unsigned32	RO	Possible	0x00000000
0x08	7 th Latest Alarm	[LASTAL7]	Unsigned32	RO	Possible	0x00000000



bit7-0: Alarm Code defined by this servo amplifier
See the Alarm Code list.

bit15-8: Status when an alarm occurs
See the Status list.

bit32-16: Cumulative operating times when an alarm occurs
(The value at the time of shipment: 0H)
The cumulative operation times when an alarm occurs (2 Hour / LSB units)
Increments every two hours after control power on.
* Please use as a guide by the hour increments.



Status (ALMSTS) function

Status Display	ALMSTS	Status Display	ALMSTS
Power OFF	0x00	Servo ON 1(Reprocessing the electric current detector)	0x07
Power ON 1 (electric current detector during setting)	0x01	Servo ON 2 (command reception allowed)	0x08
Power ON 2(main circuit charging)	0x02	magnetic pole position detected (Reserved)	0x09
Power ON 3(main circuit charged)	0x03	Emergency stop 1 (Emergency Stop status)	0x0A
Servo ready	0x04	Emergency stop 2(CNOTRDY)	0x0B
Prepared for magnetic pole position detection (Reserved)	0x05	Reserved	0x0C-0x0E
Power ON 4	0x06	Initial State	0x0F

5. Object Dictionary

0x2103: Warning Status

Index Ax1	0x2103	Indicates the warnings and limitation status of the servo amplifier.	Object Code	Record		
Ax2	0x2303					
Ax3	0x2503					
Ax4	0x2703					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x02
0x01	Warning monitor [WARMON] 0:no warning (without limitation) 1:during warning (under limitation)		Unsigned16	RO	Possible	0x0000



Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x02	Warning mask Selection [WARMASK] Sets the condition to set status word (0x6041) bit7: warning status. Clears the corresponding bits for warning monitors to get rid of from the warning status condition. After the AND operation of the Warning Monitor/ Mask, if flags are set, sets Warning status.	Unsigned16	RW	No	0x4E8D

5. Object Dictionary

0x2104: Actual Gain Monitor

Index Ax1 Ax2 Ax3 Ax4	0x2104 0x2304 0x2504 0x2704	Indicates the actual setting value of the gain parameter to switch to real time various gain parameters through auto-tuning or gain switching selection.	Object Code	Array	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Number of entry	Unsigned8	RO	No	0x07
0x01	Actual Position Loop Proportional Gain [KPMON] Outputs the value of the position loop gain (0x2005) that is switched in auto-tuning mode (0x2002) or the gain switching selection (0x2001, bit 5-4), and is currently used for the servo control.	Unsigned16	RO	Possible	0x001E (30 /s)
		Setting range	0x0001-0x0BB8 (1-3000 /s)		
		Unit	1/s		
0x02	Actual Position Integral Time Constant [TPIMON] Outputs the value of the position integral time constant (0x2006) that is switched in auto-tuning mode (0x2002) or the gain switching selection (0x2001, bit 5-4), and is currently used for the servo control.	Unsigned16	RO	Possible	0x2710 (1000ms) proportional control
		Setting range	0x0003-0x2710 (0.3-1000 ms)		
		Unit	0.1ms		
0x03	Actual Velocity Loop Proportional Gain [KVPMON] Outputs the value of the velocity loop proportional gain (0x200B) that is switched in auto-tuning mode (0x2002) or the gain switching selection (0x2001, bit 5-4), and is currently used for the servo control.	Unsigned16	RO	Possible	0x0032 (50Hz)
		Setting range	0x0001-0x07D0 (1-2000 Hz)		
		Unit	Hz		
0x04	Actual Velocity Loop Integral Time Constant [TVIMON] Outputs the value of the velocity loop integral time constant (0x200C) that is switched in auto-tuning mode (0x2002) or the gain switching selection (0x2001, bit 5-4), and is currently used for the servo control.	Unsigned16	RO	Possible	0x00C8 (20ms)
		Setting range	0x0003-0x2710 (0.3-1000 ms)		
		Unit	0.1ms		
0x05	Actual Load Inertia Moment Ratio [JRATMON] Outputs the value of the load inertia moment ratio (0x200D) that is switched in auto-tuning mode (0x2002) or the gain switching selection (0x2001, bit 5-4), and is currently used for the servo control.	Unsigned16	RO	Possible	0x0064 (100%)
		Setting range	0x0000-0x3A98 (0-15000%)		
		Unit	%		
0x06	Actual Torque (force) Command Filter [TCFILMON] Outputs the value of the torque command filter (0x2011) that is switched in auto-tuning mode (0x2002) or the gain switching selection (0x2001, bit 5-4), and is currently used for the servo control.	Unsigned16	RO	Possible	0x0258 (600Hz)
		Setting range	0x0001-0x07D0 (1-2000 Hz)		
		Unit	Hz		
0x07	Actual Model Control Gain [MKPMON] Outputs the value of the model control gain (0x2017) that is switched in auto-tuning mode (0x2002) or the gain switching selection (0x2001, bit 5-4), and is currently used for the servo control.	Unsigned16	RO	Possible	0x001E (30 /s)
		Setting range	0x0001-0x0BB8 (1-3000 /s)		
		Unit	1/s		

0x2105: Z-phase Signal Base Actual Position

Index Ax1 Ax2 Ax3 Ax4	0x2105 0x2305 0x2505 0x2705	Indicates the Actual Position from Zero-phase.	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Z-phase Signal Base Actual Position [CCUNIT] *In the incremental encoder indicates the position within one rotation based on C phase. The location increases to the direction of CCW seen head-on. The unit is 1 Pulse/LSB, four-fold value of A·B phases. It is indefinite after the turning-on until C phase is detected. (Example: At the 1024P/Re encoder, 0 - 4095Pulse indicated) *In the Absolute Encoder, indicates the position within one rotation based on Absolute Positon.	Integer32	RO	Possible	-
		Setting range	0x00000000-0xFFFFFFFF (0-4294967295 Pulse)		
		Unit	Pulse		

0x2106: Internal Velocity Command Monitor

Index Ax1 Ax2 Ax3 Ax4	0x2106 0x2306 0x2506 0x2706	Has the actual velocity value calculated from the position encoder The value is provided by the user-defined velocity unit.	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Internal Velocity Command Monitor [VCMON] An Internal Velocity Command Value after passing the Velocity Command low-pass filter.	Integer32	RO	Possible	-
		Setting range	0x80000000-0x7FFFFFFF (-2147483648-2147483647 pps)		
		Unit	Pulse/sec		

5. Object Dictionary

0x2107: Internal Torque (force) Command Monitor

Index Ax1	0x2107	Indicates the torque (force) indication monitor inside the servo amplifier.	Object Code		Variable	
Ax2	0x2307					
Ax3	0x2507					
Ax4	0x2707					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Internal Torque Command Monitor [TCMON] An Internal Torque (force) Command value after passing the Velocity Command low-pass filter. It is indicated at the ratio with the motor rated torque (force) 100%.		Integer16	RO	Possible	-
			Setting range	0x8000-0x7FFF (-3276.8-3276.7 %)		
			Unit	0.1 %		

0x2108: Motor utilization monitor (Effective torque (force) estimate value)

Index Ax1	0x2108	Indicates the estimation value of the Effective Motor Torque (force).	Object Code		Variable	
Ax2	0x2308					
Ax3	0x2508					
Ax4	0x2708					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x02
0x01	Effective Torque (force) Estimated Value [TRMS] Indicates the Effective Motor Torque (force) against the motor rated torque (force). * The exact value is indicated, but in some operation patterns, it may take several hours to stabilize the figure.		Unsigned16	RO	Possible	-
			Setting range	0x0000-0xFFFF (0-65535 %)		
			Unit	%		
0x02	Fast Effective Torque (force) Estimate Value [ETRMS] Indicates the Effective Motor Torque (force) of time constant (1/16) against TRMS. * Quick estimation is possible in applications where short-cycle operation patterns are repeated.		Unsigned16	RO	Possible	-
			Setting range	0x0000-0xFFFF (0-65535 %)		
			Unit	%		

0x2109: Temperature inside the servo amplifier

Index Ax1	0x2109	Indicates the temperature inside the servo amplifier.	Object Code		Variable	
Ax2	0x2309					
Ax3	0x2509					
Ax4	0x2709					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Temperature inside the servo amplifier [ATEMP] The monitor value inside the servo amplifier (near the control CPU). The unit is the Celsius scale and indicated by 1 °C / LSB.		Integer16	RO	Possible	-
			Setting range	0x8000-0x7FFF (-32768-32767 °C)		
			Unit	°C		
<p>If Monitor value <= -10 °C, +75 °C <= Monitor value, it indicates temperature warning. If Monitor value <= -15 °C, +95 °C <= Monitor value, it indicates temperature alarm. Conversion to Fahrenheit (F) is calculated according to the following formula: $F = 9 / 5 * C + 32$.</p>						

0x210A: Regenerative resistor operation percentage monitor

Index	0x210A	An estimate monitor of the operation ratio of the servo amplifier regenerative resistor. This amplifier has single ESC. So, this is single object, also.	Object Code		Variable	
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Regenerative resistor operation percentage monitor [REGP] An operation percentage monitor of regenerative resistors representing the regenerator-on time ratio in 1sec. The regenerative electricity PM is calculated according to the following formula, using this monitor value.		Unsigned16	RO	Possible	0x0000 (0%)
			Setting range	0x0000-0xFFFF (0-655.35%)		
			Unit	0.01 %		
<p>For DC48V input: $PM (W) = 60^2 (V) / \text{regenerative resistance value (ohm)} \times \text{Regenerative resistor operation percentage (\%)} / 100(\%)$ For DC24V input: $PM (W) = 30^2 (V) / \text{regenerative resistance value (ohm)} \times \text{Regenerative resistor operation percentage (\%)} / 100(\%)$</p>						

0x210B: Encoder Temperature Monitor

Index Ax1	0x210B	The temperature of an encoder is displayed.	Object Code		Variable	
Ax2	0x230B					
Ax3	0x250B					
Ax4	0x270B					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Encoder Temperature Monitor [ETEMP] The monitor value of the temperature of the encoder control board, shown in the unit of °C Celsius/LSB.		Integer16	RO	Possible	-
			Setting range	0xFF80-0x007F (-128-127 °C)		
			Unit	°C		
<p>✓The encoder temperature is detected at the time that the servo amplifier stops. If the stop status continues, the encoder temperature monitor continuously and repeatedly detects the temperature of the encoder each 1s cycle. ✓When the encoder temperature detection is set to disable (0x2000 bit13 = 1), it will not detect the temperature.</p>						

5. Object Dictionary

0x210C: Home Index Position Detection Value

Index Ax1	0x210C	Home Index Positions latched by various systems of homing modes.	Object Code		Variable	
Ax2	0x230C					
Ax3	0x250C					
Ax4	0x270C					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Home Index Position Detection Value [HOMEIDX] When homing activate and latched home index then indicates Internal position. *Incremental system Internal position is based on counter value when control power on. *Absolute system Internal position is based on absolute encoder value.		Integer32	RO	Possible	-
			Setting range	0x80000000-0x7FFFFFFF (-2147483648-2147483647Pulse)		
			Unit	Pulse		

0x210D: Position Synchronization Deviation Monitor

Index Ax1	0x210D	Position deviation between two synchronous connected amplifiers is monitored.	Object Code		Variable	
Ax2	0x230D					
Ax3	0x250D					
Ax4	0x270D					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Position Synchronization Deviation Monitor [PSYNDEV] When position synchronization correction function is valid, the monitor indicates error pulse quantity from position deviation of amplifiers which are subject to synchronization. ✓This is valid when 0x01 - 0x04 in 0x2035-8 Assist-function selection is set.		Integer32	RO	Possible	-
			Setting range	0x80000000-0x7FFFFFFF (-2147483648-2147483647 pulse)		
			Unit	Pulse		

0x2110: Internal Control Cycle Position Actual Value

Index Ax1	0x2110	Returns the Actual Position value latched every control cycle (125µs). Monitor unit is expressed by the resolution of the motor encoder used.	Object Code		Array	
Ax2	0x2310					
Ax3	0x2510					
Ax4	0x2710					
Sub-Idx	Description		Data Type	Access	PDO	Initial value
0x00	Number of entry		Unsigned8	RO	No	0x07
0x01	Internal Control Cycle Actual Position 1 Actual position of 0x6064, 125µs ago.		Integer32	RO	Possible	-
0x02	Internal Control Cycle Actual Position 2 Actual position of 0x6064, 250µs ago.		Integer32	RO	Possible	-
0x03	Internal Control Cycle Actual Position 3 Actual position of 0x6064, 375µs ago.		Integer32	RO	Possible	-
0x04	Internal Control Cycle Actual Position 4 Actual position of 0x6064, 500µs ago.		Integer32	RO	Possible	-
0x05	Internal Control Cycle Actual Position 5 Actual position of 0x6064, 625µs ago.		Integer32	RO	Possible	-
0x06	Internal Control Cycle Actual Position 6 Actual position of 0x6064, 750µs ago.		Integer32	RO	Possible	-
0x07	Internal Control Cycle Actual Position 7 Actual position of 0x6064, 875µs ago.		Integer32	RO	Possible	-
			Setting range	0x80000000-0x7FFFFFFF (-2147483648-2147483647 Pulse)		
			Unit	Pulse		

5. Object Dictionary

0x2111: Internal Control Cycle Actual Velocity

Index Ax1	0x2111	Returns the Actual Velocity value latched every control cycle (125µs).	Object Code	Array	
Ax2	0x2311				
Ax3	0x2511				
Ax4	0x2711				
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Number of entry	Unsigned8	RO	No	0x07
0x01	Internal Control Cycle Actual Velocity 1 Actual velocity of 0x606C, 125µs ago.	Integer32	RO	Possible	-
0x02	Internal Control Cycle Actual Velocity 2 Actual velocity of 0x606C, 250µs ago.	Integer32	RO	Possible	-
0x03	Internal Control Cycle Actual Velocity 3 Actual velocity of 0x606C, 375µs ago.	Integer32	RO	Possible	-
0x04	Internal Control Cycle Actual Velocity 4 Actual velocity of 0x606C, 500µs ago.	Integer32	RO	Possible	-
0x05	Internal Control Cycle Actual Velocity 5 Actual velocity of 0x606C, 625µs ago.	Integer32	RO	Possible	-
0x06	Internal Control Cycle Actual Velocity 6 Actual velocity of 0x606C, 750µs ago.	Integer32	RO	Possible	-
0x07	Internal Control Cycle Actual Velocity 7 Actual velocity of 0x606C, 875µs ago.	Integer32	RO	Possible	-
*Data is filtered and the cutoff frequency is 250Hz.		Setting range	0x80000000-0x7FFFFFFF (-2147483648-2147483647 pps)		
		Unit	Pulse/sec		

0x2112: Internal Control Cycle Actual Torque (force)

Index Ax1	0x2112	Returns the Actual Torque (force) value latched every control cycle (125µs).	Object Code	Array	
Ax2	0x2312				
Ax3	0x2512				
Ax4	0x2712				
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Number of entry	Unsigned8	RO	No	0x03
0x01	Internal Control Cycle Actual Torque (force) 1 Actual torque(force)position of 0x6077, 125µs ago.	Integer16	RO	Possible	-
0x02	Internal Control Cycle Actual Torque (force) 2 Actual torque(force) of 0x6077, 250µs ago.	Integer16	RO	Possible	-
0x03	Internal Control Cycle Actual Torque (force) 3 Actual torque(force) of 0x6077, 375µs ago.	Integer16	RO	Possible	-
0x04	Internal Control Cycle Actual Torque (force) 4 Actual torque(force) of 0x6077, 500µs ago.	Integer16	RO	Possible	-
0x05	Internal Control Cycle Actual Torque (force) 5 Actual torque(force) of 0x6077, 625µs ago.	Integer16	RO	Possible	-
0x06	Internal Control Cycle Actual Torque (force) 6 Actual torque(force) of 0x6077, 750µs ago.	Integer16	RO	Possible	-
0x07	Internal Control Cycle Actual Torque (force) 7 Actual torque(force) of 0x6077, 875µs ago.	Integer16	RO	Possible	-
Monitor unit is the 1/1000 units of the rated torque (force) and 0.1% / LSB.		Setting range	0x8000-0x7FFF (-3276.8-3276.7%)		
		Unit	0.1%		

5. Object Dictionary

0x2116: Actual Velocity 2

Index Ax1 Ax2 Ax3 Ax4	0x2116 0x2316 0x2516 0x2716	Has actual velocity value calculated from position encoder. Value shall be given in the velocity unit of user definition.	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Actual Velocity [ACVMON2] ✓Filter is processed data, and cutoff frequency is 20Hz	Integer32	RO	Possible	—
		Setting range	0x80000000-0x7FFFFFFF (-2147483648-2147483647 pps)		
		Unit	Pulse/sec		

0x2117: Position Actual Value 2

Index Ax1 Ax2 Ax3 Ax4	0x2117 0x2317 0x2517 0x2717	Indicates the actual position without backlash correction value.	Object Code	Variable	
Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Position Actual Value 2 [APMON2] Indicates the actual position without backlash correction value. ◆With backlash correction Position Actual Value 2 =Position Actual Value (0x6064) - Backlash correction value (0x5091) ◆Without backlash correction Position Actual Value 2 =Position Actual Value	Integer32	RO	Possible	—
		Setting range	0x80000000-0x7FFFFFFF (-2147483648-2147483647)		
		Unit	Pulse		

0x2120: Amplifier Parameter Information

Index Ax1 Ax2 Ax3 Ax4	0x2120 0x2320 0x2520 0x2720	Indicate servo amplifier status.	Object Code	Array																																																																				
Sub-Idx	Description	Data Type	Access	PDO	Initial value																																																																			
0x00	Number of entry	Unsigned8	RO	No	0x04																																																																			
0x01	Indicate status of alarm masking. Each bit fit to alarm below.	Unsigned32	RO	Possible	0x00000000																																																																			
	<table border="1"> <thead> <tr> <th colspan="2">Alarm</th> <th colspan="2">Alarm</th> </tr> </thead> <tbody> <tr><td>Bit31</td><td>EEPE2</td><td>Bit15</td><td>PARE</td></tr> <tr><td>Bit30</td><td>MPARA</td><td>Bit14</td><td>OVC</td></tr> <tr><td>Bit29</td><td>VCCE</td><td>Bit13</td><td>OVF</td></tr> <tr><td>Bit28</td><td>IPMOH</td><td>Bit12</td><td>All of encoder alarm</td></tr> <tr><td>Bit27</td><td>RSOH</td><td>Bit11</td><td>All of communication alarm</td></tr> <tr><td>Bit26</td><td>HWBBE1,2</td><td>Bit10</td><td>RGOL</td></tr> <tr><td>Bit25</td><td>Reserved</td><td>Bit9</td><td>IFBE1 - 3</td></tr> <tr><td>Bit24</td><td>SOL</td><td>Bit8</td><td>IPME</td></tr> <tr><td>Bit23</td><td>Main Circuit Under-voltage alarm</td><td>Bit7</td><td>EXOH</td></tr> <tr><td>Bit22</td><td>DBOH</td><td>Bit6</td><td>RGOH</td></tr> <tr><td>Bit21</td><td>TSKE</td><td>Bit5</td><td>AOH</td></tr> <tr><td>Bit20</td><td>ADBUSE</td><td>Bit4</td><td>OVC</td></tr> <tr><td>Bit19</td><td>RAME</td><td>Bit3</td><td>OL</td></tr> <tr><td>Bit18</td><td>PE</td><td>Bit2</td><td>OS</td></tr> <tr><td>Bit17</td><td>CPE</td><td>Bit1</td><td>FP</td></tr> <tr><td>Bit16</td><td>OVE</td><td>Bit0</td><td>MPE</td></tr> </tbody> </table>	Alarm		Alarm		Bit31	EEPE2	Bit15	PARE	Bit30	MPARA	Bit14	OVC	Bit29	VCCE	Bit13	OVF	Bit28	IPMOH	Bit12	All of encoder alarm	Bit27	RSOH	Bit11	All of communication alarm	Bit26	HWBBE1,2	Bit10	RGOL	Bit25	Reserved	Bit9	IFBE1 - 3	Bit24	SOL	Bit8	IPME	Bit23	Main Circuit Under-voltage alarm	Bit7	EXOH	Bit22	DBOH	Bit6	RGOH	Bit21	TSKE	Bit5	AOH	Bit20	ADBUSE	Bit4	OVC	Bit19	RAME	Bit3	OL	Bit18	PE	Bit2	OS	Bit17	CPE	Bit1	FP	Bit16	OVE	Bit0	MPE			
Alarm		Alarm																																																																						
Bit31	EEPE2	Bit15	PARE																																																																					
Bit30	MPARA	Bit14	OVC																																																																					
Bit29	VCCE	Bit13	OVF																																																																					
Bit28	IPMOH	Bit12	All of encoder alarm																																																																					
Bit27	RSOH	Bit11	All of communication alarm																																																																					
Bit26	HWBBE1,2	Bit10	RGOL																																																																					
Bit25	Reserved	Bit9	IFBE1 - 3																																																																					
Bit24	SOL	Bit8	IPME																																																																					
Bit23	Main Circuit Under-voltage alarm	Bit7	EXOH																																																																					
Bit22	DBOH	Bit6	RGOH																																																																					
Bit21	TSKE	Bit5	AOH																																																																					
Bit20	ADBUSE	Bit4	OVC																																																																					
Bit19	RAME	Bit3	OL																																																																					
Bit18	PE	Bit2	OS																																																																					
Bit17	CPE	Bit1	FP																																																																					
Bit16	OVE	Bit0	MPE																																																																					
	Alarm is masked by setting 1 to each bit.																																																																							
0x02	Control status Indicate control by Since this amplifier is controlled by only the EtherCAT communication, values other than 1 cannot be set.	Unsigned8	RW	No	0x01																																																																			
0x03	Amplifier running time Indicate total power on time after shipping from factory in increments of 2 hours.	Unsigned32	RO	No	—																																																																			
		Unit	2 hour																																																																					
0x04	External regenerative resistance Indicate recommended value of minimum external regenerative resistance.	Unsigned32	RW	Possible	※																																																																			
		Setting range	0x00000000-0xFFFFFFFF																																																																					
		Unit	mΩ																																																																					

※) Initial value varies addording to amplifier capacity.

5. Object Dictionary

0x2151: Error Register

Index Ax1	0x2151	Indicates error state of slave. Refer to (Error Field Definition) for the details of error.	Object Code		VAR	
Ax2	0x2351					
Ax3	0x2551					
Ax4	0x2751					
Sub-Idx	Name/Description		Data Type	Access	PDO	Initial Value
0x00	Error Register [ERRREG]		Unsigned8	RO	Possible	0x00
	<u>Bit7:Maker Definition Error</u> <u>Bit6:Reserved</u> <u>Bit5:Device Profile Definition Error</u> <u>Bit4:Communication Error</u> <u>Bit3:Temperature Error</u> <u>Bit2:Voltage Error</u> <u>Bit1:Current Error</u> <u>Bit0:Generic error</u>					
	<input checked="" type="checkbox"/> Index 0x2151 is same as Index 0x1001.					

0x2152: Device Name

Index Ax1	0x2152	Indicates product device name.	Object Code		VAR	
Ax2	0x2352					
Ax3	0x2552					
Ax4	0x2752					
Sub-Idx	Name/Description		Data Type	Access	PDO	Value
0x00	Device Name [DEVICE] Product Device Name (ASCII Code)		Visible String	RO	No	Character String (-)
	<input checked="" type="checkbox"/> Index 0x2152 is same as Index 0x1008.					
<u>RF2</u>						


0x2153: FPGA Hardware Version

Index	0x2153	Indicates FPGA hardware version.	Object Code		VAR	
Sub-Idx	Name/Description		Data Type	Access	PDO	Value
0x00	Hardware Version [HARDVER] Hardware Version of Device		Visible String (Unsigned32)	RO	No	Character String (-)

5. Object Dictionary


0x2154: Communication Software Version

Index	0x2154	Indicates product software version.	Object Code		VAR	
Sub-Idx	Name/Description		Data Type	Access	PDO	Value
0x00	Software Version [SOFTVER] Communication Software Version of Device		Visible String (Unsigned32)	RO	No	Character String (-)
8 E 0 0 . 0 . 5 7 2 0						



0x2155: Servo Software Version

Index	Ax1 0x2155 Ax2 0x2355 Ax3 0x2555 AX4 0x2755	Indicates product software version.	Object Code		VAR	
Sub-Idx	Name/Description		Data Type	Access	PDO	Value
0x00	Software Version [SOFTVER] Servo Software Version of Device ✓ Index 0x2155 is nearly same as Index 0x100A.		Visible String (Unsigned32)	RO	No	Character String (-)
8 D 0 0 . 0 . 0 7 2 0						



5. Object Dictionary

0x2156: Alarm Estimation Cause Code

Index Ax1	0x2156	Indicates estimated cause code for alarm occurrence. Amount of indicating estimated cause code differs depending on kinds of occurred alarm.	Object Code	Variable		
Ax2	0x2356					
Ax3	0x2556					
Ax4	0x2756					
Sub-Idx	Description		Data Type	Access	PDO	Initial Value
0x00	Number of entry		Unsigned8	RO	No	0x08
0x01	Alarm Estimation Cause Code 1	[ALMCAUSE1]	Unsigned16	RO	No	0x0000
0x02	Alarm Estimation Cause Code 2	[ALMCAUSE2]	Unsigned16	RO	No	0x0000
0x03	Alarm Estimation Cause Code 3	[ALMCAUSE3]	Unsigned16	RO	No	0x0000
0x04	Alarm Estimation Cause Code 4	[ALMCAUSE4]	Unsigned16	RO	No	0x0000
0x05	Alarm Estimation Cause Code 5	[ALMCAUSE5]	Unsigned16	RO	No	0x0000
0x06	Alarm Estimation Cause Code 6	[ALMCAUSE6]	Unsigned16	RO	No	0x0000
0x07	Alarm Estimation Cause Code 7	[ALMCAUSE7]	Unsigned16	RO	No	0x0000
0x08	Alarm Estimation Cause Code 8	[ALMCAUSE8]	Unsigned16	RO	No	0x0000
			Display Range	0x0000-0xFFFF		

✔ It will be 0x0000 if there is no estimated cause.

0x2157: FPGA Initialization error

Index	0x2157	Indicates state of FPGA initialization.	Object Code	VAR		
Sub-Idx	Name/Description				Data Type	Access
0x00	FPGA Initialization error	[FPGAINIERR]	Unsigned16	RO	No	0x0000
		bit7-15: Reserved				
		bit6: SRAM error				
		bit5: Internal RAM2 error				
		bit4: Internal RAM1 error				
		bit3: DPRAM error for AX4				
		bit2: DPRAM error for AX3				
		bit1: DPRAM error for AX2				
		bit0: DPRAM error for AX1				

5. Object Dictionary

0x5010: Motor data

Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Number of entry	Unsigned8	RO	No	0x07
0x01	Number of motor pole	Unsigned8	RO	Possible	0x00
		Unit		Pole	
0x02	Phase resistance	Unsigned16	RO	Possible	0x0000
		Unit		mΩ	
0x03	Phase inductance	Unsigned16	RO	Possible	0x0000
		Unit		μH	
0x04	Moment of inertia	Unsigned16	RO	Possible	0x0000
		Unit		gmm ²	
0x05	Voltage constant for each phase	Unsigned32	RO	Possible	0x0000
		Unit		μVrms/min-1	
0x06	Rated torque	Unsigned16	RO	Possible	0x0000
		Unit		mN·m/Arms	

Support R series motor only.
Disabled to Q series or previous motor.

0x5040: Position Unit System

Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Number of entry	Unsigned8	RO	No	0x05
0x01	Software expression in 100% of full scale 100% of full scale expression is applied in the value of the software. The display value is 1 (1bit) fixed.	Unsigned8	RO	Possible	0x01
0x02	Full-scale Unit Unit of full scale value. The display value is 1 (Encoder Count) fixed.	Unsigned16	RO	Possible	0x0001
0x03	Full-scale Data Type Indicates the data type to be used in the full scale value. The display value is 1 (Integer Type 32bit) fixed.	Unsigned16	RO	Possible	0x0001
0x04	Full-scale Unit Transforms into the actual unit. The display value is 1 (1bit) fixed.	Unsigned16	RO	Possible	0x0001

0x5041: Position Unit System

Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Number of entry	Unsigned8	RO	No	0x05
0x01	Software expression in 100% of full scale 100% of full scale expression is applied in the value of the software. The display value is 1 (pps) fixed.	Unsigned8	RO	Possible	0x01
0x02	Full-scale Unit Unit of full scale value. The display value is 1 (pps) fixed.	Unsigned16	RO	Possible	0x0001
0x03	Full-scale Data Type Indicates the data type to be used in the full scale value. The display value is 1 (Integer Type 32bit) fixed.	Unsigned16	RO	Possible	0x0001
0x04	Full-scale Value Transforms into the actual unit. The display value is 1 (pps) fixed.	Unsigned16	RO	Possible	0x0001

5. Object Dictionary

0x5042: Acceleration Unit System

Sub-Idx	Description	Data Type	Access	PDO	Initial value
0x00	Number of entry	Unsigned8	RO	No	0x05
0x01	Software expression in 100% of full scale 100% of full scale expression is applied in the value of the software. The display value is 1 (pps ²) fixed.	Unsigned8	RO	Possible	0x01
0x02	Full-scale Unit Unit of full scale value. The display value is 1 (pps ²) fixed.	Unsigned16	RO	Possible	0x0001
0x03	Full-scale Data Type Indicates the data type to be used in the full scale value. The display value is 1 (Integer Type 32bit) fixed.	Unsigned16	RO	Possible	0x0001
0x04	Full-scale Value Transforms into the actual unit. The display value is 1 (pps ²) fixed.	Unsigned16	RO	Possible	0x0001

6

6. Operations

6.1	Standard Setting Value upon Shipment	6-1
6.2	Test operation	6-2
1)	Installation and Wiring	6-2
2)	Safe Torque OFF Function	6-2
3)	Movement Confirmation	6-3
4)	Machine Movement Check	6-4
6.3	ESC Power ON Sequence	6-5
6.4	EtherCAT Initialization Process	6-6
1)	INIT State	6-6
2)	Pre-Operational State	6-8
3)	Safe-Operational State	6-9
4)	Operational State	6-9
6.5	Operation Sequence	6-10
1)	Operation Sequence from Power ON to Power OFF	6-10
2)	Alarm Occurrence Stop Sequence	6-14
3)	Alarm Reset Sequence	6-17

6.1 Standard Setting Value upon Shipment

The system parameters setting value upon shipment from the factory is shown below.

■ Servo Amplifier Model Number: RF2O##AΔHL5


ID	Name	Code	Setting Value	Object
00	Main Circuit Power Input Classification	○ : K ○ : J	48VDC input 02 : DC 24VDC input	0x20FD.1: MPWRIN
01	Regenerative Resistance Selection	-	Without resistor 02 : External_R	0x20FD.2: RGKIND
02	Motor Code	## : 14 ## : 24	48VDC input 025A : 0x040C (R2GAD102RM) 040A : 0x0261 (R2GA04003F)	0x20FE.0: MOCODE
03	Encoder Division Number Code	Δ : 0 Δ : 8	Absolute : 0x0006(131,072FMT) Incremental : 0x0005(2,000P/R)	0x20FF.1: ENCODE
04	Encoder Classification Code	Δ : 0 Δ : 8	Absolute: 0x0300 (Asynchronous Communication 2.5MHz High-rotation backup method) Incremental: 0x0000 (Wiring-saving Incremental Encoder)	0x20FF.2: ENTTYPE
05	Extension Station Alias	-	00:PA_S_2.5M	0x20FA.0: EXALOAS
06	Operation Mode	-	0x00 (No Mode, No Mode Definitions)	0x6060.0: OPMODE
07	Position Control Selection	-	00:Standard	0x20F3.0: PCNTSEL

* Please confirm with separate volume M0010842 for operation methods of Setup Software

6.2 Test operation

1) Installation and Wiring

Confirm the installation and wiring of the servo amplifier and servo motor.

Process	Items and Contents
1	<p data-bbox="395 465 520 495">Installation</p> <ul style="list-style-type: none"> <li data-bbox="395 499 1356 589">■ Install servo amplifier and servo motor according to “Installation 3-1”. Servo motor shaft should be in disengaged state and machine should not be connected. 
2	<p data-bbox="395 752 794 781">Wiring / Connecting → Input Power</p> <ul style="list-style-type: none"> <li data-bbox="395 786 1388 853">■ Power supply wire, servo motor and host device, however, do not connect CN0 (Port 0) / CN1 (Port 1) to servo amplifier after wiring. <li data-bbox="395 887 1409 976">■ Input power supply: Confirm no alarm code is displayed on the display screen on the upper front of the amplifier. When alarm code is displayed, take appropriate measures based on “Troubleshooting (Chapter 9)”. <li data-bbox="395 1010 1374 1077">■ When 7 segment LED does not light “≡” through main circuit power input, take appropriate measures based on “Troubleshooting (Chapter 9)”.

2) Safe Torque OFF Function

When using a product that corresponds to the Safe Torque OFF (STO) function, please check the function followed with a Confirmation Test (Chapter 13) to verify normal operation.

3) Movement Confirmation


Perform JOG operations using Setup Software or Digital Operator.

Process	Items and Contents																																								
1	Input signal check: Generic Input signals (CN2)																																								
	Select Input signals to be used from General parameter Group9 and assign in CONT1, and CONT2.																																								
	<table border="1"> <thead> <tr> <th colspan="2"></th> <th colspan="2">Factory Shipment Setting Value</th> </tr> <tr> <th>Input Signal</th> <th>CN2 Pin No.</th> <th colspan="2">Setting Value</th> </tr> </thead> <tbody> <tr> <td>CONT1</td> <td>1, 2</td> <td colspan="2">00:Always_Disable</td> </tr> <tr> <td>CONT2</td> <td>3, 4</td> <td colspan="2">00:Always_Disable</td> </tr> <tr> <td>CONT3</td> <td>5, 6</td> <td colspan="2">00:Always_Disable</td> </tr> <tr> <td>CONT4</td> <td>7, 8</td> <td colspan="2">00:Always_Disable</td> </tr> <tr> <td>CONT5</td> <td>19, 20</td> <td colspan="2">00:Always_Disable</td> </tr> <tr> <td>CONT6</td> <td>21, 22</td> <td colspan="2">00:Always_Disable</td> </tr> <tr> <td>CONT7</td> <td>23, 24</td> <td colspan="2">00:Always_Disable</td> </tr> <tr> <td>CONT8</td> <td>25, 26</td> <td colspan="2">00:Always_Disable</td> </tr> </tbody> </table>			Factory Shipment Setting Value		Input Signal	CN2 Pin No.	Setting Value		CONT1	1, 2	00:Always_Disable		CONT2	3, 4	00:Always_Disable		CONT3	5, 6	00:Always_Disable		CONT4	7, 8	00:Always_Disable		CONT5	19, 20	00:Always_Disable		CONT6	21, 22	00:Always_Disable		CONT7	23, 24	00:Always_Disable		CONT8	25, 26	00:Always_Disable	
			Factory Shipment Setting Value																																						
	Input Signal	CN2 Pin No.	Setting Value																																						
	CONT1	1, 2	00:Always_Disable																																						
	CONT2	3, 4	00:Always_Disable																																						
	CONT3	5, 6	00:Always_Disable																																						
	CONT4	7, 8	00:Always_Disable																																						
	CONT5	19, 20	00:Always_Disable																																						
CONT6	21, 22	00:Always_Disable																																							
CONT7	23, 24	00:Always_Disable																																							
CONT8	25, 26	00:Always_Disable																																							
* The factory default gives no assignment function to the general signal.																																									
2	Output signal check: Generic Output signals (CN3)																																								
	<ul style="list-style-type: none"> ■ Select Output signals to be used from General parameter Group9 and assign in OUT1 and OUT2. 																																								
	<table border="1"> <thead> <tr> <th colspan="2"></th> <th colspan="2">Factory Shipment Setting Value</th> </tr> <tr> <th>Output Signal</th> <th>CN2 Pin No</th> <th>Setting Value</th> <th>Object: Index, Sub-index</th> </tr> </thead> <tbody> <tr> <td>OUT1</td> <td>11, 12</td> <td>42:FOUT1_ON</td> <td>0x20F9,0x01 (Axis1 OUT1)</td> </tr> <tr> <td>OUT2</td> <td>13, 14</td> <td>44:FOUT2_ON</td> <td>0x20F9,0x01 (Axis1 OUT2)</td> </tr> <tr> <td>OUT3</td> <td>15, 16</td> <td>42:FOUT1_ON</td> <td>0x20F9, 0x01 (Axis2 OUT1)</td> </tr> <tr> <td>OUT4</td> <td>17, 18</td> <td>44:FOUT2_ON</td> <td>0x20F9, 0x01 (Axis2 OUT2)</td> </tr> <tr> <td>OUT5</td> <td>29, 30</td> <td>42:FOUT1_ON</td> <td>0x20F9, 0x01 (Axis3 OUT1)</td> </tr> <tr> <td>OUT6</td> <td>31, 32</td> <td>44:FOUT2_ON</td> <td>0x20F9, 0x01 (Axis3 OUT2)</td> </tr> <tr> <td>OUT7</td> <td>33, 34</td> <td>42:FOUT1_ON</td> <td>0x20F9, 0x01 (Axis4 OUT1)</td> </tr> <tr> <td>OUT8</td> <td>35, 36</td> <td>44:FOUT2_ON</td> <td>0x20F9, 0x01 (Axis4 OUT2)</td> </tr> </tbody> </table>			Factory Shipment Setting Value		Output Signal	CN2 Pin No	Setting Value	Object: Index, Sub-index	OUT1	11, 12	42:FOUT1_ON	0x20F9,0x01 (Axis1 OUT1)	OUT2	13, 14	44:FOUT2_ON	0x20F9,0x01 (Axis1 OUT2)	OUT3	15, 16	42:FOUT1_ON	0x20F9, 0x01 (Axis2 OUT1)	OUT4	17, 18	44:FOUT2_ON	0x20F9, 0x01 (Axis2 OUT2)	OUT5	29, 30	42:FOUT1_ON	0x20F9, 0x01 (Axis3 OUT1)	OUT6	31, 32	44:FOUT2_ON	0x20F9, 0x01 (Axis3 OUT2)	OUT7	33, 34	42:FOUT1_ON	0x20F9, 0x01 (Axis4 OUT1)	OUT8	35, 36	44:FOUT2_ON	0x20F9, 0x01 (Axis4 OUT2)
			Factory Shipment Setting Value																																						
	Output Signal	CN2 Pin No	Setting Value	Object: Index, Sub-index																																					
	OUT1	11, 12	42:FOUT1_ON	0x20F9,0x01 (Axis1 OUT1)																																					
	OUT2	13, 14	44:FOUT2_ON	0x20F9,0x01 (Axis1 OUT2)																																					
	OUT3	15, 16	42:FOUT1_ON	0x20F9, 0x01 (Axis2 OUT1)																																					
	OUT4	17, 18	44:FOUT2_ON	0x20F9, 0x01 (Axis2 OUT2)																																					
	OUT5	29, 30	42:FOUT1_ON	0x20F9, 0x01 (Axis3 OUT1)																																					
OUT6	31, 32	44:FOUT2_ON	0x20F9, 0x01 (Axis3 OUT2)																																						
OUT7	33, 34	42:FOUT1_ON	0x20F9, 0x01 (Axis4 OUT1)																																						
OUT8	35, 36	44:FOUT2_ON	0x20F9, 0x01 (Axis4 OUT2)																																						
Input/Output Signal Check																																									
3	<ul style="list-style-type: none"> ■ Check that the set Input/Output signals are functioning normally with the monitor. Refer to "Monitor Functions (chapter 9)" for monitor explanation. 																																								
	<ul style="list-style-type: none"> ◆ Check using Setup Software with monitor in menu. Read separate manual M0010842 for MOTOR Setup Software operations. 																																								

4	JOG Operation (Input Servo ON signal)	
	<ul style="list-style-type: none"> ■ Performs JOG operation without connection motor shaft to machine under disengaged condition. ■ Check that servo motor rotates in both Forward and Inverse directions. ■ Rotation direction of JOG operation is reverse to the one if communication on EtherCAT. <ul style="list-style-type: none"> ◆ Operating with “MOTOR Setup Software” Select JOG operation from Test Run in menu. Read separate manual M0010842 for Setup Software operations. 	
	<ul style="list-style-type: none"> ■ Input Servo ON signal. Confirm that motor excitation and LED blinking of concerned axis in the front surface of servo amplifier. 	


4) Machine Movement Check

Connect servo motor shaft to machine and check movement.

Process	Items and Contents	
1	Connect to machine	
	<ul style="list-style-type: none"> ■ Connect motor shaft to machine. <div style="text-align: center; margin: 10px 0;">  </div> <ul style="list-style-type: none"> ■ Input low velocity command and check that movements such as movement direction, travel distance, emergency stop and forward/inverse direction limit, switch, etc. are normal. ■ Be prepared to stop immediately in case of abnormal movement. 	
2	Operation	
	<ul style="list-style-type: none"> ■ Input commands of actual operation patterns and operate machine. ■ Real time auto-tuning (Automatic tuning for servo gain, filter, etc.) is enabled at the time of factory shipment. Manual tuning is not necessary if there are no problems with movement and/or characteristics. Refer to “Adjustments (Chapter 6)” for servo tuning methods. 	
3	Power OFF	Turn OFF power after turning OFF Servo ON signal.

6.3 ESC Power ON Sequence


Shows RS2 EtherCAT slave amplifier power ON sequence at input of control power supply.



ESC Power ON Sequence


6.4 EtherCAT Initialization Process


Various parameter settings from master to slave datalink layer and application layer are required to begin cyclic communication after control power of slave amplifier has been established.
 The following procedure is an example of the initialization process:



1) INIT State
 EtherCAT Master (Host)


EtherCAT Slave (Subordinate)






Initialization Procedure Example "INIT State" -2


2) Pre-Operational State



3) Safe-Operational State




4) Operational State



6.5 Operation Sequence

1) Operation Sequence from Power ON to Power OFF

■ Power ON → Servo ON



In case DB engages during servo OFF (0x605C)


* The frequency of powering the servo amplifier ON/OFF must be less than 5 times/H and 30 times/day. In addition, the intervals between Power ON/OFF must be longer than 10 minutes.

* Inrush current suppression times of each servo amplifier size are as follows:

Servo amplifier size	Inrush current suppression time
RF2 series	100[ms]


■ Servo OFF → Power OFF

Sequence in case of Servo OFF during motor rotation depends on Disable Option Code (0x605C) setting.




■ Main Circuit OFF, Quick STOP (Emergency STOP) Sequence

1. When motor did not stop with the setting value of the holding brake engage starting time, or main circuit voltage drop is detected



■ Main Circuit OFF, Quick STOP (Emergency STOP) Sequence

2. When motor is stopped within holding brake start engage time or before main circuit voltage drop detection




2) Alarm Occurrence Stop Sequence

Servo motor is stopped by dynamic brake or servo brake with alarm occurrence. To stop either with dynamic brake or servo brake, please refer to “Movement of SB, DB at the time of Alarm detection” in the alarm code list. (SB: Servo brake Stop, DB: Dynamic brake Stop)

The stop method can be selected with Quick Stop option code (0x605A) for alarms that can be stopped with the servo brake. Please refer to “Alarm Display List (9-3)” for details.


■ Stop Sequence with Dynamic brake at Alarm Occurrence



* This servo amplifier does not have dynamic brake. So, it will stop by Free Run operation.


■ Stop Sequence with Servo Stop (Quick Stop option code) at Alarm Occurrence

1. When a motor does not stop with the setting value of holding brake engage start time




■ Stop Sequence with Servo Stop (Quick Stop option code) at Alarm Occurrence

2. When a motor has stopped with the setting value of holding brake engage start time



3) Alarm Reset Sequence

Alarm can be reset by inputting alarm reset signal from generic input signals.



* Power reset (Turn off power once and re-input) or encoder clear is required for the alarm reset depending on alarm type. Refer to "Alarm Display List (11-3)" for details.

7

7. Adjustments

7.1	Servo Tuning Functions and Basic Adjustment Procedure	7-1
1)	Servo tuning functions	7-1
2)	Tuning method selection procedure	7-2
7.2	Automatic Tuning	7-3
1)	Use the following parameters for Automatic tuning	7-3
2)	Automatically adjusted parameters in auto-tuning	7-6
3)	Adjustable parameters during auto-tuning	7-6
4)	Unstable functions during auto-tuning	7-8
5)	Adjustment method for auto-tuning	7-8
6)	Auto-Tuning Characteristic selection flowchart	7-9
7)	Monitoring servo gain adjustment parameters	7-10
8)	Manual tuning method using auto-tuning results	7-10
7.3	Automatic tuning of notch filter	7-11
1)	Operation method	7-11
2)	Setting parameters	7-11
7.4	Automatic tuning of FF Vibration Suppression Frequency	7-12
1)	Operation method	7-12
2)	Setting parameters	7-12
7.5	Using Manual Tuning	7-13
1)	Servo system structure and servo adjustment parameters	7-13
2)	Basic manual tuning method for velocity control	7-14
3)	Basic manual tuning method for position control	7-14
7.6	Model Following Control	7-15
1)	Automatic tuning method for Model following control	7-15
2)	Manual tuning method for Model following control	7-16
7.7	Tuning to Suppress Vibration	7-17
1)	FF vibration suppressor control	7-17
2)	Model tracking vibration suppressor control	7-17
3)	Tuning methods	7-19
7.8	Using the Disturbance Observer Function	7-20

7.1 Servo Tuning Functions and Basic Adjustment Procedure

To operate the servo motor (and machine) using the servo amplifier, adjustments of the servo gain and its control system is necessary. Generally, the higher setting value of the servo gain increases the machine response. However, if the servo gain is too high, in a lower rigidity machine, vibration may result and the machine response will not increase. The servo gain and its control system need to be appropriately adjusted according to the operating servo motor and the mechanical system and this adjustment method is called Servo tuning. Following is an explanation of the Servo tuning procedure:

1) Servo tuning functions

■ Servo gain tuning procedures

Following is an explanation of the Servo tuning procedure:

- ◆ Automatic Tuning
The servo amplifier estimates the Load inertia moment ratio, during real time operations, and the amplifier automatically tunes the servo gain and filter frequency. This is the most basic tuning method.
- ◆ Automatic Tuning [JRAT Manual Setting]
The servo amplifier does not estimate the Load inertia moment ratio. Servo gain and filter frequency are adjusted automatically corresponding to the load inertia moment ratio and the responses that are already set. This method is used when the Load inertia moment ratio could not be estimated correctly with auto-tuning.
- ◆ Manual Tuning
Set all parameters, such as Load inertia moment ratio, servo gain, filter frequency, etc. manually. This method is used when characteristics during auto-tuning are insufficient.

■ Vibration suppressor of mechanical system

- ◆ Automatic tuning of FF Vibration Suppression Frequency
This is used to obtain the vibration frequency when FF vibration suppressor control is initiated.
- ◆ Automatic tuning of notch filter
This method is used for suppressing high frequency resonance caused by coupling and/or rigidity of the mechanical system using a notch filter.


■ Model following control

Model following control is a control method that ensures a higher detection response by composing a model control system including the mechanical system in a servo amplifier to operate the actual servo motor in order to follow the model control system.

- ◆ Model following control
Use Model control system to ensure higher detection response.
- ◆ Model following vibration suppressor control
Use the model control system to ensure a higher detection response by suppressing the machine stand vibration.

2) Tuning method selection procedure

The selection procedure is displayed in the following chart:



* Depending on the combination of these functions, use of more than two (2) methods jointly will invalidate the procedure.

7.2 Automatic Tuning

1) Use the following parameters for Automatic tuning”

Parameter List

The following parameters are used for auto-tuning.

- ◆ Group0 ID00: Tuning Mode Index: 0x2002, 0x01 [TUNMODE]

00: AutoTun	Automatic Tuning
01: AutoTun_JRAT-Fix	Automatic Tuning [JRAT manual setting]
02: ManualTun	Manual Tuning

- ◆ Group0 ID01: Auto-Tuning Characteristic Index:0x2002, 0x02 [ATCHA]

00: Positioning1	Positioning Control 1(General)
01: Positioning2	Positioning Control 2(High Response)
02: Positioning3	Positioning Control 3(High Response, FFGN Manual Setting)
03: Positioning4	Positioning Control 4(High Response, Horizontal Axis Limited)
04: Positioning5	Positioning Control 5 (High Response, Horizontal Axis Limited, FFGN Manual Setting)
05: Trajectory1	Trajectory Control 1
06: Trajectory2	Trajectory Control 2(KP, FFGN Manual Setting)

- ◆ Group0 ID02: Auto-Tuning Response Index:0x2002, 0x03 [ATRES]

1 - 30	Automatic Tuning Response
--------	---------------------------

- ◆ Group0 ID03: Auto-Tuning Automatic Parameter Saving Index:- [ATSAVE]

00: Auto_Saving	Automatically Saves in JRAT1
01: No_Saving	Automatic Saving is Invalid

- Explanation for each parameter
Explains the details of each parameter below.

ID	CoE Object ID	Contents												
00	0x2002, 0x01	<p>Tuning Mode [TUNMODE]</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-bottom: 10px;"> <thead> <tr> <th style="width: 10%;">Selection</th> <th style="width: 40%;">Meaning</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">00</td> <td>AutoTun Automatic Tuning</td> </tr> </tbody> </table> <ul style="list-style-type: none"> ◆ Servo amplifier estimates Load inertia moment ratio of the machine or equipment during real time and automatically tunes the servo gain. ◆ Parameters for the servo amplifier to automatically tune vary depending on selected auto-tuning characteristics. ◆ Servo amplifier estimates the Load inertia moment ratio at the time of acceleration/deceleration. Therefore, for operations only with excessively long acceleration/deceleration time constants or with only low torque (force) in low velocity, this mode cannot be used. Also, for operations with high disturbance torque (force) or with major mechanical clearance, this mode cannot be used. <p>[01: _AutoTun_JRAT-Fix Automatic Tuning [JRAT Manual Setting]</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-bottom: 10px;"> <thead> <tr> <th style="width: 10%;">Selection</th> <th style="width: 40%;">Meaning</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">01</td> <td>AutoTun_JRAT-Fix Automatic Tuning [JRAT manual setting]</td> </tr> </tbody> </table> <ul style="list-style-type: none"> ◆ Based on the Load inertia moment ratio (JRAT1) [Group1 ID14], which has to be set, the servo amplifier automatically tunes to the best servo gain. ◆ Parameters for the servo amplifier to automatically tune will vary depending on the selected auto-tuning characteristics. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">Selection</th> <th style="width: 40%;">Meaning</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">02</td> <td>ManualTun Manual Tuning</td> </tr> </tbody> </table> <ul style="list-style-type: none"> ◆ This mode is used in order to adjust the servo gain to the machine or equipment to ensure maximum response as well as when characteristics in auto-tuning are insufficient. 	Selection	Meaning	00	AutoTun Automatic Tuning	Selection	Meaning	01	AutoTun_JRAT-Fix Automatic Tuning [JRAT manual setting]	Selection	Meaning	02	ManualTun Manual Tuning
Selection	Meaning													
00	AutoTun Automatic Tuning													
Selection	Meaning													
01	AutoTun_JRAT-Fix Automatic Tuning [JRAT manual setting]													
Selection	Meaning													
02	ManualTun Manual Tuning													

ID	CoE Object ID	Contents																								
01	0x2002, 0x02	<p data-bbox="443 237 831 264">Auto-Tuning Characteristic [ATCHA]</p> <ul style="list-style-type: none"> <li data-bbox="443 271 1441 376">■ Auto-Tuning Characteristic to fit the mechanical requirements and movements are provided. Parameters that can be adjusted vary depending on each auto-tuning characteristic. Set the parameters based on the situation. <li data-bbox="443 383 1441 488">■ [Positioning control (Positioning)] Positioning control is a control method used to reach the servo motor quickly to target a position from the present position by disregarding the trajectory between the positions. Select this mode when positioning point by point is necessary. <li data-bbox="443 517 1441 656">■ [Trajectory control (Trajectory)] Trajectory control is a method used to move the servo motor to the target position from the present position while considering the trajectory between the positions. Select this mode when the Position command corresponding trajectory control is needed such as in processing work. <table border="1" data-bbox="497 680 1278 741"> <thead> <tr> <th colspan="2">Selection</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>00</td> <td>Positioning1</td> <td>Positioning Control 1(General)</td> </tr> </tbody> </table> <ul style="list-style-type: none"> <li data-bbox="497 745 970 772">◆ Select for general positioning purposes. <li data-bbox="497 775 1169 801">◆ Parameters shown in table 2 cannot be adjusted manually. <table border="1" data-bbox="497 824 1278 884"> <thead> <tr> <th colspan="2">Selection</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>01</td> <td>Positioning2</td> <td>Positioning Control 2(High Response)</td> </tr> </tbody> </table> <ul style="list-style-type: none"> <li data-bbox="497 889 935 916">◆ Select for high response positioning. <li data-bbox="497 918 1169 945">◆ Parameters shown in table 2 cannot be adjusted manually. <table border="1" data-bbox="497 967 1278 1050"> <thead> <tr> <th colspan="2">Selection</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>02</td> <td>Positioning3</td> <td>Positioning control 3(High Response, FFGN Manual Setting)</td> </tr> </tbody> </table> <ul style="list-style-type: none"> <li data-bbox="497 1055 1002 1081">◆ Select this mode to adjust FFGN manually. <li data-bbox="497 1084 1233 1137">◆ The following parameter adjustment is made manually: General parameters GROUP1 [Basic control parameter settings] <table border="1" data-bbox="552 1162 1278 1223"> <thead> <tr> <th>ID</th> <th>Symbol</th> <th>Name</th> </tr> </thead> <tbody> <tr> <td>05</td> <td>FFGN</td> <td>Feed Forward Gain</td> </tr> </tbody> </table>	Selection		Meaning	00	Positioning1	Positioning Control 1(General)	Selection		Meaning	01	Positioning2	Positioning Control 2(High Response)	Selection		Meaning	02	Positioning3	Positioning control 3(High Response, FFGN Manual Setting)	ID	Symbol	Name	05	FFGN	Feed Forward Gain
Selection		Meaning																								
00	Positioning1	Positioning Control 1(General)																								
Selection		Meaning																								
01	Positioning2	Positioning Control 2(High Response)																								
Selection		Meaning																								
02	Positioning3	Positioning control 3(High Response, FFGN Manual Setting)																								
ID	Symbol	Name																								
05	FFGN	Feed Forward Gain																								

ID	CoE Object ID	Contents																																							
01	0x2002, 0x02	<p>Auto-Tuning Characteristic [ATCHA]</p> <table border="1" data-bbox="499 320 1302 405"> <thead> <tr> <th colspan="2">Selection</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>03</td> <td>Positioning4</td> <td>Positioning control 4 (High Response, Horizontal Axis Limited)</td> </tr> </tbody> </table> <ul style="list-style-type: none"> ◆ Select this mode when the machine movement is on a horizontal axis and receives no disturbing influence from external sources. ◆ Positioning time may be shortened compared to “Positioning Control 2”. ◆ Parameters shown in table 2 cannot be adjusted manually. <table border="1" data-bbox="499 544 1302 656"> <thead> <tr> <th colspan="2">Selection</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>04</td> <td>Positioning5</td> <td>Positioning control 5 (for high response, horizontal axis only, FFGN manual setting)</td> </tr> </tbody> </table> <ul style="list-style-type: none"> ◆ Select this mode when the machine movement is on a horizontal axis and receives no disturbing influence from external sources or when you want to adjust FFGN manually. ◆ Positioning time may be shortened compared to “Positioning control 2”. ◆ The following parameter adjustment is done manually. <p>General parameters GROUP1 [Basic Control Parameter Settings]</p> <table border="1" data-bbox="552 824 1302 887"> <thead> <tr> <th>ID</th> <th>Symbol</th> <th>Name</th> </tr> </thead> <tbody> <tr> <td>05</td> <td>FFGN</td> <td>Feed Forward Gain</td> </tr> </tbody> </table> <table border="1" data-bbox="499 913 1074 976"> <thead> <tr> <th colspan="2">Selection</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>05</td> <td>Trajectory1</td> <td>Trajectory Control 1</td> </tr> </tbody> </table> <ul style="list-style-type: none"> ◆ Select this mode for single axis use. The response of each axis can be different. ◆ Parameters shown in table 2 cannot be adjusted manually. <table border="1" data-bbox="499 1059 1302 1144"> <thead> <tr> <th colspan="2">Selection</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>06</td> <td>Trajectory2</td> <td>Trajectory Control 2 (KP, FFGN Manual Setting)</td> </tr> </tbody> </table> <ul style="list-style-type: none"> ◆ Select this mode when you need equal responses from multiple axes, respectively. Adjust KP, FFGN. ◆ The following parameter adjustment is done manually. <p>General parameters GROUP1 [Basic control parameter settings]</p> <table border="1" data-bbox="552 1283 1302 1379"> <thead> <tr> <th>ID</th> <th>Symbol</th> <th>Name</th> </tr> </thead> <tbody> <tr> <td>02</td> <td>KP1</td> <td>Position Loop Proportional Gain 1</td> </tr> <tr> <td>05</td> <td>FFGN</td> <td>Feed Forward Gain</td> </tr> </tbody> </table>	Selection		Meaning	03	Positioning4	Positioning control 4 (High Response, Horizontal Axis Limited)	Selection		Meaning	04	Positioning5	Positioning control 5 (for high response, horizontal axis only, FFGN manual setting)	ID	Symbol	Name	05	FFGN	Feed Forward Gain	Selection		Meaning	05	Trajectory1	Trajectory Control 1	Selection		Meaning	06	Trajectory2	Trajectory Control 2 (KP, FFGN Manual Setting)	ID	Symbol	Name	02	KP1	Position Loop Proportional Gain 1	05	FFGN	Feed Forward Gain
Selection		Meaning																																							
03	Positioning4	Positioning control 4 (High Response, Horizontal Axis Limited)																																							
Selection		Meaning																																							
04	Positioning5	Positioning control 5 (for high response, horizontal axis only, FFGN manual setting)																																							
ID	Symbol	Name																																							
05	FFGN	Feed Forward Gain																																							
Selection		Meaning																																							
05	Trajectory1	Trajectory Control 1																																							
Selection		Meaning																																							
06	Trajectory2	Trajectory Control 2 (KP, FFGN Manual Setting)																																							
ID	Symbol	Name																																							
02	KP1	Position Loop Proportional Gain 1																																							
05	FFGN	Feed Forward Gain																																							
02	0x2002, 0x03	<p>Auto-Tuning Response [ATRES]</p> <ul style="list-style-type: none"> ■ Select this mode when Auto-tuning and Auto-tuning [JRAT manual setting] are used. ■ As the setting value rises, the response increases. Set the value suitable for equipment rigidity. ■ This does not function for manual tuning. 																																							
03	(-)	<p>Auto-Tuning Automatic Parameter Saving [ATSAVE]</p> <ul style="list-style-type: none"> ■ Load inertia moment ratio obtained from the result of auto-tuning is automatically saved in parameter JRAT1 every two (2) hours. ■ The value is effective when auto-tuning is used. This does not function for [JRAT manual setting]. 																																							

2) Automatically adjusted parameters in auto-tuning

The following parameters are automatically adjusted at the time of auto-tuning. These parameters will not reflect on motor movements by changing or overriding those values. However, some of them can be adjusted manually depending on selected [Tuning Mode] and [Auto-Tuning Characteristic].

■ General parameters Group1 [Basic control parameter settings]

ID	CoE Object ID	Symbol	Name	Notes
02	0x2005, 0x01	KP1	Position Loop Proportional Gain 1	Note 1)
05	0x2008, 0x01	FFGN	Feed Forward Gain	Note 1) Note 2)
12	0x200B, 0x01	KVP1	Velocity Loop Proportional Gain 1	
13	0x200C, 0x01	TVI1	Velocity Loop Integral Time Constant 1	
14	0x200D, 0x01	JRAT1	Load Inertia Moment Ratio 1	Note 3)
15	0x200E, 0x00	TRCVGN	Higher Tracking Control Velocity Compensation Gain	
1A	0x2011, 0x01	TCFIL1	Torque (force) Command Filter 1	

Note 1) Manual setting is available on Trajectory Control 2 (KP, FFGN Manual Setting).

Note 2) Manual setting is available on Positioning Control 3 (High Response, FFGN Manual Setting).

Manual setting is available on Positioning Control 5 (High Response, Horizontal Axis Limited, FFGN Manual Setting).

Manual setting is available on Trajectory Control 2 (KP, FFGN Manual Setting).

Note 3) Manual is available on auto-tuning [JRAT manual setting].

3) Adjustable parameters during auto-tuning

The following parameters are adjustable during auto-tuning:

■ General parameters Group1 [Basic control parameter settings]

ID	CoE Object ID	Symbol	Name
00	0x2003, 0x00	PCSMT	Position Command Smoothing Constant
01	0x2004, 0x00	PCFIL	Position Command Filter
06	0x2008, 0x02	FFFIL	Feed Forward Filter
10	0x2009, 0x00	VCFIL	Velocity Command Filter
11	0x200A, 0x00	VDFIL	Velocity Feedback Filter
21	0x202B, 0x00	TCFILOR	Torque (force) Command Filter Order

■ General parameters Group2 [FF vibration suppressor control/ Notch filter/ Disturbance observer settings]

ID	CoE Object ID	Symbol	Name
00	0x2012, 0x01	SUPFRQ1	FF Vibration Suppressor Frequency 1
01	0x202C, 0x00	SUPLV	FF Vibration Suppressor Level Selection
02	0x2040, 0x01	VCGFIL_SET	Velocity Command Filter Setting
03	0x2041, 0x01	VCGFIL_SET	Velocity Command Filter Setting
04	0x2041, 0x02	VCGFIL_TYP	Type of Velocity Filter
05	0x2041, 0x03	VCGFIL_LPF	Velocity Low Pass Filter cutoff frequency *
06	0x2041, 0x04	VCGFIL_HPF	Cutoff frequency of Velocity Bypass Filter *
07	0x2041, 0x05	VCGFIL_BPFC	Center frequency of Velocity Band Pass Filter *
08	0x2041, 0x06	VCGFIL_BPFW	Band width of Velocity Band Pass Filter
09	0x2041, 0x07	VCGFIL_NCFC	Center frequency of Velocity Notch Filter *
0A	0x2041, 0x08	VCGFIL_NCFW	Band width of Velocity Notch Filter *
10	0x2040, 0x02	TCFIL_SET	Torque Command Filter Setting
11 - 30 **	0x204n, 0x01	TCGFiLn_SET	General Torque Command Filter Setting n **
	0x204n, 0x02	TCGFiLn_TYP	Type of Torque Filter
	0x204n, 0x03	TCGFiLn_LPF	Cutoff frequency of Torque Low Pass Filter n **
	0x204n, 0x04	TCGFiLn_HPF	Cutoff frequency of Torque High Pass Filter n **
	0x204n, 0x05	TCGFiLn_BPFC	Cutoff frequency of Torque Band Pass Filter n **
	0x204n, 0x06	TCGFiLn_BPFW	Band width of Torque Band Pass Filter n **
	0x204n, 0x07	TCGFiLn_NCFC	Center frequency of Torque Notch Filter n **
0x204n, 0x08	TCGFiLn_NCFW	Band width of Torque Notch Filter n **	
31	0x2016, 0x01	OBCHA	Observer Characteristic
32	0x2016, 0x02	OBG	Observer Compensation Gain
33	0x2016, 0x03	OBLPF	Observer Output Low-pass Filter
34	0x2016, 0x04	OBNFIL	Observer Output Notch Filter
35	0x2034, 0x01	PVLPFset	(Position/Velocity) command Low Pass Filter On/Off
36	0x2034, 0x02	LPF_OFF_V	Off velocity of (Position/Velocity) command Low Pass Filter

* Setting value is valid when filter on, setting type and values are correct.

** General torque filter has 1 to 4.

■ General parameters Group4 [Gain switching control/Vibration suppressor frequency switching settings]

ID	CoE Object ID	Symbol	Name
40	0x2012, 0x02	SUPFRQ2	FF Vibration Suppressor Frequency 2
41	0x2013, 0x03	SUPFRQ3	FF Vibration Suppressor Frequency 3
42	0x2013, 0x04	SUPFRQ4	FF Vibration Suppressor Frequency 4

■ General parameters Group5 [High setting control setting]

ID	CoE Object ID	Symbol	Name
00	0x2015, 0x01	CVFIL	Command Velocity Low-pass Filter
01	0x2015, 0x02	CVTH	Command Velocity Threshold
02	0x2015, 0x03	ACCC0	Acceleration Compensation
03	0x2015, 0x04	DFCC0	Deceleration Compensation

4) Unstable functions during auto-tuning

The following functions cannot be used during auto-tuning:

■ General parameters Group1 [Basic control parameter setting]

ID	CoE Object ID	Symbol	Name
04	0x2007, 0x00	TRCPGN	Higher Tracking Control Position Compensation Gain
16	0x200E, 0x00	AFBK	Acceleration Feedback Gain

* [Disturbance observer] cannot be used together with auto-tuning.
 Render [Disturbance observer] function invalid when auto-tuning is used.

■ Parameter characteristics for EtherCAT objects


ID	CoE Object ID	Symbol	Name
-	0x2001, 0x00 bit5-4	GC	Gain Switching Selection
-	0x2000, 0x00 bit1	PPCON	Position Loop Proportional Control Switching Function
-	0x2000, 0x00 bit2	PCON	Velocity Loop Proportional Control Switching Function

5) Adjustment method for auto-tuning

Auto-tuning is a function where the servo amplifier automatically tunes to the best servo gain in real time.

Procedure 1	<p>■ Estimate the load inertia ratio with the servo amplifier in real time and adjust the servo gain automatically >> [Tuning Mode] to 00:_AutoTun Automatic Tuning]</p> <p>When automatically tuned, the best servo gain based on the previous manual setting load inertia ratio (JRAT1) >> Set [Tuning Mode] to 01:_AutoTun_JRAT-Fix Automatic Tuning [JRAT Manual Setting].</p>
Procedure 2	<p>■ After setting [Tuning Mode] select [Auto-Tuning Characteristic] for the machine or equipment.</p>
Procedure 3	<p>■ Next, boot the servo motor and adjust [Auto-Tuning Response] according to equipment rigidity.</p> <ul style="list-style-type: none"> ◆ Set [Auto-Tuning Response] at a low value initially and allow the machine to work about 10 times or more by commanding higher-rank equipment. ◆ When response is low and the positioning setting time is slow, after machine movement, try to improve the response and positioning times by increasing [Auto-tuning] gradually. ◆ If increasing the response has caused the machine to develop vibration, lower the value of the [Auto-Tuning Response] slightly. <p>* If the machine has not developed vibration, enable the Vibration suppressor by setting the Notch filter and /or FF Vibration suppressor frequency. Set the filter frequency to suppress mechanical vibration by using [Automatic tuning of notch filter] and/or [Automatic tuning of FF Vibration Suppression Frequency].</p> <p>* Tuning methods are the same in [01:_AutoTun_JRAT-Fix [JRAT Manual Setting].</p>

6) Auto-Tuning Characteristic selection flowchart



7) Monitoring servo gain adjustment parameters

The following parameters can be monitored with Digital Operator and Software Setup when auto-tuning is used. Refer to [See Section 10] for use of Digital Operator.

ID	CoE Object ID	Symbol	Name	Unit
1D	0x2104, 0x05	JRAT MON	Load Inertia Moment Ratio monitor	%
1E	0x2104, 0x01	KP MON	Position Loop Proportional Gain monitor	1 / s
1F	0x2104, 0x02	TPI MON	Position Loop Integral Time Constant monitor	Mss
20	0x2104, 0x03	KVP MON	Velocity Loop Proportional Gain monitor	Hz
21	0x2104, 0x04	TVI MON	Velocity Loop Integral Time Constant monitor	ms
22	0x2104, 0x06	TCFIL MON	Torque (force) Command Filter monitor	Hz
23	0x2104, 0x07	MKP MON	Model Control Gain monitor	1/s

8) Manual tuning method using auto-tuning results

Save auto-tuning results as a batch, and it can be utilized in manual tuning. For Software Setup, use Auto-tuning >> Auto-tuning result saving.

■ Saving parameters

◆ General parameters Group1 [Basic control parameter settings]

ID	CoE Object ID	Symbol	Name	Unit
02	0x2005, 0x01	KP1	Position Loop Proportional Gain 1	1 / s
12	0x200B, 0x01	KVP1	Velocity Loop Proportional Gain 1	Hz
13	0x200C, 0x01	TVI1	Velocity Loop Integral Time Constant 1	ms
14	0x200D, 0x01	JRAT1	Load Inertia Moment Ratio 1	%
1A	0x2011, 0x01	TCFIL1	Torque (force) Command Filter 1	Hz

◆ General parameters Group3 [Model following control settings]

ID	CoE Object ID	Symbol	Name	Unit
00	0x2017, 0x01	KM1	Model Control Gain 1	1 / s

7.3 Automatic tuning of notch filter

Automatic notch filter can suppress high frequency resonance resulting from coupling and rigidity from the device mechanism.

With short periods of operation of servo amplifier and servo motor, the mechanical resonance frequency can be found easily.

1) Operation method

- Operate from Auto-tuning mode in Software Setup.
- The tuning results are saved automatically in [Group2 ID17: Center frequency of Torque (force) Notch Filter1].
 - * Torque (force) command notch filter function can be used together with Auto-tuning.
 - * Holding torque (force) falls while auto notch filter is running. Do not use as a gravity axis.
- When resonance of the device does not stop even after using Automatic tuning of notch filter, there may be two or more resonance points. In this case, inquire about the resonance frequency using the system analysis function and insert Notch filter 2, 3, 4 (Manual setting) to suppress each resonance. If resonance is still not suppressed, there is a possibility that auto-tuning response or gain control is too high. Lower the Auto-Tuning Response or control gain.

2) Setting parameters

- Torque (force) command value for notch filter tuning
Setting the Torque (force) command value to the motor at the time of Automatic tuning of notch filter:

◆ General parameters Group0 [Auto-tuning settings]

ID	CoE Object ID	Symbol	Name	Unit	Setting range
10	—	ANFILTC	Automatic tuning of notch filter Torque (force) Command	%	10.0 - 100.0

* As the value increases so does tuning accuracy. However, machine movement will increase as well. Please monitor it closely.

- Automatically saving parameters with Automatic tuning of notch filter
 - ◆ General parameters Group2 [FF vibration suppressor control/Notch filter/ Disturbance observer settings]

ID	CoE Object ID	Symbol	Name	Unit	Setting range
13	0x2042, 0x03	TCGFIL1_LPF	Cutoff frequency of Torque Low Pass Filter n **	Hz	10 - 2000

* The above parameter is saved automatically with Automatic tuning of notch filter

7.4 Automatic tuning of FF Vibration Suppression Frequency

Set FF vibration suppressor frequency to suppress low frequency vibration at the tip or body of the machine. Automatic tuning of FF Vibration suppression frequency simply enables the frequency tune in minimal motion cycle time between the servo amplifier and the servo motor.

1) Operation method

- Operate from Auto-tuning mode in Software Setup.
- The tuning result is automatically saved in Group2 ID00: FF Vibration suppressor frequency 1 [SUPFREQ1].
- FF vibration suppressor frequency is obtained by executing auto-tuning of vibration suppressor frequency or by calculating vibration frequency from the mechanical vibration period at the time of positioning.
 - * When vibration does not stop with FF vibration suppressor frequency, there is a possibility that the gain for control system may be too high. In this case, lower the control system gain.
 - * When used together with Higher Tracking Control Velocity Compensation Gain, vibration- suppressor effect may be improved.
 - * FF vibration suppressor control function can be used with auto-tuning.
 - * Holding torque (force) falls while Automatic tuning of FF Vibration Suppression Frequency is executing. Do not use as gravity axis.

2) Setting parameters

- Torque (force) command value of Auto-FF vibration suppressor frequency
Sets torque (force) command value to servo motor at the time of Automatic tuning of FF Vibration Suppression Frequency execution.

◆ General parameters Group0 [Auto-tuning setup]

ID	CoE Object ID	Symbol	Name	Unit	Setting range
11	-	ASUPTC	Automatic tuning of FF Vibration Suppression Frequency Friction torque (force) Compensation Value	%	10.0 - 100.0

- * As the value increases so does tuning accuracy. However, machine movement will increase as well. Please monitor it closely.

- Friction torque (force) compensation amount during Automatic tuning of FF Vibration Suppression Frequency.
Sets additional frictional torque (force) compensation amount when Automatic tuning of FF Vibration Suppression Frequency is executed.
By setting the value close to the actual friction torque (force), the accuracy of Automatic tuning of FF Vibration Suppression Frequency can be improved.

◆ General parameters Group0 [Auto-tuning setup]

ID	CoE Object ID	Symbol	Name	Unit	Setting range
12	-	ASUPFC	Automatic tuning of FF Vibration Suppression Frequency Friction torque (force) Compensation Value	%	0.0 - 50.0

- Automatically saved parameter of Automatic tuning of FF Vibration Suppression Frequency.

◆ General parameters Group2 [FF vibration suppressor control/Notch filter/
Disturbance observer settings]

ID	CoE Object ID	Symbol	Name	Unit	Setting range
00	0x2012, 0x01	SUPFRQ1	FF Vibration Suppressor Frequency 1	Hz	5 - 500

7.5 Using Manual Tuning

All gain is adjustable manually using manual tuning mode when characteristics in auto-tuning are insufficient.


Sets the Tuning Mode to Manual tuning.

- General parameters Group0 ID00: Tuning Mode Index:0x2002, Sub-Index:0x01 [TUNMOD]

02: ManualTun	Manual Tuning
---------------	---------------

1) Servo system structure and servo adjustment parameters

The servo system consists of three (3) subsystems: Position loop, Velocity loop and Current loop. Higher response is required for internal loops. If this structure is compromised, it could result in instability, low response, vibration or oscillation.



Explains each servo parameter (Group 1) below

- Position Command Smoothing Constant Index:0x2003, 0x00 [PCSMT]
This moving low-pass filter smoothes the position command pulse. Sets time constants. The position command pulse will become smoother by setting this parameter when the communication cycle is long.
- Position Command Filter Index:0x2004, 0x00 [PCFIL]
When the position command resolution is low, set this parameter to suppress the ripples contained in the position command. A larger value of this parameter will cause a greater ripple suppressing effect; however, delay will be increased.
* When Higher Tracking Control Position Compensation Gain is set to other than 0%, this parameter is automatically set.
- Position Loop Proportional Gain Index:0x2005, 0x01 - 0x04 [KP]
Sets the response of Position control.
Set this to: $KP_{[1/S]} = KVP_{[Hz]} / 4 \cdot 2\pi$
- Higher Tracking Control Position Compensation Gain Index:0x2007, 0x00 [TRCPGN]
When the tracking effect needs to be improved under high resolution of position command, increase this parameter after adjustment of Higher Tracking Control Velocity Compensation Gain.
- Feed Forward Gain Index:0x2008, 0x01 [FFGN]
The tracking effect of position command can be improved by increasing this gain. Under positioning control, set this to approximately 30 - 40% as the standard.
* When Higher Tracking Control Position Compensation Gain is set to other than 0%, this parameter is automatically set.
- Feed Forward Filter Index:0x2008, 0x02 [FFFIL]
When position command resolution is low, set this parameter to suppress ripples.
- Velocity Loop Proportional Gain Index:0x200B, 0x01 - 0x04 [KVP]
Sets the response of Velocity control. Set this parameter as high as possible within a stable operating range that does not cause vibration or oscillation.
If JRAT is accurately set, the set value of KVP becomes the Velocity loop response zone.
- Velocity Loop Integral Time Constant Index:0x200C, 0x01 - 0x04 [TVI]
Set this to: $TVI_{[ms]} = 1000 / (KVP_{[Hz]})$

- Load inertia moment ratio Index:0x200D, 0x01 - 0x04 [JRAT]
Set this value to the calculation shown below:

$$\text{JRAT} = \frac{\text{Motor axis converted load inertia (J}_L\text{)}}{\text{Motor rotor inertia (J}_M\text{)}} \times 100\%$$

- Higher Tracking Control Velocity Compensation Gain Index:0x2007, 0x00 [TRCVGN]
Tracking effect can be improved by increasing compensation gain.
Adjust this to shorten the position setting time.
 - * Set the value of JRAT properly to use this function.
 - * Set 0% when you use [Velocity Loop Proportional Control Switching Function] during operation.
 - * Set at 100% to equal Q-series servo amplifier.
- Torque (force) Command Filter Index:0x2011, 0x01
When rigidity of the mechanical device is high, set this value high and the Velocity Loop Proportional Gain can also be set higher. When the rigidity of the mechanical device is low, set this value low and resonance in the high frequency zone as well as abnormal sound can be suppressed. For normal usage, set this below 1200Hz.

2) Basic manual tuning method for velocity control

- Set Velocity Loop Proportional Gain(0x200B, 0x01) (KVP1) as high as possible within the range that allows the mechanical device to maintain stability without causing vibration or oscillation.
If vibration increases, lower the value.
- Set Velocity Loop Integral Time Constant (0x200C, 0x01) (TV1) to: $\text{TVI [ms]} = 1000 / (\text{KVP [Hz]})$
 - * When you cannot increase the gain because of mechanical resonance, etc., and the response is insufficient (after using the Torque notch filter and/or FF vibration suppressor frequency to suppress resonance) try the procedure again.

3) Basic manual tuning method for position control

- Set Velocity Loop Proportional Gain (0x200B, 0x01)(KVP1) as high as possible within the range that allows the mechanical device to maintain stability without causing vibration or oscillation.
If vibration increases, lower the value.
- Set Velocity Loop Integral Time Constant (0x200C, 0x01)(TVI1) to: $\text{TVI}_{[\text{ms}]} = 1000 / (\text{KVP}_{[\text{Hz}]})$
- Position Loop Proportional Gain (0x2005, 0x01)(KP1) to: $\text{KP}_{[1/\text{s}]} = \text{KVP}_{[\text{Hz}]} / 4 \cdot 2\pi$
In case vibration occurs, lower the value.
 - * When you cannot increase the gain because of mechanical resonance, etc., and the response is insufficient (after using the Torque notch filter and/or FF vibration suppressor frequency to suppress resonance) try the procedure again.

7.6 Model Following Control

Model following control is a method used to obtain a higher response. Model control systems include mechanical devices in a servo amplifier and run a servo motor in order to track the Model control system.

Select [Position control form] in [Control mode]

Select [Model following control] in [Position control selection]

ID	CoE Object ID	Content						
0A	0x20F3, 0x01	Position Control Selection						
		<table border="1"> <thead> <tr> <th>Select value</th> <th>Content</th> </tr> </thead> <tbody> <tr> <td>01</td> <td>Model1</td> </tr> <tr> <td></td> <td>Model following control</td> </tr> </tbody> </table>	Select value	Content	01	Model1		Model following control
		Select value	Content					
01	Model1							
	Model following control							

- * Model following control cannot be used when in velocity control mode or torque (force) control mode.
- * Model following control can be used with auto-tuning.
- * Model following control can be used with full-closed control.

1) Automatic tuning method for Model following control

The Model following control can be used in conjunction with the Auto-tuning.

Follow the tuning procedure shown in [Adjustment method for auto-tuning].

Model Control Gain 1 is tuned in addition to tuning the parameter at Standard position control.

- Automatically adjust parameters using Model following control auto-tuning.

◆ General parameters Group1 [Basic control parameter settings]

ID	CoE Object ID	Symbol	Name	Notes
02	0x2005, 0x01	KP1	Position Loop Proportional Gain 1	Note 1)
12	0x200B, 0x01	KVP1	Velocity Loop Proportional Gain 1	
13	0x200C, 0x01	TVI1	Velocity Loop Integral Time Constant 1	
14	0x200D, 0x01	JRAT1	Load Inertia Moment Ratio 1	Note 2)
1A	0x2011, 0x01	TCFIL1	Torque (force) Command Filter 1	

Note 1) Manual setting is available in Trajectory Control 2 [KP, FFGN manual setting]

Note 2) Manual setting is available in Automatic Tuning [JRAT Manual Setting]

◆ General parameters Group3 [Model following control settings]

ID	CoE Object ID	Symbol	Name	Notes
00	0x2017, 0x01	KM1	Model Control Gain 1	Note 3)

Note 3) KP1 setting value is set in Trajectory Control 2 [KP, FFGN Manual Setting]

- * Parameters automatically adjusted by the servo amplifier vary according to selected Auto-Tuning Characteristic.

2) Manual tuning method for Model following control

- Set Velocity Loop Proportional Gain (0x2005, 0x01)(KVP1) at as high a value as possible within a stable range that will not cause vibration or oscillation. If vibration increases, lower the value.
- Set Velocity Loop Integral Time Constant (0x200C, 0x01)(TVI1) to: $TVI_{[ms]} = 1000 / (KVP_{[Hz]})$.
- Set Position Loop Proportional Gain (0x2005, 0x01)(KP1) to: $KP_{[1/s]} = KVP_{[Hz]} / 4 \cdot 2\pi$.
- Set Model Control Gain (0x2017, 0x01)(KM1) to: $KM \approx KP$. If vibration increases, lower the value.
- When response is low, set the value of KM to: approximately 1.1 - 1.2 times.
 - * When the gain cannot rise because of mechanical vibration, etc., and the response time is insufficient, use Torque notch filter and/or FF Vibration suppressor frequency to suppress resonance and attempt it again.
- Adjustable parameters in Model following control
In addition to the parameters in Standard position control, the following parameters are also adjustable:

◆ General parameters Group3 [Model following control settings]

ID	CoE Object ID	Symbol	Name
00	0x2017, 0x01	KM1	Model Control Gain 1
01	0x2018, 0x01	OSSFIL	Overshoot Suppressor Filter

- ◆ Model Control Gain 1 Index: 0x2017, 0x01 [KM1]
Proportional gain fro Model following control position controller. Adjust this to: $KM \approx KP$.
- ◆ Overshoot Suppressor Filter index: 0x2019, 0x01 [OSSFIL]
Set cutoff frequency of overshoot suppressor filter in Model following control.
If overshoot occurred on a position deviation, lower the setting value.

7.7 Tuning to Suppress Vibration

1) FF vibration suppressor control

FF vibration suppressor control can be used as a method of suppressing the vibration of the mechanical tip.

- Adjust this gain by using the same basic tuning procedures from Position control.
- When vibration rises on the machine tip during operation, use [Auto-FF vibration suppressor frequency tuning] or calculate the vibration frequency from the vibration period and set the vibration frequency to [FF vibration suppressor frequency (SUPFRQ1)].

◆ General parameters Group2 [FF vibration suppressor control/Notch filter/
Disturbance observer settings]

ID	CoE Object ID	Symbol	Name	Unit	Setting range
00	0x2012, 0x01	SUPFRQ1	FF Vibration Suppressor Frequency 1	Hz	5 - 500

- * If the machine tip vibration does not stop after taking the above steps, there is a possibility the gain for the control system could be too high. In this case, lower the Control system gain.
- * Do not change the Setting value when the motor is running.

2) Model tracking vibration suppressor control

When you use the servo motor to drive tables on a machine stand, the stand itself may vibrate as a reciprocal reactor of the motor.

When the machine stand vibrates, the vibration may cause a reaction with the Positioning stabilizing time of the table working on the stand.

Model following vibration suppressor control suppresses this type of machine stand vibration and improves Position stabilization time and response.

- When you use Model following vibration suppressor control, select Position control at Control Mode Selection and Model following vibration suppressor control at Position Control Selection at System parameters.
You can run the servo motor under the condition that the machine stand vibration is suppressed using Model control system.

ID	CoE Object ID	Contents	
0A	0x20F3, 0x01	Position Control Selection	
		Select value	Contents
		02	Model2 Model Following Vibration Suppress Control

- * Do not use Auto-tuning with Model following vibration suppressor control.
- * Full-closed control cannot be used with Model following vibration suppressor control.
- * Model following vibration suppressor control cannot be used when in Velocity control mode or Torque (force) control mode.

■ Adjustable parameters in Model following vibration suppressor control

◆ General parameters Group3 [Model following control settings]

ID	CoE Object ID	Symbol	Name	Unit	Setting range
00	0x2017, 0x01	KM1	Model Control Gain 1	1 / s	15 - 315
01	0x2018, 0x01	OSSFIL	Overshoot Suppressor Filter	Hz	1 - 4000
02	0x2019, 0x01	ANRFRQ1	Model Control Antiresonance Frequency 1	Hz	10.0 - 80.0
03	0x201A, 0x01	RESFRQ1	Model Control Resonance Frequency 1	Hz	10.0 - 80.0

- ◆ Model Control Gain 1 Index:0x2017, 0x01 [KM1]
This is the proportional gain of the Model following controlling position controller and set response for Model control system.
- ◆ Overshoot Suppressor Filter Index:0x2018, 0x01 [OSSFIL]
This parameter is to set the cutoff frequency of the Overshoot suppressor filter in Model following vibration suppressor control. If overshoot occurred on a position deviation, lower the setting value.
- ◆ Model Control Antiresonance Frequency 1 Index:0x2019, 0x01 [ANRFRQ1]
This is to set the Anti-resonance frequency of the machine using Model following vibration suppressor control.
When the value is set higher than Model Control Resonance Frequency, vibration suppressor control will be invalid.
- ◆ Model Control Resonance Frequency 1 Index:0x201A, 0x01 [RESFRQ1]
This is to set the Resonance frequency of the machine model using Model following vibration suppressor control.
Vibration suppressor control will be invalid at 80.0Hz.

* Do not change the setting value when the motor is running.

■ Parameter setting range for Model following vibration suppressor control
Setting ranges for the following parameters are restricted:

◆ General parameters Group1 [Basic control parameter settings]

ID	CoE Object ID	Symbol	Name	Unit	Setting Range
14	0x200D, 0x01	JRAT1	Load Inertia Moment Ratio 1	%	100 - 3000
1A	0x2011, 0x01	TCFIL1	Torque (force) Command Filter 1	Hz	10-600

◆ General parameters Group3 [Model following control settings]

ID	CoE Object ID	Symbol	Name	Unit	Setting Range
00	0x2017, 0x01	KM1	Model Control Gain1	1 / s	15 - 315

3) Tuning methods

- First, execute Model following control auto-tuning by selecting [01:_Model following control] in [Position Control Selection(0x20F3, 0x01)(ID07)] at System parameters and tune the machine with the best servo gain.
Refer to Auto-tuning method in Model following control for instructions on tuning.
- * When the best servo gain for the machine has been selected, ignore this step.
- When servo gain tuning is completed, please change tuning mode to manual tuning after performing an auto tuning result storing function.
- After completing servo gain tuning, set the Resonance frequency and Anti-resonance frequency of the mechanical device using [02:_ Model following vibration suppressor control] in [Position Control Selection (0x20F3, 0x01)(ID07)] at System parameters.
When anti-resonance and resonance frequencies are already known, set the values. When these values are unknown, these frequencies can be measured using System analysis.
- * Refer to MOTOR Setup Software Instruction manual M0010842 for instructions on using System analysis.
- * When you measure the anti-resonance and resonance frequencies using System analysis, set the [Frequency range selection] in the low range.
If you set the range in a high range, the anti-resonance and resonance frequencies in suppressible ranges created by the Model following vibration suppressor control may not be measured.
1 - 125Hz for [Frequency range selection] is recommended.
- * When the mass of the drive motor is smaller than the machine stand mass, the anti-resonance and resonance frequencies may not be measured in system analysis. In this case, obtain the vibration frequency (Model anti-resonance frequency) by calculating the machine vibration period of the vibrating point at positioning and its reciprocal and set the model resonance frequency 1.05 - 1.2 times the anti-resonance frequency.
- Set the Velocity Loop Proportional Gain (0x200B,0x01)(KVP1) as high as possible within stable range without causing vibration or oscillation. If vibration increases, lower the value.
- Set the Velocity Loop Integral Time Constant (0x200C, 0x01)(TVI1) to: $TVI_{[ms]} = 1000 / (KVP_{[Hz]})$.
- Set the Position Loop Proportional Gain (0x2005, 0x01)(KP1) to: $KP_{[1/S]} = KVP_{[Hz]} / 4 \cdot 2\pi$.
- Set the Model Control Gain (0x2017, 0x01)(KM1) to: $KM \approx KP$. If vibration increases, lower the value.
- Set the Model Control Gain (0x2017, 0x01)(KM1) value to: 1.1 - 1.2 times when the response is low.
- Depending on the mechanical system, there may be two or more frequency vibrations aside from anti-resonance and resonance frequencies that have already been set.
In this case, the vibration can be suppressed using FF vibration suppressor controls together. Set the vibration frequency to: [Group02 ID00 : FF vibration suppressor frequency 1(0x2012, 0x01)(SUPFRQ1)] by calculating the frequency from the vibration period.
- In case you cannot increase the gain because of mechanical resonance, etc., and response is insufficient, use Torque (force) command notch filter and FF vibration suppressor frequency to suppress the resonance, and then try again.

7.8 Using the Disturbance Observer Function

The servo motor speed will fluctuate when an external force is applied to the operating machine, and it may affect the machine operation. The Disturbance Observer is a function to suppress the influence of external load torque (force) by estimating the load torque (force) inside the servo amplifier and adding the load torque (force) compensation to the torque (force) command. To use the Disturbance Observer, set [Group9 ID33: Disturbance Observer Function] in [Functions Valid]. Adjust the observer related parameters in [Group2 ID30-33] and suppress or reject the disturbance.

■ Parameters for using the Disturbance Observer

◆ Parameter characteristics for EtherCAT objects

ID	CoE Object ID	Symbol	Name	Setting range
—	0x2000, 0x00 bit11	OBS	Disturbance observer compensation Enable	00, - 27

◆ General parameters Group2

[FF vibration suppressor control/Notch filter/Disturbance observer settings]

ID	CoE Object ID	Symbol	Name	Unit	Setting range
30	0x2016, 0x01	OBCHA	Observer Characteristic	—	00 - 02
31	0x2016, 0x02	OBG	Observer Compensation Gain	%	0 - 100
32	0x2016, 0x03	OBLPF	Observer Output Low-pass Filter	Hz	1 - 4000
33	0x2016, 0x04	OBNFIL	Observer Output Notch Filter	Hz	100 - 4000

■ Explanation of the parameters using the Disturbance Observer.

Provides three observer characteristics: “00_Low for low frequency disturbance suppression” “01_Middle for middle frequency disturbance suppression” and “02_High for high frequency disturbance suppression” depending on the disturbance frequency to be suppressed.

- 10 - 40[Hz] [00_Low for low frequency disturbance suppression]
- 40 - 80[Hz] [01_Middle for middle frequency disturbance suppression]
- 80 - 200[Hz] [02_High for high frequency disturbance suppression]

◆ Increase the Observer Compensation Gain gradually. (Do not set the value at the beginning.)

The higher the Observer Compensation Gain becomes, the more disturbance suppressing characteristics will improve. However, if the gain is excessively high, oscillation may result. Use this within a range that will not cause oscillation.

- * Disturbance Observer cannot be used with Auto-tuning.
- * Observer low-pass filter can be used when the encoder resolution is high or the Load inertia ratio is low. Observer characteristics can be improved by setting the frequency high.
- * Use the Observer notch filter to suppress vibration in case the resonance in high frequency zones has changed.
- * Use [02_High for High frequency disturbance suppression] when encoder resolution is above 1048576 division.

No Text on This Page.

8

8. Indication

8.1	EtherCAT Indicator	8-1
1)	IN/OUT Link / Activity Indicator Code: IN L/A, OUT L/A.....	8-1
2)	RUN Indicator Code: RUN.....	8-2
3)	Error Indicator Code: ERR.....	8-3
8.2	Servo Amplifier Indicator	8-4
1)	Main Circuit Power Supply Indicator Code: CHARGE.....	8-4
2)	Control Power Supply Establish Indicator Code: POW	8-4
3)	Amplifier Status Indicator Code: ST1, ST2, ST3, ST4.....	8-4
4)	Amplifier Alarm Indicator Code: AL1, AL2, AL3, AL4	8-5


8.1 EtherCAT Indicator

The servo amplifier has four (4) indicators standardized by EtherCAT specifications, two (2) indicators for power establishment, four (4) indicators for amplifier status with green and for (4) indicators for amplifier error with red LED.

There are 3 LEDs in green and 1 LED in red for the EtherCAT indicators.

- * IN Link/Activity indicator : LED (GREEN)
- * OUT Link/Activity indicator : LED (GREEN)
- * RUN indicator : LED (GREEN)
- * ERR indicator : LED (RED)

■ Names



EtherCAT Status LED

1) IN/OUT Link / Activity Indicator Code: IN L/A, OUT L/A

Link / Activity Indicator (Green LED) can confirm physical link state and operation status of each port with lighting / extinguishing / blinking.

Explanation of Link / Activity Indicator state is shown below.

Link / Activity Indicator			
Link	Activity	Link / Activity Indicator LED State	
Yes	No	ON	(light)
Yes	Yes	Flickering	(flicker)
No	-	OFF	(extinguish)

2) RUN Indicator Code: RUN


RUN indicator (Green LED) displays EtherCAT communication State machine status with Lighting /Extinguishing/ Flickering of the LED. Explains the RUN indicator below.

RUN Indicator explanation

RUN State	ESM	Explanation
Off	INIT	"INIT" state
Blinking	PRE-OPERATIONAL	"PRE-OPERATIONAL" state
Single flash	SAFE-OPERATIONAL	"SAFE-OPERATIONAL" state
On	OPERATIONAL	"OPERATIONAL" state
Flickering	INITIALISATION or BOOTSTRAP	"INIT" state not ready in initialization state or in "Bootstrap" state. (Firmware download is under operation)

Please refer to ERR / RUN LED display state and flickering cycle for details of the flickering cycle.

RUN LED display state and Flickering Cycle



3) Error Indicator Code: ERR


Error Indicator (Red LED) displays invalid state machine (ESM) change and/or watchdog error with an ON/OFF flickering of the LED.

Explains the Error Indicator status below.

Error Indicator Explanation

Error State	State	Explanation
Off	No error	EtherCAT operating normally
Flickering	Boot error	Boot error has occurred *Transitioned to INIT state but error was set in AL status register
Blinking	Invalid configuration	General configuration error *ESM commands from master became invalid caused by settings of register and/or object
Single flash	Invalid ESM change	Error has been set in AL status register because ESM has changed slave independently *In cases of transition to Safe-Operational automatically with synchronization error, etc.
Double flash	Application Watchdog timeout	Application Watchdog timeout has occurred *SyncManager Watchdog timeout has occurred
On	PDI Watchdog timeout	PDI Watchdog timeout has occurred *CPU application controller is not working

Display of "Blinking", "Single flash" and "Flickering" and display method of flickering cycle, RUN Indicator "RUN" and Error Indicator "ERR" is shown below.



8.2 Servo Amplifier Indicator

This servo amplifier has four types of indicator characteristics for the R ADVANCED MODEL, other than EtherCAT indicators:

- * Main circuit power charge indicator : LED (RED)
- * Control power supply establish indicator : LED (BLUE)
- * Amplifier status indicator : LED (GREEN)
- * Amplifier alarm indicator : LED (RED)

1) Main Circuit Power Supply Indicator Code: CHARGE

Main Circuit Power Supply Indicator (Red LED) shows the main circuit power (P, N) has been input and power is charging in the main circuit power supply smoothing capacitor.

The LED stays ON until electric discharge has completed even after the main circuit power supply has shut down.

- * Make sure not to touch the servo amplifier until this LED goes OFF. Electric shock may result.

2) Control Power Supply Establish Indicator Code: POW


Control Power Supply Establish Indicator (Blue LED) shows the control power supply (CP, CN) has been input and the 5V control power supply has been established through the switching power supply inside the amplifier.

3) Amplifier Status Indicator Code: ST1, ST2, ST3, ST4

Indicates servo amplifier status.

Indication	State of servo amplifier
Off	<ul style="list-style-type: none"> • Main circuit power is not established. • EtherCAT FSA is state of "Switch on Disabled" or "Ready to Switch on".
Blinking with 256ms cycle	<ul style="list-style-type: none"> • Main circuit power is established. • Main circuit power (P, N) is established and operation preparation completion signal is state of OFF. • EtherCAT FSA is state of "Switch on Disabled" or "Ready to Switch on".
	<ul style="list-style-type: none"> • State of operation preparation completion. • Main circuit power (P, N) is established and operation preparation completion signal is state of ON. • EtherCAT FSA is state of "Switch on Disabled", "Ready to Switch on" or "Switch on".
Blinking with 1.024s cycle	<ul style="list-style-type: none"> • State of servo ON. • EtherCAT FSA is state of "Operation Enabled".

LED blinking cycle




4) Amplifier Alarm Indicator Code: AL1, AL2, AL3, AL4

Indicates servo amplifier alarm/warning.

Indication	State of servo amplifier
Off	<ul style="list-style-type: none"> No alarm/warning.
Blinking with 256ms cycle	<ul style="list-style-type: none"> State of Safe Torque Off. Main circuit power (P, N) is established and both or either of Safe Torque Off input is OFF. EtherCAT FSA is state of "Switch on Disabled", "Ready to Switch on" or "Switch on".
Blinking with 1.024s cycle	<ul style="list-style-type: none"> State of warning. Battery warning, position deviation warning, overload warning, amplifier temperature warning, positive/negative over travel, velocity limiting or torque limiting.
On	<ul style="list-style-type: none"> State of alarm. For alarm occurrence, take action according to "Maintenance".

LED blinking cycle



9

9. Maintenance

9.1	Trouble shooting	9-1
9.2	Warning and Alarm List.....	9-3
1)	Warning Overview	9-3
2)	Warning List	9-3
9.3	Alarm Display	9-3
1)	Alarm Display Overview.....	9-3
2)	Alarm display list	9-4
9.4	Trouble shooting When Alarm Occurs	9-6
9.5	Encoder Clear and Alarm Reset Methods	9-23
9.6	Inspection	9-24
9.7	Maintenance Parts.....	9-25
1)	Inspection Parts	9-25
9.8	Replacing battery for motor encoder.....	9-26

9.1 Trouble shooting

When troubles occur without any alarm displayed, check and take corrective actions for them referring to the description below. When alarm occurs take corrective measures referring to "Trouble Shooting When Alarm Occurs".

- Cannot transit to state of Servo Ready even if main power is ON.

Investigation	Assumed causes and corrective actions
Check the voltage at the power input terminal.	<ul style="list-style-type: none"> ■ If voltage is low, check the power supply. ■ Check that wires and screws are fastened properly.
Red "CHARGE" LED goes out.	<ul style="list-style-type: none"> ■ Internal power circuit of servo amplifier is defective, so replace the servo amplifier.
Over-travel status, or Emergency Stop status.	<ul style="list-style-type: none"> ■ Stop the input of Over-travel. ■ Stop the input of Emergency Stop. ■ Check of "Functions enabling condition settings".
Safe Torque Off working status.	<ul style="list-style-type: none"> ■ Turn on /HWGOFF1 and /HWGOFF2 inputs.
Check which axis has alarm.	<ul style="list-style-type: none"> ■ Solve cause of alarm and then perform alarm clearing. Note)

Note) When one axis has alarm, the other axis will be state of emergency stop and disabling servo-ON.

- 7-segment LED displays a rotating character "8" (Servo ON status), but motor does not rotate.

Investigation	Assumed causes and corrective actions
Check the command is inputted or not by the monitor in the MOTOR seup software . Page07: Velocity command monitor(VCMON) Page09: Torque (force) command monitor(TCMON) Page13: Position command pulse frequency monitor (FMON1)	<ul style="list-style-type: none"> ■ If the value of a monitor is zero, input a command.
Check the servo motor is locked or not.	<ul style="list-style-type: none"> ■ Check that the power line of a servo motor is connected.
Check if torque (force) limit is input.	<ul style="list-style-type: none"> ■ Since torque (force) restrictions are inputted, a servo motor cannot output the torque (force) beyond the load torque (force). ■ Check of "Functions enabling condition settings"
Enter deviation clear to check if process is continued.	<ul style="list-style-type: none"> ■ Stop the input of deviation clear. ■ Check of "Functions enabling condition settings"
Enter encoder clear to check if process is continued.	<ul style="list-style-type: none"> ■ Stop the input of encoder clear. ■ Check of "Functions enabling condition settings"

* When performing the work for correction processing, be sure to intercept power supply.

- Rotations of servo motor are unstable and less than the specified velocity command.

Investigation	Assumed causes and corrective actions
Check if proportional control is entered.	<ul style="list-style-type: none"> ■ Stop the input of proportional control. ■ Check of "Functions enabling condition settings"
Check if torque (force) limit is input.	<ul style="list-style-type: none"> ■ Stop the input of torque (force) limit. ■ Check of "Functions enabling condition settings"

- Servo motor rotates only once, and stops.

Investigation	Assumed causes and corrective actions
Check motor power line.	■ The servo motor power line is not connected.
Check a setup of a combination motor.	■ Change the settings and turn ON the power again.
Check a setup of encoder resolution. (System parameter)	

* When performing the work for correction processing, be sure to intercept power supply.

- Servo motor hangs up.

Investigation	Assumed causes and corrective actions
Check motor power line.	■ Phase order of servo motor power line is wrong.
Check the wiring of encoder cable.	■ Wiring of the encoder is incorrect.

* When performing the work for correction processing, be sure to intercept power supply.

- Servo motor is vibrating.

Investigation	Assumed causes and corrective actions
Motor is vibrating with frequency above 200 Hz.	■ Reduce the loop gain speed. Set the torque (force) command low-pass filter and torque (force) command notch filter.

- Occurs over shoot/ under shoot during starting / stopping.

Assumed causes and corrective actions
<ul style="list-style-type: none"> ■ Adjust the auto tuning "response". ■ Reduce the loop gain speed. ■ Increase the velocity integral time constant. ■ Simplify the acceleration and deceleration command. ■ Use position command low-pass filter.

- Abnormal sound occurs

Investigation	Assumed causes and corrective actions
Check whether there is any problem in mechanical attachment.	<ul style="list-style-type: none"> ■ Observe by operating one servo motor. ■ Pay attention while coupling and confirm that there is no core shift or unbalance.
Operate at a low speed and check whether abnormal sound has periodicity.	<ul style="list-style-type: none"> ■ Confirm that the twisted pair and shield processing of motor encoder signal line are correct. ■ Confirm that the wiring for motor encoder line and servo motor power line are not installed in the same port. ■ Confirm that the power supply voltage is sufficient.

9.2 Warning and Alarm List

1) Warning Overview

The method of warning displayed, the name of alarm, contents, stop operation at the time of detection, and alarm reset is described on the following tables.

Corresponding bit of the warning monitor (Index:0x2103, 0x01) is set when a warning has occurred.

Normal operation is possible even when detecting a warning; however, an alarm may result if operation is continued.

Examine operational conditions prior to alarm occurrence.

Warning detected status will not be locked. It will be automatically cancelled when warning status returns to normal.

The overload detection process is estimated as 75% of rated load at control power input (Hot Start). Therefore, in case the setting value of the overload warning is below 75%, an overload warning may be detected at the time of control power input.

2) Warning List

Warning Table			
Affiliate	Index, Sub-Index, Bit	Warning Title	Warning Contents
Load system	0x2103, 0x01, Bit2	Overload Warning	*The effective torque (force) is exceeding the set torque
	0x2103, 0x01, Bit3	Regenerated Overload Warning	*In case of overload of regenerative resistance
	0x2103, 0x01, Bit0	Amplifier Overheating Warning	*The ambient temperature of the amplifier is greater than the range of the preset temperature
Power supply system	0x2103, 0x01, Bit8	Main circuit is charging	*Voltage of main circuit is above DC 105 V
	0x2103, 0x01, Bit15	Detecting power failure	*Detecting decrease in control power voltage
Sensor system	0x2103, 0x01, Bit14	Serial encoder Battery warning	*Battery voltage is below 3.0 V
Control system	0x2103, 0x01, Bit4	Restricting torque (force) command	*While restricting the torque command by torque (force) restriction value.
	0x2103, 0x01, Bit5	Restricting speed command	*While restricting the speed command by speed value.
	0x2103, 0x01, Bit7	Excessive position deviation	*When position deviation warning setup value is outside the proscribed limits
	0x2103, 0x01, Bit10	Restricting position command	*Exceeding position command range

9.3 Alarm Display

1) Alarm Display Overview

Displays a corresponding alarm code on alarm occurrence to alarm history of MOTOR setup software.

Alarms shall be displayed with Error Register (0x1001), Error code (0x603F) read via EtherCAT communication when alarm activated, and servo amplifier definition (0x2001, 0x2002) code list is shown in 2).

Operation at detecting: "DB" performs the slowdown stop of the servo motor in dynamic brake operation when the alarm generating. This servo amplifier does not have dynamic brake. So, it will stop by Free Run operation.

Operation at detecting: "SB" performs the slowdown stop of the servo motor with sequence current limiting value.

When dynamic brake is selected by Emergency Stop Operation selection, the servo motor is decelerating stopped for the dynamic brake operation regardless of the operation when detecting it.

Operation at detecting: "-" means an alarm is detected only in initial processing after control power input.

Alarm reset: "No" means an alarm that cannot be cancelled unless control power is shut off and re-input.

Bit definitions of Error Register (0x1001) are as follows:

Bit7: Maker definition error	Bit6: Reserved	Bit5: Device profile definition error	Bit4: Communication error
Bit3: Temperature error	Bit2: Voltage error	Bit1: Current error	Bit0: General error

2) Alarm display list

Alarm code list 1/2

0x1001 Error Resister	0x603F Error Code	0x2101 0x2102 Code	Alarm name	Alarm contents	Detection Operations	Alarm Reset
Bit4	0x7510	0x10	IN Rx Invalidity Frame Error	* Received invalid frame successively at Port 0	SB	Yes
		0x11	OUT Rx Invalidity Frame Error	* Received invalid frame successively at Port 1	SB	Yes
		0x12	IN Rx CRC Error	* Port 0 Successive Rx error	SB	Yes
		0x13	OUT Rx CRC Error	* Port 1 Rx occurrence error	SB	Yes
		0x14	IN Tx Error	* Port 0 Successive TX error	SB	Yes
		0x15	OUT Tx Error	* Port 1 TX occurrence error	SB	Yes
	0x7520	0x18	IN Lost link	* Port 0/1 cable was disconnected or unplugged in servo-on state. Host power supply was shutdown.	SB	Yes
		0x19	OUT Lost link		SB	Yes
	0x7510	0x1A	Communication time out	* Did not receive output data within regulated cycle time	SB	Yes
0x7510	0x1E	Position Synchronization Communication Time-Out	* Position sync communication is not able to receive correctly.	SB	Yes	
Bit1	0x5400	0x21	Main Circuit Power Device Error (Power Device Error)	* Over current of drive module * Abnormality in drive power supply * Overheating of drive module	DB	Yes
	0x5210	0x22	Current Detection Error 0	* Abnormality of electric current detection value	DB	Yes
		0x23	Current Detection Error 1	* Abnormality of Electric current detection circuit	DB	Yes
		0x24	Current Detection Error 2	* Abnormality in communication with Electric current detection circuit	DB	Yes
	0x8312	0x25	Safe Torque (force) Off Error 1	* Timing error of safe torque (force) off input	DB	No
0x26		Safe Torque (force) Off Error 2	* Failure of safe torque (force) off circuit	SB, (DB)	No	
Bit1	0x8311	0x41	Overload 1	* Failure of safe torque (force) off circuit	SB	Yes
	0x2220	0x42	Overload 2	* Stall over load	DB	Yes
	0x3212	0x43	Regenerative Overload	* Regeneration load ratio exorbitance	DB	Yes
	0x7300	0x44	Magnetic Pole Position Detection Error	* CS detection error	-	Yes
	0x8400	0x45	Average continuous over speed	* Over speed in average rotational speed	SB	Yes
Bit3	0x4110	0x51	Servo Amplifier Temperature Error	* Overheating detection of amplifier ambient temperature	SB	Yes
	0x4210	0x52	RS Overheat	* Detection of in-rush prevention resistance overheating	SB	Yes
		0x53	Dynamic Brake Resistance Overheat	* Overheating detection of dynamic brake resistor	SB	Yes
	0x4310	0x54	Internal Regenerative Resister Overheat	* Overheating detection of Internal regeneration resistor	DB	Yes
	0x4310	0x55	External Error	* Abnormality of external regenerative resistor, etc.	SB	Yes
	0x4210	0x56	Main Circuit Power Device Overheat	* Overheating detection of Drive module (15, 30, 50A)	DB	Yes
Bit2	0x3211	0x61	Over-voltage	* DC Excess voltage of main circuit	DB	Yes
	0x3220	0x62	Main Circuit Under-voltage	* DC Main circuit low voltage	DB	Yes
Bit2	0x5114	0x71	Control Power Supply Under-voltage	* Control power supply low voltage or instantaneous stoppage occurred	DB	Yes Note3
	0x5115	0x72	Control Power Supply Under-voltage 1	* Under voltage of ±12V of control switching power supply	SB	Yes
	0x5113	0x73	Control Power Supply Under-voltage 2	* Under voltage of ±5V of control switching power supply	DB	Yes
Bit0	0x7305	0x81	Encoder Connector 1 Disconnection	* Incremental encoder (A, B, Z) signal line break * Power supply cable break	DB	No
	0x7306	0x83	Encoder Connector 2 Disconnection	* Full close encoder (A, B, Z) signal line break * Power supply cable break	DB	Yes note4
	0x7300	0x84	Serial Encoder Communication Error	* CRC, SYNC, FORM, Command error occurrence in communication with sensor	DB	No
		0x85	Encoder Initial Process Error	* CS data read failure of Incremental encoder * Initial processing abnormality of Absolute encoder * Cable break	-	No
		0x86	CS error	* Position skip of CS data	DB	No
		0x87	CS Signal Disconnection	* CS signal line break	DB	No

Note 1) When the main power voltage increases or decreases gradually or is suspended, main circuit low voltage or main power failed phase may be detected.

Note 2) Control power supply under-voltage or servo ready OFF is detected during instantaneous break of 1.5 to 2 cycles. Detection of control power supply under-voltage and servo ready OFF can be delayed by setting larger value of PFDDLY (GroupB ID16).

Note3) When moment cutting of a control power source is long, it regards in power supply interception and re-input, and does not leave detected control power supply under-voltage to an alarm history.
(If cutting exceeds 1 second at the moment, it will be certainly judged as power supply interception.)

Alarm code list 2/2

0x1001 Error Resister	0x603F Error Code	0x2001 0x2002 Code	Alarm name	Alarm contents	Detection Operations	Alarm Reset
Bit0	0x7300	0xA0	Serial Encoder Internal Error 0	* Absolute encoder rotation overflow * Frequent rotation counter overflow	DB	No
		0xA1	Serial Encoder Internal Error 1	* Multi-turn error * Battery low voltage	DB	Yes
	0x7310	0xA2	Serial Encoder Internal Error 2	* Accelerate error	DB	Note 5
	0x7310	0xA3	Serial Encoder Internal Error 3	* Over-speed error	DB	Note 5
	0x7300	0xA4	Serial Encoder Internal Error 4	* Access error of Encoder internal EEPROM	DB	Note 5
		0xA5	Serial Encoder Internal Error 5	* Detection of single rotation coefficient incorrect	DB	Note 5
		0xA6	Serial Encoder Internal Error 6	* Detection of multiple rotation coefficient incorrect	DB	Note 5
		0xA9	Serial Encoder Internal Error 9	* Overheating of encoder with built-in servo motor	DB	Note 5
	0x7320	0xAA	Serial Encoder Internal Error 10	* Incremental error (Position data error)	DB	Note 5
	0x7300	0xAB	Serial Encoder Internal Error 11	* Encoder error	DB	Note 5
		0xAC	Serial Encoder Internal Error 12	* Multi-rotation error generation	DB	Note 5
		0xAD	Serial Encoder Internal Error 13	* Encoder built-in EEPROM data is not set	DB	Note 5
	0x7303	0xAE	Serial Encoder Internal Error 14	* Resolver output abnormality	DB	Note 5
	0x7304	0xAF	Serial Encoder Internal Error 15	* Resolver disconnection	DB	Note 5
Bit0	0x8400	0xC1	Over-speed	* Motor rotation speed is 120 % more than the highest speed limit	DB	Yes
		0xC2	Velocity Control Error	* Nonconformity of electrical current command and acceleration signs	DB	Yes
	0x7122	0xC3	Velocity Feedback Error	* Servo motor power disconnection Note 6	DB	Yes
	0x8500	0xC5	Model tracking vibration suppression control error	* Machine cycle time is not mach with model tracking vibration suppression control.	DB	Yes
Bit0	0x8611	0xD1	Excessive Position Deviation	* Position Deviation exceeds setup value.	DB	Yes
	0x8500	0xD2	Position Command Error 1	* Position command exceeded setting range 0x201D	SB	Yes
		0xD3	Position Command Error 2	* Position command input exceeded processing range	SB	Yes
	0x8611	0xD4	Excessive Position Synchronization Deviation	* Position Synchronization Deviation exceeds setup value	DB	Yes
	0xFF01	0xDE	Parameter change completion Note7	* Parameter change of motor and sensor codes is complete	—	No
0xFF00	0xDF	Test Run Close Note 7	* Detection in 'Test mode end' status	DB	Yes	
Bit7	0x5530	0xE1	EEPROM Error	* Abnormality of amplifier with built-in EEPROM	DB	No
	0x6310	0xE2	EEPROM Check Sum Error	* Access error in CPU built in RAM EPROM (entire area)	—	No
	0x5510	0xE3	Memory Error 1	* Access error in CPU built in RAM	—	No
	Note7	0xE4	Memory Error 2 Note7	* Error in check sum of Flash memory	—	No
	0x6320	0xE5	System Parameter Error 1	* System parameter is outside a setting range.	—	No
		0xE6	System Parameter Error 2	* Combination of a system parameter is abnormal. * System parameter and amplifier mismatch	—	No
		0xE7	Motor Parameter Error	* Check sum of a motor parameter is abnormal.	—	No
	0x5220	0xE8	CPU Circumference Circuit Error	* Abnormal access to CPU and peripheral devices	—	No
		0xE9	System Code Error	* Control board code and sensor setting mismatch	—	No
	0x6320	0xEA	Motor code setting Error	* Motor code is outside a setting range.	—	No
		0xEB	Sensor code setting Error	* Sensor code is outside a setting range.	—	No
		0xEE	Motor parameter automatic setting error 1	* Motor parameter automatic setting disabled.	—	No
		0xEF	Motor parameter automatic setting error 2	* The result of motor parameter automatic setting has an abnormality.	—	No
Bit7	0x8700	0xF1	Task Process Error	* Error in interruption process of CPU	DB	No
	0x6010	0xF2	Initial Process Time-Out	* Initial process does not end within initial process time	—	No
— Note9	— Note8	0xFF	Self flash timeout Note7	* Self-flash re-writing procedure is completed within the sepecified time.	—	No

Note 4) It can not reset, depends on the kinds of encoder.

Note 5) Detecting only Synchronization encoder.

Due to abnormality in encoder main body, encoder clear may sometimes be needed. "An encoder clear and the alarm reset method" change with motor encoders in use. Please refer to "11.5 Encoder clear and the alarm reset method."

Note 6) When there is a rapid motor slow down simultaneous with servo ON, there is a possibility that a break in the motor's power line cannot be detected.

Note 7) Alarm activated at test mode completeion, alarm when changing, memory error 2, and self-flashtimeout are not stored in alarm-record.

Note 8) "Memory Error 2" shall not be set to object dictionary "0x603F."

Note 9) Self-flash timeout shall not be set to object dictionary "0x1001."

9.4 Trouble shooting When Alarm Occurs

Note) V means the cause number with possibility.

- Alarm code 10 (IN Rx Invalid Frame Error)
- Alarm code 11 (OUT Rx Invalid Frame Error)
- Alarm code 12 (IN Rx CRC Error)
- Alarm code 13 (OUT Rx CRC Error)
- Alarm code 14 (IN Tx Error)
- Alarm code 15 (OUT Tx Error)

Status at the time of alarm	Cause		
	1	2	3
Issued when control power is turned ON.	V	V	V
Issued during operation of servo motor	V	V	V

Corrective actions

Cause		Investigative and Corrective Actions
1	■ Defect of communications cable	■ Check if there is contact failure in the communication cable wiring system
2	■ Malfunction due to noise	■ Confirm proper grounding of the amplifier. ■ Check encoder cable shield ■ Add ferrite core or similar countermeasures against noise.
3	■ Defect of control printed wiring board	■ Replace the servo amplifier.

- Alarm code 18 (IN Lost link)
- Alarm code 19 (OUT Lost link)

Status at the time of alarm	Cause	
	1	2
The cable was unplugged.	V	
Issued during operation.		V

Corrective actions

Cause		Investigative and Corrective Actions
1	■ Cable unplugged when motor was in operation.	■ Plug in / unplug cable in servo-off or below Pre-OP state.
2	■ Communication cable break. ■ Contact failure of connector and/or terminal.	■ Check the wiring of motor encoder and servo amplifier, and correct the wiring if needed.

- Alarm code 1A (Communication Time-Out)

Status at the time of alarm	Cause	
	1	2
Issued in Safe-OP or OP status	V	
Issued during operation.		V

Corrective actions

Cause		Investigation and corrective actions
1	■ Could not receive command within the prescribed time of the Communication Timeout value (SM2 Event: Cannot receive Output data of PDO)	■ Examine if data is being Output by controller communication timing.
2	■ Malfunction due to noise	■ Confirm proper grounding of the amplifier. ■ Check the shielding of the encoder cable. ■ Add ferrite core or similar countermeasures against noise.

- Alarm code 1E (Corrected Position Synchronization Communication Time-Out)

Status at the time of alarm	Cause	
	1	2
Issued before use.	V	V
Issued during operation.		V

Corrective actions

Cause		Investigation and corrective actions
1	■ After enabling position synchronization, data transmission from amplifier for synchronization does not start. (After enabling, 4sec passed but data could not be recieved.)	■ Confirm that the communication cable is connected through CN4 in another amplifier for synchronization. ■ Check cable wiring, and review.
2	■ Malfunction due to noise. (Data from amplifier for synchronization could not be received for consecutive 4ms.)	■ Confirm proper grounding of the amplifier. ■ Check communication cable shield. ■ Add ferrite core or similar countermeasures against noise.

■ Alarm code 21 (Main Circuit Power Device Error)

Status at the time of alarm	Cause			
	1	2	3	4
Issued when control power is turned ON.	✓		✓	✓
Issued at input of servo ON.	✓	✓	✓	
Issued while starting and stopping the servo motor.	✓	✓	✓	
Issued after extended operating time.	✓	✓	✓	✓

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> U/V/W-phase of amplifier is short circuited due to the wiring in amplifier and motor. Also, U/V/W-phases are grounded in the earth. 	<ul style="list-style-type: none"> Check the wiring conditions and restore if improper.
2	<ul style="list-style-type: none"> Short circuit or fault in U/V/W phases on servo motor side. 	<ul style="list-style-type: none"> Replace the servo motor.
3	<ul style="list-style-type: none"> Defect in internal circuit of servo amplifier. 	<ul style="list-style-type: none"> Replace the servo amplifier.
4	<ul style="list-style-type: none"> Overheating detection of the main circuit power device functioned. 	<ul style="list-style-type: none"> For an amplifier equipped with a cooling fan motor, check that the cooling fan motor is running; if not, replace the servo amplifier. Confirm that the temperature of the control panel (ambient temperature of the servo amplifier) does not exceed 55°C. If in excess of 55(C, check the installation method of the servo amplifier, and confirm that the cooling temperature of the control panel is set to below 55°C

■ Alarm code 22 (Current Detection Error 0)

Status at the time of alarm	Cause	
	1	2
Issued when servo is turned ON.	✓	✓

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> Defect in internal circuit of servo amplifier. 	<ul style="list-style-type: none"> Replace the servo amplifier.
2	<ul style="list-style-type: none"> Servo amplifier and motor are not combined properly. Electric current has exceeded maximum current (IP) of combined motor. (MOC: Motor Overcurrent) 	<ul style="list-style-type: none"> Confirm that the proper codes (per the specified Motor Codes) have been used for the servo motor; if not, replace the servo motor.

■ Alarm code 23 (Current Detection Error 1)

Status at the time of alarm	Cause	
	1	2
Issued at input of servo ON.	✓	
Issued during operation.	✓	✓

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> Defect in internal circuit of servo amplifier. Data from electric current detector is always fixed. 	<ul style="list-style-type: none"> Replace the servo amplifier.
2	<ul style="list-style-type: none"> Malfunction due to noise 	<ul style="list-style-type: none"> Confirm proper grounding of the amplifier. Add ferrite core or similar countermeasures against noise.

■ Alarm code 24 (Current Detection Error 2)

Status at the time of alarm	Cause	
	1	2
Issued at input of servo ON.	✓	
Issued during operation.	✓	✓

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> Defect in internal circuit of servo amplifier. Cannot get data from electric current detector. 	<ul style="list-style-type: none"> Replace the servo amplifier.
2	<ul style="list-style-type: none"> Malfunction due to noise 	<ul style="list-style-type: none"> Confirm proper grounding of the amplifier. Add ferrite core or similar countermeasures against noise.

■ Alarm code 25 (Safe Torque (force) Off error 1)

Status at the time of alarm	Cause	
	1	2
Occurred in about 10 sec. after control power turned on	✓	✓
Issued during operation.	✓	

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> Input logic of Safe Torque (force) Off 1 and Safe Torque (force) Off 2 are mismatched 	<ul style="list-style-type: none"> Match Input logic of SAFETOFF1/2 Check wiring of SAFETOFF1, SAFETOFF2 and correct if necessary When switching either signal logic of SAFETOFF1 or SAFETOFF2 always switch the other one's signal within 10 sec
2	<ul style="list-style-type: none"> Defect in internal circuit of servo amplifier. 	<ul style="list-style-type: none"> Replace the servo amplifier.

■ Alarm code 26 (Safe Torque (force) Off error 2)

Status at the time of alarm	Cause	
	1	2
Occurred when control power is turned on.	✓	✓
Issued during operation.		✓

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> Defect in internal circuit of servo amplifier. 	<ul style="list-style-type: none"> Replace the servo amplifier.
2	<ul style="list-style-type: none"> Malfunction due to noise 	<ul style="list-style-type: none"> Confirm proper grounding of the amplifier. Add ferrite core or similar countermeasures against noise.

■ Alarm code 41 (Overload 1)

Status at the time of alarm	Cause								
	1	2	3	4	5	6	7	8	9
Issued at input of servo ON.	✓	✓							✓
After command input, issued without rotating the motor.		✓			✓	✓	✓		✓
After command input, brief motor rotation			✓	✓	✓		✓	✓	

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> Defect in internal circuit of servo amplifier. 	<ul style="list-style-type: none"> Replace the servo amplifier.
2	<ul style="list-style-type: none"> Defect in internal circuit of motor encoder. 	<ul style="list-style-type: none"> Replace the servo motor.
3	<ul style="list-style-type: none"> Effective torque (force) exceeds the rated torque (force). 	<ul style="list-style-type: none"> Monitor the load status by using execution torque (force) monitor (TRMS), and check if effective torque (force) exceeds the rated value. Then calculate servo motor effective torque (force) according to load and operation conditions. If the effective torque (force) is excessive, check the operating or loading, or replace with large sized servo motor.
4	<ul style="list-style-type: none"> Defect in servo motor-servo amplifier combination. 	<ul style="list-style-type: none"> Check if the motor in use matches with the recommended type, and replace if it is improper.
5	<ul style="list-style-type: none"> Holding brake of servo motor does not release. 	<ul style="list-style-type: none"> Check that the wiring and voltage of the holding brake are acceptable; if not, repair. If the above are OK, replace the servo motor.
6	<ul style="list-style-type: none"> Wiring of U/V/W –phase between servo amplifier and motor do not match. 	<ul style="list-style-type: none"> Check the wiring conditions and restore if improper.
7	<ul style="list-style-type: none"> One or all connections of U/V/W -phase wiring of servo amplifier / motor is disconnected. 	<ul style="list-style-type: none"> Check the wiring conditions and restore if improper.
8	<ul style="list-style-type: none"> Machines collided. 	<ul style="list-style-type: none"> Check the operating conditions and limit switch.
9	<ul style="list-style-type: none"> Motor encoder pulse number setting does not match with the servo motor. 	<ul style="list-style-type: none"> Match the encoder pulse number with the servo motor.

Note) During the alarm caused by conditions in #3 (above), if OFF -> ON of control power supply is repeated, there is a risk of burning out the servo motor. Wait for longer than 30 min. for cooling purposes after power shut OFF, and resume operations.

■ Alarm code 42 (Overload 2)

Status at the time of alarm	Cause								
	1	2	3	4	5	6	7	8	9
Issued at input of servo ON.	V	V							V
After command input, issued without rotating the servo motor.		V			V	V	V		V
After command input, brief motor rotation.			V	V	V		V	V	

Corrective actions

Cause		Investigation and corrective actions
1	■ Defect in internal circuit of servo amplifier.	■ Replace the servo amplifier.
2	■ Defect in internal circuit of motor encoder.	■ Replace the servo motor.
3	■ Rotation is less than 50min ⁻¹ and torque (force) command exceeds approx. 2 times of rated torque (force).	■ Check if torque (force) command exceeds approx. 2 times of the rated torque by torque (force) command monitor (TCMON). Or, calculate the motor effective torque from load conditions and operation conditions. If the effective torque (force) is excessive, check the operating or loading, or replace with large sized servo motor.
4	■ Defect in servo motor-servo amplifier combination	■ Check the motor type setting and the motor in use are matching. If not, correct them.
5	■ Holding brake of servo motor does not release.	■ Check that wirings and voltage for holding brake are correct. If not, repair them. If they are appropriate, replace the servo motor.
6	■ Wiring of U/V/W –phase between servo amplifier and motor do not match.	■ Check the wiring conditions and restore if improper.
7	■ One or all connections of U/V/W -phase wiring of servo amplifier / motor is disconnected.	■ Check the wiring conditions and restore if improper.
8	■ Machines collided.	■ Check the operating conditions and limit switch.
9	■ Motor encoder pulse number setting does not match with the servo motor.	■ Match the encoder pulse number with the servo motor.

■ Alarm code 43 (Regenerative Overload)

Status at the time of alarm	Cause							
	1	2	3	4	5	6	7	8
Issued when control power supply is turned ON.							V	
Issued when power supply of main circuit is turned ON.		V	V	V		V	V	V
Issued during operation.	V	V	V	V	V		V	

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> ■ Exceeded permitted value of regenerating power in built-in regenerative resistance specifications. ■ Excessive load inertia, or tact time is short. 	<ul style="list-style-type: none"> ■ Check the load and operating conditions. ■ Use an external regeneration resistor. ■ Set the load inertia within the specified range. ■ Increase the deceleration time. ■ Increase the tact time.
2	■ Regenerative resistance wiring conflicts with built-in regenerative resistance specifications.	■ Check wiring and replace if incorrect.
3	■ Regenerative resistance wiring conflicts with external regeneration resistor specifications.	■ Check wiring and replace if incorrect.
4	■ Regeneration resistor is disconnected.	<ul style="list-style-type: none"> ■ For built-in regeneration resistor specifications, replace the servo amplifier. ■ For external regeneration resistor specifications, replace the regeneration resistor.
5	■ Resistance value of external regeneration resistor is excessive.	■ Replace the current resistance value with a value matching the specifications.
6	■ Input power supply voltage exceeds the specified range.	■ Check the input power supply voltage level.
7	■ Defect in internal circuit of servo amplifier.	■ Replace the servo amplifier.
8	■ When external regenerative resistance is selected for system parameter ID02 and external regenerative resistance is not installed.	<ul style="list-style-type: none"> ■ Install the external regenerative resistance. ■ Set to "Do not connect regenerative resistance".

Note) If the setting of system parameter Regenerative Resistor Selection is incorrect, regeneration overload is not detected properly, and the amplifier and surrounding circuit may be damaged or burnt.

■ Alarm code 44 (Magnetic pole position estimation error)

Status at the time of alarm	Cause	
	1	2
Occurred when control power supply was turned on.		√
Occurred during magnetic pole position error detection.	√	

Corrective action

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> ■ Magnetic pole position detection frequency and mechanical resonance point are matched. ■ Motor hit the stroke end. 	<ul style="list-style-type: none"> ■ Change magnetic pole position detection frequency. ■ Secure the distance to the stroke end.
2	<ul style="list-style-type: none"> ■ Control circuit fault of servo amplifier. 	<ul style="list-style-type: none"> ■ Replace servo amplifier.

■ Alarm code 45 (Average continuous over speed)

Status at the time of alarm	Cause
Occurred during operation.	√

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> ■ The average speed exceeds the maximum speed of continuous rotation speed range. 	<ul style="list-style-type: none"> ■ Review the operating conditions. ■ Resize the servo motor.

■ Alarm code 51 (Amplifier Overheat)

Status at the time of alarm	Cause				
	1	2	3	4	5
Issued when control power supply is turned ON.	√		√	√	
Issued during operation.	√	√	√	√	
Issued after emergency stop.					√

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> ■ Defect in internal circuit of servo amplifier. 	<ul style="list-style-type: none"> ■ Replace the servo amplifier.
2	<ul style="list-style-type: none"> ■ Regenerating power exceeded. 	<ul style="list-style-type: none"> ■ Check the operating conditions. ■ Use external regeneration resistor.
3	<ul style="list-style-type: none"> ■ Regenerating power is within the specified range but ambient temperature of servo amplifier is out of specified range. 	<ul style="list-style-type: none"> ■ Confirm that the cooling method maintains the temperature of control board between 0 to 55°C.
4	<ul style="list-style-type: none"> ■ Regenerating power is within the specified range but built-in cooling fan of servo amplifier is stopped. 	<ul style="list-style-type: none"> ■ For an amplifier equipped with a cooling fan motor, check that the cooling fan motor is running; if not, replace the servo amplifier.
5	<ul style="list-style-type: none"> ■ Regeneration energy during emergency stop exceeded. 	<ul style="list-style-type: none"> ■ Change the servo amplifier. ■ Check the loading condition.

Note) Abnormalities are detected in the internal temperature of the amplifier regardless of its ambient temperature. When an amplifier temperature warning is issued, please be sure to check the cooling method of the control panel.

■ Alarm Code 52 (In-rush prevention resistance Overheat)

Status at the time of alarm	Cause		
	1	2	3
Issued when control power supply is turned ON.	√		
Issued when main circuit power supply is turned ON.		√	
Issued during operation.			√

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> ■ Defect in internal circuit of servo amplifier. 	<ul style="list-style-type: none"> ■ Replace the servo amplifier.
2	<ul style="list-style-type: none"> ■ Power turning ON is repeated too frequently. 	<ul style="list-style-type: none"> ■ Turn ON/OFF the power less frequently.
3	<ul style="list-style-type: none"> ■ Ambient temperature is high. 	<ul style="list-style-type: none"> ■ For an amplifier equipped with a cooling fan motor, check that the cooling fan motor is running; if not, replace the servo amplifier. ■ Check if the temperature inside the control board (servo amplifier ambient temperature) exceeds 55°C. If it does, review the servo amplifier installing method and cooling method of control board to make it below 55°C.

■ Alarm Code 55 (External Error)

◆ When host device or thermal output signal of external regenerative resistor are not connected

Status at the time of alarm	Cause	
	1	2
Issued when control power supply is turned ON.	√	√

Corrective actions

Cause		Investigation and corrective actions
1	■ Validity condition for external trip function is set to 'Valid'.	■ Set Generic Input signal to 00:_Always_Disable
2	■ Defect in internal circuit of servo amplifier.	■ Replace the servo amplifier.

◆ When thermal signal of the external regenerative resistor is connected

Status at the time of alarm	Cause		
	1	2	3
Issued when control power supply is turned ON.	√		√
Issued after operation for some time.		√	√

Corrective actions

Cause		Investigation and corrective actions
1	■ Improper wiring of external regenerative resistance.	■ Check wiring and replace if necessary.
2	■ External regeneration resistor is operating.	■ Check the operating conditions. ■ Increase the capacity of the external regeneration resistor.
3	■ Defect in internal circuit of servo amplifier.	■ Replace the servo amplifier.

Note) When output terminal of upper level device is connected, eliminate the alarm trigger of the host level device.

■ Alarm Code 56 (Main Circuit Power Device Overheat)

Status at the time of alarm	Cause			
	1	2	3	4
Issued when control power is turned ON.	√		√	√
Issued at input of servo ON.	√	√	√	
Issued while starting and stopping the servo motor.	√	√	√	
Issued after operation for some time.	√	√	√	√

Corrective actions

Cause		Investigation and corrective actions
1	■ U/V/W-phase of amplifier is short circuited due to the wiring in amplifier and motor. Also, U/V/W-phases are grounded in the earth.	■ Check wiring and replace if necessary.
2	■ Short circuit or fault in U/V/W phases on servo motor side.	■ Replace the servo motor.
3	■ Defect in internal circuit of servo amplifier.	■ Replace the servo amplifier.
4	■ Ambient temperature is high.	■ For an amplifier equipped with a cooling fan motor, check that the cooling fan motor is running; if not, replace the servo amplifier. ■ Confirm that the temperature of the control board (ambient temperature of the servo amplifier) does not exceed 55°C. If in excess of 55°C, check the installation method of the servo amplifier, and confirm that the cooling temperature of the control board is set to below 55°C.

■ Alarm Code 61 (Over-Voltage)

Status at the time of alarm	Cause			
	1	2	3	4
Issued when control power supply is turned ON.	√			
Issued when power supply of main circuit is turned ON.	√	√		
Issued while decelerating the servo motor.		√	√	√

Corrective actions

Cause		Investigation and corrective actions
1	■ Defect in internal circuit of servo amplifier.	■ Replace the servo amplifier.
2	■ The power supply voltage of main circuit is out of the specification.	■ Reduce the power supply voltage to within the specified range.
3	■ Excessive load inertia.	■ Reduce the load inertia to within the specified range.
4	■ Incorrect wiring for regeneration resistance. ■ Built-in regeneration circuit is not functioning.	■ Wire the regeneration resistance correctly. ■ While using the external regenerative resistance, check the wiring and resistance value. ■ Replace the servo amplifier if any abnormality occurs.

■ Alarm Code 62 (Main Circuit Under-voltage)

Status at the time of alarm	Cause				
	1	2	3	4	5
Issued when control power supply is turned ON.				√	√
Issued after power supply of main circuit is turned ON.	√	√	√		
Issued during operation.		√	√		

Corrective actions

Cause		Investigation and corrective actions
1	■ Input power supply voltage is below the specified range.	■ Check the power supply and set it within the specified range.
2	■ Rectifier of main circuit is broken.	■ Replace the servo amplifier.
3	■ Input power supply voltage is reduced and/or blinking.	■ Check the power supply and confirm that there is no blinking or low voltage.
4	■ Low voltage outside of the specified range is supplied to the main circuit (R/S/T).	■ Check the main circuit voltage. Confirm that there is no external power supply to R/S/T when the main circuit is OFF.
5	■ Defect in internal circuit of servo amplifier.	■ Replace the servo amplifier.

■ Alarm Code 71 (Control Power Supply Under-voltage)

Status at the time of alarm	Cause		
	1	2	3
Issued when control power supply is turned ON.	√	√	
Issued during operation.	√		√

Corrective actions

Cause		Investigation and corrective actions
1	■ Defect in internal circuit of servo amplifier.	■ Replace the servo amplifier.
2	■ Input power supply voltage is below the specified range.	■ Confirm that the power supply is set within the specified range.
3	■ Input power supply voltage is fluctuating or blinking.	■ Confirm that the power supply is not going to neither blink nor reduce the power.

■ Alarm Code 72 (Control Circuit Under-voltage 1)

Status at the time of alarm	Cause	
	1	2
Issued when control power supply is turned ON.	√	√

Corrective actions

Cause		Investigation and corrective actions
1	■ Defect in internal circuit of the servo amplifier.	■ Replace the servo amplifier.
2	■ Defect in external circuit.	■ Restart the power supply after removing the connector; if alarm is not issued, check the external circuit. ■ Restart the power supply after replacing the servo motor; if alarm is not issued, there is defect in internal circuit of motor encoder.

■ Alarm Code 73 (Control Circuit Under-voltage 2)

Status at the time of alarm	Cause	
	1	2
Issued when control power supply is turned ON.	√	√

Corrective actions

Cause		Investigation and corrective actions
1	■ Defect in internal circuit of servo amplifier.	■ Replace the servo amplifier.
2	■ Defect in external circuit.	■ Restart the power supply after removing the connector; if alarm is not issued, check the external circuit.

- Alarm Code 81 (Encoder Connector Disconnection 1)
- Alarm Code 83 (Encoder Connector Disconnection 2)
- Alarm Code 87 (CS Signal Disconnection)

Status at the time of alarm	Cause				
	1	2	3	4	5
Issued when control power supply is turned ON.	✓	✓	✓	✓	✓
Issued during operation.	✓		✓	✓	

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> ■ For motor encoder wiring: <ul style="list-style-type: none"> ◆ Improper wiring. ◆ Connector is removed. ◆ Loose connection. ◆ Encoder cable is too long. ◆ Encoder cable is too thin. 	<ul style="list-style-type: none"> ■ Check wiring and replace if necessary. ■ Confirm that the encoder power supply voltage of the motor is above 4.75 V; increase it if below 4.75 V.
2	<ul style="list-style-type: none"> ■ Servo amplifier and motor encoder are not combined properly. 	<ul style="list-style-type: none"> ■ Replace with servo motor equipped with proper encoder.
3	<ul style="list-style-type: none"> ■ Defect in internal circuit of servo amplifier. 	<ul style="list-style-type: none"> ■ Replace the servo amplifier.
4	<ul style="list-style-type: none"> ■ Defect in internal circuit of motor encoder. 	<ul style="list-style-type: none"> ■ Replace the servo motor.
5	<ul style="list-style-type: none"> ■ Parameter set to 'Full-closed servo system'. 	<ul style="list-style-type: none"> ■ Change of system parameter to "Semi-close Control / Motor Encoder" (Only with alarm code 83)

- Alarm Code 84 (Serial Encoder Communication Error)

Status at the time of alarm	Cause		
	1	2	3
Issued when control power supply is turned ON.	✓	✓	✓

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> ■ Defect in internal circuit of motor encoder. 	<ul style="list-style-type: none"> ■ Replace the servo motor.
2	<ul style="list-style-type: none"> ■ Malfunction due to noise. 	<ul style="list-style-type: none"> ■ Confirm proper grounding of the amplifier. ■ Check the shielding of the encoder cable. ■ Add ferrite core or similar countermeasures against noise.
3	<ul style="list-style-type: none"> ■ Motor encoder wiring has abnormalities. 	<ul style="list-style-type: none"> ■ Check the wiring of motor encoder and servo amplifier, and correct the wiring if needed.

- Alarm Code 85 (Encoder Initial Process Error)

Status at the time of alarm	Cause				
	1	2	3	4	5
Issued when control power supply is turned ON.	✓	✓	✓	✓	✓

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> ■ For motor encoder wiring: <ul style="list-style-type: none"> ◆ Improper wiring. ◆ Connector is removed. ◆ Loose connection. ◆ Encoder cable is too long. ◆ Encoder cable is too thin. 	<ul style="list-style-type: none"> ■ Check wiring and replace if necessary. ■ Confirm that the encoder power supply voltage of the motor is above 4.75 V; increase it if below 4.75 V.
2	<ul style="list-style-type: none"> ■ Servo amplifier and motor encoder are not combined properly. 	<ul style="list-style-type: none"> ■ Replace with servo motor equipped with proper encoder.
3	<ul style="list-style-type: none"> ■ Defect in internal circuit of servo amplifier. 	<ul style="list-style-type: none"> ■ Replace the servo amplifier.
4	<ul style="list-style-type: none"> ■ Defect in internal circuit of motor encoder. 	<ul style="list-style-type: none"> ■ Replace the servo motor.
5	<ul style="list-style-type: none"> ■ Initial position data could not be set, as the number of rotations of the motor is more than 250 min⁻¹ during power supply. 	<ul style="list-style-type: none"> ■ Restart the power supply after motor is stopped. (Only when PA035C and PA035S encoder is used.)

- Alarm Code 86 (CS Error)

State when alarm activated	Cause
	Occurred motor was in operation.

Corrective action

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> ■ Malfunction due to noise occurred in linear sensor and hole sensor wirings. 	<ul style="list-style-type: none"> ■ Check to see if ground lead is properly placed. ■ Check shielding of linear sensor cable. ■ Add ferritic core to protect from noise.

■ Alarm Code A0 (Serial Encoder Internal Error 0)

Status at the time of alarm	Cause	
	1	2
Issued when control power supply is turned ON.	✓	✓
Issued while driving the servo motor.	✓	✓

Corrective actions

Cause		Investigation and corrective actions
1	■ Defect in internal circuit of motor encoder.	■ Turn ON the power supplies again; if not restored, replace the servo motor.
2	■ Malfunction due to noise.	■ Confirm proper grounding of the amplifier. ■ Check the shielding of the encoder cable. ■ Add ferrite core or similar countermeasures against noise.

■ Alarm Code A1 (Serial Encoder Internal Error 1)

Status at the time of alarm	Cause			
	1	2	3	4
Issued when control power supply is turned ON.	✓	✓		
Issued during operation.			✓	✓

Corrective actions

Cause		Investigation and corrective actions
1	■ Loose connection of battery cable.	■ Check the battery connector of encoder cable attachment.
2	■ The fall of battery voltage.	■ Check the voltage of battery.
3	■ Loose connection of encoder connector.	■ Check the wiring of motor encoder and servo amplifier, and correct the wiring if needed.
4	■ Defect in internal circuit of motor encoder.	■ Turn ON the power supplies again; if not restored, replace the servo motor.

Note) "Encoder clear and alarm reset methods" vary depending on the motor encoder in use.

■ Alarm Code A2 (Serial Encoder Internal Error 2)

Status at the time of alarm	Cause		
	1	2	3
Issued while stopping the servo motor.	✓	✓	
Issued while rotating the servo motor.	✓	✓	✓

Corrective actions

Cause		Investigation and corrective actions
1	■ Defect in internal circuit of motor encoder.	■ Turn ON the power supplies again; if not restored, replace the servo motor.
2	■ Malfunction due to noise.	■ Confirm proper grounding of the amplifier. ■ Check the shielding of the encoder cable. ■ Add ferrite core or similar countermeasures against noise.
3	■ The acceleration of motor rotation exceeds the permitted acceleration.	■ Check the operation condition, and extend the acceleration and deceleration time.

Note) "Encoder clear and alarm reset methods" vary depending on the motor encoder in use.

■ Alarm Code A3 (Serial Encoder Internal Error 3)

Status at the time of alarm	Cause		
	1	2	3
Issued when control power supply is turned ON.	✓		✓
Issued while stopping the servo motor.	✓	✓	
Issued while stopping the servo motor.	✓	✓	✓

Corrective actions

Cause		Investigation and corrective actions
1	■ Defect in internal circuit of motor encoder.	■ Turn ON the power supplies again; if not restored, replace the motor.
2	■ Malfunction due to noise.	■ Confirm proper grounding of the amplifier. ■ Check the shielding of the encoder cable. ■ Add ferrite core or similar countermeasures against noise.
3	■ Number of motor rotations exceeds the permitted velocity.	■ Check the operation condition and reduce the maximum number of rotations.

Note) "Encoder clear and alarm reset methods" vary depending on the motor encoder in use.

- Alarm Code A4 to A6 (Serial Encoder Internal Error 4 - 6)
- Alarm Code AA to AF (Serial Encoder Internal Error 10 - 15)

Status at the time of alarm	Cause	
	1	2
Issued when control power supply is turned ON.	√	
Issued during operation.	√	√

Corrective actions

Cause		Investigation and corrective actions
1	■ Defect in internal circuit of motor encoder.	<ul style="list-style-type: none"> ■ Turn ON the power supplies again; if not restored, replace the motor.
2	■ Malfunction due to noise.	<ul style="list-style-type: none"> ■ Confirm proper grounding of the amplifier. ■ Check the shielding of the encoder cable. ■ Add ferrite core or similar countermeasures against noise.

Note) "Encoder clear and alarm reset methods" vary depending on the motor encoder in use.

- Alarm Code A9 (Serial Encoder Internal Error 9)

Status at the time of alarm	Cause		
	1	2	3
Issued when control power supply is turned ON.	√	√	
Issued while stopping the servo motor.	√	√	
Issued while rotating the servo motor.		√	√

Corrective actions

Cause		Investigation and corrective actions
1	■ Defect in internal circuit of motor encoder.	<ul style="list-style-type: none"> ■ Turn ON the power supplies again; if not restored, replace the servo motor.
2	■ Servo motor is not generating heat, but encoder ambient temperature is too high.	<ul style="list-style-type: none"> ■ Confirm that the cooling method keeps the motor encoder ambient temperature below 80°C
3	■ Servo motor is overheated.	<ul style="list-style-type: none"> ■ Confirm the cooling procedure of the servo motor.

Note) "Encoder clear and alarm reset methods" vary depending on the motor encoder in use.

- Alarm Code C1 (Over-speed)

Status at the time of alarm	Cause			
	1	2	3	4
Issued when command is entered after Servo ON.	√	√		
Issued when the servo motor is started.			√	√
Issued other than operating and starting the motor.		√	√	

Corrective actions

Cause		Investigation and corrective actions
1	■ Defect in internal circuit of servo amplifier.	<ul style="list-style-type: none"> ■ Replace the servo amplifier.
2	■ Defect in internal circuit of motor encoder.	<ul style="list-style-type: none"> ■ Replace the servo motor.
3	■ Excessive overshoot while starting.	<ul style="list-style-type: none"> ■ Adjust the servo parameters. ■ Simplify the acceleration and deceleration command pattern. ■ Reduce the load inertia.
4	■ Wiring of U/V/W -phase between servo amplifier and motor do not match.	<ul style="list-style-type: none"> ■ Check the wiring and repair any irregularities.

■ Alarm Code C2 (Velocity Control Error)

Status at the time of alarm	Cause			
	1	2	3	4
Issued at input of servo ON.	√		√	
Issued if command is entered.	√	√	√	
Issued while starting and stopping the servo motor				√

Corrective actions

Cause		Investigation and corrective actions
1	■ Wiring of U/V/W -phase between servo amplifier and motor do not match.	■ Check the wiring and repair any irregularities.
2	■ Wiring of A/B -phase of pulse encoder do not match.	■ Check the wiring and repair any irregularities.
3	■ The servo motor is vibrating (oscillating).	■ Adjust the servo parameters so that servo motor will not vibrate (oscillate).
4	■ Excessive overshoot and undershoot.	■ Monitor speed with the analog monitor. ■ Adjust the servo parameters to reduce overshoot and undershoot. ■ Simplify the acceleration and deceleration command pattern. ■ Increase the acceleration and deceleration time of the command. Mask the alarm.

Note) For the velocity control error alarm, an alarm may occur while starting and stopping when load inertia is excessive. For this reason, in the gravitational axis applications, "Do not detect" is selected as the standard setting. If its detection is needed, consult our representatives.

■ Alarm Code C3 (Velocity Feedback Error)

Status at the time of alarm	Cause		
	1	2	3
Issued when command is entered.	√	√	√
Generated at the time of control input.		√	

Corrective actions

Cause		Investigation and corrective actions
1	■ Motor is not rotating.	■ Confirm that the power line is properly connected. ■ Replace the servo motor.
2	■ Defect in internal circuit of servo amplifier.	■ Replace the servo amplifier.
3	■ The motor is vibrating (oscillating).	■ Adjust the servo parameter so that servo motor will not vibrate (oscillate).

■ Alarm Code C5 (Model Tracking Vibration Suppression, Control Error)

Status at the time of alarm	Cause		
	1	2	3
Issued after entering position command	√	√	√

Corrective actions

Cause		Investigation and corrective actions
1	■ Setup of model control gain is high.	■ Lower model control gain.
2	■ The acceleration and deceleration time of a position command is short.	■ Simplify the acceleration and deceleration command pattern.
3	■ Torque (force) limiting value is low.	■ Enlarge a torque (force) limiting value or repeal torque (force) restrictions.

* These alarms may be generated if the servo brake performs alarm reset during a slowdown.

■ Alarm Code D1 (Following Error / Excessive Position Deviation)

Status at the time of alarm	Cause											
	1	2	3	4	5	6	7	8	9	10	11	12
Issued when control power supply is turned ON.										√		
Issued when servo ON is stopped.						√					√	
Issued immediately after entering the command.	√	√	√	√	√		√	√	√		√	
Issued during starting or stopping at high speed.	√	√					√	√	√		√	√
Issued during the operations by lengthy command.		√					√	√			√	

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> Position command changes excessively, or acceleration and deceleration time is short. 	<ul style="list-style-type: none"> Correct the position command of the controller.
2	<ul style="list-style-type: none"> Excessive initial load or low motor capacity. 	<ul style="list-style-type: none"> Correct the load condition or increase the motor capacity.
3	<ul style="list-style-type: none"> Holding brake is not released. 	<ul style="list-style-type: none"> Check wiring and replace if necessary. If specified voltage is applied, replace the servo motor.
4	<ul style="list-style-type: none"> Servo motor is mechanically locked or machine is colliding. 	<ul style="list-style-type: none"> Check the machinery system.
5	<ul style="list-style-type: none"> One or all phases of U/V/W -phase of the servo amplifier and motor has disconnected. 	<ul style="list-style-type: none"> Check wiring and replace if necessary.
6	<ul style="list-style-type: none"> Motor is being rotated by an external force (Gravity, etc.) during stopping (positioning completion). 	<ul style="list-style-type: none"> Check the load, and/or increase the servo motor capacity.
7	<ul style="list-style-type: none"> Valid torque (force) limit command is entered by the controller, and the torque (force) limit setting is too much reduced. Setting of a Velocity Limit Command is too little. Number of motor encoder pulses does not match with the servo motor. 	<ul style="list-style-type: none"> Increase the torque (force) limit value or disable the torque (force) limit. Enlarge setting of a Velocity Limit Command. Match the number of servo motor encoder pulses.
8	<ul style="list-style-type: none"> Settings of servo parameters (Position Loop Gain, etc.) are not appropriate. 	<ul style="list-style-type: none"> Check the servo parameter settings (Raise the position loop gain, etc.).
9	<ul style="list-style-type: none"> Excessive deviation setting value is much reduced. 	<ul style="list-style-type: none"> Set a greater value for excessive deviation.
10	<ul style="list-style-type: none"> Defect in internal circuit of servo amplifier. 	<ul style="list-style-type: none"> Replace the servo amplifier.
11	<ul style="list-style-type: none"> Defect in internal circuit of motor encoder. 	<ul style="list-style-type: none"> Replace the servo motor.
12	<ul style="list-style-type: none"> Power supply voltage is low. 	<ul style="list-style-type: none"> Check the power supply voltage.

■ Alarm Code D2 (Position Command Error 1)※

Status at the time of alarm	Cause	
	1	2
Issued after entering position command	√	√

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> Velocity converted value of Position command exceeds the setting value of Position command error 1. CSP: Converted velocity has exceeded setting level of previous and current position commands. PP : Converted velocity of trajectory generated position command has exceeded setting value. 	<ul style="list-style-type: none"> Lower command input travel distance.
2	<ul style="list-style-type: none"> In cases where Position command cannot be received due to CRC error generation. 	<ul style="list-style-type: none"> Add ferrite core or similar countermeasures against noise.

Note) Alarm "D2" must reset after deviation clear.

■ Alarm Code D3 (Position Command Error 2)

Status at the time of alarm	Cause	
	1	2
Issued after entering position command	√	√

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> Excessive difference of recent command compared to previous Position command 	<ul style="list-style-type: none"> Lower command input travel distance.
2	<ul style="list-style-type: none"> In cases where Position command cannot be received due to CRC error generation. 	<ul style="list-style-type: none"> Add ferrite core or similar countermeasures against noise.

Note) Alarm "D3" must reset after deviation clear.

■ Alarm Code D4 (Excessive Position Synchronization Deviation)

Status at the time of alarm	Cause				
	1	2	3	4	5
Issued immediately after entering the command.	V	V	V	V	V
Issued during starting or stopping at high speed.	V	V			V
Issued during long run.	V	V			V

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> 2-axis position loop control parameters are not appropriate. Response setting of corrected position synchronization is too high. Parameters setting for corrected position synchronization are not appropriate. 	<ul style="list-style-type: none"> In mutual synchronization correction mode, disable integral compensation. Also, set the parameter at the same setting. In master-slave mode position synchronization correction, Turn on mutual synchronization correction mode.
2	<ul style="list-style-type: none"> 2-axis load inertia balance is not appropriate. 	<ul style="list-style-type: none"> Review the load condition, or perform countermeasures such as increasing the capacity of servomotor.
3	<ul style="list-style-type: none"> Valid torque (force) limit command is entered by the controller, and the torque (force) limit setting is too low. Setting of Velocity Limit Command is too low. No. of pulses of 2-axis sensor is not appropriate. 	<ul style="list-style-type: none"> Increase the torque (force) limit value. Or disable the torque (force) limit. Increase the Velocity Limit Command. Replace the motor which has same No. of sensor pulses.
4	<ul style="list-style-type: none"> Holding brake does not release. Servo motor is mechanically locked or machine has a collision. 	<ul style="list-style-type: none"> Check the wiring, and correct the wiring if needed. If the specified voltage is applied, replace the servo motor. Check if the machinery system is mechanically locked.
5	<ul style="list-style-type: none"> Setting of Position Synchronization Deviation is too low. 	<ul style="list-style-type: none"> Increase setting of Position Synchronization Deviation.

■ Alarm Code DE (Parameter change completion)

Status at the time of alarm	Cause
	Issued after setting initialization (0x20FE, 0x20FF)

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> Normal operation in alarm status. Motor code or encoder code change has detected. (The change above needs control power-cycle.) 	<ul style="list-style-type: none"> Shut down control power supply and restart servo amplifier.

■ Alarm Code DF (Test Run Close)

Status at the time of alarm	Cause
	Occurred after execution of test mode.

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> Normal operation of alarm in test mode completion. (After completion of test mode, to confirm any deviation in the controller). 	<ul style="list-style-type: none"> Clear the alarm and restore operation.

* Alarm will not be issued by marking the checkmark in "(Disabling support function completion alarm) at completion time" in test mode operation screen.

■ Alarm Code E1 (EEPROM Error)

Status at the time of alarm	Cause
	Issued during parameter change in Setup Software

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> Defect in internal circuit of servo amplifier. No response from EEPROM when saving servo parameters. (Defect in amplifier control board) 	<ul style="list-style-type: none"> Replace the servo amplifier.

■ Alarm Code E2 (EEPROM Check Sum Error)

Status at the time of alarm	Cause	
	1	2
Issued when control power supply is turned ON.	V	V

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> Correct value not read by CPU by EEPROM built-in servo amplifier. 	<ul style="list-style-type: none"> Replace the servo amplifier.
2	<ul style="list-style-type: none"> Failed to write into the EEPROM during last power supply cutoff. 	<ul style="list-style-type: none"> Replace the servo amplifier.

■ Alarm Code E3 (Memory Error 1)

Status at the time of alarm	Cause
	1
Issued when control power supply is turned ON.	V

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> Proper access failure of CPU internal RAM (Defect in control board of servo amplifier.) 	<ul style="list-style-type: none"> Replace the servo amplifier.

■ Alarm Code E4 (Memory Error 2)

Status at the time of alarm	Cause
	1
Issued when control power supply is turned ON.	V

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> Defect in internal circuit of servo amplifier. (Program check sum of flash memory was incorrect at control power input.) (Firmware defect in amplifier CPU) 	<ul style="list-style-type: none"> Replace the servo amplifier.

■ Alarm Code E5 (System Parameter Error 1)

Status at the time of alarm	Cause	
	1	2
Issued when control power supply is turned ON.	V	V

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> Selected value is outside the specified range for a system parameter. 	<ul style="list-style-type: none"> Confirm the model number of the servo amplifier. Turn ON the control power again and confirm that alarm is cleared.
2	<ul style="list-style-type: none"> Defect in internal circuit of servo amplifier. 	<ul style="list-style-type: none"> Replace the servo amplifier.

■ Alarm Code E6 (System Parameter Error 2)

Status at the time of alarm	Cause	
	1	2
Issued when control power supply is turned ON.	V	V

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> Selected values of system parameters and actual hardware do not match. Improper assembly of system parameter settings. 	<ul style="list-style-type: none"> Confirm the model number of the servo amplifier. Turn ON the control power again and confirm that alarm is cleared.
2	<ul style="list-style-type: none"> Defect in internal circuit of servo amplifier. 	<ul style="list-style-type: none"> Replace the servo amplifier.

■ Alarm Code E7 (Motor Parameter Error)

Status at the time of alarm	Cause	
	1	2
Issued when control power supply is turned ON.	V	V

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> Correct value not read by CPU by EEPROM built-in servo amplifier. 	<ul style="list-style-type: none"> If control power supply is re-switched on and alarm recurs after re-setting a motor parameter, replace servo amplifier.
2	<ul style="list-style-type: none"> Failed to write into the EEPROM when changing motor parameter. 	<ul style="list-style-type: none"> If control power supply is re-switched on and alarm recurs after re-setting a motor parameter, replace servo amplifier.

■ Alarm Code E8 (CPU Circumference Circuit Error)

Status at the time of alarm	Cause
	1
Issued when control power supply is turned ON.	V

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> ■ Access failure of CPU and peripheral devices at initialization. ■ Defect in control circuit board of servo amplifier. 	<ul style="list-style-type: none"> ■ Replace the servo amplifier.

■ Alarm Code E9 (System code Error)

Status at the time of alarm	Cause
	1
Issued when control power supply is turned ON.	V

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> ■ Corresponding encoder on servo amplifier control board and encoder setting value do not match. (Defect in control circuit board of servo amplifier.) 	<ul style="list-style-type: none"> ■ Replace the servo amplifier.

■ Alarm Code EA (Motor code setting Error)

Status at the time of alarm	Cause
	1
Issued during amplifier initialization.	V

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> ■ Motor code transferred to 0x20FE is out of combination range. 	<ul style="list-style-type: none"> ■ Combinable motor code of amplifier capacity is not set. ■ Check if a combinable motor is set.

■ Alarm Code EB (Sensor code setting Error)

Status at the time of alarm	Cause
	1
Issued during amplifier initialization.	V

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> ■ Sensor division number transferred to 0x20FF is out of range or is an unsupported sensor. 	<ul style="list-style-type: none"> ■ Sensor classification code or division number cannot be combined. Set combinable sensor code or division number. ■ Change motor sensor to supported amplifier when motor sensor differs from sensor specification of non-responding amplifier.

■ Alarm Code EE (Motor Parameter Automatic Setting Error 1)

Status at the time of alarm	Cause		
	1	2	3
Occurred after motor parameter automatic setting functional performed.	V	V	V

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> ■ Encoder being connected is not supported by motor parameter automatic setting function. 	<ul style="list-style-type: none"> ■ Replace with supported servo motor.
2	<ul style="list-style-type: none"> ■ Servo motor being connected is not supported by motor parameter automatic setting function. 	<ul style="list-style-type: none"> ■ The servo motor you use cannot be supported by this function, so please download motor parameters from setup software.
3	<ul style="list-style-type: none"> ■ Failure in internal circuit of motor encoder. 	<ul style="list-style-type: none"> ■ Replace the servo motor.

■ Alarm Code EF (Motor Parameter Automatic Setting Error 2)

Status at the time of alarm	Cause	
	1	2
Occurred after motor parameter automatic setting functional performed.	V	V

Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> ■ Combination of servo amplifier and motor is incorrect. 	<ul style="list-style-type: none"> ■ Check the model number of servo amplifier and servo motor, and correct the combination.
2	<ul style="list-style-type: none"> ■ Failure in internal circuit of motor encoder. 	<ul style="list-style-type: none"> ■ Replace the servo motor.

■ Alarm Code F1 (Task Process Error)

Status at the time of alarm	Cause	
	1	2
Issued during operation.	√	
Issued in Safe-OP or OP status, with SM2 event sync mode.		√

Corrective actions

	Cause	Investigation and corrective actions
1	■ Defect in internal circuit of servo amplifier.	■ Replace the servo amplifier.
2	■ There is jitter in the transfer frame from master for the cycle time setting (0x1C32:0x02).	■ Drives with Free Run mode or SYNC0/1 mode in Synchronous mode. ■ Please check that the jitter of master frame is less than 5us, and transmit the frame exactly.
3	■ Excessive number of PDO mappings	■ Revise No. of mappings.

■ Alarm Code F2 (Initial Process Time-Out)

Status at the time of alarm	Cause	
	1	2
Issued when control power supply is turned ON.	√	√

Corrective actions

	Cause	Investigation and corrective actions
1	■ Defect in internal circuit of servo amplifier.	■ Replace the servo amplifier.
2	■ Malfunction due to noise.	■ Confirm proper grounding of the servo amplifier. ■ Add ferrite core or similar countermeasures against noise.

9.5 Encoder Clear and Alarm Reset Methods

A procedure of "encoder clear and alarm reset method" differs by the motor encoder in use. Refer table below and recover from alarm state depending on alarm reset method applicable to motor encoder in use. In addition, please operate "Alarm reset" in the state where the issuing factor of "alarm" is removed.

Alarm reset method

Alarm code	Absolute encoder for incremental system	Battery backup method absolute encoder	Battery-less absolute encoder
A1	—	<ul style="list-style-type: none"> Perform "Alarm reset" after "Encoder clear" 	<ul style="list-style-type: none"> Perform "Alarm reset" after "Encoder clear" Power cycle
A3	<ul style="list-style-type: none"> Perform "Alarm reset" after "Encoder clear" Power cycle 	<ul style="list-style-type: none"> Perform "Alarm reset" after "Encoder clear" Power cycle 	<ul style="list-style-type: none"> Perform "Alarm reset" after "Encoder clear" Power cycle
A4	<ul style="list-style-type: none"> Perform "Alarm reset" after "Encoder clear" Power cycle 	<ul style="list-style-type: none"> Perform "Alarm reset" after "Encoder clear" Power cycle 	<ul style="list-style-type: none"> Perform "Alarm reset" after "Encoder clear" Power cycle
A5	<ul style="list-style-type: none"> Power cycle 	<ul style="list-style-type: none"> Power cycle 	<ul style="list-style-type: none"> Perform "Alarm reset" after "Encoder clear" Power cycle
A6	<ul style="list-style-type: none"> Power cycle 	<ul style="list-style-type: none"> Power cycle 	<ul style="list-style-type: none"> Power cycle after "Encoder clear"
A9	<ul style="list-style-type: none"> Perform "Alarm reset" 	<ul style="list-style-type: none"> Perform "Alarm reset" 	<ul style="list-style-type: none"> Perform "Alarm reset"
AA	—	—	<ul style="list-style-type: none"> Perform "Alarm reset" after "Encoder clear" Power cycle
AF	—	—	<ul style="list-style-type: none"> Perform "Alarm reset" after "Encoder clear" Power cycle

* When performed encoder clearing, multi turn part of encoder position data is cleared. Operate after matching an encoder position data and mechanical coordinate.

9.6 Inspection

For maintenance purposes, a daily inspection is typically sufficient. Upon inspection, refer to the following description.

Inspection location	Testing conditions			Inspection Items	Inspection Methods	Solution if abnormal
	Time	During operation	While stopping			
Servo motor	Daily	√		Vibration	Check for excessive vibration.	Contact dealer/sales office.
	Daily	√		Sound	Check if there is no abnormal sound as compared to normal sound.	
	Periodic		√	Cleanliness	Check for dirt and dust.	Clean with cloth or air. (Note 1)
	Yearly		√	Measure value of insulation resistance	Contact dealer or sales office.	
	5000 hours (Note 2)		√	Replacement of oil seal		
Servo amplifier	Periodic		√	Cleaning	Check for dust accumulated in the accessories.	Clean with air. (Note 1)
	Yearly		√	Loose screws	Check for loose connections.	Fasten the screws properly.
Battery for serial encoder	Regularly (Note 3)		√	Battery voltage	Confirm that battery voltage is more than DC3.6V.	Replace the Battery.
Temperature	Periodic	√		Measure temperature	Ambient temperature Motor frame temperature	Set the ambient temperature within the specified range. Check the load condition.

Note 1) While cleaning with air, confirm that there is no oil content and/or moisture in the air.

Note 2) This inspection and replacement period is when water- or oil-proof functions are required.

Note 3) The life expectancy of the battery is approximately 2 years, when its power is OFF throughout the year. For replacement, a lithium battery (ER3VLY: 3.6V, 1000mAh) manufactured by Toshiba Lifestyle Products & Services Corporation is recommended.

9.7 Maintenance Parts

1) Inspection Parts

Parts may deteriorate over time. Perform periodic inspection for preventive maintenance.

No.	Part name	Number of average replacement years	Corrective measures / usage conditions
1	Cooling Fan motor	5 Years	Replacement with new part is necessary. Usage condition: Average temp. 40°C year-round.
2	Lithium battery for serial encoder [ER3VLY]	3 Years	Replacement with new part is necessary.
3	Electrolytic capacitor	5 Years	Replacement with new part is necessary. Usage condition: Average temp. 40°C year-round. Annual usage period is 4800 hours.

■ Cooling Fan motor

- ◆ This Amplifier is set corresponding to the degree of pollution specified in EN50178 or IEC 664-1. As it is not dust proof or oil proof, use it in an environment above Pollution Level 2 (i.e., Pollution Level 1,2).
- ◆ RF2-Series servo amplifiers models RF2K have a built-in cooling fan; therefore make sure to maintain a space of 50mm on the upper and lower side of the amplifier for airflow. Installation in a narrow space may cause damage due to a reduction in the static pressure of the cooling fan and/or degradation of electronic parts. Replacement is necessary if abnormal noise occurs, or oil or dust is observed on the parts. Also, at an average temperature of 40°C year-round, the life expectancy is 5 years.

■ Lithium battery for serial encoder


- ◆ The standard replacement period recommended by our company is the life expectancy of lithium battery based on normal usage conditions. However, if there is high frequency of turning the power ON/OFF, or the motor is not used for a long period, then the life of lithium battery is reduced. If the battery power is less than 3.6 V during inspection, replace it with new one.

- At SANYO DENKI, the overhauled servo amplifier is shipped with the same parameters as the ones before overhauling, however, be sure to confirm the parameters before use.

9.8 Replacing battery for motor encoder

For Battery box attached to the servo amplifier


Process	Description
1	Turn ON the servo amplifier control power supply.
2	Prepare the replacement lithium battery. [Our model number: AL-00879511-01]
3	Detach the battery connector from servo amplifier.
4	Detach the battery box from servo amplifier.
5	Open the battery box.
6	Take out the old lithium battery and insert prepared new one to the battery box.
7	Close the battery box.
8	Attach the battery box to the bottom of servo amplifier.
9	Attach the connector in the right direction.



* If the battery is replaced while the control power is OFF, multiple rotation counter (position data) of the motor encoder might be instable. When the amplifier control power is turned ON in this status, an alarm (AL_A1: Serial Encoder Internal Error 1) might be issued. For this case, execute encoder clear and alarm reset to release the alarm status. Also, absolute encoder position data might be instable. So adjust the relations between a position data and a machine coordinate system to match, and then perform operation.

For Battery unit attached to junction cable for motor encoder

Process	Description
1	Turn ON the servo amplifier control power supply.
2	Prepare the replacement lithium battery. [Our model number: AL-00697958-01]
3	Open the battery unit.
4	Remove the battery connector.
5	Take out the used lithium battery and put in the new replacement one.
6	Attach the connector in the right direction.
7	Close the battery unit.



10


10 Safe Torque Off (STO) Function

10.1	System configuration	10-1
10.2	Safe Torque Off (STO) Function	10-2
1)	Overview	10-2
2)	Standards Conformity	10-3
3)	Risk assessment	10-3
4)	Residual risk	10-3
5)	Delay Circuit	10-4
10.3	Wiring	10-5
1)	CN1 connector disposition	10-5
2)	CN1 terminal connection circuit	10-5
3)	Example of wiring	10-6
4)	Safety input-off shot pulse for safety device self-diagnosis	10-8
10.4	Safe Torque Off Operations	10-8
1)	Safe Torque Off active state	10-8
2)	Recovery from Safe Torque Off active state	10-9
3)	Safe Torque Off while Servo Motor Running	10-10
4)	Safe Torque Off while Servo Motor stoppage	10-12
5)	Deviation clear	10-13
6)	Detecting HWGOFF signal errors	10-13
10.5	Error Detection Monitor (EDM)	10-14
1)	Specifications	10-14
2)	Connection example	10-14
3)	Error detection method	10-15
10.6	Confirmation Test	10-16
1)	Preparations	10-16
2)	Confirmation procedure	10-16
3)	Acceptance criteria	10-16
10.7	Safety Precautions	10-17

10.1 System configuration

■RF2□24A□HL5

SANMOTION R ADVANCED MODEL
With EtherCAT Interface




10.2 Safe Torque Off (STO) Function

The Safe Torque Off function reduces injury risks for those working near the moving parts of the equipment. This function uses 2-channel input signals to interrupt electric current to the servo motor. Historically, we used to keep machine safety by shutting down power supply to servo amplifier using Circuit breaker etc. Thanks to STO function, you can keep machine safety without shutting down power supply even when you need to do jobs like machine maintenance in some dangerous area. Because you do not have to shut down power supply, you can expect improvement in working efficiency.

1) Overview

One of the circuits connected to the 2-channel safety input signal paths (HWGOFF1, HWGOFF2) suspends current control signals for the servo motor generated by the control circuit and shut down current from the power device to the servo motor.



2) Standards Conformity

The Safe Torque Off function is applicable to the following safety function, functional safety standards and safety-related parameters.

Item	Standard
Safety Function	<ul style="list-style-type: none"> ■ IEC61800-5-2, Safe Torque Off (STO) / EN61800-5-2 ■ IEC60204, Stop Category 0 / EN60204
Safety Standard	<ul style="list-style-type: none"> ■ IEC61508(2nd), SIL3 / EN61508 ■ IEC62061, SILCL3/ EN62061 ■ ISO13849-1: 2006, Cat3, PL = e (In case of detecting failure by using EDM) / EN ISO 13849-1 / AC: 2009 ■ ISO13849-1: 2006, Cat3, PL = c (In case of without failure detection) / EN ISO 13849-1 / AC: 2009

- * PFH (Probability of a dangerous Failure per Hour) of this function (Safe Torque Off circuit) achieves less than 3% of required level of SIL2 or less than 25% of required level of SIL3.
- * To suffice ISO13849-1, PL=e, you need to design machine safety system so as to detect failure of STO circuit by surely using Error Detection Monitor (EDM).
- * Mean Time to Dangerous Failure (MTTFd) of this function is 100 years. When Error Detection Monitor (EDM) is used, Diagnostic Coverage (DC) is 92%.
- * For another standards conformity of Safety Function and Safety Standard, refer to Chapter 13.

3) Risk assessment

The servo amplifier meets the requirements of the above functional safety standards. However, before activating this safety function, be sure to assess the risks associated with the overall equipment to ensure safety.

4) Residual risk

Note that activating the STO function does not address the following hazards. Perform risk assessments to ensure safety in cases that may involve exposure to such hazards.

- When this function is activated while servo motor running, the power supply to the motor is shut down, however, the motor continues to run a while because of inertia. Make sure to design safety system to prevent any danger until the motor stops completely.
- When in vertical axes and the like, the motor rotates because of gravity loads. Take measures to hold the motor shaft such as mechanical brake. Incidentally, servo brake circuit, dynamic brake circuit of servo amplifier, holding brake excitation signal or holding brake of servo motor are not safety related devices.
- If the power device malfunctions and causes inter-phase shorting, the servo motor may move within a range of up to 180 degrees in electrical angle and remain in the excited state. For your information, the travel distance of R motor in this occasion is as follows;
R-motor travel distance: 1/10 turns (rotation angle at the motor shaft).
- Be sure to check if this function works properly when the machine is operated for the first time or servo amplifier is replaced.
If the servo amplifier is incorrectly used due to wrong wiring of input / output signals, this function will not work properly, which may incur danger.
- Even when this function is working, power supply to servo amplifier is not shut down. Be sure to shut down power supply before you perform maintenance or checkup of servo amplifier, in which you may be exposed to electric shock.

5) Delay Circuit

With this product, two kinds of hardware are provided, with or without delay circuit between safety input 1 (HGWOFF1), safety input 2 (HWG OFF2) signal input circuit and servo motor current control signal blocking circuit (optional). In vertical axis and the like, by choosing the hardware with delay circuit, you can prevent falling of the load by holding motor shaft with holding brake when the safe torque off function is activated.


Servo amplifier model number	Delay Circuit (Max. delay time)
RF2###A#HL3	Without (Max.20ms)
RF2###A#HL5	With (Max.500ms)

- * Even the hardware without delay circuit, there are still max. 20ms of delay until the safe torque off function works due to the delay in the input circuit.
- * Holding brake excitation signal and servo motor holding brake are not safety related parts.

10.3 Wiring

1) CN1 connector disposition

CN1: 2013595-3 (The figure below is viewed from connector's soldered side.)




2) CN1 terminal connection circuit

Indicates the functions and connection circuit for CN1 terminals.

Signal name	Terminal number	Symbol	Description
	1		This is a connecting terminal when function is not used. Do not use this terminal.
	2		
Safety input 1	3	HWGOFF1-	Input signal to control Safe-Torque-Off state. Connection circuit Connected to a relay or open collector transistor circuit. Power supply voltage range : DC24V±10% Internal impedance : 2.2kΩ
	4	HWGOFF1+	
Safety input 2	5	HWGOFF2-	
	6	HWGOFF2+	


Signal name	Terminal number	Symbol	Description
Error Detection Monitor	7	EDM-	The signal for monitoring a failure of Safe Torque Off function. Connection circuit Connects to photo coupler or relay circuit. Power supply voltage range (Uext): DC24V±10% Maximum current: 50mA Output voltage: Uext-0.5 to Uext
	8	EDM+	




If you do not use this function, please connect the short-circuit plug for safety instrument that is attached to this product. If the short-circuit plug for safety instrument is required, please order "AL-00849548-02", as our model number. Also, if you do not use this function by connector "2013595-3", please make short-circuit within terminal No. group 1/3/5 and within terminal No. group 2/4/6.

3) Example of wiring

Example of wiring to safety switch (1-axis used) (In case of Performance Level: PL=C)




Example of wiring to safety unit (multiple axis used) (In case of Performance Level: PL=e)



4) Safety input-off shot pulse for safety device self-diagnosis

When you connect safety device supplied with safety input-off shot pulse signal for self-diagnosis added to safety output signal, such as safety unit or safety sensor, use safety device whose safety input-off shot pulse signal is 1ms or less. Safe-torque-off function is not activated when the period of safety input signal (HWGOFF1, HWGOFF2)-OFF is 1ms or less. In order to surely fulfill the safe-torque-off function, turn off safety input signal for 500ms or more.




10.4 Safe Torque Off Operations

1) Safe Torque Off active state

The safe torque off is active when the safety input 1(HWGOFF1) or safety input 2(HWGOFF2) signal is Off (see the table below). In the safe torque off active state, the Servo Ready signal is Off. The Servo On signal will not be accepted in this state.


Signal	Input condition	Servo Amplifier condition
Safety input 1 (HWGOFF1)	On	Normal state
	Off	Safe torque off active state
Safety input 2 (HWGOFF2)	On	Normal state
	Off	Safe torque off active state

- * Off: Electric current will not flow (contact open).
- * On: Electric current will flow (contact closed).




2) Recovery from Safe Torque Off active state

While servo-on signal is not input as described in 10.4.1, turning on the safety input 1 or safety input 2 signal activates SRDY state. Operations may resume when servo-on signal is input. (The time to transit to SRDY state is maximum 550ms.)



While servo-on signal is input, it will stay to Safe Torque Off state if safety input 1 or safety input 2 signal is turned on. To re-start the operation, input the servo-off signal, and then input the servo-on signal again.




* If always sending the operation enabled signal, it may not be able to recover from Safe Torque Off state. Avoid this setting when using the Safe Torque Off function.

3) Safe Torque Off while Servo Motor Running

Depending on setting of quick stop option code (0x605A, 0x00:[QSTOP]), it will vary how the motor stops.

- In case the setting value is 0


When either safety input 1 or safety input 2 is off, the current to servo motor is shut down, then the motor stops by dynamic brake after moving to safe-torque-off state.
 After turning off safety input and elapsing delay time (Max.500ms), the state moves to safe-torque-off state.
 Dynamic brake is activated on turning off safety input.



* Dynamic brake circuit and holding brake excitation signal are not safety-related sections.

- In case the setting value is either 3 or 7 (motor stops with servo brake when servo off)


If either safety input 1 or safety input 2 input is off, motor stops with servo brake.




- * When set value of BONDLY (holding brake activation delay time OD: 0x2024) is more than safe-torque-off delay time (500ms max.), the states comes to be motor-free after period of safe-torque-off delay time. Please note that recommended set value for BONDLY is less than 500ms.
- * Servo brake circuit, dynamic brake circuit, and holding brake excitation signal are not safety-related sections.

4) Safe Torque Off while Servo Motor stoppage

Turning Off safety input 1 or safety input 2 input causes the holding brake signal to issue notification of the operating status. However, since this interrupts current supply to the servo motor, the "holding brake delay time" setting is disabled. This means the servo motor is subject to and may be moved by external forces during the interval from the output of the operating status via the holding brake signal to actual operation of the holding brake.



For amplifier model number RF2###A#HL5 (with Safe Torque Off delay circuit), 500ms maximum delay time is there between turning off safety input 1 or safety input 2 and activating Safe Torque Off function. So, it is able to get the operating time of holding brake.



* Set below 500ms in BONDLY (Delay Time of Engaging Holding Brake OD:0x2024)

5) Deviation clear

Note the following if the Deviation Clear Selection parameter (0x20F0,0x05:[CLR]) is set to Type 3 or Type 4 (do not clear deviations when Servo Off).

As long as positioning commands are being issued during position control, activating the safe torque off function will trigger the excessive cumulative positional deviation error (alarm D1). If the Servo On signal is input once again before this alarm is issued, the servo motor will continue to operate according to cumulative positional deviations. To keep this from happening, stop issuing positioning commands as soon as the safe torque off function is activated and clear any positional deviations.

(If the Deviation Clear Selection parameter (0x20F0,0x05[CLR]) is set to Type 1 or Type 2 (clear deviation when Servo On), any positional deviation is automatically cleared when the Servo Off signal is transmitted.

6) Detecting HWGOFF signal errors

- **Safe Torque Off function error 1 (alarm 25)**
After the safety input 1 or safety input 2 signal is turned Off, this alarm is issued if the other signal does not turn Off within 10 seconds. This enables detection of a broken wire or disconnected HWGOFF signals.
- **Safe Torque Off function error 2 (alarm 26)**
This alarm is issued when an internal circuit failure is detected based on the safety signal input status and internal status. This enables detection of circuit problems that interrupt control signals to the power module based on the safety signal input.

10.5 Error Detection Monitor (EDM)

1) Specifications


The EDM output signals monitor errors in the safe torque off circuit, /HWGOFF1 wire, or /HWGOFF2 wire. The following table shows the relationships among /HWGOFF1 input, /HWGOFF2 input, and EDM output.

Signal	State			
Safety input 1 (HWGOFF1)	On	On	Off	Off
Safety input 2 (HWGOFF2)	On	Off	On	Off
Error detection monitor (EDM)	Off	Off	Off	On

* If the above relationships are not satisfied, the Safe Torque Off circuit or EDM output circuit shall be malfunctions.

2) Connection example

The following is a connection example. This example uses a safety unit and activates the Safe Torque Off function when the operator presses the Emergency Stop button.



Connect safety unit output signal to safety input1 (HWGOFF1) and safety input 2 (HWGOFF2) respectively, and then connect error detection monitor (EDM) from servo amplifier to feedback input of safety unit.

Under normal conditions, pressing emergency stop button turns off both of safety inputs and on EDM output.

Once the emergency stop button is cancelled, as EDM output is on, the feedback circuit of safety unit is reset, and both safety inputs are turned on, which resumes the operation.

* In case such a malfunction occurs that EDM will not be turned on despite both the safety input being off, even if the emergency stop button is cancelled, the operation will not resume as the feedback circuit has not been reset yet. (The amplifier keeps Safety Torque Off state).

3) Error detection method

When any failures occurred with any of safety inputs remained ON inside the servo amplifier, EDM output will not be turned on, and EDM signal will remain OFF even if emergency stop button pressed. Errors can be detected by system configuration with safety unit detecting the condition that relationship between safety input and EDM output in the above table is not effective.

- * In case you need to meet requirements of ISO13849-1, PL=e, make sure to perform testing of failure detection by using EDM output once a month or more frequently.
- * For discussions on connecting and operating the safety unit, please refer to the manual provided with your safety unit.
- * The EDM signal is not safety output. Do not use EDM signal for any purpose other than malfunction monitoring.

10.6 Confirmation Test

For use of the Safe Torque Off function, you must confirm that the safe torque off operations correctly during machine startup, servo amp replacement and test operation.
 Even if it is not fit to the case above, strongly recommended that confirmation of function operation at least annually.

1) Preparations

Before performing the confirmation test, perform a test operation to confirm that the equipment operates properly and that there are no problems in the servo amp, servo motor installation, or wire connections.
 For a discussion of installation, wiring, and test operations, refer from "3. Installation" to "6.2. Test operation".

2) Confirmation procedure

Follow the procedure described below to run an STO function confirmation test:
 Procedure 1. Supply control power and main circuit power.
 Procedure 2. Turn On both safety input 1 and 2 input signals.
 Procedure 3. Input the Servo On signal to excite the servo motor.
 Procedure 4. Turn Off both the safety input 1 and 2 input signals.

3) Acceptance criteria

Confirmation procedure 2 to 4, confirm the states listed below.

Procedure 1 and 2, make sure that the EDM output and LED indication are as follows:

Confirmation item	State
EDM output	Off
LED indication	[ST]LED (Green) : Blinking with 256mscycle [AL]LED (Red) : Off

Procedure 2 and 3, confirm that the servo motor is excited.

Procedure 3 and 4, confirm that the EDM output and LED indication are as follows:
 Also, confirm that servo motor excitation has been cancelled.

Confirmation item	State
EDM output	On
LED indication	[ST]LED (Green) : Blinking with 256mscycle [AL]LED (Red) : Blinking with 256mscycle

10.7 Safety Precautions

As for Safe Torque Off function, strictly adhere to the following safety precautions.

Incorrect use of this function can result in physical injury and damage to people and/or machinery.

- ✓ The person who designs a system using the safety function (STO function) must have full knowledge of the related safety standards and full understanding of the instructions in this manual.
- ✓ Ensure performing Risk assessment when designing safety system using this function.
- ✓ When STO function is activated while servo motor running, the power supply to the motor is shut down, however, the motor continues to run a while through inertia. Make sure to design safety system to prevent any danger until the motor stops completely.
- ✓ When in vertical axes and the like, the motor rotates because of gravity loads. Take measures to hold the motor shaft with mechanical brake etc. Incidentally, dynamic brake of servo amplifier, holding brake excitation signal or holding brake of servo motor are not safety related parts.
- ✓ The motor may rotate within the electric angle of 180 degrees keeping motor excitation in case of servo motor between phases short-circuit due to the power device failure, etc. Use the function only in the applications where you can judge the above behavior will not lead to dangerous condition.
- ✓ Be sure to check if this function works properly when the machine is operated for the first time or servo amplifier is replaced. If the servo amplifier is incorrectly used due to faulty wiring of input / output signals, this function will not work properly, which may incur danger.
- ✓ For the time of Safe Torque Off function working and the cause concerning information, recommended that recording as error log at user device.
- ✓ At inspection and maintenance for servo amplifier, strongly recommended that recording and storing a detail of inspection and maintenance.


11

11. Linear motor

11.1	System configuration diagram	11-1
11.2	Wiring.....	11-2
1)	Recommended specification for encoder cable.....	11-2
2)	Encoder cable length.....	11-2
3)	Linear encoder wiring (Incremental differential output)	11-2
4)	Terminal numbers on servo amplifier	11-3
5)	Linear encoder signal on motor (D-sub 9 pin).....	11-3
6)	Wire diameter - Permissible current.....	11-3
11.3	Linear motor control-related parameters	11-4
1)	Setting of system parameter	11-4
2)	Setting of linear scale sensor	11-5
3)	Setting of magnetic pole position estimation method.....	11-5
4)	Setting of moving direction	11-6

11.1 System configuration diagram

■RF2J24A8HL5



11.2 Wiring

For RF2 series multi axis EtherCAT servo amplifier, only apply to compact cylinder linear motor DE0AC001A03M.

1) Recommended specification for encoder cable

Shielded many-to-one cable	Cable rating	80°C 30V
	Conductor resistance value	1 Ω or less Note1)
	Conductor size	AWG size: 26 to 18 SQ(mm ²): 0.15 to 0.75

Note1) Shows conductor resistance value for the conductor length to be actually used.

2) Encoder cable length

Maximum cable lengths by conductor size of power (5V, SG) cable

Conductor size		Conductor resistance Ω / km (20°C)	Length (m)
AWG	26	150 or less	5
	24	100 or less	10
	22	60 or less	15
	20	40 or less	25
	18	25 or less	40
SQ(mm ²)	0.15	150 or less	5
	0.2	100 or less	10
	0.3	65 or less	15
	0.5	40 or less	25
	0.75	28 or less	35

Conductor resistance varies depending on conductor specifications.

3) Linear encoder wiring (Incremental differential output)

Indicates the terminal number and signal name of linear scale sensor EN1 to EN4.


Servo amplifier EN1 to 4 Terminal No.	Servo motor lead color	Signal name	Description	Remarks
1	Red	5V	Power supply	Twisted-pair
2	Black	SG	Power supply common	
3	-	-	-	
4	-	-	-	
5	Green	B	B-phase pulse output	Twisted-pair
6	Purple	/B		
7	Blue	A	A-phase pulse output	Twisted-pair
8	Brown	/A		
9	White	Z	Z-phase pulse output	Twisted-pair
10	Yellow	/Z		
-	Earth	Shield	-	

* Use shielded cable and perform twisted-pair wiring.

* Connect the shielded cable to the metal case (ground) on EN1 to 4 sides and connect the ground to the motor encoder side.

* Must connect to power supply common.

4) Terminal numbers on servo amplifier



Solder connection

* Please make sure to check wiring as wiring varies depending on encoder types to be connected.

I/O	Model number	Applicable wire size	Applicable cable outer diameter	Manufacturer
Connector	36210-0100PL	AWG30 to AWG18	—	3M
Shell kit (Soldering type)	36310-3200-008	—	φ7 to φ9	

5) Linear encoder signal on motor (D-sub 9 pin)

For wiring from D-sub 9 pin output of linear motor encoder to EN1 -EN4, please prepare at customer side.

Motor Terminal No.	Signal name	Description
1	NC	-
2	Z	Z-phase pulse+ output
3	B	B-phase pulse+ output
4	A	A-phase pulse+ output
5	5V	DC5V input for encoder
6	/Z	Z-phase pulse- output
7	/B	B-phase pulse- output
8	/A	A-phase pulse- output
9	SG	GND/inner shield

* Use shielded cable and perform twisted-pair wiring.

6) Wire diameter - Permissible current

Refer to chapter 4, for wiring example.

Indicate wire diameter and permissible current for DE0AC001A03M motor, to below.

Servo motor model No.	Motor power (U·V·W· ⊕)		Servo amplifier to be combined	Main circuit power supply (P, N)		Control power supply (CP, CN)		Regenerative resistor		⊕	
	mm ²	AWG No		mm ²	AWG No	mm ²	AWG No	mm ²	AWG No	mm ²	AWG No
DE0AC001A03M	1.25	16	RF2#24	1.25	16	1.25	16	1.25	16	2.0	14

- * "#" is optional number or alphabetical letter.
- * The above values are provided under condition that ambient temperature is 40°C and rated current is applied to 3 lead bands.
- * Consider wire allowable current reduction rate, when you band wires and then insert them into duct such as cured vinyl tube or metal tube.
- * If ambient temperature is relatively high, the lifetime is shortened due to heat deterioration. In this case special heat-resistant vinyl covered wire (HIV) is recommended.
- * For the main circuit power supply, wire diameter less than above table is able to use depending on servo motor capacity.

11.3 Linear motor control-related parameters

Set the parameters as follows to use linear motor.

1) Setting of system parameter

Group ID	Parameter symbol	Contents																												
System ID10	MOCODE	Motor code																												
		<ul style="list-style-type: none"> ■ Set combination motor code you use. Set the combination motor code by selecting the linear motor code you use from "section 1.5, Combination motor list" or "section 5, Motor code". ✓ For the case of 0xFFFF whose motor code is specific, make sure to download motor parameters from setup software. ⚡ System parameter becomes effective by control power cycle. 																												
System ID05	ENCODE	Sensor division number code																												
		<ul style="list-style-type: none"> ■ Set division number of linear scale sensor you use. Set 0x0004 because resolution of DE0AC001A03M is 1μm. <table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>0x0000</td><td>: 5μm</td><td>[200P/mm]</td></tr> <tr><td>0x0001</td><td>: 2.5μm</td><td>[400P/mm]</td></tr> <tr><td>0x0002</td><td>: 2μm</td><td>[500P/mm]</td></tr> <tr><td>0x0003</td><td>: 1.25μm</td><td>[800P/mm]</td></tr> <tr><td>0x0004</td><td>: 1μm</td><td>[1,000P/mm]</td></tr> <tr><td>0x0005</td><td>: 0.5μm</td><td>[2,000P/mm]</td></tr> <tr><td>0x0006</td><td>: 0.25μm</td><td>[4,000P/mm]</td></tr> <tr><td>0x0007</td><td>: 0.125μm</td><td>[8,000P/mm]</td></tr> <tr><td>0x0008</td><td>: 0.1μm</td><td>[10,000P/mm]</td></tr> <tr><td>0x0009</td><td>: 0.05μm</td><td>[20,000P/mm]</td></tr> </table> ⚡ System parameter becomes effective by control power cycle. 	0x0000	: 5μm	[200P/mm]	0x0001	: 2.5μm	[400P/mm]	0x0002	: 2μm	[500P/mm]	0x0003	: 1.25μm	[800P/mm]	0x0004	: 1μm	[1,000P/mm]	0x0005	: 0.5μm	[2,000P/mm]	0x0006	: 0.25μm	[4,000P/mm]	0x0007	: 0.125μm	[8,000P/mm]	0x0008	: 0.1μm	[10,000P/mm]	0x0009
0x0000	: 5μm	[200P/mm]																												
0x0001	: 2.5μm	[400P/mm]																												
0x0002	: 2μm	[500P/mm]																												
0x0003	: 1.25μm	[800P/mm]																												
0x0004	: 1μm	[1,000P/mm]																												
0x0005	: 0.5μm	[2,000P/mm]																												
0x0006	: 0.25μm	[4,000P/mm]																												
0x0007	: 0.125μm	[8,000P/mm]																												
0x0008	: 0.1μm	[10,000P/mm]																												
0x0009	: 0.05μm	[20,000P/mm]																												
System ID04	ENTYPE	Sensor type code																												
		<ul style="list-style-type: none"> ■ Set linear sensor and CS-normalization method you use. 0x0830: signal/ wire-saving incremental encoder : CS-normalization/ phase Z 0x0840: signal/ wire-saving incremental encoder : CS-normalization/ none 0x0850: signal/ A, B, Z only: CS-normalization/ Software setting (Magnetic pole position estimation) 0x0860: signal/ A, B, Z only: CS-normalization/ Software setting (fixed excitation) ⚡ System parameter becomes effective by control power cycle. ⚡ This RF2 series amplifier cannot use as the control system using hall effect sensor. For use of hall effect sensor, please use RS2 series single axis type amplifier. 																												
System ID0B	PLMODE	Encoder selection to control position loop																												
		<ul style="list-style-type: none"> ■ Verify the set value is as indicated below. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Present set value</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00: External-Enc</td> <td>Semi-closed control/ motor encoder</td> </tr> </tbody> </table> 	Present set value	Contents	00: External-Enc	Semi-closed control/ motor encoder																								
Present set value	Contents																													
00: External-Enc	Semi-closed control/ motor encoder																													

2) Setting of linear scale sensor

CS-detection method of linear motor varies depending on system parameter "System ID04" or "Device parameter: 0x0x0004 sensor type code". Verify the following parameter settings.

Group ID	Parameter symbol	Contents																
GroupC ID00	ENFIL	Encoder digital filter selection (EN1)																
		<ul style="list-style-type: none"> Set digital filter for motor pulse encoder pulse signal, which is contained in pulse output encoder. Digital filter value of incremental pulse from the linear scale sensor you use can be set. When noises superimposed on incremental encoder, pulse under the set value shall be eliminated as noise. Set the value in consideration of encoder resolution and operational maximum velocity of servo motor you use. Use the value under a quarter of encoder pulse width at maximum rotational velocity as a guide. <table border="1"> <thead> <tr> <th>Value to select</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00: _110nsec</td> <td>Minimum pulse width =110ns (Minimum phase difference37.5ns)</td> </tr> <tr> <td>01: _220nsec</td> <td>Minimum pulse width =220ns (Minimum phase difference75ns)</td> </tr> <tr> <td>02: _440nsec</td> <td>Minimum pulse width =440ns (Minimum phase difference150ns)</td> </tr> <tr> <td>03: _880nsec</td> <td>Minimum pulse width =880ns (Minimum phase difference300ns)</td> </tr> <tr> <td>04: _75nsec</td> <td>Minimum pulse width = 75ns (Minimum phase difference37.5ns)</td> </tr> <tr> <td>05: _150nsec</td> <td>Minimum pulse width =150ns (Minimum phase difference75ns)</td> </tr> <tr> <td>06: _300nsec</td> <td>Minimum pulse width =300ns (Minimum phase difference150ns)</td> </tr> <tr> <td>07: _600nsec</td> <td>Minimum pulse width =600ns (Minimum phase difference300ns)</td> </tr> </tbody> </table>	Value to select	Contents	00: _110nsec	Minimum pulse width =110ns (Minimum phase difference37.5ns)	01: _220nsec	Minimum pulse width =220ns (Minimum phase difference75ns)	02: _440nsec	Minimum pulse width =440ns (Minimum phase difference150ns)	03: _880nsec	Minimum pulse width =880ns (Minimum phase difference300ns)	04: _75nsec	Minimum pulse width = 75ns (Minimum phase difference37.5ns)	05: _150nsec	Minimum pulse width =150ns (Minimum phase difference75ns)	06: _300nsec	Minimum pulse width =300ns (Minimum phase difference150ns)
Value to select	Contents																	
00: _110nsec	Minimum pulse width =110ns (Minimum phase difference37.5ns)																	
01: _220nsec	Minimum pulse width =220ns (Minimum phase difference75ns)																	
02: _440nsec	Minimum pulse width =440ns (Minimum phase difference150ns)																	
03: _880nsec	Minimum pulse width =880ns (Minimum phase difference300ns)																	
04: _75nsec	Minimum pulse width = 75ns (Minimum phase difference37.5ns)																	
05: _150nsec	Minimum pulse width =150ns (Minimum phase difference75ns)																	
06: _300nsec	Minimum pulse width =300ns (Minimum phase difference150ns)																	
07: _600nsec	Minimum pulse width =600ns (Minimum phase difference300ns)																	
GroupC ID09	ENCDIR	Linear sensor polarity selection (EN1 - EN4)																
		<ul style="list-style-type: none"> Select linear encoder (EN1 - EN4) signal polarity. Phase A and B signal polarity are selectable. <table border="1"> <thead> <tr> <th>Value to select</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00</td> <td>Standard Phase B signal rises in first in forward direction operation.</td> </tr> <tr> <td>01</td> <td>Reversed Phase A signal rises in first in forward direction operation.</td> </tr> </tbody> </table> <p>⚡ Function enabled on re-turning control power on.</p>	Value to select	Contents	00	Standard Phase B signal rises in first in forward direction operation.	01	Reversed Phase A signal rises in first in forward direction operation.										
Value to select	Contents																	
00	Standard Phase B signal rises in first in forward direction operation.																	
01	Reversed Phase A signal rises in first in forward direction operation.																	

3) Setting of magnetic pole position estimation method

CS-detection method of linear motor varies depending on system parameter "System ID04" or "Device parameter: 0x0x0004 sensor type code". Verify the following parameter settings.

Group ID	Parameter symbol	Contents
System ID0D	CSOF	CS-offset
		<ul style="list-style-type: none"> Set electrical angle of motor. For motor with hall sensor, offset from phase U electrical angle 0 degree to phase U hall sensor output edge shall be set in electrical angle. Setting range :0 to 359deg Initial value :330deg ✓ Sensor type code: 0x0004 = 0x0830, 0x0840, 0x0850 and 0x0860 need to be set. ⚡ Function enabled on re-turning control power on.
System ID0E	ZPHOF	Phase Z CS-normalization offset
		<ul style="list-style-type: none"> Set offset of phase Z signal to electrical angle of motor. This is effective only when performing CS-normalization with phase Z signal. Set offset from phase U electrical angle 0 degree to phase Z signal output position shall be set in electrical angle. Setting range :0 to 359deg Initial value :330deg ✓ Sensor type code: 0x0004 = 0x0810, 0x0830 need to be set. ⚡ Function enabled on re-turning control power on.

Group ID	Parameter symbol	Contents																																		
GroupB ID01	EMPFREQ	<p>Magnetic pole position estimation frequency</p> <ul style="list-style-type: none"> ■ Set frequency of torque (force) applied at magnetic pole position estimation. Setting range : 5 to 100Hz Initial value : 50Hz ✓ Change excitation frequency when detection cannot be normally completed due to resonance point of machine, at amplifier hardware magnetic pole position estimation. 🔌 Function enabled on re-turning control power on. 																																		
—	CSETMD	<p>Magnetic pole position estimation mode selection</p> <ul style="list-style-type: none"> ■ Set the magnetic pole position estimation run mode. <table border="1"> <thead> <tr> <th>Value to select</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00</td> <td>Follow the setting of the valid condition of magnetic pole position pointing function.</td> </tr> <tr> <td>01</td> <td>Magnetic pole position estimation will run one time automatically only after turning on the main power.</td> </tr> </tbody> </table> <ul style="list-style-type: none"> ✓ Sensor Classification Cord Function will be enabled by setting 0x0004 = 0x0850. 🔌 Function enabled on re-turning control power on. 	Value to select	Contents	00	Follow the setting of the valid condition of magnetic pole position pointing function.	01	Magnetic pole position estimation will run one time automatically only after turning on the main power.																												
Value to select	Contents																																			
00	Follow the setting of the valid condition of magnetic pole position pointing function.																																			
01	Magnetic pole position estimation will run one time automatically only after turning on the main power.																																			
Group9 ID1A	CSET	<p>Magnetic pole position pointing function</p> <ul style="list-style-type: none"> ■ Set valid condition of magnetic pole position estimation, for linear motor without hall sensor output function. <table border="1"> <thead> <tr> <th>Value to select</th> <th>Contents</th> </tr> </thead> <tbody> <tr><td>02: _CONT1_ON</td><td>Function enabled when general input CONT1 is ON.</td></tr> <tr><td>03: _CONT1_OFF</td><td>Function enabled when general input CONT1 is OFF.</td></tr> <tr><td>04: _CONT2_ON</td><td>Function enabled when general input CONT2 is ON.</td></tr> <tr><td>05: _CONT2_OFF</td><td>Function enabled when general input CONT2 is OFF.</td></tr> <tr><td>06: _CONT3_ON</td><td>Function enabled when general input CONT3 is ON.</td></tr> <tr><td>07: _CONT3_OFF</td><td>Function enabled when general input CONT3 is OFF.</td></tr> <tr><td>08: _CONT4_ON</td><td>Function enabled when general input CONT4 is ON.</td></tr> <tr><td>09: _CONT4_OFF</td><td>Function enabled when general input CONT4 is OFF.</td></tr> <tr><td>0A: _CONT5_ON</td><td>Function enabled when general input CONT5 is ON.</td></tr> <tr><td>0B: _CONT5_OFF</td><td>Function enabled when general input CONT5 is OFF.</td></tr> <tr><td>0C: _CONT6_ON</td><td>Function enabled when general input CONT6 is ON.</td></tr> <tr><td>0D: _CONT6_OFF</td><td>Function enabled when general input CONT6 is OFF.</td></tr> <tr><td>0E: _CONT7_ON</td><td>Function enabled when general input CONT7 is ON.</td></tr> <tr><td>0F: _CONT7_OFF</td><td>Function enabled when general input CONT7 is OFF.</td></tr> <tr><td>10: _CONT8_ON</td><td>Function enabled when general input CONT8 is ON.</td></tr> <tr><td>11: _CONT8_OFF</td><td>Function enabled when general input CONT8 is OFF.</td></tr> </tbody> </table> <ul style="list-style-type: none"> ✓ Input time to become all the function enabled is 8ms. 🔌 Function enabled on re-turning control power on. 	Value to select	Contents	02: _CONT1_ON	Function enabled when general input CONT1 is ON.	03: _CONT1_OFF	Function enabled when general input CONT1 is OFF.	04: _CONT2_ON	Function enabled when general input CONT2 is ON.	05: _CONT2_OFF	Function enabled when general input CONT2 is OFF.	06: _CONT3_ON	Function enabled when general input CONT3 is ON.	07: _CONT3_OFF	Function enabled when general input CONT3 is OFF.	08: _CONT4_ON	Function enabled when general input CONT4 is ON.	09: _CONT4_OFF	Function enabled when general input CONT4 is OFF.	0A: _CONT5_ON	Function enabled when general input CONT5 is ON.	0B: _CONT5_OFF	Function enabled when general input CONT5 is OFF.	0C: _CONT6_ON	Function enabled when general input CONT6 is ON.	0D: _CONT6_OFF	Function enabled when general input CONT6 is OFF.	0E: _CONT7_ON	Function enabled when general input CONT7 is ON.	0F: _CONT7_OFF	Function enabled when general input CONT7 is OFF.	10: _CONT8_ON	Function enabled when general input CONT8 is ON.	11: _CONT8_OFF	Function enabled when general input CONT8 is OFF.
Value to select	Contents																																			
02: _CONT1_ON	Function enabled when general input CONT1 is ON.																																			
03: _CONT1_OFF	Function enabled when general input CONT1 is OFF.																																			
04: _CONT2_ON	Function enabled when general input CONT2 is ON.																																			
05: _CONT2_OFF	Function enabled when general input CONT2 is OFF.																																			
06: _CONT3_ON	Function enabled when general input CONT3 is ON.																																			
07: _CONT3_OFF	Function enabled when general input CONT3 is OFF.																																			
08: _CONT4_ON	Function enabled when general input CONT4 is ON.																																			
09: _CONT4_OFF	Function enabled when general input CONT4 is OFF.																																			
0A: _CONT5_ON	Function enabled when general input CONT5 is ON.																																			
0B: _CONT5_OFF	Function enabled when general input CONT5 is OFF.																																			
0C: _CONT6_ON	Function enabled when general input CONT6 is ON.																																			
0D: _CONT6_OFF	Function enabled when general input CONT6 is OFF.																																			
0E: _CONT7_ON	Function enabled when general input CONT7 is ON.																																			
0F: _CONT7_OFF	Function enabled when general input CONT7 is OFF.																																			
10: _CONT8_ON	Function enabled when general input CONT8 is ON.																																			
11: _CONT8_OFF	Function enabled when general input CONT8 is OFF.																																			
Group9 ID40	EXT-E	<p>External trlp-input function</p> <p>Set the condition that trip input becomes effective to use thermal of linear motor.</p> <ul style="list-style-type: none"> ■ The setting contents are the same as the above magnetic pole position indication function. ✓ Input time to become all the function enabled is 8ms. 🔌 Function enabled on re-turning control power on. 																																		

4) Setting of moving direction

Moving direction of linear motor depends on polarity of command and linear scale sensor.

■ Setting of command-input polarity

Group ID	Parameter symbol	Contents
Group8 ID00	CMDPOL	<p>Polarity</p> <ul style="list-style-type: none"> ■ Select position command polarity from the following contents. Servo motor moving direction can be reversed without changing command wiring. 🔌 Please use, after verifying move direction that the command polarity is set to plus.

No Text on This Page.

12


12. Selection

12.1	Rotary Motor Sizing	12-1
1)	Flowchart of Servo Motor Sizing	12-1
2)	Make an operation pattern	12-2
3)	Calculate motor axis conversion load inertia (J_L)	12-2
4)	Calculate motor shaft conversion load torque (T_L)	12-3
5)	Calculate acceleration torque (T_a)	12-4
6)	Calculate deceleration torque (T_b)	12-4
7)	Calculate effective torque (T_{rms})	12-4
8)	Judgment condition	12-4
12.2	Capacity Selection of Regenerative Resistor	12-5
1)	How to find "regeneration effective power (PM)" of the horizontal axis drive by a formula (Rotary motor)	12-5
2)	How to find "regeneration effective power (PM)" of the vertical axis drive by a formula (Rotary motor)	12-6
3)	How to find "regeneration effective power (PM)" of the vertical axis drive by a formula (Linear motor)	12-7
4)	Capacity Selection of Regenerative Resistor	12-8
5)	Selection of external regenerative resistor instantaneous tolerance	12-8
6)	Capacity of External Regenerative Resistor and Resistor Model Name	12-8
7)	Thermostat Connection of External Regenerative Resistor	12-9
8)	Protection Function of Regenerative Resistance	12-9
9)	Confirmation method of regeneration effective power PM in actual operation	12-10
10)	Precaution for external regenerative resistor installation	12-10

12.1 Rotary Motor Sizing

It is estimated that selection of servo motor capacity computes required servo motor capacity from machine specification (composition). In addition, since the capacity selection of a servo motor can download "the capacity selection software of a servo motor" for free from our company "website", please use it here. Here, the fundamental formula is described.


1) Flowchart of Servo Motor Sizing



1. Make an operation pattern.
2. Calculate load moment of inertia from a machine configuration.
3. Calculate load torque from a machine configuration.
4. Load moment of inertia (J_L) is 10 or less times of the rotor moment of a servo motor inertia (J_M), and the load torque (T_L) should do temporary motor selection less than 80% of a motor rating torque (T_R).
 $J_L \leq J_M \times 10$
 $T_L \leq T_R \times 0.8$
5. Calculate the required accel/decel torque from an operation pattern.
6. Calculate the effective torque from a torque pattern.
7. Judge whether the accel/decel torque (T_a , T_b) is less than 80% of the instant maximum torque (T_p) of a servo motor, and the effective torque (T_{rms}) is less than 70% of the rating torque (T_R) of a servo motor.
 $T_a \leq T_p \times 0.8$
 $T_b \leq T_p \times 0.8$
 $T_{rms} \leq T_R \times 0.7$
8. Calculate regeneration electric power, and if required, select an external regeneration resistor.
9. Improve servo motor capacity, such as raising the capacity of a servo motor.

Note1) The operational pattern shall be created so that average motor rotational velocity does not exceed maximum rotational velocity.

2) Make an operation pattern



t_a = Acceleration time

t_b = Deceleration time

t_r = Constant velocity time

t_s = Stop time

t =1 cycle

3) Calculate motor axis conversion load inertia (J_L)

■ The load inertia of a moving part

$$J_L = \left(\frac{1}{G}\right)^2 \times \frac{\pi \times \rho \times D^4 \times L}{32} \quad [\text{kg} \cdot \text{m}^2]$$

G: Reduction ratio

ρ : Moving part specific gravity [kg/m^3]

D: Moving part diameter [m]

L: Moving part length [m]

■ The load inertia of a work

$$J_L = \left(\frac{1}{G}\right)^2 \times W \times \left(\frac{P}{2\pi}\right)^2 \quad [\text{kg} \cdot \text{m}^2]$$

G: Reduction ratio

W: Moving part mass [kg]

P: In the case of a ball screw, is the lead of a ball screw. [m]

In the case of a belt pulley, is an outside diameter of a pulley. [m]

($P = \pi D$)

4) Calculate motor shaft conversion load torque (T_L)

- Ball screw (in horizontal axis)

$$T_L = \frac{(F + \mu W)}{\eta} \times \frac{P}{2\pi} \times \frac{1}{G} \times 9.8 \quad [\text{N}\cdot\text{m}]$$

- Ball screw (in vertical axis)

When motor drives upward

$$T_L = \frac{(F + (\mu + 1)W)}{\eta} \times \frac{P}{2\pi} \times \frac{1}{G} \times 9.8 \quad [\text{N}\cdot\text{m}]$$

When motor drives downward

$$T_L = \frac{(F + (\mu - 1)W)}{\eta} \times \frac{P}{2\pi} \times \frac{1}{G} \times 9.8 \quad [\text{N}\cdot\text{m}]$$

- When ball screw stops (in horizontal axis)

$$T_L = \frac{F}{\eta} \times \frac{P}{2\pi} \times \frac{1}{G} \times 9.8 \quad [\text{N}\cdot\text{m}]$$

- When ball screw stops (in vertical axis)

$$T_L = \frac{(F + W)}{\eta} \times \frac{P}{2\pi} \times \frac{1}{G} \times 9.8 \quad [\text{N}\cdot\text{m}]$$

F: External force [kg] η : Transmission efficiency
 μ : Coefficient of friction W: Moving part mass [kg]
 P: Ball screw lead [m] G: Reduction ratio

- Belt pulley (in horizontal axis)

$$T_L = \frac{(F + (\mu + 1)W)}{\eta} \times \frac{D}{2} \times \frac{1}{G} \times 9.8 \quad [\text{N}\cdot\text{m}]$$

- Belt pulley (in vertical axis)

When motor drives upward

$$T_L = \frac{(F + (\mu + 1)W)}{\eta} \times \frac{D}{2} \times \frac{1}{G} \times 9.8 \quad [\text{N}\cdot\text{m}]$$

When motor drives downward

$$T_L = \frac{(F + (\mu - 1)W)}{\eta} \times \frac{D}{2} \times \frac{1}{G} \times 9.8 \quad [\text{N}\cdot\text{m}]$$

- When belt pulley stops (in horizontal axis)

$$T_L = \frac{F}{\eta} \times \frac{D}{2} \times \frac{1}{G} \times 9.8 \quad [\text{N}\cdot\text{m}]$$

- When belt pulley stops (in vertical axis)

$$T_L = \frac{(F + W)}{\eta} \times \frac{D}{2} \times \frac{1}{G} \times 9.8 \quad [\text{N}\cdot\text{m}]$$

F: External force [kg] η : Transmission efficiency
 μ : Coefficient of friction W: Moving part mass [kg]
 D: Diameter of a pulley [m] G: Reduction ratio

5) Calculate acceleration torque (T_a)

$$T_a = \frac{2\pi(N_2 - N_1) \times (J_L + J_M)}{60 \times t_a} + T_L \quad [\text{N} \cdot \text{m}]$$

N_2 : Servo motor rotation velocity after acceleration [min^{-1}]

N_1 : Servo motor rotation velocity before acceleration [min^{-1}]

J_L : Load inertia [$\text{kg} \cdot \text{m}^2$]

J_M : Rotor inertia of servo motor [$\text{kg} \cdot \text{m}^2$]

6) Calculate deceleration torque (T_b)

$$T_b = \frac{2\pi(N_2 - N_1) \times (J_L + J_M)}{60 \times t_b} - T_L \quad [\text{N} \cdot \text{m}]$$

N_2 : Servo motor rotation velocity before deceleration [min^{-1}]

N_1 : Servo motor rotation velocity after deceleration [min^{-1}]

J_L : Load inertia [$\text{kg} \cdot \text{m}^2$]

J_M : Rotor inertia of servo motor [$\text{kg} \cdot \text{m}^2$]

7) Calculate effective torque (T_{rms})

$$T_{rms} = \sqrt{\frac{(T_a^2 \times t_a) + (T_L^2 \times t_r) + (T_b^2 \times t_b)}{t}} \quad [\text{N} \cdot \text{m}]$$

8) Judgment condition

■ We consider the followings as the standard of the judgment.

- Load factor of load torque $T_L \leq T_R \times 0.8$
(Load torque is 80% or less of rated torque)
- Load factor of acceleration torque $T_a \leq T_p \times 0.8$
(Acceleration torque is 80% or less of peak torque at stall)
- Load factor of deceleration torque $T_b \leq T_p \times 0.8$
(Deceleration torque is 80% or less of peak torque at stall)
- Load factor of effective torque $T_{rms} \leq T_R \times 0.7$
(The effective torque is 70% or less of rated torque)
- Inertia moment ratio $J_L \leq J_M \times 10$
(It is 10-times or less of rotor inertia moment of motor.)

In addition, the rise in heat of motor can be suppressed by taking the large degree of margin at torque load ratio. Moreover, when rotating a table mechanism slowly depending on inertia moment ratio, it may be able to control 10 or more times. We recommend you the check by the real machine.

- * In DC48V<24V>-input servo system, when wiring of main circuit power or motor input line is relatively long, motor-generated torque notably decreases due to voltage drop on cables. Make sure to verify torque on actual machine with sufficient torque to select motor capacity.
- * Regenerative energy can occur, depending on mechanical specification and selected motor. Refer to "Section 12.2, Caution on regeneration" for the detail of regenerative energy and confirm.

12.2 Capacity Selection of Regenerative Resistor

Calculate "regeneration effective power (PM)", and determine the capacity of the regeneration resistance to be used. Judge whether usage of an internal regenerative register machine is possible by this calculation result.

1) How to find "regeneration effective power (PM)" of the horizontal axis drive by a formula (Rotary motor)

- Calculate regeneration energy.

$$EM = E_{hb} = \frac{1}{2} \times N \times 3 \cdot K_e \phi \times \frac{T_b}{K_T} \times t_b - \left[\frac{T_b}{K_T} \right]^2 \times 3 \cdot R \phi \times t_b$$

EM	:	Regeneration energy during operations along horizontal axis	[J]
E _{hb}	:	Regeneration energy during deceleration	[J]
K _e φ	:	Induced voltage constant	[Vrms/min ⁻¹] (Motor constant)
K _T	:	Torque constant	[N·m/Arms] (Motor constant)
N	:	Motor rotation speed	[min ⁻¹]
Rφ	:	Armature resistance	[Ω] (Motor constant)
t _b	:	Deceleration time	[s]
T _b	:	Torque during deceleration	[N·m]

- Calculate "regeneration effective power" from regeneration energy.

$$PM = \frac{EM}{t_o}$$

PM	:	Effective regeneration power	[W]
EM	:	Regeneration energy	[J]
t _o	:	Cycle time	[s]

2) How to find "regeneration effective power (PM)" of the vertical axis drive by a formula (Rotary motor)

- Calculate regeneration energy.

$$EM = EVUb + EVD + EVDb$$

$$= \frac{1}{2} \times N \times 3 \cdot Ke\phi \times \frac{TUb}{KT} \times tUb - \left[\frac{TUb}{KT} \right]^2 \times 3 \cdot R\phi \times tUb$$

$$+ N \times 3 \cdot Ke\phi \times \frac{TD}{KT} \times tD - \left[\frac{TD}{KT} \right]^2 \times 3 \cdot R\phi \times tD$$

$$+ \frac{1}{2} \times N \times 3 \cdot Ke\phi \times \frac{TDb}{KT} \times tDb - \left[\frac{TDb}{KT} \right]^2 \times 3 \cdot R\phi \times tDb$$

Keφ	: Induced voltage constant	[Vrms/min ⁻¹] (Motor constant)
KT	: Torque constant	[N·m/Arms] (Motor constant)
N	: Motor rotation speed	[min ⁻¹]
Rφ	: Armature resistance	[Ω] (Motor constant)
EM	: Regeneration energy during operations along vertical axis	[J]
EVD	: Regeneration energy during descending run	[J]
Tub	: Torque during increased deceleration	[N·m]
TD	: Torque during descending run	[N·m]
tD	: Descending run time	[s]
TDb	: Torque during decreased deceleration	[N·m]
tDb	: Decreased deceleration time	[s]
EVUb	: Regeneration energy during increased deceleration	[J]
EVDb	: Regeneration energy during decreased deceleration	[J]
tUb	: Increased deceleration time	[s]

* When the calculation result of either of **EVUb**, **EVD**, or **EVDb** is negative, calculate **EM** by considering the value of those variables as 0.

- Calculate "regeneration effective power" from regeneration energy.

$$PM = \frac{EM}{to}$$


PM	: Effective regeneration power	[W]
EM	: Regeneration energy during deceleration	[J]
to	: Cycle time	[s]

3) How to find "regeneration effective power (PM)" of the vertical axis drive by a formula (Linear motor)

- Calculate regeneration energy.

$$PM = \left[\left(\frac{1}{2 \cdot t} \cdot M \cdot V^2 \right) \left(\frac{v}{2 \cdot t} \cdot F_f \cdot t_b \right) \right] - \left[\left(\frac{3 \cdot R \phi \cdot t_b}{t} \right) \times \left(\frac{M \cdot V - F_f \cdot t_b}{K_f \cdot t_b} \right)^2 \right] \quad [J/s]=[W]$$

- PM : Regenerative electrical power [W]
- M : Moving part mass [kg]
- V : Acceleration just before decelerating [m/s]
- t : Cycle [s]
- t_b : Decelerating time [s]
- F_f : Frictional force [N]
- Rφ : Resistance per 1 motor [Ω]
- K_f : Force constant [N/A]



$$F_b = M \cdot V / t_b - F_f$$

4) Capacity Selection of Regenerative Resistor

Judge whether an internal regenerative resistor can be used from the calculation result. Moreover, when you cannot use it, determine the capacity of an external regeneration resistor.
 For DC input amplifier use, decide a regenerative resistor so that the voltage rise does not exceed 60V in the main circuit by the regenerative energy.

■ Allowable power of a regeneration resistor

When regeneration effective power "PM" turns into more than the allowable power of the amplifier internal regenerative resistor, the external regeneration resistor (option) of the following table can be connected to operate.

Optional regenerative resistor	Resistance value	Allowable power for external regenerative resistor [PRO]
REGIST-080W50B	50 Ω	10W
REGIST-120W50B	50 Ω	30W
REGIST-220W20B	20 Ω	55W

- * When regeneration effective power **PM** exceeds the maximum permitted power (**PRO**) of the external regeneration resistor, reconsider the acceleration constant, load inertia, etc.
- * The resistor sign of an external regeneration resistor and the connection number correspond with the following page.
- * The permissible effective power of external regenerative resistor is maximum 25% of the rated power under natural air cooling.
- * A regeneration resistance usage rate can be raised about a maximum of 50% by carrying out an air cooling with blower using a cooling fan.

5) Selection of external regenerative resistor instantaneous tolerance

Verify the regenerative energy calculated according to 1) horizontal axis drive and 2) vertical axis drive is the resistor allowable instantaneous tolerance JI [J] selected according to in the above 4) or less.

$$EM [J] \leq JI [J]$$

When regenerative energy exceeds the instantaneous tolerance of resistor you use, select the resistor with large instantaneous tolerance.

- * Abnormal regeneration may occurred when vertical axis continuously driven, even if the value is under allowable regenerative resistor power "PRO" and allowable instantaneous tolerance "JI" of usable external regenerative resistor.

6) Capacity of External Regenerative Resistor and Resistor Model Name

The resistor model name corresponds with the sign of the external regeneration resistor selected for the preceding clause.

Resistor Model Number	Resistance Value	Thermostat Detection temperature (Contact specification)	Permissible Effective Power [PM]	Allowable instantaneous tolerance [JI]	Mass
REGIST-080W50B	50 Ω	135°C±7°C (Contact b)	10W	35J	0.19kg
REGIST-120W50B	50 Ω		30W	80J	0.24kg
REGIST-220W20B	20 Ω		55W	210J	0.44kg

Refer to "13.7 Regenerative resistor outline drawing" for resistor outer shape.
 Permissible Effective Power is the value under natural air cooling.

7) Thermostat Connection of External Regenerative Resistor

Connect a thermostat to either of "the general inputs CONT1-CONT8."

Please allocate the connected general input signal to [Group9 ID40: External Trip Input Function [EXT-E]].

- Example: When connecting the thermostat to CONT2

The external trip function will be valid when【05H:CONT2_OFF】CONT2 is turned off in [Grop9 ID02 External Trip Input Function(0x20F8,0x03)[EXT-E]]. Alarm (ALM-55) will be output from the servo amplifier when the thermostat of a generative resistor trips (the contact point comes off) because of heating. Refer to [Wiring with host unit for the wiring method (Chapter 4)].

8) Protection Function of Regenerative Resistance

The regenerative resistance protection function is specified by parameter selections. Appropriate protection for regenerative resistance is applied by setting parameters according to the type of regenerative resistance to be connected. Set the appropriate parameters by following the instructions given below.

- The two parameters requiring settings are given below.
 - ◆ Regenerative Resistor Selection [System parameter ID01 (0x20FD,0x02)]
 - ◆ External Trip Input Function [General parameter [Group9 ID02](0x20F8, 0x03)]
- The protection functions are divided into three main types:
 - ◆ Protection for a short-time, high load factor (using built-in or external regenerative resistance):
An error is detected when the power absorption of regenerative resistance is extremely high over a short time period (100msec to 10 seconds). A 'Regenerative Error' alarm ("ALM_43") is issued when this error is detected.
 - When the internal regenerative resistor is being used, be sure to set a setup of "system-parameter ID01(0X20FD,0X02)" Regeneration Resistor Selection as [01:_Built-in_R.]
 - When external regeneration resistance is being used, be sure to set a setup of "system-parameter ID01(0X20FD,0X02)" Regeneration Resistor Selection as [02:_External_R.]
 - ◆ Protection when allowable power absorption is exceeded for long time (using built-in regenerative resistance):
An error is detected when the power absorption of the built-in regenerative resistance exceeds the allowable power absorption over a long time period (from a few seconds to a few minutes). An 'Internal Overheat' alarm ("ALM_54") is issued when this error is detected.
 - When the internal regenerative register is being used, be sure to set it as a setup [01:_Built-in_R] of "system-parameter ID01(0X20FD,0X02)" Regeneration resistor Selection.
 - ◆ Protection during thermostat operation of the external regenerative resistor:
An error is detected when the external trip function is started. An 'External error / external trip' alarm ("ALM_55") is issued when this error is detected.
 - When the thermostat is connected to servo amplifier, be sure to set up [general parameter Group9 ID02: external trip input function (0x20F8, 0x03)[EXT-E]].

9) Confirmation method of regeneration effective power PM in actual operation

Regeneration effective power **PM** can be easily confirmed by MOTOR setup software or CoE Object.

- MOTOR setup software·····Monitor display : ID16·RegP·Regeneration circuit operating rate
- CoE Object·····Index : 0x210A, 0x00·Regeneration circuit operating rate[REGP]
 - * The monitor value of the regeneration circuit operating rate shows the operating rate of regeneration circuit.
 - * The display range is 0.01% - 99.99%.

- The actual regeneration effective power **PM** can be calculated from this monitor value by following equation.

- ◆ Input Supply Voltage: In case of DC48V specification

$$\text{Regeneration effective power PM (W)} = \frac{60(\text{V}) \times 60(\text{V})}{\text{Regeneration resistance } (\Omega)} \times \frac{\text{Regeneration circuit operating rate } (\%)}{100(\%)}$$

- ◆ Input Supply Voltage : In case of DC48V specification

- Regeneration effective power PM (W) = $\frac{30(\text{V}) \times 30(\text{V})}{\text{Regeneration resistance } (\Omega)} \times \frac{\text{Regeneration circuit operating rate } (\%)}{100(\%)}$

- Calculation Example

Input Supply Voltage: [DC48V Specification]
 Regeneration resistance value: 20Ω[Built-in Regenerative Resistor]
 Monitor Value (RegP): 0.12%

$$\text{Regeneration power PM (W)} = \frac{60(\text{V}) \times 60(\text{V})}{20(\Omega)} \times \frac{0.12(\%)}{100(\%)} = 0.22(\text{W})$$

- * The regeneration effective power calculated from this monitor value continues to be the target until the end of operations. Regeneration power varies with the voltage fluctuation of the input power supply and changes across the ages of the servo amplifier and the loading device.
- * Be sure to opt for selection of regeneration resistance based on the regeneration effective power "PM" found from calculation of a pattern of operation and regeneration power.
- * Install the external regeneration resistor on equipment, and measure the temperature of the external regeneration resistor by the operating condition that the regeneration effective power PM becomes the maximum. Then do sufficient mounting check of alarm not being generated. In addition, it takes 1 to 2 hours until the temperature of the external regeneration resistor is saturated.

10) Precaution for external regenerative resistor installation

- The place where corrosive gas has occurred, and when there is much dust, insulated degradation, corrosion, etc., may arise. There fore be careful of an attachment place.
- Arrangement of the external regeneration resistor should open an interval so that it is not influenced by generation of heat from other parts.
- Must wire an external regeneration resistor with using twisted line. Wiring length shall be shorter as possible, at least less than 5m.
- For wire, use fireproof type or perform fireproof process (as silicon tube), and wires avoiding touch with regenerative resistor.

No Text on This Page.

13

13. Appendix




13.1	Standards Conformity	13-1
1)	Standards conformity	13-1
2)	Appliance classes, Degrees of Protection, Pollution Level	13-2
3)	Connection and installation	13-2
4)	UL File Number	13-2
13.2	Compliance with EU Directives	13-3
1)	Conformity verification test	13-3
2)	EMC Installation Requirements	13-4
3)	Precautions for noise filter connection	13-5
13.3	Servo motor outline drawing	13-6
1)	R2 motor, flange size 40mm and 60mm	13-6
2)	R2 motor, flange size 20mm	13-7
3)	Flange size 14mm R2GAD102RM (DC48V)	13-7
4)	Compact cylinder linear motor DE0AC001A03MX00 (DC48V)	13-8
13.4	Servo Motor Data Sheet	13-9
1)	Characteristics table	13-9
2)	Velocity-torque characteristics	13-12
3)	R2GAD102RM velocity-torque characteristics	13-13
4)	DE0AC001A03MX00 velocity—force characteristic	13-13
5)	Overload characteristics	13-14
13.5	Outline drawing of servo amplifier	13-15
13.6	Optional items	13-16
1)	Connector arrangement drawing	13-16
2)	Connector set model number	13-17
3)	Related items of battery for battery backup method absolute encoder	13-18
4)	Fixing bracket for side surface	13-20
5)	Related items for MOTOR setup software and serial communication	13-20
6)	External regenerative resistor	13-21
13.7	Outline drawing of regenerative resistor	13-22

13.1 Standards Conformity

In our company, conformance test is carried out in certificate authorities according to concerned standards, laws and regulations, and attestation markings are done based on the published certificate of attestation.

1) Standards conformity

- The following overseas standard examinations are implemented.

Product model NO.	Applicable laws and Regulations		Standard code	Certificate authorities	
	Classification	Detailed Classification			
RF2##### #	UL/c-UL standard	---	UL508C	UL (Underwriters Laboratories inc.) 	
RF2##### 0 (Safe Torque Off function Unequipped model)	Electrical safety	Electrical safety under Low Voltage Directive (2006/95/EC)	IEC61800-5-1:2007/ EN61800-5-1:2007	TÜV (TÜV SÜD Japan, Ltd.) 	
	EMC	EMC under EMC directive (2004/108/EC)	EN61000-6-2:2005 IEC61800-3:2004/ EN61800-3:2004	TÜV (TÜV SÜD Japan, Ltd.)	
RF2##### 2 RF2##### 4 (Safe Torque Off function equipped model)	Electrical safety	Electrical safety under Low Voltage Directive (2006/95/EC)	IEC61800-5-1:2007/ EN61800-5-1:2007	TÜV (TÜV SÜD Japan, Ltd.)  (Blue octagon)	
	Machine safety	Machine safety under Machinery Directive (2006/42/EC)	IEC60204-1:2005/ EN60204-1:2006		
	Functional safety	Generic Functional safety			IEC61508:2000/ EN61508:2001(SIL2)
		Functional safety under machinery directive (2006/42/EC)			IEC62061:2005/ EN62061:2005 (SILCL2)
		Functional safety under machinery directive (2006/42/EC)			EN ISO13849-1 / AC:2009(Cat.3, PL=d)
		Functional safety for PDS under machinery directive (2006/42/EC)			IEC61800-5-2 :2007/ EN61800-5-2 :2007
	EMC	EMC under EMC directive (2004/108/EC)			IEC61800-3:2004/ EN61800-3:2004
		Functional safety EMC for machine, factory automation application			IEC61326-3-1 :2008/ EN61326-3-1 :2008

- The servo motor implements the conformance test against the following standards.

Standard	Standard code	Certificate authorities
UL standard	UL1004	UL (Underwriters Laboratories inc.)
	UL1446	
EU directive	IEC-34-1	TÜV (TÜV SÜD Japan, Ltd.)
	IEC34-5	

- ✓ For servo motor products conforming to conformity standards, some specifications may differ from the standard product due to prerequisites necessary for obtaining approval. Contact us for more details.

2) Appliance classes, Degrees of Protection, Pollution Level

- RF2 servo amplifier is Class III appliance which depends on Safety Extra-Low Voltage (SELV) power source with respect to protection against electric shock, and without higher voltage than Safety Extra-Low Voltage. Use 4mm² or more wire when protective grounding terminal is used for protective grounding. Use the wire described in this manual when protective grounding terminal is used for frame grounding (FG).
- For control/interface power supply to servo amplifier, use the SELV 24 V DC power supply. For main circuit power supply, use the DC power supply with reinforced insulation.
- Make sure to install the servo amplifier in your control panel in an environment where the pollution level specified in EN61800-5-1 and IEC664 is no less than 2 (pollution level 1, 2). The protection grade of servo amplifier is IP1X. The control panel installation configuration (under IP54) must exclude exposure to water, oil, carbon, dust, etc.

3) Connection and installation

Be careful of connection and installation as follows.

- ✓ Always ground the protective earth terminals of the servo amplifier to the power supply earth.
- ✓ When connecting grounding wire to the protective earth terminal, always connect one wire in one terminal; never connect jointly with multiple wires or terminals.
- ✓ When connecting the leakage stopper, make sure to connect the protective earth terminal to the power supply earth.
- ✓ Connect earthing wire by using a crimping terminal with insulated tube, so that the connected wire will not touch the neighboring terminals.
- ✓ For wire relays, use a fixed terminal block to connect wires; never connect wires directly.
- ✓ Connect an EMC filter to the input power supply of the unit.
- ✓ Use an EN/ IEC-standard compatible no-fuse Circuit breaker and electromagnetic contactor.
- ✓ This product is certified at the state of arranging the fuses below to power input port of servo amplifier.

Grounding position	Model number	Manufacturer	Current	Voltage	Spec
Control power input	0215005.MXP	Littelfuse	5 A	250Vac / 125Vdc	UL certified product
Main circuit power input	400KH-30UL	Hinode	30 A	400Vac / 400Vdc	UL certified product

4) UL File Number

The UL file number of servo amplifier and servo motor is as follows. Can check from the website of UL. <http://www.ul.com/database/>

The UL file number of servo amplifier: E179775

The UL file number of servo motor: E179832

13.2 Compliance with EU Directives

In our company, for ease of user's CE Marking acquisition, conformity verification test for "Low Voltage Directive" and "an EMC command" is carried out in certificate authority, and servo amplifier CE Marking is done based on the published certificate of attestation.

1) Conformity verification test

The following conformity verification tests are implemented.


Directive classification	Classification	Test	Test standard
Low voltage Directive (Servo amplifier)	-	-	EN61800-5-1: 2007
Low voltage Directive (Servo motor)	-	Rotating electrical machines- Part1: Rating and performance	IEC-34-1
		Rotating electrical machines-Part5: Classification of degrees of protection provided by enclosures of rotating electrical machines (IP code)	IEC34-5
		Rotating electrical machines-Part9: Noise limits	IEC34-9
EMC Directive (Servo amplifier / servo motor)	Emission	Conducted emission	EN61800-3 (Category C2)
		Radiated emission	EN61800-3 (Category C2)
	Immunity	Electrostatic discharge immunity	EN61000-4-2
		Radiated electromagnetic field immunity	EN61000-4-3
		Electrical fast transient/ burst immunity	EN61000-4-4
		Conducted disturbance immunity	EN61000-4-6
		Surge immunity	EN61000-4-5
		Voltage Dips & Interruptions immunity	EN61000-4-11
		Adjustable speed electrical power drive system	EN61800-3
		Safety of machinery	EN62061 (Annex E) Note1)

Note1) Standards applicable only to Safe Torque Off function equipped models.

2) EMC Installation Requirements

For the installation requirements, in our company the verification test is implemented by the following installations and measures methods, as machines and configurations differ depending on customers' needs. This servo amplifier has been authorized to display CE marking based on the recognition certificate issued by a certifying authority. Customers are instructed to perform the final conformity tests for all instruments and devices in use.

The terminal marked with "⊕" is certified by TUV as functional earth terminal. Connect to FG terminal of customer application.



No	Name	Remarks
A	Noise filter	HF3030C-UQA: SOSHIN ELECTRIC Co. Ltd. Rated voltage / rated current: Line-Line 480V AC / 30A
B	Servo Motor	-
B'	Servo Motor	-
C	Sequencer	Fxo-30MR
D	Control panel	-
E	Surge-absorber (Recommended prevention components)	LV275DI-U4: OKAYA
F	DC power supply (for main circuit)	HWS1500-48: TDK-Lambda
G	DC power supply (for control)	DC power supply for 24Vdc must be used SELV 24VDC model. HWS50-24/A: TDK-Lambda
1	Power Line 1	-
2	Power Line 2	-
3	Power Line 3	-
4	Motor Encoder	Shielded cable
5	Motor Drive	Shielded cable
6	Safety I/O	Shielded cable
7	EtherCAT Line	Shielded cable
8	AC Line	-

- ✓ Use metallic materials for the door and main body of control panel.
- ✓ Use EMI gasket so that there is zero clearance between the door and control panel. Install EMI gasket uniformly to the contact points between door and main body of control panel to confirm their conductivity.
- ✓ Please close cabinet door which has this product, in use.
- ✓ Ground noise filter frame to control panel.
- ✓ Use shielded cables for motor power line and encoder cable. Clamp grounding of shield at the frame of control panel and equipment.
- ✓ Use conducting metal P-clip or U-clip to ground and clamp shielded wire, and fix it directly with metal screws. Do not ground by soldering electric wire to shielded wire.
- ✓ Wire servo amplifier at a short distance from the secondary side of noise filter, and wire the primary side and secondary side of noise filter separately.


3) Precautions for noise filter connection

Precautions for noise filter mounting and wiring


See below precautions for mounting and wiring when noise filter is used.

Do not bundle with input line and output line of noise filter. (Earth line also.)

Avoid that go through a same duct. (It might reduce effect of filter, and noise might come around through that point.)




Each of earth line shall be connected to grounding plate in a control panel by single-point. Also in case of multi axes construction in same control panel, grounding by single-point.



13.3 Servo motor outline drawing

1) R2 motor, flange size 40mm and 60mm




Servo motor model number	Without Oil Seal		With Oil Seal		LG	KL	LA	LB	LE	LH
	Battery backup method absolute encoder									
	Absolute encoder for incremental system									
	Without brake	With brake	Without brake	With brake						
R2GA04003△□◇	LL	LL	LL	LL	5	35.4	46	0 30-0.021	2.5	56
R2GA04005△□◇	51.5	87.5	56.5	92.5						
R2GA04008△□◇	56.5	92.5	61.5	97.5						
R2GA06010△□◇	72	108	77	113	6	44.6	70	0 50-0.025	3	82
R2GA06020△□◇	58.5	82.5	65.5	89.5						
R2GA06020△□◇	69.5	97.5	76.5	104.5						

Servo motor model number	LC	LZ	LR	S	Q	QE	LT	D1	D2	D3
R2GA04003△□◇	40	2-φ 4.5	25	0 6-0.008	20	-	-	6	5	5
R2GA04005△□◇				0						
R2GA04008△□◇				8-0.009						
R2GA06010△□◇	60	4-φ 5.5	25	0 8-0.009	20	-	-	6	5	5
R2GA06020△□◇			30	0 14-0.011	25	M5	12			


- ✓ If oil seal is required, whole motor length shall be changed.
- ✓ For motor without brake, no brake connector (or cable) attached.
- ✓ Contact us for the other motor spec above.

2) R2 motor, flange size 20mm




- ✓ Oil seal is not attached.
- ✓ It is the spec without a holding brake. The spec with a holding brake is unselectable.
- ✓ Sensor spec is only the absolute encoder for incremental system. Spec of battery backup method absolute encoder, battery-less encoder and pulse encoder is not selectable.

3) Flange size 14mm R2GAD102RM (DC48V)



- ✓ Oil seal is not attached.
- ✓ It is the spec without a holding brake. The spec with a holding brake is unselectable.
- ✓ Sensor spec is only the absolute encoder for incremental system. Spec of battery backup method absolute encoder, battery-less encoder and pulse encoder is not selectable.

4) Compact cylinder linear motor DE0AC001A03MX00 (DC48V)



13.4 Servo Motor Data Sheet

1) Characteristics table

■ R2 motor, DC48V input spec

Servo motor model number R2GA			D102RM	04003F	04005F	04008F	06010F	06020F
Combination servo amplifier capacity			RF2J14	RF2J24 RF2K24	RF2K24			
*Rated output	P _R	W	2.4	30	50	80	100	200
*Rated velocity	N _R	min ⁻¹	1000	3000	3000	3000	3000	3000
*Maximum velocity	N _{max}	min ⁻¹	1500	6000	6000	5000	5000	4500
*Rated torque	T _R	N·m	0.023	0.098	0.159	0.255	0.318	0.637
*Continuous Torque at stall	T _S	N·m	0.023	0.108	0.167	0.255	0.353	0.637
* Peak Torque at stall	T _P	N·m	0.06	0.24	0.54	0.86	0.84	1.5
* Rated armature current	I _R	Arms	0.67	1.9	3.8	4.1	5.1	6.0
* Armature current at stall	I _S	Arms	0.64	2.0	3.9	4.1	5.5	6.0
* Peak armature current at stall	I _P	Arms	1.7	4.8	13.7	14.1	14.1	14.1
Torque constant	K _T	N·m/Arms	0.042	0.0582	0.047	0.0693	0.0673	0.117
Voltage constant for each phase	K _{Eφ}	mV/min ⁻¹	1.47	2.03	1.64	2.42	2.35	4.07
Phase resistance	R _φ	Ω	7.2	1.00	0.33	0.32	0.19	0.19
* Rated power rate	Q _R	W/s	2.2	3.9	6.7	10	8.6	19
Rotor inertia Note1)	J _M	kg·m ² (GD ² /4)×10 ⁻⁴	0.0023	0.0247	0.0376	0.0627	0.117	0.219
Mass Note1)	WE	kg	0.08	0.35	0.39	0.51	0.71	0.96
Brake mass	W	kg	-	0.27	0.27	0.27	0.34	0.39
Aluminum plate		mm	t6×250	t6×250	t6×250	t6×250	t6×250	t6×250

Note1) Contains battery backup method absolute encoder.

- ✓ Constant in the table above is the value when motor is installed on heat releasing aluminum plate, indicates "thickness" x "length of a side of square".
- ✓ Items marked with * and Velocity-Torque Characteristics indicate values after temperature rise saturation. The others indicate values at 20°C. Each value indicates TYP.

Servo amplifier model number				RF2J24, RF2K24	
Servo amplifier model number				R2GA02D20FXC	R2GA02D30FXC
Item	Condition	Code	Unit	<□20>	<□20>
Rated output	★	P _R	W	20	30
Rated revolution velocity	★	N _R	min ⁻¹	3000	3000
Maximum revolution velocity	★	N _{max}	min ⁻¹	6000	6000
Rated torque	★	T _R	N·m	0.064	0.095
Continuous stall torque	★	T _S	N·m	0.064	0.095
Peak Torque at stall	★	T _P	N·m	0.23	0.38
Rated armature current	★	I _R	Arms	1.8	2.6
Armature current at stall	★	I _S	Arms	1.8	2.6
Peak armature current at stall	★	I _P	Arms	6.0	9.6
Torque constant		K _T	N·m/ Arms	0.0458	0.0487
Voltage constant per phase		K _{Eφ}	mV/ min ⁻¹	1.6	1.7
Phase resistance		R _φ	Ω	1.06	0.76
Rates power rate	★	Q _R	kW/s	12.4	20
Inertia moment note 1)		J _M	kg·m ² (GD ² /4) × 10 ⁻⁴	0.0033	0.0046
Mass note 1)		WE	kg	0.14	0.18
Brake mass				IP40	IP40

Note 1) This value includes the absolute encoder.

- ✓ The above values show the figures with 20W motor mounted in t6x150mm and 30W motor mounted in t6x150mm-heat sink aluminum plate.
- ✓ Items marked with ★ and Velocity-Torque Characteristics indicate values after temperature rise saturation. The others indicate values at 20°C. Each value indicates TYP.
- ✓ The spec without holding brake. The spec with holding brake can not select.
- ✓ Sensor spec is only the absolute encoder for incremental system. It cannot select the spec of Battery Backup Method Absolute Encoder, Battery-less Absolute Encoder and Pulse encoder.

■ Compact cylinder linear motor (DC48V spec)

Linear motor model number			DE0AC001A03MX00
Combination servo amplifier capacity			RF2J24A8HL5
** Rated output	Pr	W	5.1
** Rated force	Fr	N	5.1
** Continuous force at stall	Fs	N	5.1
Peak force	Fp	N	16.5
** Rated current	Ir	Arms	0.6
** Continuous current at stall	Ir	Arms	0.6
** Peak current	Ip	Arms	2.0
Rated velocity	vr	m/s	1.0
Maximum velocity	vp	m/s	2.0
Force constant	Kf	N/A	8.8±10%
Inductive voltage constant	Keφ	V·m/s	2.93±10%
Mover mass	Mc	g	45±10%
** Motor constant	Km	N/√W	1.5
Phase resistance	Rφ	Ω	8.3Ω±10%
Phase inductance	Lφ	mH	0.75±20%
Mass	W	g	185±10%

✓ Mark "***" indicates the value after temperature increase. The other values are the ones at 20°C. Each value is typical.


■ DE0AC001A03MX00 Linear encoder characteristics

Signal cycle	P	μm	4
Resolution	S	μm	1.0
Maximum move velocity	V	m/s	2.0
Power voltage	-	DC V	5±5%
Output circuit method	-	-	EIA RS422 differential driver
Operating temperature	-	°C	0 to 70
Z-phase channel signal width	Zw	μm	20
Forced excitation CSU	-	°	75 (Electrical angle at the position that mover is pulled out maximally.)


2) Velocity-torque characteristics

Velocity-torque characteristic of R2GA servo motor shows the value when input power is DC48V. When power voltage drops, impedance on power input line is high, or cable between amplifier and servo motor is relatively long, high-velocity revolution in momentary range shall decrease, so please consider sufficient margins for these values when selecting servo motor.


R2GA04003F




R2GA04005F




R2GA04008D




R2GA06010D




R2GA06020D




R2GA02D20F



R2GA02D30F




3) R2GAD102RM velocity-torque characteristics











4) DE0AC001A03MX00 velocity – force characteristic

Velocity-force characteristic of DS linear motor shows the value when input power is DC48V. When power voltage drops less than 48V, instantaneous area will decrease.




5) Overload characteristics

R2GA Motor overload characteristics are indicated below.



13.5 Outline drawing of servo amplifier

■ RF2□□□A□HL□




13.6 Optional items

1) Connector arrangement drawing

Optional items prepared in our company are shown below.

■RF2##A#HL5



2) Connector set model number

■ Our model number for connector as single item

Connector number	Contents	Our model number	Manufacturer model number	Quantity	Manufacturer name
IN, OUT	Ethernet For host unit connection	Not provided by our company. Please use shielded type modular plug (RJ-45) corresponding to the CAT5e standard.			
CN A	For power supply	AL-00922656	5557-08R_NATURAL x 1 pcs 5556TL x 8pcs (Note1)	1	MOLEX
CN C	For regenerative resistor connection	AL-00922658	5557-02R_NATURAL x 1 pcs 5556TL x 2pcs (Note1)	1	MOLEX
MOT1 to 4	For servo motor connection, single axis	AL-00922660	5557-04R_NATURAL x 1 pcs 5556TL x 4 pcs (Note1)	1	MOLEX
EN1 to 4	For encoder connection, single axis	AL-00632607	36210-0100PL x 1 pcs 36310-3200-008 x 1 pcs	1	Sumitomo 3M Ltd.
I/O	For general I/O signal	AL-00922662	10136-3000PE x 1 pcs 10336-52A-008 x 1 pcs	1	Sumitomo 3M Ltd.
CN1	For safety device connection	AL-00718252-01	2013595-3	1	Tyco Electronics AMP K.K.
CN1	Safety device short plug	AL-00849548-02	1971153-2	1	Tyco Electronics AMP K.K.

■ Our model number for connector set

Set connector	Contents	Our model number
CN A, CN C, MOT1 to 4	The set including Power supply input connector x1pcs, Regenerative resistor connector x1pcs, Motor connector x 4pcs, Contact x 26pcs. Note 1)	AL-00922664
EN1 to 4, CN1, I/O	The set including Encoder connector x 4pcs, Connector for safety x1pcs, General I/O connector x1pcs.	AL-00922666

Note 1) For 5556TL contact, dedicated crimp tool below is required.
For automatic crimping, contact to the connector manufacturer.


Crimp tool	Model number	Applicable wire size	Manufacturer
Part No.	63819-0900	AWG16 to AWG24	MOLEX

■ Our model number for one side finished cable

Set connector	Contents	Our model number	Remarks
For CN A	Power supply input cable (Amplifier side connector has assembled)	AL-00921367-01	Cable length 2m, Qty 1
For CN C	Regenerative resistor connection cable (Amplifier side connector has assembled)	AL-00921368-01	Cable length 2m, Qty 1
For MOT1 to 4	Motor power cable (Amplifier side connector has assembled)	AL-00921369-01	Cable length 3m, Qty 1
		AL-00921369-02	Cable length 5m, Qty 1
		AL-00921369-03	Cable length 10m, Qty 1
For EN1 to 4	Serial encoder cable (Amplifier side connector has assembled)	AL-00921370-01	Cable length 3m, Qty 1
		AL-00921370-02	Cable length 5m, Qty 1
		AL-00921370-03	Cable length 10m, Qty 1

3) Related items of battery for battery backup method absolute encoder


Battery body for battery box (Model No.: AL-00879511-01)




1. Battery and connector specifications

Lithium battery	Thionyl Chloride Lithium Battery ER3VLY (Toshiba Lifestyle Products & Services Corporation) Nominal Voltage: 3.6V Nominal Capacity: 1000mAh Lithium metal mass as standard: 0.31g
Connector	DF3-2S-2C; Socket Housing (HIROSE) DF3-2428SCFC; Contact (HIROSE)

2. Wiring diagram




Battery BOX (Model No.:AL-00880402-01)




See "9.8 Replacing battery for motor encoder" for how to replace battery box.

- Battery trunk cable with both side connectors (Model number: AL-00731792-01)



1. Spec: Trunk cable for encoder with the both side connectors and the battery unit

2. Wiring spec



3. Specification for the connector and the battery unit

Connector for servo amplifier	36210-0100PL; Wiremount Receptacle (3M) 36310-3200-008; Shell Kit (3M)
Connector for encoder	36110-3000FD; Wiremount Plug (3M) 36310-F200-008; Shell Kit (3M)
Battery unit	Built-in battery; ER3VLY (Toshiba Lifestyle Products & Services Corporation) Nominal Voltage: 3.6V Nominal Capacity: 1000mAh Lithium-metal mass: 0.31g

4. Battery model number for replacement: AL-00697958-01

As note, model number of replacement battery differs with for battery box and for trunk cable.


4) Fixing bracket for side surface

Fixing bracket for side surface is prepared for RF2 servo amplifier.


■ Fixing bracket list for side surface of RF2

Position of fixing bracket	Model number	Contents
Side surface	AL-00921371-01	Includes a bracket and M4 screw (qty 4) for bracket mount

These fixing brackets are processed trivalent chromium plating.
(Surface color: blue-silver/ different from body color.)



Fixing bracket outer dimension (Unit: mm)




Mounting image (Unit: mm)

5) Related items for MOTOR setup software and serial communication

Connector number	Name	Contents	Quantity	Our model number
PC	PC communication cable	Connection cable between PC and servo amplifier	1	AL-00689703-01

PC communication cable outline drawing (Model number: AL-00689703-01)




6) External regenerative resistor


Resistor Model Number	Rated power [PR]	Resistance value	Thermostat Detection temperature (Contact specification)	Mass
REGIST-080W50B	80W	50 Ω	135°C \pm 7°C (b contact)	0.19kg
REGIST-120W50B	120W	50 Ω		0.24kg
REGIST-220W20B	220W	20 Ω		0.44kg

13.7 Outline drawing of regenerative resistor


■ REGIST-080W



■ REGIST-120W



■ REGIST-220W



R ADVANCED MODEL EtherCAT interface amplifier (RF2 type H) Combination motor code list

Indicates list of servo motor which is able to set Object Index: 0x20FE.
Gray colored cell is standard combination motor.

■Rotary motor (48V)							
Series	Motor code	Motor model number	Input type	Amplifier capacity	Flange size	Output	Maximum speed
R2 Series	0x0261	R2GA04003F	DC48V	40A	40mm sq.	30W	6,000 min ⁻¹
	0x0262	R2GA04005F	DC48V	40A	40mm sq.	50W	6,000 min ⁻¹
	0x0263	R2GA04008D	DC48V	40A	40mm sq.	80W	5,000 min ⁻¹
	0x0264	R2GA06010D	DC48V	40A	60mm sq.	100W	5,000 min ⁻¹
	0x0265	R2GA06020D	DC48V	40A	60mm sq.	200W	4,500 min ⁻¹
	0x040C	R2GAD102RM	DC48V	25A	14mm sq.	2.4W	1,500 min ⁻¹
	0x049B	R2GA02D20F	DC48V	40A	20mm sq.	20W	6,000 min ⁻¹
	0x0497	R2GA02D30F	DC48V	40A	20mm sq.	30W	6,000 min ⁻¹

■Linear motor							
Series	Motor code	Motor model number	Input type	Amplifier capacity	Width	Output	Maximum speed
DE Series	0x435A	DE0AC0001M	DC48V	40A	30mm	5.1N	2.0m/s

Release	
Revision A	Jun. 2015
Revision B	Sep. 2015



■ ECO PRODUCTS

Sanyo Denki's ECO PRODUCTS are designed with the concept of lessening impact on the environment in the process from product development to waste. The product units and packaging materials are designed for reduced environmental impact.

We have established our own assessment criteria on the environmental impacts applicable to all processes, ranging from design to manufacture.

■ Precautions For Adoption

Failure to follow the precautions on the right may cause moderate injury and property damage, or in some circumstances, could lead to a serious accident.

Always follow all listed precautions.

Cautions

- Read the accompanying Instruction Manual carefully prior to using the product.
- If applying to medical devices and other equipment affecting people's lives please contact us beforehand and take appropriate safety measures.
- If applying to equipment that can have significant effects on society and the general public, please contact us beforehand.
- Do not use this product in an environment where vibration is present, such as in a moving vehicle or shipping vessel.
- Do not perform any retrofitting, re-engineering, or modification to this equipment.
- The Products presented in this Instruction Manual are meant to be used for general industrial applications. If using for special applications related to aviation and space, nuclear power, electric power, submarine repeaters, etc., please contact us beforehand.

* For any question or inquiry regarding the above, contact our Sales Department.

<http://www.sanyodenki.com>

SANYO DENKI CO., LTD.

3-33-1, Minami-Otsuka, Toshima-ku, Tokyo, 170-8451, Japan

TEL: +81 3 5927 1020

SANYO DENKI EUROPE SA.

P.A. Paris Nord II, 48 Allée des Erables-VILLEPINTE, BP.57286, F-95958 ROISSY CDG Cedex, France

TEL: +33 1 48 63 26 61

SANYO DENKI AMERICA, INC.

468 Amapola Avenue Torrance, CA 90501, U.S.A.

TEL: +1 310 783 5400

SANYO DENKI SHANGHAI CO., LTD.

Room 2106-2109, Bldg A, Far East International Plaza, No.319, Xianxia Road, Shanghai, 200051, China

TEL: +86 21 6235 1107

Beijing Branch

Room1222, Tower B, Beijing COFCO Plaza, No.8 Jianguomennei Dajie, Dong Cheng District, Beijing 100005 China

TEL: +86 10 6522 2160

SANYO DENKI (H.K.) CO., LIMITED

Room 2305, 23/F, South Tower, Concordia Plaza, 1 Science Museum Rd., TST East, Kowloon, Hong Kong

TEL: +852 2312 6250

Tianjin Representative Office

Room AB 16th Floor TEDA Building, No. 256 Jie Fang Nan Road, Hexi District, Tianjin 300042 China

TEL: +86 22 2320 1186

Chengdu Representative Office

Room2105B, Block A, Times Plaza, 2 Zongfu Road, Jinjiang District, Chengdu, 610016 China

TEL: +86 28 8661 6901

SANYO DENKI TAIWAN CO., LTD.

N-711, 7F, Chia Hsin 2nd Bldg., No.96, Sec.2, Zhongshan N. Rd., Taipei 10449, Taiwan (R.O.C.)

TEL: +886 2 2511 3938

SANYO DENKI SINGAPORE PTE.LTD.

988 Toa Payoh North, #04-05/06/07/08, Singapore 319002

TEL: +65 6223 1071

Indonesia Representative Office

Summitmas II 4th Floor, Jl. Jend. Sudirman Kav.61-62, Jakarta 12190, Indonesia

TEL: + 62 21 252 3202

SANYO DENKI GERMANY GmbH

Frankfurter Strasse 92, 65760 Eschborn, Germany

TEL: +49 6196 76113 0

SANYO DENKI KOREA CO., LTD.

9F, Sunhwa B/D 89, Seosomun-ro, Jung-gu, Seoul, 100-731, Korea

TEL: +82 2 773 5623

Busan Branch

8F, CJ Korea Express Bldg., 119, Daegyo-ro, Jung-gu, Busan, 600-016, Korea

TEL: +82 51 796 5151

SANYO DENKI (Shenzhen) CO., LTD.

2F 02-11, Shenzhen International Chamber of Commerce Tower, No.168 Fuhua 3 Road, Futian District, Shenzhen, China 518048

TEL: +86 755 3337 3868

SANYO DENKI (THAILAND) CO., LTD.

388 Exchange Tower, 25th Floor, Unit 2501-1, Sukhumvit Road, Klongtoey, Klongtoey, Bangkok 10110 Thailand

TEL: +66 2261 8670

The names of companies and/or their products specified in this manual are the trade names, and/or trademarks and/or registered trademarks of such respective companies.

*Specifications are subject to change without notice.

Translated version of the original instructions