

**SANMOTION**

**AC SERVO SYSTEMS**

**R**

**TYPE S**

with CANopen Interface

For Rotary Motor

**Instruction Manual**

**SANYODENKI**

## Preface

This product corresponds with the shipping regulations given in the Export Trade Control Ordinance (Table 1, item 16) and the Foreign Exchange Ordinance (Table 1, item 16). When these products are exported by customers, and when exported including the other freight or together with other freight, it is recommended to fulfill the requirements related to Security Export Control with the relevant authorities, including “Information Requirements” and “Objective Requirements”.

This manual outlines the functions, wiring, installation, operations, maintenance, specifications, etc. of the AC servo amplifier “R” Series Type S. The “R” Series Type S AC servo amplifier system is compatible with a wide variety of various applications requiring low, medium or high capacity, high efficiency, reduced footprint, and excellent cost performance.

This product was developed to offer a series of servo motors that are easy to use and offer excellent functionality in an AC servo motor. It fulfills various needs, such as the downsizing of the control panel, and offers compatibility for a wide range of applications requiring a servo motor.

### ★Precautions related to this Instruction Manual

- In order to fully understand the functions of AC servo amplifier “R” Series Type S, please read this instruction manual thoroughly before using it.
- After reading this manual thoroughly, please keep it handy for reference.
- Please contact the dealer or sales representative if there are defects such as nonconsecutive pages, missing pages or if the manual is lost or damaged.
- Carefully and completely follow the safety instructions outlined in this manual. Please note that safety is not guaranteed for usage methods other than those specified in this manual or usage methods intended for the original product.
- The contents of this manual may be modified without prior notice, as revisions or additions are made in the usage method of this product. Modifications are performed per the revisions of this manual.
- Permission is granted to reproduce or omit part of the attached figures (as abstracts) for use.
- Although the manufacturer has taken all possible measures to ensure the veracity of the contents of this manual, if you should notice any error or omission, please notify the dealer or sales office of the finding.

# 【Safety Precautions】

This chapter is a summary of the safety precautions regarding the use of the R-series type-S amplifier. Please read this entire manual carefully prior to installing, operating, performing maintenance or inspecting this device to ensure proper use.

Use this device only after learning about its operation, safety information, and the precautions related to its use. After reading the User Manual, keep it in a location where it is always available to the user for easy reference.

The R-series servo amplifiers and servo motors were designed for use with general industrial equipment. The following instructions should be followed:









- Read the User Manual carefully before any installation or assembly work to ensure proper use.
- Do not perform any retrofitting or modification of the product.
- Consult with your sales representatives or a trained professional technician regarding the installation and maintenance of these devices.
- Please contact your distributor or sales office if you intend to use these devices in applications such as;
  - ※ In medical instruments or systems used for life support;
  - ※ With control systems for trains or elevators, the failure of which could cause bodily injury;
  - ※ In computer systems of social or public importance;
  - ※ In other equipment or systems related to human safety or public infrastructure.
- Additionally, please contact your distributor or sales office if the device is to be used in an environment where vibration is present, such as in-vehicle or transport applications.

# Safety Precautions







**[Make sure to follow.]**

This documentation uses the following annotation. Make sure to strictly follow these safety precautions.

■ Safety Precautions and symbols

Safety Precautions		symbols	
<b>Danger</b>	Denotes immediate hazards that will probably cause severe bodily injury or death as a result of incorrect operation.		Danger /Injury
			Electric shock
<b>Caution</b>	Denotes hazards that could cause bodily injury and product or property damage as a result of incorrect operation. Even those hazards denoted by this symbol could lead to a serious accident.		Caution
			Fire
			Burn
<b>Prohibited</b>	Indicates actions that must be carried out (mandatory actions).		Prohibited
			Disassembly prohibited
<b>Mandatory</b>	Indicates actions that must not be allowed to occur prohibited actions.		Mandatory

 **Danger**

<p>Do not use this device in explosive environment.</p> <p> Injury or fire could otherwise result.</p>	<p>Do not touch the inside of the amplifier.</p> <p> Electric shock could otherwise result.</p>
<p>Do not perform any wiring, maintenance or inspection when the device is hot-wired. After switching the power off, wait at least 5 minutes before performing these tasks.</p> <p> Electric shock could otherwise result.</p>	<p>Only technically qualified personnel should transport, install, wire, operate, or perform maintenance and inspection on this device.</p> <p> Electric shock, injury or fire could otherwise result.</p>
<p>The protective ground terminal (⊕) should always be grounded to the control box or equipment. The ground terminal of the motor should always be connected to the protective ground terminal (⊕) of the amplifier.</p> <p> Electric shock could otherwise result.</p>	<p>Do not damage the cable, do not apply unreasonable stress to it, do not place heavy items on it, and do not insert it in between objects.</p> <p> Electric shock could otherwise result.</p>

# Safety Precautions

**[Make sure to follow.]**



## Danger

<p>Wiring should be done based on the wiring diagram or the user manual.</p> <p> Electric shock or fire could otherwise result.</p>	<p>Do not touch the rotating part of the motor during operation.</p> <p> Bodily injury could otherwise result.</p>
<p>Do not touch or get close to the terminal and the connector while the device is powered up.</p> <p> Electric shock could otherwise result.</p>	<p>Do not unplug the terminal and the connector while the device is powered up.</p> <p> Electric shock could otherwise result.</p>

















## Caution

<p>Please read the User Manual carefully before installation, operation, maintenance or inspection, and perform these tasks according to the instructions.</p> <p> Electric shock, injury or fire could otherwise result.</p>	<p>Do not use the amplifier or the motor outside their specifications.</p> <p> Electric shock, injury or damage to the device could otherwise result.</p>
<p>Do not use the defective, damaged and burnt amplifier or the motor.</p> <p> Injury or fire could otherwise result.</p>	<p>Use the amplifier and motor together in the specified combination.</p> <p> Fire or damage to the device could otherwise result.</p>
<p>Be careful of the high temperatures generated by the amplifier/motor and the peripherals.</p> <p> Burn could otherwise result.</p>	<p>Open the box only after checking its top and bottom location.</p> <p> Bodily injury could otherwise result.</p>

# Safety Precautions

[Make sure to follow.]

## Caution













<p>Verify that the products correspond to the order sheet/packing list. If the wrong product is installed, injury or damage could result.</p> <p> Injury or damage could result.</p>	<p>Do not impress static electricity, the high voltage, etc. to the cable for encoders of the servo motor.</p> <p> Damage to the device could otherwise result.</p>
<p>Do not measure the insulation resistance and the pressure resistance.</p> <p> Damage to the device could otherwise result.</p>	<p>Wiring should follow electric equipment technical standards and indoor wiring regulations.</p> <p> An electrical short or fire could otherwise result.</p>
<p>Wiring connections must be secure.</p> <p> Motor interruption or bodily injury could otherwise result.</p>	<p>Keep static electricity and high voltage away from the encoder terminals of the motor.</p> <p> Damage to the device could otherwise result.</p>
<p>Do not place heavy objects on top of it or stand on the device.</p> <p> Bodily injury could otherwise result.</p>	<p>Do not obstruct the air intake and exhaust vents, and keep them free of debris and foreign matter.</p> <p> Fire could otherwise result.</p>
<p>Make sure the mounting orientation is correct.</p> <p> Fire or damage to the device could otherwise result.</p>	<p>Put the distance according to the manual in the array in the control board of the servo amplifier.</p> <p> Damage to the device could otherwise result.</p>
<p>Do not subject the device to excessive shock or vibration.</p> <p> Damage to the device could otherwise result.</p>	<p>Secure the device against falling, overturning, or shifting inadvertently during installation.</p> <p> Use the hardware supplied with the motor (if applicable).</p>
<p>Do not expose the device to water, corrosive or flammable gases, or any flammable material.</p> <p> Fire or damage to the device could otherwise result.</p>	<p>Install the device on a metal or other non-flammable support.</p> <p> Fire could otherwise result.</p>

# Safety Precautions

**[Make sure to follow.]**



## Caution





<p>There is no safeguard on the motor. Use an over-voltage safeguard, short-circuit breaker, overheating safeguard, and emergency stop to ensure safe operation.</p> <p> Injury or fire could otherwise result.</p>	<p>Do not touch the radiation fin of the amplifier, the regenerative resistor, or the motor while the device is powered up, or immediately after switching the power off, as these parts generate excessive heat.</p> <p> Burn could otherwise result.</p>
<p>In the case of any irregular operation, stop the device immediately.</p> <p> Electric shock, injury or fire could otherwise result.</p>	<p>Do not perform extensive adjustments to the device as they may result in unstable operation.</p> <p> Bodily injury could otherwise result.</p>
<p>Trial runs should be performed with the motor in a fixed position, separated from the mechanism. After verifying successful operation, install the motor on the mechanism.</p> <p> Bodily injury could otherwise result.</p>	<p>The securing brake is not to be used as a safety stop for the mechanism. Install a safety stop device on the mechanism.</p> <p> Bodily injury could otherwise result.</p>
<p>In the case of an alarm, first remove the cause of the alarm, and then verify safety. Next, reset the alarm and restart the device.</p> <p> Bodily injury could otherwise result.</p>	<p>Make sure the input power supply voltage is in or less than the specification range.</p> <p> Damage to the device could otherwise result</p>
<p>Avoid getting close to the device, as a momentary power outage could cause it to suddenly restart (although it is designed to be safe even in the case of a sudden restart).</p> <p> Bodily injury could otherwise result.</p>	<p>Standard specification servo amplifiers have a dynamic brake resistor. Do not rotate the motor continuously from the outside when the amplifier is not powered on, because the dynamic brake resistor will heat up, and can be dangerous.</p> <p> Fire or burn could otherwise result.</p>
<p>Be careful during maintenance and inspection, as the body of the amplifier becomes hot.</p> <p> Burn could otherwise result.</p>	<p>It is recommended to replace the electrolytic capacitors in the amplifier after 5 years, if used at an average temperature of 40°C year round.</p> <p> Damage to the device could otherwise result.</p>

# Safety Precautions

[Make sure to follow.]







## Caution

<p>Please contact your distributor or sales office if repairs are necessary. Disassembly could render the device inoperative.</p> <p> Damage to the device could otherwise result.</p>	<p>Make sure the device does not fall, overturn, or move inadvertently during transportation.</p> <p> Bodily injury could otherwise result.</p>
<p>Do not hold the device by the cables or the shaft while handling it.</p> <p> Damage to the device or bodily injury could otherwise result.</p>	<p>If the amplifier or the motor is no longer in use, it should be discarded as industrial waste.</p> <p></p>









## Prohibited

<p>Do not store the device where it could be exposed to rain, water, toxic gases or other liquids.</p> <p> Damage to the device could otherwise result.</p>	<p>The built-in brake is intended to secure the motor; do not use it for regular control. Damage to the brake could otherwise result.</p> <p> Damage to the device could otherwise result.</p>
<p>Do not overhaul the device.</p> <p> Fire or electric shock could otherwise result.</p>	<p>Do not remove the nameplate cover attached to the device.</p> <p></p>



## Mandatory

<p>Avoid direct sunlight and keep it by temperature and humidity within the range of the specification. {−20°C to +65°C, below 90% RH (non-condensing)}.</p> <p></p>	<p>Please contact our office if the amplifier is to be stored for a period of 3 years or longer. The capacity of the electrolytic capacitors decreases during long-term storage, and could cause damage to the device.</p> <p> Damage to the device could otherwise result.</p>
<p>Install an external emergency stop circuit and enable it to stop the device and cut off the power supply immediately. Install an external protective circuit to the amplifier to cut off the power from the main circuit in the case of an alarm.</p> <p></p> <p>Motor interruption, bodily injury, burnout, fire and secondary damages could otherwise result.</p>	<p>Operate within the specified temperature and humidity range</p> <p>Amplifier:          Temperature 0°C to 55°C,          Humidity below 90% RH(non-condensing).</p> <p>Motor:          Temperature 0°C to 40°C,          Humidity below 90%RH(non-condensing).</p> <p> Burnout or damage to the device could otherwise result.</p>
<p>Follow the directions written on the outside box. Excess stacking could result in collapse.</p> <p> Bodily injury could otherwise result.</p>	<p>The motor angling bolts are used for transporting the motor. Do not use them for transporting the machinery, etc.</p> <p> Damage to the device or bodily injury could otherwise result.</p>

# [Table of Contents]

## [1 Prior to use]

Product verification	1-1
Servo motor model number	1-2
Servo amplifier model number	1-4
Servo amplifier part names(AC200V input type)	1-6
Servo amplifier part names(AC400V input type)	1-8
Servo motor part names	1-9

## [2 Installation]

Servo amplifier	2-1
Mounting direction and location	2-3
Arrangement within the machine	2-3
Servo motor	2-4
Waterproofing and dust proofing	2-5
Protective cover installation	2-5
Gear installation	2-6
Integration with the target machinery	2-6
Allowable bearing load	2-8
Cable installation considerations	2-9

## [3 Wiring]

Packaged Wiring Diagram (AC200V)	3-1
Packaged Wiring Diagram (AC400V)	3-6
High Voltage Circuit Terminal Name and Function	3-8
Wiring Example of High Voltage/Protective Circuit	3-10
Low Voltage Circuit/Description of CN1 terminal (AC200V input type)	3-14
Low Voltage Circuit/Description of CN1 terminal / Overall Wiring (AC200V input type)	3-15
Low Voltage Circuit/Description of CN1 Overall Wiring / Wiring Example of CN1 Input Circuit (AC200V input type)	3-16
Low Voltage Circuit/Description of CN1 Output Circuit (AC200V input type)	3-17
Low Voltage Circuit/Description of CN1 terminal (AC400V input type)	3-18
Low Voltage Circuit/CN1 Overall Wiring (AC400V input type)	3-19
Low Voltage Circuit/Wiring Example of CN1 input Circuit (AC400V input type)	3-21
Low Voltage Circuit/Wiring Example of CN1 output Circuit (AC400V input type)	3-24
Low voltage circuit/CN2 Wiring	3-27
Power Supply Peripherals	3-32
Wire diameter	3-34
How to Process CN1/CN2 Shields	3-37

## [4 —]

There is not the Capture 4.

## [5 Description of parameters]

Parameter List	5-1
Parameter setting value 【Group0】 【Group1】	5-7
Parameter setting value 【Group2】	5-9
Parameter setting value 【Group3】	5-10
Parameter setting value 【Group4】	5-13
Parameter setting value 【Group5】	5-13
Parameter setting value 【Group8】	5-14
Parameter setting value 【Group9】	5-19
Parameter Setting Value 【GroupA】	5-21
Parameter Setting Value 【GroupB】	5-25
Parameter Setting Value 【GroupC】	5-28
System parameter setting value	5-31

## [6 Operations]

Procedure prior to operation	6-1
Confirmation of Installation and Wiring	6-3
Confirmation and Change of servo amplifier specification	6-4
JOG operation	6-5
Confirmation of I/O signal	6-7
Confirmation of I/O signals/Confirmation of device operation	6-8
Operation sequence	6-9

## [7 Adjustment ▪ Functions]

Servo Gain Tuning	7-1
Functions of Group8	7-7
Functions of Group9	7-25
Functions of GroupB	7-31
Functions of GroupC	7-36
Functions of Monitors	7-39

## [8 Maintenance]

Trouble Shooting	8-1
Alarm List	8-3
Trouble Shooting When the Alarm Occurs	8-6
Inspection/Parts Overhaul	8-31

## [9 Specifications]

Servo amplifier	9-1
Pulse output	9-5
Serial output	9-6
Servo motor	9-14
Rotation Direction Specifications	9-14
Mechanical specifications	9-15
Holding brake specifications	9-18

## [Materials]

## [Selection Details]

Time of Acceleration and Deceleration/Permitted Repetition	1
Permitted Repetition	2
Permitted Repetition/Loading Precaution	3
Dynamic Brake	4
Regeneration Process	7
Calculation Method of Regeneration Power by Operations along Horizontal Axis	8
Calculation Method of Regeneration Power by Operations along Vertical Axis	9
Confirmation Method of Regeneration Power	10
External Regenerative Resistor	11
External Regenerative Resistor Dimension	15

## [International Standards]

International standards Conformity	18
Compliance with EC Directives	20

## [Dimension]

Servo amplifier	24
Servo motor	33

## [Servo Motor Data Sheet]

Characteristics table	39
Velocity – Torque characteristics	44
Over load characteristics	51

## [Option]

Connectors	55
Monitor Box	57
Lithium battery • EMCKit	58

## [Encoder Clear]

Encoder clear/ reset method	59
-----------------------------	----

## [Electronic Gear]

Usage	60
-------	----

# [Prior to Use]


◆	Product verification .....	1-1
◆	Servo motor model number .....	1-2
◆	Servo amplifier model number .....	1-4
◆	Servo amplifier part names(AC200V input type) ...	1-6
◆	Servo amplifier part names(AC400V input type) ...	1-8
◆	Servo motor part names .....	1-9

# 1. Prior to Use


## [Product verification]

- Verify the followings when the product arrives. If you find any discrepancy, contact your distributor or sales office.
  - Verify that the model number of the servo motor or servo amplifier is the same as ordered. (The model number is located on the main name plate, following the word "MODEL".)
  - Make sure) that there is no problem on externals of the servo motor and the servo amplifier.
  - Verify that there are no loose screws on the servo motor or servo amplifier.


Servo motor




Servo motor main nameplate



Servo amplifier



Servo amp main nameplate




### Interpretation of the serial number

Month (2 digits) + Year (2 digits) + Day (2 digits)+  
Serial number (4 digits) + Revision ("A" is abbreviated)

# 1. Prior to Use

# [Servo motor model number]

## ■ Interpretation of servo motor model number



## ■ Encoder specifications

Type	Within 1 rotation	Multiple rotation	Notes
PA035C	131072(17bit)	65536(16bit)	Battery backup method absolute encoder
PA035S	131072(17bit)	—	Absolute encoder for incremental system ⚠



To the customers using “Absolute encoder for incremental system”;

See the parameter set values for your servo amplifier in the table below and make sure to use them.


### General parameter

Group	Page	Symbol	Name	Setting value	contents
C	00	ABS/INCSYS	Position detection system choice	00:_Absolute	Absolute system
C	08	ECLRFUNC	Absolute Encoder Clear Function Selection	01:_Status	Clear Only Encoder Status

# 1. Prior to Use

# [Servo motor model number]

## ■ Interpretation of servo motor model number



## ■ Encoder specifications

### • Incremental encoder

Type	Resolution	Flange angle dimensions	Notes
PP031	8000/8192 P/R	40mm Min	Wire-saving incremental encoder
PP038	4096~25000 P/R	42mm Min	Wire-saving incremental encoder
PP062	8000/8192/20000/32768/40000 P/R	72mm Min	Wire-saving incremental encoder

### • Absolute encoder

Type	Within 1 rotation	Multiple rotation	Notes
PA035C	131072(17bit)	65536(16bit)	Battery backup method absolute encoder
PA035M	8192(13bit)	—	Absolute encoder with incremental output ⚠
RA062C	131072(17bit)	8192(13bit)	Absolute encoder without battery



To the customers using “Battery backup method absolute encoder” with incremental system;  
 See the parameter set values for your servo amplifier in the table below and make sure to use them.


### General parameter

Group	Page	Symbol	Name	Setting value	Contents
C	00	ABS/INCSYS	Position detection system choice	01:_Incremental	Absolute system
C	08	ECLRFUNC	Absolute Encoder Clear Function Selection	01:_Status	Clear Only Encoder Status

# 1. Prior to Use

# [Servo amplifier model number]

## ■ Interpretation of servo amplifier model number (Abbreviated number)



Interface type of encoder	
L...Generic output: NPN(Sink) output	
Interface type : CANopen I/F	
* AC400V input type is support standard I/F AND CANopen I/F.	
Encoder type	
• Wire-saving incremental encoder	
• Battery backup method absolute encoder	
U...Generic output: PNP(Source) output	
Interface type : CANopen I/F	
* AC400V input type is support standard I/F AND CANopen I/F.	
Encoder type	
• Wire-saving incremental encoder	
• Battery backup method absolute encoder	

**PNP**

General output : PNP (Source) output :

External power supply DC24V is taken in as common power supply, and DC24V is outputted when a general-purpose output turns on.

【AC200V/AC100V input type】					
Power input, power part details				Model numbers by amplifier capacity	
Input voltage		Regenerative resistor	DB	15A...RS1□01	50A...RS1□05
Main	Control			30A...RS1□03	
AC200V	AC200V	Built-in	W	L	A
			W/O	M	B
		—	W	A	L
			W/O	B	M
AC100V	AC100V	Built-in	W	N	—
			W/O	P	—
		—	W	E	—
			W/O	F	—
AC200V	DC24V	—	W	J	J
		Built-in	W	K	K


【AC400V input type】					
Power input, power part details				Model numbers by amplifier capacity	
Input voltage		Regenerative resistor	DB	25A...RS1□02	—
Main	Control			50A...RS1□05	100A...RS1□10
AC400V	DC24V	—	W	C	—
			W/O	D	—

### NPN (Sink) output and PNP (Source) output

NPN (Sink) output and PNP (Source) output are the names of the general-purpose output circuit system of servo amplifier.

PNP (Source) output was added from August, 2008 to NPN (Sink) output old standard type.

Please refer to the right figure.





# 1. Prior to Use

[Servo amplifier model number]

Refer to Chapters 5 and 6 for how to set parameters which have been set at the time of shipment.

The design order is noted by alphabetical characters at the end of the Lot Number on the name plate.

## ■ Motor setting and Encoder type of abbreviated model numbers

### ▪ Single-phase / 3-phase 200V class

Servo amplifier model number		Servo motor model number	Encoder
Generic output: NPN (Sink) output	Generic output: PNP (Source) output		
RS1Δ01AL	RS1Δ01AU	P50B03003D	Standard I/F such as a wire-saving incremental encoder or Battery backup method absolute encoder 2000P/R
RS1Δ03AL	RS1Δ03AU	P50B07040D	
RS1Δ05AL	RS1Δ05AU	P50B08075D	

### ▪ 3-phase 400V class

Servo amplifier model number		Servo motor model number	Encoder
Generic output: NPN (Sink) output	Generic output: PNP (Source) output		
RS1Δ02AL	RS1Δ02AU	Q2CA08050H	Standard I/F such as a wire-saving incremental encoder or Battery backup method absolute encoder 2000P/R
RS1Δ05AL	RS1Δ05AU	Q2CA13200H	
RS1Δ10AL	RS1Δ10AU	Q2CA18450H	

Δ : Depends on input power voltage, regeneration resistance and dynamic brake resistance.  
In case of 200VAC input voltage, A, B, L and M will be filled in.  
In case of 100VAC input voltage, E, F, N and P will be filled in. (However, there are only RS1Δ01、RS1Δ03.)

**PNP**

General output : PNP (Source) output :  
External power supply DC24V is taken in as common power supply, and DC24V is outputted when a general-purpose output turns on.


# 1. Prior to Use

# [Servo amplifier part names]

## ■ Single-phase / 3-phase 200V class (Control Power AC200V Input Type)

[ RS1□01AL / RS1□03AL / RS1□01AU / RS1□03AU ]

Parts inside the cover (Same for all capacity amplifiers)



Cover open



Analog monitor connector


Main power supply LED (CHARGE · Red)

Control power, main power supply input connector  
CNA MSTB2.5/5-GF-5.08  
(Phoenix Contact Co. Ltd.)


External regenerative resistor, DC reactor connector  
CNB IC2.5/6-GF-5.08  
(Phoenix Contact Co. Ltd.)

Servo motor power connector  
CNC IC2.5/3-GF-5.08  
(Phoenix Contact Co. Ltd.)

Protective ground terminal



[ RS1□05AL / RS1□05AU ]




# 1. Prior to Use


## [Servo amplifier part names]

### ■ Single-phase / 3-phase 200V class (Control Power DC24V Input Type)

[ RS1□01AL / RS1□03AL / RS1□01AU / RS1□03AU ]



[ RS1□05AL / RS1□05AU ]




# 1. Prior to Use


## [Servo amplifier part names]

### ■ 3-phase 400V class

[ RS1□02AL / RS1□05AL / RS1□02AU / RS1□05AU ]



[ RS1□10AL / RS1□10AU ]




# 1. Prior to Use

## [Servo motor part names]

### ■ Lead wire types


Q1□A04○○○△□◇  
Q1□A06○○○△□◇  
Q1AA07○○○△□◇  
Q2□A04○○○△□◇  
Q2□A05○○○△□◇  
Q2□A07○○○△□◇  
Q2AA08○○○△□◇  
R2□A04○○○△□◇  
R2□A06○○○△□◇  
R2AA08○○○△□◇



### ■ Cannon plug type

Q1AA10○○○△□◇  
Q1AA12○○○△□◇  
Q1AA13○○○△□◇  
Q1AA18○○○△□◇  
Q2AA10○○○△□◇  
Q2AA13○○○△□◇  
Q2AA18○○○△□◇  
Q2AA22○○○△□◇

Q2CA08○○○△□◇  
Q2CA10○○○△□◇  
Q2CA13○○○△□◇  
Q2CA18○○○△□◇  
Q2CA22○○○△□◇



## [Installation]

◆	Servo amplifier .....	2-1
	■ Mounting direction and location .....	2-3
	■ Arrangement within the machine .....	2-3
◆	Servo motor .....	2-4
	■ Waterproofing and dust proofing .....	2-5
	■ Protective cover installation .....	2-5
	■ Gear installation .....	2-6
	■ Integration with the target machinery .....	2-6
	■ Allowable bearing load .....	2-8
	■ Cable installation considerations .....	2-9

## 2. Installation

## [Servo amplifier]

- Please note the following points regarding the servo amplifier installation location and mounting method.

### Various precautions



Installation on or near flammable materials can cause fire.	Do not place heavy objects or stand on it.
Operate the device within the specified environmental conditions.	Do not drop the device or subject it to excessive shock.
The device, which damaged or loading parts have damaged, should return for repair to the sales office.	Make sure no screws or other conductive or flammable materials get inside the servo amplifier.
Contact your distributor or sales office when storage of servo amplifier is an extended period of time (three years or more as a standard). The capacity of the electrolytic capacitor decreases by keeping a long term.	

### If enclosed in a cabinet



The temperature inside the cabinet can exceed the external temperature depending on the power consumption of the device and the size of the cabinet. Consider the cabinet size, cooling, and placement, and make sure the temperature around the servo amplifier does not exceed 55°C. For longevity and reliability purposes it is recommended to keep the temperature below 40°C.

### If there is a vibration source nearby



Protect the servo amplifier from vibration by installing it on a base with a shock absorber.

### If there is a heat generator nearby



If the ambient temperature may increase due to convection or radiation, make sure the temperature near the servo amplifier does not exceed 55°C.

### If corrosive gas is present



Long-term use may cause contact failure on the connectors and connecting parts.  
Never use the device where it may be exposed to corrosive gas.

## 2. Installation

[Servo amplifier]

### If explosive or combustible gas is present

Never use the device where explosive or combustible gas is present. The device's relays and contacts, regenerative resistors and other parts can arc (spark) and can cause fire or explosion.

### If dust or oil mist is present

The device cannot be used where dust or oil mist is present. If dust or oil mist accumulates on the device, it can cause insulation deterioration or leakage between the conductive parts, and damage the servo amplifier.

### If a large noise source is present


If inductive noise enters the input signals or the power circuit, it can cause a malfunction. If there is a possibility of noise, inspect the line wiring and take appropriate noise prevention measures. A noise filter should be installed to protect the servo amplifier.



## 2. Installation

## [Servo amplifier]


### ■ Mounting direction and location



For metal fittings for front/rear mounting, refer to options (compatible with PY2 mounting).

### ■ Arrangement within the control machine

- Leave at least 50 mm space above and below the servo amplifier to ensure unobstructed airflow from the inside of the servo amplifier and the radiator. If heat gets trapped around the servo amplifier, use a cooling fan to create airflow.
- The ambient temperature of servo amplifier should always become 55°C or less. In addition, in order to secure a long-life and high reliability, we recommend you to use temperature below 40°C.
- Leave at least 10 mm space on both sides of the servo amplifier to ensure unobstructed airflow from the heat-sinks on the side and from the inside of the servo amplifier.
- If the R-series servo amplifier is installed on its side, make sure that the ambient temperature does not exceed 50°C, and mount the back panel to a metal plate.  
 RS1□01, RS1□03, RS1□05 : 2mm or more of recommendation metal plate thickness  
 RS1□02, RS1□05, RS1□10 : 5mm or more of recommendation metal plate thickness
- For RS1□03 · RS1□05, a cooling fan is attached at the side. Therefore, it is recommended that the servo amplifier be mounted in an arrangement as shown below.



## 2. Installation


## [Servo motor]

- Please note the following regarding the installation location and mounting method for the servo motor.

The servo motor is designed for indoor use. Make sure to Install it indoors.	
Do not use the device in locations where the oil seal lip is continuously exposed to oil, or where the device is exposed to large quantities of water, oil drops, or cutting fluid. The motor is designed to withstand only small amounts of moisture spray.	
Ambient temperature: 0 to 40°C Storage temperature: -20 to 65°C Ambient humidity: 20 to 90%	Good ventilation, no corrosive or explosive gases present. No dust or dirt accumulation in the environment. Easy access for inspection and cleaning.

### ■ Mounting method

- Mounting in several orientations - horizontal, or with the shaft on top or bottom- is acceptable.
- If the output shaft is used in reduction devices that use grease, oil, or other lubricants, or in mechanisms exposed to liquids, the motor should be installed in a perfectly horizontal or downward position.  
In some models, there is an oil-seal attached to the output shaft. If the shaft is facing upwards and the seal lip is continuously exposed to oil, oil can enter inside the motor and cause damage, as a result of wear and degradation of the oil seal. In such cases an oil-seal should be used on the load-side as well. Contact your distributor or sales office if the device is to be used in such conditions.
- The motor connector and cable outlet should be installed facing downwards, as nearly vertical as possible.
- In vertical installation, create a cable trap to prevent oily water from getting into the motor.




### ■ Waterproofing and dust proofing

- The protection inside the motor conforms to IEC standards (IEC34-5). However, such protection is suitable only for short-term use. For regular use, additional sealing measures are required. Be sure to handle the connector carefully, as damage to the exterior of the connector (painted surface) can reduce its waterproofing capability.
- The motor waterproofing is of IPX 7 class level, but still requires careful handling. If the motor is continuously wet, due to the respiratory effect of the motor, liquid may penetrate inside the motor.
- Install a protective cover to prevent corrosion of the coating and the sealing material, which can be caused by certain types of coolants (especially water soluble types).
- Q1- and Q2-series motors with the canon plugs are only IP67 rated if waterproof connectors and/or conduits are used on the matching canon connectors.
- Q1-series motors (with all flange sizes) and Q2-series motors (with the 42mm flange size) not of the canon plug type are IP40 rated, but IP67 rated waterproofing is also available as an option. Q2-series motors with flange sizes of 54mm, 76mm and 86mm have IP67 rated waterproofing. R2-series motors have IP67 rated waterproofing, except for shaft passages and cable ends.

### ■ Protective cover installation

- Install a protective cover (as described below) for motors continuously subjected to liquids.
- Turn the connectors (lead outlets) downwards within the angle range shown in the picture below.
- Install the cover on the side where the water or oil would drip.
- Install the cover at an angle (for runoff), to prevent water or oil from collecting.
- Make sure that the cable does not get soaked in water or oil.
- Create a sag in the cable outside the cover, to make sure water or oil does not penetrate to the motor.
- If it is not possible to install the connectors (lead outlets) facing downwards, create a sag in the cable to prevent water or oil from entering the motor.




## 2. Installation

[Servo motor]


### ■ Gear installation

- The oil level of the gear box should be below the oil seal lip, for a slight spraying effect on the lip.
- Create a hole to prevent pressure build-up inside the gear box, as pressure can cause water or oil to penetrate the oil seal and enter inside the motor.
- If the motor is used with the shaft facing upwards, an oil seal should be used on the opposite side of the mechanism as well. In addition, install a drain to expel the water or oil that may penetrate through this oil seal.



### ■ Integration with the target machinery



- Refer to the drawing below for correct centering of the motor shaft and the target machinery. Please note when using a rigid coupling that even a slight mistake in centering can damage the output shaft.





## 2. Installation

## [Servo motor]



- Do not subject the motor shaft to shock, as the precision encoder is directly connected to it. If it is absolutely necessary to hit the motor for position adjustment or other reasons, use a rubber or plastic hammer and hit the front flange area.



- If mounting to a machine, create enough mounting holes for smooth coupling of the motor flange rabbet. The mounting surface should be flat, otherwise damage to the shaft or the load may occur.
- Use the screw at the end of the shaft for installing parts such as the gear, pulley, or coupling, to avoid shock.



- Tapered motor shafts transmit the torque via the tapered surface. Make sure the key fits without rattling. The tapered surface contact should be no less than 70%.
- Use a special tool for removing the gear, pulley, etc.




## 2. Installation

[Servo motor]

### ■ Allowable bearing load

- The table below shows the allowable bearing load of the servo motors. Do not apply excessive thrust load or radial load. In case of belt driving, make sure that the shaft converted value of belt tension does not exceed the allowable values shown below. The thrust load and radial load tolerance values assume individual application to the shaft.



### [ AC200V input type ]

	Model	Assembly			Operation		
		Radial load (N)s	Thrust load (N)		Radial load (N)	Thrust load (N)	
		$F_R$	F direction	F1 direction	$F_R$	F direction	F1 direction
Q1	Q1□A04003	98	78	78	49	29	29
	Q1□A04005	150	98	98	98	29	29
	Q1□A04010	150	98	98	98	29	29
	Q1□A06020	390	200	200	200	78	78
	Q1AA06040	390	200	200	250	98	98
	Q1AA07075	590	390	390	340	200	200
	Q1AA10100	980	290	290	690	200	200
	Q1AA10150	980	290	290	690	200	200
	Q1AA10200	980	290	290	690	200	200
	Q1AA10250	980	290	290	690	200	200
	Q1AA12100	980	290	290	690	290	290
	Q1AA12200	980	290	290	690	290	290
	Q1AA12300	980	290	290	690	290	290
	Q1AA13300	2000	390	390	980	390	390
	Q1AA13400	2000	390	390	1200	390	390
Q1AA13500	2000	390	390	1200	390	390	
Q1AA18450	2300	1900	1900	1500	490	490	
Q1AA18750	3900	2000	2000	1800	590	590	
Q2	Q2□A04006	150	98	98	98	29	29
	Q2□A04010	150	98	98	98	29	29
	Q2□A05005	200	200	150	150	78	78
	Q2□A05010	200	200	150	150	78	78
	Q2□A05020	250	200	150	200	78	78
	Q2□A07020	250	490	200	200	98	98
	Q2AA07030	250	490	200	200	98	98
	Q2AA07040	250	490	200	250	98	98
	Q2AA07050	250	490	200	250	98	98
	Q2AA08050	590	780	290	340	200	200
	Q2AA08075	590	780	290	340	200	200
	Q2AA08100	590	780	290	340	200	200
	Q2AA10100	980	290	290	690	200	200
	Q2AA10150	980	290	290	690	200	200
	Q2AA13050	1700	1300	1300	490	290	290
	Q2AA13100	1700	1300	1300	690	290	290
	Q2AA13150	1700	1300	1300	690	290	290
	Q2AA13200	1700	1300	1300	690	290	290
Q2AA18200	2300	1900	1900	1500	490	490	

## 2. Installation

[Servo motor]

	Model	Assembly			Operation		
		Radial load (N)s	Thrust load (N)		Radial load (N)	Thrust load (N)	
		$F_R$	F direction	F1 direction	$F_R$	F direction	F1 direction
Q2	Q2AA22350	2300	1900	1900	1500	490	490
	Q2AA22450	2300	1900	1900	1500	490	490
	Q2AA22550	3900	2000	2000	1800	590	590
	Q2AA22700	3900	2000	2000	2500	1100	1100
	Q2AA2211K	3900	2000	2000	2700	1500	1500
	Q2AA2215K	3900	2000	2000	2300	1500	1500
R2	R2□A04003F	98	78	78	49	29	29
	R2□A04005F	150	98	98	98	29	29
	R2EA04008F	150	98	98	98	29	29
	R2AA04010F	150	98	98	98	29	29
	R2□A06010F	150	98	98	98	29	29
	R2□A06020F	390	200	200	200	68	68
	R2AA08020F	390	200	200	200	98	98
	R2AA06040F	390	200	200	250	68	68
	R2AA08040F	390	200	200	250	98	98
	R2AA08075F	590	390	390	340	200	200

[ AC400V input type ]

	Model	Assembly			Operation		
		Radial load (N)s	Thrust load (N)		Radial load (N)	Thrust load (N)	
		$F_R$	F direction	F1 direction	$F_R$	F direction	F1 direction
Q2	Q2CA08050H	590	780	290	340	200	200
	Q2CA10100H	980	290	290	690	200	200
	Q2CA13150H	1700	1300	1300	690	290	290
	Q2CA13200H	2300	1900	1900	1500	490	490
	Q2CA18350H	2300	1900	1900	1500	490	490
	Q2CA18450H	2300	1900	1900	1500	490	490
	Q2CA22550H	3900	2000	2000	1800	590	590
	Q2CA22700H	3900	2000	2000	2500	1100	1100

### ■ Cable installation considerations

- Make sure that no stress is applied to the cable and that it is undamaged.
- If the servo motor is installed in a moving location, make sure that no excessive stress is applied to the cable, by allowing a large bending radius.
- Avoid pulling the cable over sharp objects such as cutting scrap that can damage its exterior. Make sure the cable is not touching any machinery, and that it is out of the path of people and machines.
- Prevent bending or additional weight stress on the cable connection by clamping the cable to the machinery.  
In applications where the motor or the cable is moving using a cable bear, the bending radius should be based on the required cable-life and the type of cable used.
- Install the cables of moving parts in a manner that permits easy regular replacement.  
Consult with your distributor or sales office for recommendations, if you use cables for moving parts.

---

# [Wiring]


◆ Packaged Wiring Diagram (AC200V) .....	3-1
◆ Packaged Wiring Diagram (AC400V) .....	3-6
◆ High Voltage Circuit Terminal Name and Function .....	3-8
◆ Wiring Example of High Voltage/Protective Circuit .....	3-10
◆ Low Voltage Circuit/Description of CN1 terminal (AC200V input type) ...	3-14
◆ Low Voltage Circuit/Description of CN1 terminal / Overall Wiring (AC200V input type) ..	3-15
◆ Low Voltage Circuit/ Description of CN1 Overall Wiring / Wiring Example of CN1 Input Circuit (AC200V input type) ..	3-16
◆ Low Voltage Circuit/Description of CN1 Output Circuit (AC200V input type) .....	3-17
◆ Low Voltage Circuit/Description of CN1 terminal (AC400V input type) ...	3-18
◆ Low Voltage Circuit/CN1 Overall Wiring (AC400V input type) .....	3-19
◆ Low Voltage Circuit/Wiring Example of CN1 input Circuit (AC400V input type) .....	3-21
◆ Low Voltage Circuit/Wiring Example of CN1 output Circuit (AC400V input type) .....	3-24
◆ Low voltage circuit/CN2 Wiring .....	3-27
◆ Power Supply Peripherals .....	3-32
◆ Wire diameter .....	3-34
◆ How to Process CN1/CN2 Shields .....	3-37



# 3. Wiring

## [Packaged Wiring Diagram (AC200V) RS1□01/RS1□03]

### ■ Packaged wiring diagram (Control Power AC200V input type)




# 3. Wiring

## [Packaged Wiring Diagram (AC200V) RS1□01/RS1□03]

### ■ Packaged wiring diagram (Control Power DC24V input type)


Do not connect S-phase terminal in the usage of AC200V single phase input.



# 3. Wiring

## [Packaged Wiring Diagram (AC200V) RS1□01/RS1□03]

■ Packaged wiring diagram (AC100V input type)




Model number of input/output connector plug/housing	
CNA connector plug	MSTB2.5/4-STF-5.08 Phoenix Contact
CNC connector plug	IC2.5/3-STF-5.08 Phoenix Contact
CN1 connector plug	10114-3000PE SUMITOMO 3M Ltd.
CN1 connector housing	10314-52A0-008 SUMITOMO 3M Ltd.
CN2 connector plug	10120-3000PE SUMITOMO 3M Ltd.
CN2 connector housing	10320-52A0-008 SUMITOMO 3M Ltd.
CN3,4 connector	RJ-45 modular connector
PC connector plug/housing (amplifier side)	3240-12P-TO-C HIROSE Electric Co., Ltd.
PC connector plug (PC side)	HDEB-9S HIROSE Electric Co., Ltd.
PC connector case (PC side)	GM-9L HIROSE Electric Co., Ltd.

Communication cable for R-Setup RS232C can be purchased at SANYO DENKI.

# 3. Wiring

## [Packaged Wiring Diagram (AC200V) RS1□05]


### ■ Packaged wiring diagram (Control Power AC200V input type)



# 3. Wiring

# [Packaged Wiring Diagram (AC200V) RS1□05]


## ■ Packaged wiring diagram (Control Power DC24V input type)



# 3. Wiring

## [Packaged Wiring Diagram (AC400V) RS1□02/RS1□05]

### ■ Packaged wiring diagram (AC400V input type)




Model number of input/output connector plug/housing	
CNA connector plug	GIC2.5/7-STF-7.62 Phoenix Contact
CNB connector plug	MSTB2.5/2-STF-5.08 Phoenix Contact
CNC connector plug	GIC2.5/3-STF-7.62 Phoenix Contact
CN1 connector plug	10150-3000PE SUMITOMO 3M Ltd.
CN1 connector housing	10350-52A0-008 SUMITOMO 3M Ltd.
CN2 connector plug	10120-3000PE SUMITOMO 3M Ltd.
CN2 connector housing	10320-52A0-008 SUMITOMO 3M Ltd.
CN3,4 connector	RJ-45 modular connector
PC connector plug/housing (amplifier side)	3240-12P-TO-C HIROSE Electric Co., Ltd.
PC connector plug (PC side)	HDEB-9S HIROSE Electric Co., Ltd.
PC connector case (PC side)	GM-9L HIROSE Electric Co., Ltd.

# 3. Wiring

## [Packaged Wiring Diagram (AC400V) RS1□10]

### ■ Packaged wiring diagram (AC400V input type)



Set-up software- R-Setup



### 3. Wiring [High Voltage Circuit; Terminal Name and Function]



#### ■ High voltage circuit; terminal name and functions

##### [ AC200V input type ]

Terminal name	Connector marking	Remarks
Main power source	R · T	Single phase AC100~115V +10%,-15% 50/60Hz±3%
	or	Single phase AC200~230V +10%,-15% 50/60Hz±3%
	R · S · T	Three phase AC200~230V +10%,-15% 50/60Hz±3%
Control power source (Note)	r · t	Single phase AC100~115V +10%,-15% 50/60Hz±3%
	24V · 0V	DC24V +15%,-15%
Servo motor connector	U · V · W	Connected with servo motor
Safeguard connector		Connected with grounding wire of power source and of servo motor.
Regeneration resistance connector	RB1 · RB2	RS1□01AL RS1□03AL RS1□05AL RS1□01AU RS1□03AU RS1□05AU Regeneration resistance will be connected to RB1 · RB2. If it is built-in, regeneration resistance has been connected at the time of shipment. In case of short regeneration power, an external regeneration resistance is connected to RB1 · RB2.
DC reactor connector	DL1 · DL2	Short circuited at the time of shipment. If high frequency waves need to be controlled, remove the short bar between DL1 · DL2 and connect a DC reactor between DL1 · DL2.
Maker maintenance	P · 	For maker maintenance. Do not connect anything.

Note) By a control power supply input type, wiring methods are different.


##### [ AC400V input type ]

Terminal name	Connector marking	Remarks
Main power source	R · S · T	Three phase AC380~480V +10%,-15% 50/60Hz±3%
Control power source	24V · 0V	DC24V +15%,-15%
Servo motor connector	U · V · W	Connected with servo motor
Safeguard connector		Connected with grounding wire of power source and of servo motor.
Regeneration resistance connector	RB1 · RB2	RS1□02AL RS1□05AL RS1□10AL RS1□02AU RS1□05AU RS1□10AU External regeneration resistance is connected to RB1 · RB2.
Maker maintenance	P · 	For maker maintenance. Do not connect anything.

#### ■ How to insert high voltage circuit connector

- Insert the wire into ferrule, and use a special tool to crimp it in.
- Insert the ferrule deep into the connector, and tighten it with a special minus screw driver or something.

The recommended torque is 0.5~0.6 N·m.





### 3. Wiring [High Voltage Circuit; Terminal Name and Function]

- Model number of recommended ferrules and crimping tools for various wire sizes (Manufactured by Phoenix Contact.)

mm <sup>2</sup>	AWG	Model number		
		1Pcs/Pkt	1000Pcs/Pkt	Taped components
0.75 mm <sup>2</sup>	18	AI0.75-8GY	AI0.75-8GY-1000	AI0.75-8GY-B (1000Pcs/Pkt)
1.0 mm <sup>2</sup>	18	AI1-8RD	AI1-8RD-1000	AI1-8RD-B (1000Pcs/Pkt)
1.5 mm <sup>2</sup>	16	AI1.5-8BK	AI1.5-8BK-1000	AI1.5-8BK-B (1000Pcs/Pkt)
2.5 mm <sup>2</sup>	14	AI2.5-8BU	AI2.5-8BU-1000	AI2.5-8BU-B (500Pcs/Pkt)

Note) GY: Gray, RD: Red, BK : Black, BU : Blue

Crimping tool model number : 0.25mm<sup>2</sup>~6mm<sup>2</sup>: CRIMPFOX UD 6-4、 0.75mm<sup>2</sup>~10mm<sup>2</sup>: CRIMPFOX UD 10-4

#### ■ High voltage circuit terminal; tightening torque

##### 【 AC200V input type 】

Amplifier type	Terminal marking			
	CNA	CNB	CNC	⊕
RS1□01	[0.5~0.6 N·m]			[1.18 N·m] M4 (screw size)
RS1□03				
RS1□05				

##### 【 AC400V input type (RS1□02/05) 】

Amplifier type	Terminal marking			
	CNA	CNB	CNC	⊕
RS1□02	[[0.5~0.6 N·m]		[0.5~0.6 N·m]	[1.18 N·m] M4 (screw size)
RS1□05				

##### 【 AC400V input type (RS1□10) 】


Amplifier type	Terminal marking											
	R	S	T	⊖	RB1	RB2	P	U	V	W	⊕	CNB
RS1□10	[1.13 N·m] M4 (screw size)											[0.5~0.6 N·m]

#### ■ Wiring of the power line UVW

	Servo amplifier terminal number	Servo motor canon type terminal number
Q1AA10*	U	A
Q1AA187*	V	B
Q2AA10*	W	C
Q2AA185*, Q2AA187*		
Q2AA22□□K*	E	D
Q1AA12*	U	D
Q1AA13*	V	E
Q1AA184*		
Q2AA13*	W	F
Q2AA182*~184*	E	G, H
Q2AA22□□0*		


### 3. Wiring [Wiring Example of High Voltage/Protective Circuit]

■ Three phase 200V RS1□01AL · RS1□03AL · RS1□05AL [General output: NPN output]



Note) In the case of the control power supply DC24V input type, please be connected to the DC24V power supply.


■ Single phase 200V RS1□01AL · RS1□03AL · RS1□05AL [General output: NPN output]



Note) In the case of the control power supply DC24V input type, please be connected to the DC24V power supply.


# 3. Wiring [Wiring Example of High Voltage/Protective Circuit]

■ Three phase 400V RS1□02AL · RS1□05AL · RS1□10AL [General output: NPN output]




■ Single phase 100V RS1□01AL · RS1□03AL

[General output: NPN output]




### 3. Wiring [Wiring Example of High Voltage/Protective Circuit]

■ Three phase 200V RS1□01AU · RS1□03AU · RS1□05AU [General output: PNP output]



Note) In the case of the control power supply DC24V input type, please be connected to the DC24V power supply.


■ Single phase 200V RS1□01AU · RS1□03AU · RS1□05AU [General output: PNP output]



Note) In the case of the control power supply DC24V input type, please be connected to the DC24V power supply.


### 3. Wiring [Wiring Example of High Voltage/Protective Circuit]

■ Three phase 400V RS1□02AU · RS1□05AU · RS1□10AU [General output: PNP output]



■ Single phase 100V RS1□01AU · RS1□03AU

[General output: PNP output]



# 3. Wiring [Low Voltage Circuit/Description of CN Terminal]


## ■ Low voltage circuit; terminal name and functions

Terminal name	Terminal symbol	Description
Upper device input/output signal connector	CN1	Connects the input/output circuit between upper device (upper controller) and the Servo amplifier.
Encoder connector	CN2	Connects the encoder circuit of the servo motor.


## ■ Connector terminal number

### ● CN1


**【AC200V input Type :10114-3000PE (Soldered side)】**



**【AC400V input Type :10150-3000PE (Soldered side)】**




### ● CN2 10120-3000PE (Soldered side)



# 3. Wiring [Low Voltage Circuit/Description of CN1 terminal / Overall Wiring]

## [AC200V Input Type]

### ■ CN1 connector terminal layout



**PNP**

General output : PNP output :  
 External power supply DC24V is taken in as common power supply, and DC24V is outputted when a general-purpose output turns on.

\* In the case of PNP output, don't connect.


### ■ CN1 terminal name

Terminal number	Signal name	
1	BTP-1	Battery plus
2	BTN-1	Battery minus
3	CONT1	Generic input
4	CONT3	Generic input
5	CONT7	Generic input
6	OUT1	Generic output
7	OUT-COM*	Generic output common / NC
8	CONT-COM	Generic input power source
9	CONT-COM	Generic input power source
10	CONT2	Generic input
11	CONT4	Generic input
12	CONT8	Generic input
13	OUT2	Generic output
14	OUT-PWR	Generic output power source

\* In the case of PNP output, don't connect.

### ■ CN1 Connector terminal layout


[General output: NPN output]




# 3. Wiring [Low Voltage Circuit/Description of CN1 Overall Wiring / Wiring Example of CN1 Input circuit]

## ■ CN1 Connector terminal layout

[General output: PNP output]




## ■ Connection example with analog input circuit



## ■ Connection example with generic input circuit

### ● Generic input circuit CONT1~CONT6[Input circuit : Bi-directional photo coupler]






# 3. Wiring [Low Voltage Circuit / Description of CN1 Output Circuit]


## ■ Connection example with generic output circuit

### ● Generic output circuit OUT1,OUT2

[output circuit : open collector]  
[General output : NPN output]



[General output : PNP output]



**PNP**

General output : PNP output :

External power supply DC24V is taken in as common power supply, and DC24V is outputted when a general-purpose output turns on.

### 3. Wiring [Low Voltage Circuit/Description of CN1 terminal]

#### [AC400V Input Type]

##### ■ CN1 connector terminal layout

24	22	20	18	16	14	12	10	8	6	4	2	
OUT-COM*	T-COMP	SG	F-TLA	CONT8	CONT7	SG	PS	ZO	BO	A0	BTN-1	
25	23	21	19	17	15	13	11	9	7	5	3	1
OUT-COM*	SG	V/T-REF	R-TLA	SG	CONT8	CONT7	ZOP	PS	ZO	BO	A0	BTP-1
49	47	45	43	41	39	37	35	33	31	29	27	
OUT-PWR	SG	OUT7	OUT5	OUT3	OUT1	CONT1	CONT3	CONT5	SG	R-PC	F-PC	
50	48	46	44	42	40	38	36	34	32	30	28	26
IN-COM	SG	OUT8	OUT6	OUT4	OUT2	SG	CONT2	CONT4	CONT6	MON1	R-PC	F-PC

\* In the case of PNP output, don't connect.

**PNP**

General output : PNP output :

External power supply DC24V is taken in as common power supply, and DC24V is outputted when a general-purpose output turns on.

##### ■ CN1 terminal name

Terminal number	Signal name	
1	BTP-1	Battery plus
2	BTN-1	Battery minus
3	A0	A phase position signal output
4	A0	/A phase position signal output
5	BO	B phase position signal output
6	BO	/B phase position signal output
7	ZO	Z phase position signal output
8	ZO	/Z phase position signal output
9	PS	Position data output
10	PS	Position data output
11	ZOP	Z phase Position data output
12	SG	Common for pins 3~11
17	SG	Common for pins 18·19
18	F-TLA	Analog current limit input
19	R-TLA	Analog current limit input
20	SG	Common for pin 21
21	V-REF	Speed command input
	T-REF	Torque command input
22	T-COMP	Torque compensation input
23	SG	2Common for pin 22
26	F-PC	Command pulse input
27	F-PC	Command pulse input
28	R-PC	Command pulse input
29	R-PC	Command pulse input
47	SG	Common for pins 26·27
48	SG	Common for pins 28·29


Terminal number	Signal name	
30	MON1	Analog monitor output
31	SG	Common for pin 30
13	CONT7	Generic input
14	CONT7	Generic input
15	CONT8	Generic input
16	CONT8	Generic input
38	SG	Common for pins 13~16
32	CONT6	Generic input
33	CONT5	Generic input
34	CONT4	Generic input
35	CONT3	Generic input
36	CONT2	Generic input
37	CONT1	Generic input
50	CONT-COM	Generic input power source
39	OUT1	Generic output
40	OUT2	Generic output
41	OUT3	Generic output
42	OUT4	Generic output
43	OUT5	Generic output
44	OUT6	Generic output
45	OUT7	Generic output
46	OUT8	Generic output
49	OUT-PWR	Generic output power source
24	OUT-COM*	Generic output Common / NC
25	OUT-COM*	Generic output Common / NC

\* In the case of PNP output, don't connect.

# 3. Wiring [Low Voltage Circuit/CN1 Overall Wiring]

■ CN1 Connector terminal layout

[General output: NPN output]



# 3. Wiring [Low Voltage Circuit/CN1 Overall Wiring]

## ■ CN1 Connector terminal layout


[General output: PNP output]

**PNP**

General output : PNP output :  
External power supply DC24V is taken in as  
common power supply, and DC24V is  
outputted when a general-purpose output  
turns on.

Host unit




Host unit



# 3. Wiring [Low Voltage Circuit/Wiring Example of CN1 Input Circuit]



## ■ Connection example with analog input circuit

### ● Analog input circuit




# 3. Wiring [Low Voltage Circuit/Wiring Example of CN1 Input Circuit]

● Position command input circuit [Input circuit : Line receiver]



● Battery input circuit




# 3. Wiring [Low Voltage Circuit/Wiring Example of CN1 Input Circuit]

## ■ Connection example with generic input circuit



### ● Generic input circuit CONT1~CONT6

[Input circuit : Bi-directional photo coupler]



### ● Generic input circuit CONT7・CONT8

[Input circuit : Line receiver]




# 3. Wiring [Low Voltage Circuit/Wiring Example of CN1 output Circuit]

## ■ Connection example with position signal output circuit


### ● Incremental pulse signal output circuit

[output circuit : line driver]



### ● Absolute position data output circuit


[output circuit : line driver]



### ● Origin Z phase output circuit

[output circuit : open collector]

[General output : NPN output]






# 3. Wiring [Low Voltage Circuit/Wiring Example of CN1 output Circuit]

● Origin Z phase output circuit

[output circuit : open collector]  
 [General output : PNP output]



- Outputs the signals of incremental encoder origin Z phase pulse. (open collector)
- Maximum voltage : DC24V
- Maximum current : 50mA


**PNP**

General output : PNP output :  
 External power supply DC24V is taken in as common power supply, and DC24V is outputted when a general-purpose output turns on.

■ Connection example with generic output circuit

● Generic output circuit OUT1~OUT8

[output circuit : open collector]  
 [General output : NPN output]




- Connected with photo coupler or relay circuit.
- OUT-PWR(outer power source)specification  
 Power source voltage range : DC5V  $\pm$ 5% ,  
 DC12V~24V  $\pm$ 10%  
 Minimum current : 20mA
- Specification of input circuit power  
 Power source voltage range : DC5V  $\pm$ 5%  
 Power source voltage range : DC12V~15V  $\pm$ 10%  
 Power source voltage range : DC24V  $\pm$ 10%
- Maximum current : DC5V.....10mA  
 Maximum current : DC12V~15V.....30mA  
 Maximum current : DC24V.....50mA

### 3. Wiring [Low Voltage Circuit/Wiring Example of CN1 output Circuit]

● Generic output circuit OUT1~OUT8

[output circuit : open collector]  
 [General output : PNP output]




**PNP**

General output : PNP output :  
 External power supply DC24V is taken in as common power supply, and DC24V is outputted when a general-purpose output turns on.

■ Connection example with analog output circuit

● Analog monitor output circuit



### 3. Wiring [Low Voltage circuit/CN2 Wiring · Incremental encoder]

■ CN2 terminal layout

10	8	6	4	2	
	9	7	5	3	1
20	18	16	14	12	
	19	17	15	13	11

■ Wiring for Wire-saving incremental encoder

Wire-saving Incremental encoder				
Terminal No.	Signal name	Description	Servo motor lead type wire color	Servo motor canon type terminal number
1	-	-	-	-
2				
3	A0	A phase position signal output	blue	A
4	A0		brown	D
5	BO	B phase position signal output	green	B
6	BO		purple	E
7	ZO	Z phase position signal output	white	F
8	ZO		yellow	G
9	5V	5V power source	(red)	(J)
10	SG	5V power source common	(black)	(N)
11	SG	5V power source common	(black)	(N)
12	5V	5V power source	(red)	(J)
13	-	-	-	-
14				
15				
16	SG	5V power source common	(black)	(N)
17	5V	5V power source	(red)	(J)
18	SG	5V power source common	(black)	(N)
19	5V	5V power source	red	J
20	SG	5V power source common	black	N
G Plate	shield wire			H

- Refer to page 3-37 for how to process the shield wires.
- The number of power terminals for servo motor encoder connections varies depending on the encoder cable length. Refer to the following table.

Encoder cable length	Power connection (CN2) terminal number for servo motor encoder	
	5V power source terminal number	5V power source common terminal number
Less than 5m	19	20
Less than 10m	19, 17	20, 18
Less than 20m	19, 17, 12	20, 18, 11
Less than 30m	19, 17, 12, 9	20, 18, 11, 16, 10

- Use twisted pair and outer insulated shield cables.
- CN2 plug : 10120-3000PE
- CN2 shell : 10320-52A0-008
- Servo motor encoder : canon plug
  - JL04V-6A20-29S-J1(A72)
  - JL04V-8A20-29S-J1-EB
  - JL04V-6A20-29S-J1-EB
  - MS3108B20-29S
  - MS3106B20-29S

# 3. Wiring

## [Low Voltage circuit/CN2 Wiring

### - Absolute encoder with incremental signal]

#### ■ CN2 terminal layout

10	8	6	4	2
	9	7	5	3
20	18	16	14	12
	19	17	15	13

#### ■ Wiring for Battery backup method absolute encoder/Absolute encoder without battery/Absolute encoder for incremental system

Battery backup method absolute encoder/Absolute encoder without battery/Absolute encoder for incremental system				
Terminal No.	Signal name	Description	Servo motor lead type wire color	Servo motor canon type terminal number
1	BAT+	Battery	pink	T
2	BAT-		purple	S
3	-	-	-	-
4				
5				
6				
7				
8				
9	5V	5V power source	(red)	(H)
10	SG	5V power source common	(black)	(G)
11	SG	5V power source common	(black)	(G)
12	5V	5V power source	(red)	(H)
13	ES	Position data output	brown	E
14	ES		blue	F
15	-	-		
16	SG	5V power source common	(black)	(G)
17	5V	5V power source	(red)	(H)
18	SG	5V power source common	(black)	(G)
19	5V	5V power source	red	H
20	SG	5V power source common	black	G
G Plate	shield wire			J

No battery wiring necessary for Absolute encoder without battery/Absolute encoder for incremental system

- Refer to page 3-37 for how to process the shield wires.
- The number of power terminals for servo motor encoder connections varies depending on the encoder cable length. Refer to the following table.

Encoder cable length	Power connection (CN2) terminal number for servo motor encoder	
	5V power source terminal number	5V power source common terminal number
Less than 10m	19	20
Less than 25m	19, 17	20, 18
Less than 40m	19, 17, 12	20, 18, 11

- Use twisted pair and outer insulated shield cables.
- CN 2 plug : 10120-3000PE
- CN 2 shell : 10320-52A0-008
- Servo motor encoder : canon plug
  - JL04V-6A20-29S-J1(A72)
  - JL04V-8A20-29S-J1-EB
  - JL04V-6A20-29S-J1-EB
  - MS3108B20-29S
  - MS3106B20-29S

### 3. Wiring

### [Low Voltage circuit/CN2 Wiring

### - Absolute encoder with incremental signal]

■ CN2 terminal layout

10	8	6	4	2
	9	7	5	3
20	18	16	14	12
	19	17	15	13

■ Absolute encoder with incremental output

Absolute encoder with incremental output				
Terminal No.	Signal name	Description	Servo motor lead type wire color	Servo motor canon type terminal number
1	BAT+	Battery	light orange or clear	T
2	BAT-		brown	S
3	A0	A phase position signal output	pink	A
4	A0		red	B
5	BO	B phase position signal output	blue	C
6	BO		green	D
7	ZO	Z phase position signal output	yellow	K
8	ZO		Orange	L
9	5V	5V power source	(white)	(H)
10	SG	5V power source common	(black)	(G)
11	SG	5V power source common	(black)	(G)
12	5V	5V power source	(white)	(H)
13	PS	Position data output	Pale blue	E
14	PS		purple	F
15	ECLR	Clear signal	Dark green or light green	R
16	SG	5V power source common	(black)	(G)
17	5V	5V power source	(white)	(H)
18	SG	5V power source common	(black)	(G)
19	5V	5V power source	white	H
20	SG	5V power source common	black	G
G Plate		shield wire		J


- Refer to page 3-37 for how to process the shield wires.
- The number of power terminals for servo motor encoder connections varies depending on the encoder cable length. Refer to the following table.

Encoder cable length	Power connection (CN2) terminal number for servo motor encoder	
	5V power source terminal number	5V power source common terminal number
Less than 5m	19	20, 16
Less than 10m	19, 17	20, 16, 18
Less than 20m	19, 17, 12	20, 16, 18, 11
Less than 30m	19, 17, 12, 9	20, 16, 18, 11, 10

- Use twisted pair and outer insulation shield cables.
- CN2 plug : 10120-3000PE
- CN2 shell : 10320-52A0-008
- Servo motor encoder : canon plug
  - JL04V-6A20-29S-J1(A72)
  - JL04V-8A20-29S-J1-EB
  - JL04V-6A20-29S-J1-EB
  - MS3108B20-29S
  - MS3106B20-29S

### **3. Wiring [Low Voltage circuit/CN2 Wiring - Absolute sensor]**

■ CN2 terminal layout



■ Request method absolute encoder

Request method absolute encoder				
Terminal No.	Signal name	Description	Servo motor lead type wire color	Servo motor canon type terminal number
1	-	-	-	-
2	-	-	-	-
3	REQ+	Requested Signal	purple or orange	N
4	REQ-		green	P
5	-	-	-	-
6	-	-	-	-
7	-	-	-	-
8	-	-	-	-
9	5V	5V power source	(red)	(H)
10	SG	5V power source common	(black)	(G)
11	SG	5V power source common	(black)	(G)
12	5V	5V power source	(red)	(H)
13	PS	Position data output	brown	E
14	PS		blue	F
15	ECLR	Clear signal	white	R
16	SG	5V power source common	yellow	(G)
17	5V	5V power source	(red)	(H)
18	SG	5V power source common	(black)	(G)
19	5V	5V power source	red	H
20	SG	5V power source common	black	G
G Plate		shield wire		J

- Refer to page 3-37 for how to process the shield wires.
- The number of power terminals for servo motor encoder connections varies depending on the encoder cable length. Refer to the following table.

Encoder cable length	Power connection (CN2) terminal number for servo motor encoder	
	5V power source terminal number	5V power source common terminal number
Less than 5m	19,9	20,16,10
Less than 30m	19,9,17,12	20,16,10,18,11

- Use twisted pair and outer insulated shield cables.
- CN 2 plug : 10120-3000PE
- CN 2 shell : 10320-52A0-008
- Servo motor encoder : canon plug
  - JL04V-6A20-29S-J1(A72)
  - JL04V-8A20-29S-J1-EB
  - JL04V-6A20-29S-J1-EB
  - MS3108B20-29S
  - MS3106B20-29S

### **3. Wiring [Low Voltage circuit/CN2 Wiring - Absolute sensor]**

Wiring between servo motor encoder and external encoder at full-closed control

Battery backup method absolute encoder		
Terminal No.	Signal name	Description
1	BAT+	Battery
2	BAT-	
9	5V	5V power source
10	SG	5V power source common
11	SG	5V power source common
12	5V	5V power source
13	ES	Position data output
14	ES	
15	-	-
16	SG	5V power source common
17	5V	5V power source
18	SG	5V power source common
19	5V	5V power source
20	SG	5V power source common
External encoder signal		
Terminal No.	Signal name	Description
3	A	A phase position signal output
4	A	
5	B	B phase position signal output
6	B	
7	Z	Z phase position signal output
8	Z	

Absolute encoder without battery/Absolute encoder for incremental system		
Terminal No.	Signal name	Description
1	-	-
2	-	-
9	5V	5V power source
10	SG	5V power source common
11	SG	5V power source common
12	5V	5V power source
13	ES	Position data output
14	ES	
15	-	-
16	SG	5V power source common
17	5V	5V power source
18	SG	5V power source common
19	5V	5V power source
20	SG	5V power source common
External encoder signal		
Terminal No.	Signal name	Description
3	A	A phase position signal output
4	A	
5	B	B phase position signal output
6	B	
7	Z	Z phase position signal output
8	Z	

Users must prepare the power supply for external encoder signals.

The external encoder's signal ground(SG) must be connected to the signal ground(SG) of the servo amplifier CN2.

Wire-saving incremental encoder		
Terminal No.	Signal name	Description
1	-	-
2	-	-
3	A0	A phase position signal output
4	A0	
5	B0	B phase position signal output
6	B0	
7	Z0	Z phase position signal output
8	Z0	
11	SG	5V power source common
12	5V	5V power source
17	5V	5V power source
18	SG	5V power source common
19	5V	5V power source
20	SG	5V power source common
External encoder signal		
Terminal No.	Signal name	Description
9	A	A phase position signal output
10	A	
13	B	B phase position signal output
14	B	
15	Z	Z phase position signal output
16	Z	

Users must prepare the power supply for external encoder signals

The external encoder's signal ground(SG) must be connected to the signal ground(SG) of the servo amplifier CN2.

# 3. Wiring

# [Power Supply · Peripherals]

## ■ Power Capacity · Peripherals Examples

### [AC200V input type]

Input Voltage	Servo amplifier capacity RS1 * □□A	Servo motor model number	Rated Output(W)	Rated main power supply (KVA)	Power supply control (VA)	Circuit breaker	Noise filter (EMC) corresponding time	Electro magnetic contactor
AC 200V	01	Q1AA04003D	30	0.2	40	NF30 shape 10A Manufactured by Mitsubishi Ltd.	RF3020-DLC Manufactured by RASMI	S-N10 Manufactured by Mitsubishi Ltd.
		Q1AA04005D	50	0.2				
		Q1AA04010D	100	0.3				
		Q1AA06020D	200	0.8				
		Q2AA04006D	60	0.3				
		Q2AA04010D	100	0.4				
		Q2AA05005D	50	0.3				
		Q2AA05010D	100	0.4				
		Q2AA05020D	200	0.8				
		Q2AA07020D	200	0.8				
		Q2AA07030D	300	1.0				
		R2AA04003F	30	0.2				
		R2AA04005F	50	0.2				
		R2AA04010F	100	0.4				
		R2AA06010F	100	0.4				
	R2AA06020F	200	0.8					
	R2AA08020F	200	0.8					
	03	Q1AA06040D	400	1.0				
		Q1AA07075D	750	1.7				
		Q2AA07040D	400	1.3				
		Q2AA07050D	500	1.5				
		Q2AA08050D	500	1.5				
		Q2AA13050H	500	1.4				
		R2AA06040F	400	1.0				
		R2AA08040F	400	1.0				
	R2AA08075F	750	1.7					
	05	Q1AA10100D	1000	2.5				
		Q1AA10150D	1500	3.0				
		Q1AA12100D	1000	2.5				
		Q2AA08075D	750	2.0				
		Q2AA08100D	1000	2.5				
		Q2AA10100H	1000	2.5				
		Q2AA10150H	1500	3.0				
		Q2AA13100H	1000	2.5				
		Q2AA13150H	1500	3.0				
		Q2AA13100D	1000	2.5				
Q2AA13150D		1500	3.0					

AC 100V	01	Q1EA04003D	30	0.2	40	NF30 shape 10A Manufactured by Mitsubishi Ltd.	RF1010-DLC Manufactured by RASMI	S-N10 Manufactured by Mitsubishi	
		Q1EA04005D	50	0.3					
		Q1EA04010D	100	0.5					
		Q2EA04006D	60	0.3					
		Q2EA04010D	100	0.5					
		Q2EA05005D	50	0.3					
		Q2EA05010D	100	0.5					
		R2EA04003F	30	0.2					
		R2EA04005F	50	0.2					
		R2EA04008F	80	0.4					
		R2EA06010F	100	0.5					
		03	Q1EA06020D	200					0.5
			Q2EA05020D	200					0.5
			Q2EA07020D	200					0.5
			R2EA06020F	200					0.8

● Recommended surge protector : R·A·V-781BXZ-2A Manufactured by Okaya Electric Industries Co.,Ltd.



### 3. Wiring

### [Power Supply - Peripherals]

#### [AC400V input type]

Input Voltage	Servo amplifier capacity RS1 * □□A	Servo motor model number	Rated Output(W)	Rated main power supply (KVA)	Power supply control (VA)	Circuit breaker	Noise filter (EMC) corresponding time	Electro magnetic contactor
AC 400V	02	Q2CA08050H	500	1.2	40	<b>NF50 Shape 10A</b> Manufactured by Mitsubishi Ltd	<b>RF3010-DLC</b> Manufactured by RASMI	<b>H10C</b> Manufactured by HitachiCo.,Ltd
		Q2CA10100H	1000	2.1	40			
		Q2CA13150H	1500	3.1	40			
	05	Q2CA13200H	2000	4.1	40	<b>NF50 Shape 20A</b> Manufactured by Mitsubishi Ltd	<b>RF3020-DLC</b> Manufactured by RASMI	<b>H20</b> Manufactured by HitachiCo.,Ltd
		Q2CA18350H	3500	7.1	40			
	10	Q2CA18450H	4500	9.2	40	<b>NF50 Shape 50A</b> Manufactured by Mitsubishi Ltd	<b>RF3040-DLC</b> Manufactured by RASMI	<b>H20</b> Manufactured by HitachiCo.,Ltd
		Q2CA22550H	5500	11.2	40			
		Q2CA22700H	7000	14.3	40			

# 3. Wiring

[Wire diameter]

## Recommended Wire Diameter Examples

### [AC200V input type]

Input Voltage	Servo motor model number	Motor power wire diameter (U · V · W · ⊕)		servo amplifier combination	Main power supply wire diameter (R · S · T · ⊕)		Control power wire diameter	Regenerative resistor, DC reactor wire diameter	CN 1 · CN 2 Signal wire diameter
		mm <sup>2</sup>	AWG No		mm <sup>2</sup>	AWG No			
AC200v	Q1AA04003D	0.5	#20	RS1□01	1.25	#16	AWG 16	-	-
	Q1AA04005D								
	Q1AA04010D								
	Q1AA06020D	0.75	#18	RS1□03	2.0	#14			
	Q1AA06040D								
	Q1AA07075D	3.5	#12	RS1□05	3.5	#12			
	Q1AA10100D								
	Q1AA10150D								
	Q1AA12100D	0.5	#20	RS1□01	1.25	#16			
	Q2AA04006D								
	Q2AA04010D								
	Q2AA05005D	0.75	#18	RS1□01	1.25	#16			
	Q2AA05010D								
	Q2AA05020D								
	Q2AA07020D								
	Q2AA07030D	0.75	#18	RS1□03	2.0	#14			
	Q2AA07040D								
	Q2AA07050D								
	Q2AA08050D	2.0	#14	RS1□03	2.0	#14			
	Q2AA13050H								
	Q2AA08075D								
	Q2AA08100D	0.75	#18	RS1□05	3.5	#12			
	Q2AA10100H								
	Q2AA10150H								
	Q2AA13100H	3.5	#12	RS1□05	3.5	#12			
	Q2AA13150H								
	R2AA04003F	0.5	#20	RS1□01	1.25	#16			
	R2AA04005F								
R2AA04010F									
R2AA06010F									
R2AA06020F	0.75	#18	RS1□01	1.25	#16				
R2AA08020F									
R2AA06040F	0.75	#18	RS1□03	2.0	#14				
R2AA08040F									
R2AA08075F									

AC100V	Q1EA04003D	0.5	#20	RS1□01	1.25	#16	AWG 16	-	-
	Q1EA04005D								
	Q1EA04010D								
	Q2EA04006D	0.75	#18	RS1□03	2.0	#14			
	Q2EA04010D								
	Q2EA05005D	0.75	#18	RS1□03	2.0	#14			
	Q2EA05010D								
	Q1EA06020D								
	Q2EA05020D	0.5	#20	RS1□01	1.25	#16			
	Q2EA07020D								
	R2EA04003F								
	R2EA04005F								
	R2EA04008F	0.75	#18	RS1□03	2.0	#14			
	R2EA06010F								
R2EA06020F	0.75	#18	RS1□03	2.0	#14				
R2EA06020F									

- The information in this table is based on rated current flowing through three bundled lead wires in ambient temperature of 40°C.
- When wires are bundled or put into a wire-duct, take the allowable current reduction ratio into account.
- If ambient temperature is high, service life of the wires becomes shorter due to heat-related deterioration. In this case, use heat-resistant vinyl wires.
- The use of heat-resistant vinyl wires (HIV) is recommended.
- Depending on the servo motor capacity, thinner electric wires than indicated in the above table can be used for the main circuit power input terminal.

# 3. Wiring

[Wire diameter]

## 【AC400V input type】

Input Voltage	Servo motor model number	Motor power wire diameter (U · V · W · ⊕)		servo amplifier combination	Main power supply wire diameter (R · S · T · ⊕)		Control power wire diameter	Regenerative resistor, DC reactor wire diameter	C N 1 · C N 2 Signal wire diameter
		mm <sup>2</sup>	AWG No		mm <sup>2</sup>	AWG No			
AC400v	Q2CA08050H	1.25	#16	RS1□02	1.25	#16	AWG 16	AWG 16 1.25 mm <sup>2</sup>	AWG 24 0.2 mm <sup>2</sup>
	Q2CA10100H								
	Q2CA13150H								
	Q2CA13200H	1.25	#16	RS1□05	1.25	#16		AWG 14 2.0 mm <sup>2</sup>	
	Q2CA18350H	2.0	#14		2.0	#14			
	Q2CA18450H	2.0	#14		2.0	#14			
	Q2CA22550H	5.5	#10	RS1□10	5.5	#10		AWG 12 3.5 mm <sup>2</sup>	
Q2CA22700H	5.5	#10	5.5		#10				

## ■ Connector for Servo Amplifier

### 【AC200V input type(Control Power AC200V input type)】

	Name	Sanyo Denki Model No.	Model No. of applicable amplifier	Name	Manufacturer's model No.	Manufacturer	Recommended tightening torque
①	CN1	AL-00608710	All	Plug	10114-3000PE	Sumitomo 3M Ltd.	0.196±0.049 N · m (jack-screw)
				Shell kit	10314-52A0-008		
②	CN2	AL-00385596	All	Plug	10120-3000PE	Phoenix Contact Ltd.	0.5~0.6 N · m
				Shell kit	10320-52A0-008		
③	CNA	AL-00329461-01	RS1□01~RS1□05 (200V input only)	Plug	MSTB2.5/5-STF-5.0 8	Phoenix Contact Ltd.	0.5~0.6 N · m
④	CNA	AL-00329461-02	RS1□01~RS1□03 (100V input only)	Plug	MSTB2.5/4-STF-5.0 8		
⑤	CNB	AL-Y0000988-01	RS1□01~RS1□05 (for both 100V·200V)	Plug	IC2.5/6-STF-5.08	Phoenix Contact Ltd.	0.5~0.6 N · m
⑥	CNC	AL-00329458-01	RS1□01~RS1□05 (for both 100V·200V)	Plug	IC2.5/3-STF-5.08		
⑦	PC	AL-00490833-01	All	Communication cable for Set-up software - 『R-Setup』			

Combination	Sanyo Denki Model No.	Model No. of applicable amplifier
Set of ①+②	AL-00661729	RS1□01~RS1□05
Set of ①+②+③+⑥	AL-00661731	RS1□01~RS1□05 (200V input only)
Set of ①+②+④+⑥	AL-00492384	RS1□01~RS1□05 (100V input only)

### 【AC200V input type(Control Power DC24V input type)】

	Name	Sanyo Denki Model No.	Model No. of applicable amplifier	Name	Manufacturer's model No.	Manufacturer	Recommended tightening torque
①	CN1	AL-00608710	All	Plug	10114-3000PE	Sumitomo 3M Ltd.	0.196±0.049 N · m (jack-screw)
				Shell kit	10314-52A0-008		
②	CN2	AL-00385596	All	Plug	10120-3000PE	Phoenix Contact Ltd.	0.5~0.6 N · m
				Shell kit	10320-52A0-008		
③	CNA	AL-Y0000988-02	All	Plug	IC2.5/7-STF-5.08	Phoenix Contact Ltd.	0.5~0.6 N · m
④	CNB	AL-00329460	All	Plug	MSTB2.5/2-STF-5.08		
⑤	CNC	AL-00329458-01	All	Plug	IC2.5/3-STF-5.08	Phoenix Contact Ltd.	0.5~0.6 N · m
⑥	PC	AL-00490833-01	All	Communication cable for Set-up software - 『R-Setup』			

Combination	Sanyo Denki Model No.	Model No. of applicable amplifier
Set of ①+②	AL-00661729	RS1□01~RS1□05
Set of ①+②+③+④+⑤	AL-00667184	RS1□01~RS1□05

- To have an insulation distance between the main circuit wires and between the main circuit and the signal circuit wires, the use of pole terminals with insulation sleeves is recommended. (If the wire in use is thicker than AWG12, these cannot be used.)

### 3. Wiring

[Wire diameter]

#### [AC400V input type]

	Name	Sanyo Denki Model No.	Model No. of applicable amplifier	Name	Manufacturer's model No.	Manufacturer	Recommended tightening torque
①	CN1	AL-00385594	All	Plug	10150-3000PE	Sumitomo 3M Ltd.	0.196±0.049 N·m (jack-screw)
				Shell kit	10350-52A0-008		
②	CN2	AL-00385596	All	Plug	10120-3000PE		
				Shell kit	10320-52A0-008		
③	CNA	AL-Y0003760	RS1□02,RS1□05	Plug	IC2.5/6-STF-5.08	Phoenix Contact Ltd.	0.5~0.6 N·m
④	CNB	AL-00329460	All	Plug	MSTB2.5/2-STF-5.08		0.5~0.6 N·m
⑤	CNC	AL-Y0003761	RS1□02,RS1□05	Plug	IC2.5/3-STF-5.08		0.5~0.6 N·m
⑥	PC	AL-00490833-01	All	Communication cable for Set-up software - 『 R-Setup 』			

Combination	Sanyo Denki Model No.	Model No. of applicable amplifier
Set of ①+②	AL-00292309	All
Set of ①+②+③+④+⑤	AL-00661738	RS1□02,RS1□05

- To have an insulation distance between the main circuit wires and between the main circuit and the signal circuit wires, the use of pole terminals with insulation sleeves is recommended. (If the wire in use is thicker than AWG12, these cannot be used.)


# 3. Wiring

## [How to process CN1/CN2 shields]

### ■ How to process CN1/CN2 shields.


The drawings below show how to process shields for CN1/CN2 connectors. There are two ways to process shields; clamping and soldering.

#### ● Clamping



\* Compression insert should only be attached before soldering the cable to the connector.

#### ● Soldering (Conditions 1 and 2 are the same as for clamping.)



## 3. Wiring [How to process CN1/CN2 shields]

● **Applicable  $\phi A$  measurements for CN1,CN2.**

Applicable  $\phi A$  measurements are shown below. Compression insert is not required if the  $\phi A$  measurements are within these.

Connector NO.	Input	Applicable $\phi A$ measurement	Connector model number	Manufacturer
CN1	AC200V	7.0~8.0mm	10114-3000PE 10314-52A0-008	Sumitomo 3M Ltd.
	AC400V	15.0~16.5mm	10150-3000PE 10350-52A0-008	Sumitomo 3M Ltd.
CN2		10.5~12.0mm	10120-3000PE 10320-52A0-008	Sumitomo 3M Ltd.

# [Parameter]

◆	Parameter List .....	5-1
◆	Parameter setting value 【Group0】 【Group1】 ...	5-7
◆	Parameter setting value 【Group2】 .....	5-9
◆	Parameter setting value 【Group3】 .....	5-10
◆	Parameter setting value 【Group4】 【Group5】 ..	5-13
◆	Parameter setting value 【Group8】 .....	5-14
◆	Parameter setting value 【Group9】 .....	5-19
◆	Parameter setting value 【GroupA】 .....	5-21
◆	Parameter setting value 【GroupB】 .....	5-25
◆	Parameter setting value 【GroupC】 .....	5-28
◆	System parameter setting value .....	5-31

# 1. Prior to Use

## [Servo motor model number]

### ■ General Parameter Group 0 [Auto-tuning setting]

Page	Symbol	Name	Standard Value	Unit	Display Range	Reference page	Type
00	TUNMODE	Tuning mode	00: AutoTun	—	00~02	5-7	S/C
01	ATCHA	Automatic Tuning Characteristic	00: Positioning1	—	00~04	5-7	S/C
02	ATRES	Automatic Tuning Response	5	—	1~30	5-7	S/C
03	ATSAVE	Automatic Tuning, Automatic Parameter Saving	00: Auto_Saving	—	00~01	5-7	S/C
10	ANFILTC	Automatic Notch Filter Tuning, Torque Command	50	%	10~100	5-7	S/C
20	ASUPTC	Automatic Vibration Suppressor Frequency Tuning, Torque Command	25	%	10~100	5-7	S/C
21	ASUPFC	Automatic Vibration Suppressor Frequency Tuning, Friction Compensation Value	5	%	0~50	5-7	S/C

### ■ General Parameter Group 1 [Basic controlling parameter setting]

Page	Symbol	Name	Standard Value	Unit	Display Range	Reference page	Type
01	PCFIL	Position command filter	0.0	ms	0.0~2000.0	5-7	S/C
02	KP1	Position Loop Proportional Gain 1	30	1/s	1~3000	5-7	S/C
03	TP1	Position Loop Integral Time Constant 1	1000.0	ms	0.5~1000.0	5-7	S/C
04	TRCPGN	Higher Tracking Control, Position Compensation Gain	0	%	0~100	5-8	S/C
05	FFGN	Feed Forward Gain	0	%	0~100	5-8	S/C
08	FFFIL	Feed Forward Filter	2000	Hz	1~2000	5-8	S/C
10	VCFIL	Velocity Command Filter	2000	Hz	1~2000	5-8	S/C
12	VDFIL	Velocity Feedback Filter	1500	Hz	1~2000	5-8	S/C
13	KVP1	Velocity Loop Proportional Gain 1	50	Hz	1~2000	5-8	S/C
14	TV1	Velocity Loop Integral Time Constant 1	20.0	ms	0.5~1000.0	5-8	S/C
15	JRAT1	Load Inertia Ratio (Load Mass Ratio) 1	100	%	0~15000	5-8	S/C
16	TRCVGN	Higher Tracking Control, Velocity Compensation Gain	0	%	0~100	5-8	S/C
17	AFBK	Acceleration Feedback Gain	0.0	%	-100.0~100.0	5-8	S/C
18	AFBFIL	Acceleration Feedback Filter	500	Hz	1~2000	5-8	S/C
20	TCFIL1	Torque Command Filter 1	600	Hz	1~2000	5-8	S/C
21	TCFILOR	Torque Command Filter Order	2	Order	1~3	5-8	S/C

\*When manual tuning, set the [Page 16: high tracking control position compensation gain] at 100 % to bring conditions in line with Q-Series standard characteristics.

### ■ General Parameter Group 2 [Vibration suppressing control / Notch filter / Disturbance observer setting]

Page	Symbol	Name	Standard Value	Unit	Display Range	Reference page	Type
00	SUPFRQ1	Vibration Suppressor Frequency 1	500	Hz	5~500	5-9	S/C
01	SUPLV	Vibration Suppressor Level Selection	00	—	00~03	5-9	S/C
10	VCNFIL	Velocity Command, Notch Filter	500	Hz	50~500	5-9	S/C
20	TCNFILA	Torque Command, Notch Filter A	2000	Hz	100~2000	5-9	S/C
21	TCNFPA	TCNFILA, Low Frequency Phase Delay Improvement	00	—	00~02	5-9	S/C
22	TCNFILB	Torque Command, Notch Filter B	2000	Hz	100~2000	5-9	S/C
23	TCNFDB	TCNFILB, Depth Selection	00	—	00~03	5-9	S/C
24	TCNFILC	Torque Command, Notch Filter C	2000	Hz	100~2000	5-9	S/C
25	TCNFDC	TCNFILC, Depth Selection	00	—	00~03	5-9	S/C
26	TCNFILD	Torque Command, Notch Filter D	2000	Hz	100~2000	5-9	S/C
27	TCNFDD	TCNFILD, Depth Selection	00	—	00~03	5-10	S/C
30	OBCHA	Observer characteristic	00: Low	—	00~01	5-10	S/C
31	OBG	Observer Compensation Gain	0	%	0~100	5-10	S/C
32	OBLPF	Observer Output, Low Pass Filter	50	Hz	1~2000	5-10	S/C
33	OBNFIL	Observer Output, Notch Filter	2000	Hz	100~2000	5-10	S/C

NOTE) S/C in column 'Type' are supported for position /velocity/torque control mode and CAN open mode.

S in column 'Type' are supported for only position /velocity/torque control mode.

C in column 'Type' are supported for only CANopen mode.



# 1. Prior to Use

[Servo motor model number]

## ■ General Parameter Group 3 [Setting for gain switching control/vibration suppressing frequency switching]

Page	Symbol	Name	Standard Value	Unit	Display Range	Reference page	Type
00	KP2	Position Loop Proportional Gain 2	30	1/s	1~3000	5-10	S/C
01	TPI2	Position Loop Integral Time Constant 2	1000.0	ms	0.5~1000.0	5-10	S/C
02	KVP2	Velocity Loop Proportional Gain 2	50	Hz	1~2000	5-10	S/C
03	TVI2	Velocity Loop Integral Time Constant 2	20.0	ms	0.5~1000.0	5-10	S/C
04	JRAT2	Load Inertia Ratio (Load Mass Ratio) 2	100	%	0~15000	5-10	S/C
05	TCFIL2	Torque Command Filter 2	600	Hz	1~2000	5-10	S/C
10	KP3	Position Loop Proportional Gain 3	30	1/s	1~3000	5-11	S/C
11	TPI3	Position Loop Integral Time Constant 3	1000.0	ms	0.5~1000.0	5-11	S/C
12	KVP3	Velocity Loop Proportional Gain 3	50	Hz	1~2000	5-11	S/C
13	TVI3	Velocity Loop Integral Time Constant 3	20.0	ms	0.5~1000.0	5-11	S/C
14	JRAT3	Load Inertia Ratio (Load Mass Ratio) 3	100	%	0~15000	5-11	S/C
15	TCFIL3	Torque Command Filter 3	600	Hz	1~2000	5-11	S/C
20	KP4	Position Loop Proportional Gain 4	30	1/s	1~3000	5-11	S/C
21	TPI4	Position Loop Integral Time Constant 4	1000.0	ms	0.5~1000.0	5-11	S/C
22	KVP4	Velocity Loop Proportional Gain 4	50	Hz	1~2000	5-11	S/C
23	TVI4	Velocity Loop Integral Time Constant 4	20.0	ms	0.5~1000.0	5-11	S/C
24	JRAT4	Load Inertia Ratio (Load Mass Ratio) 4	100	%	0~15000	5-11	S/C
25	TCFIL4	Torque Command Filter 4	600	Hz	1~2000	5-11	S/C
30	GCFIL	Low Pass Filter of Gain Switching	0	ms	0~100	5-11	S/C
40	SUPFRQ2	Vibration Suppressor Frequency 2	500	Hz	5~500	5-12	S/C
41	SUPFRQ3	Vibration Suppressor Frequency 3	500	Hz	5~500	5-12	S/C
42	SUPFRQ4	Vibration Suppressor Frequency 4	500	Hz	5~500	5-12	S/C

## ■ General Parameter Group 4 [To set high setting control]

Page	Symbol	Name	Standard Value	Unit	Display Range	Reference page	Type
00	CVFIL	Command Velocity, Low Pass Filter	1000	Hz	1~2000	5-13	S/C
01	CVTH	Command Velocity Threshold	20	min <sup>-1</sup>	0~65535	5-13	S/C
02	ACCC0	Acceleration Compensation	0	× 50 Pulse	-9999~+9999	5-13	S/C
03	DECC0	Deceleration Compensation	0	× 50 Pulse	-9999~+9999	5-13	S/C

## ■ General Parameter Group 5 [To set CAN mode control]

Page	Symbol	Name	Standard Value	Unit	Display Range	Reference page	Type
00	NODE-ID	NODE ID	1	—	1~127	5-13	C
01	BITRATE	BITRATE	06:_500Kbps	—	00~08	5-13	C

# 1. Prior to Use

[Servo motor model number]

## ■ General Parameter Group 8 [Control system setting]

Page	Symbol	Name	Standard Value	Unit	Display Range	Reference page	Type
00	CMDPOL	Command Input Polarity	00:_PC+_VC+_TC+	—	00~07	5-14	S
01	VC/TC-DB	Analog Input Dead Band	00:_Disabled	—	00~01	5-14	S
02	VCZDAT	Analog Input Dead Band Width	0.0	mV	0.0~6553.5	5-14	S
11	PCPTYP	Position Command Pulse, Form Selection	00:_F-PC_R-PC	—	00~02	5-14	S
12	PCPPOL	Position Command Pulse, Count Polarity	00:_Type1	—	00~03	5-14	S
13	PCPFIL	Position Command Pulse, Digital Filter	00:_834nsec	—	00~07	5-15	S
14	PCPMUL	Position Command, Pulse Multiplier	1	—	1~63	5-15	S
15	GER1	Electric Gear Ratio 1	1/1	—	1/32767~32767/1	5-15	S
16	GER2	Electric Gear Ratio 2	1/1	—	1/32767~32767/1	5-15	S
17	EDGEPOS	Positioning method	00:_Pulse_Interval	—	00~01	5-15	S/C
18	PDEVMON	Inposition / Position Deviation Monitor	00:_After_Filter	—	00~01	5-15	S/C
19	CLR	Deviation Clear Selection	00:_Type1	—	00~03	5-15	S/C
20	VC1	Preset Velocity Command 1	100	min <sup>-1</sup>	0~32767	5-16	S
21	VC2	Preset Velocity Command 2	200	min <sup>-1</sup>	0~32767	5-16	S
22	VC3	Preset Velocity Command 3	300	min <sup>-1</sup>	0~32767	5-16	S
23	VCOMSEL	Velocity Compensation Command, Input Selection	02:_VCOMP	—	01~02	5-16	S
24	VCOMP	Preset Velocity Compensation Command	0	min <sup>-1</sup>	-9999~+9999	5-16	S
25	VCGN	Analog Velocity Command, Reference (Analog Velocity Compensation Command, Ref.)	500	min <sup>-1</sup> /V	0~4000	5-16	S
26	TVCACC	Velocity Command, Acceleration Time Constant	0	ms	0~16000	5-16	S
27	TVCDEC	Velocity Command, Deceleration Time Constant	0	ms	0~16000	5-16	S
28	VCLM	Velocity Limit	65535	min <sup>-1</sup>	1~65535	5-16	S/C
30	TCOMSEL	Torque Compensation Command, Input Selection	02:_TCOMP	—	01~02	5-16	S
31	TCOMP1	Preset Torque Compensation Command 1	0	%	-500~500	5-17	S/C
32	TCOMP2	Preset Torque Compensation Command 2	0	%	-500~500	5-17	S/C
33	TCGN	Analog Torque Command, Reference	50	%/V	0~500	5-17	S
34	TCOMPGN	Analog Torque Compensation Command, Reference	50	%/V	0~500	5-17	S
35	TLSEL	Torque Limit, Input Selection	00:_TCLM	—	00~03	5-17	S
36	TCLM	Internal Torque Limit	100	%	10~500	5-17	S
37	SQTCLM	Torque Limit at Sequence Operation	120	%	10~500	5-17	S
40	NEAR	In-Position Near Range	500	Pulse	1~65535	5-18	S/C
41	INP	In-Position Window	100	Pulse	1~65535	5-18	S/C
42	ZV	Speed Zero Range	50	min <sup>-1</sup>	50~500	5-18	S/C
43	LOWV	Low Speed Range	50	min <sup>-1</sup>	0~65535	5-18	S/C
44	VCOMP	Speed Matching Width	50	min <sup>-1</sup>	0~65535	5-18	S/C
45	VA	High Speed Range	1000	min <sup>-1</sup>	0~65535	5-18	S/C

■ As for the parameter, setting becomes effective after control power supply re-input.

# 1. Prior to Use

[Servo motor model number]

## ■ General Parameter Group 9 [Function enabling condition setting]

Page	Symbol	Name	Standard Value	Display Range	Reference page	Type
00	F-OT	Positive Over-Travel Function	0D:_CONT6_OFF	00~27	5-19,20	S/C
01	R-OT	Negative Over-Travel Function	0B:_CONT5_OFF	00~27	5-19,20	S/C
02	AL-RST	Alarm Reset Function	10:_CONT8_ON	00~27	5-19,20	S/C
03	ECLR	Absolute Encoder Clear Function	06:_CONT3_ON	00~27	5-19,20	S/C
04	CLR	Deviation Clear Function	08:_CONT4_ON	00~27	5-19,20	S/C
05	S-ON	SERVO-ON Function	02:_CONT1_ON	00~27	5-19,20	S
10	MS	Control Mode Switching Function	00:_Always_Disable	00~27	5-19,20	S/C
11	INH/Z-STP	Position Command Pulse Inhibit Function and Velocity Command Zero Clamp Function	00:_Always_Disable	00~27	5-19,20	S/C
12	GERS	Electric Gear Switching Function	00:_Always_Disable	00~27	5-19,20	S
13	GC1	Gain Switching Function, Select Input 1	00:_Always_Disable	00~2F	5-19,20	S/C
14	GC2	Gain Switching Function, Select Input 2	00:_Always_Disable	00~2F	5-19,20	S/C
15	SUPFSEL1	Vibration Suppressor Frequency, Select Input 1	00:_Always_Disable	00~2F	5-19,20	S/C
16	SUPFSEL2	Vibration Suppressor Frequency, Select Input 2	00:_Always_Disable	00~2F	5-19,20	S/C
17	PLPCON	Position Loop Proportional Control, Switching Function	01:_Always_Enable	00~2F	5-19,20	S/C
20	SP1	Preset Velocity Command, Select Input 1	00:_Always_Disable	00~27	5-19,20	S
21	SP2	Preset Velocity Command, Select Input 2	00:_Always_Disable	00~27	5-19,20	S
22	DIR	Preset Velocity Command, Direction of Move	00:_Always_Disable	00~27	5-19,20	S
23	RUN	Preset Velocity Command, Operation Start Signal Input	00:_Always_Disable	00~27	5-19,20	S
24	RUN-F	Preset Velocity Command, Positive Move Signal Input	00:_Always_Disable	00~27	5-19,20	S
25	RUN-R	Preset Velocity Command, Negative Move Signal Input	00:_Always_Disable	00~27	5-19,20	S
26	VLPCON	Velocity Loop Proportional Control, Switching Function	04:_CONT2_ON	00~2F	5-19,20	S/C
27	VCOMPS	Velocity Compensation Function, Select Input	00:_Always_Disable	00~27	5-19,20	S/C
30	TCOMPS1	Torque Compensation Function, Select Input 1	00:_Always_Disable	00~27	5-19,20	S/C
31	TCOMPS2	Torque Compensation Function, Select Input 2	00:_Always_Disable	00~27	5-19,20	S/C
32	TL	Torque Limit, Input Selection	0E:_CONT7_ON	00~27	5-19,20	S/C
33	OBS	Disturbance Observer	00:_Always_Disable	00~2F	5-19,20	S/C
40	EXT-E	External Error Input	00:_Always_Disable	00~27	5-19,20	S/C
41	DISCHARG	Main Power Discharge Function	01:_Always_Enable	00~27	5-19,20	S/C
42	EMR	Emergency Stop Function	07:_CONT3_OFF	00~27	5-19,20	S/C
50	HOME	Home Signal Input Selection	00:_Always_Disable	00~27	5-19,20	C
51	PROBE	Probe Signal Input Selection	00:_Always_Disable	00~27	5-19,20	C

# 1. Prior to Use

## [Servo motor model number]

### ■ General Parameter Group A [Setting for output condition of general output terminal/monitor output selection/setup software]

Page	Symbol	Name	Standard Value	Display Range	Reference page	Type
00	OUT1	General Purpose Output 1	18:_INP_ON	00~6B	5-21,22,23	S/C
01	OUT2	General Purpose Output 2	0C:_TLC_ON	00~6B	5-21,22,23	S/C
02	OUT3	General Purpose Output 3	02:_S-RDY_ON	00~6B	5-21,22,23	(S/C)
03	OUT4	General Purpose Output 4	0A:_MBR_ON	00~6B	5-21,22,23	(S/C)
04	OUT5	General Purpose Output 5	33:_ALM5_OFF	00~6B	5-21,22,23	(S/C)
05	OUT6	General Purpose Output 6	35:_ALM6_OFF	00~6B	5-21,22,23	(S/C)
06	OUT7	General Purpose Output 7	37:_ALM7_OFF	00~6B	5-21,22,23	(S/C)
07	OUT8	General Purpose Output 8	39:_ALM_OFF	00~6B	5-21,22,23	(S/C)
10	DMON	Digital Monitor, Output Signal Selection	00:Always_OFF	00~6B	5-21,22,23	(S/C)
11	MON1	Analog Monitor 1, Output Signal Selection	05:VMON_2mV/ min <sup>-1</sup>	00~15	5-21	S/C
12	MON2	Analog Monitor 2, Output Signal Selection	02:TCMON_2V/TR	00~15	5-21	S/C
13	MONPOL	Analog monitor output polarity	00:_MON1+_MON2+	00~08	5-24	S/C
20	COMAXIS	Setup Software, Communication Axis Number	01:_#1	01~0F	5-24	S/C
21	COMBAUD	Setup Software, Communication Baud Rate	05:_38400bps	00~05	5-24	S/C

NOTE) (S/C) in column 'Type' are only supported in AC400V Input type.

As for the parameter, setting becomes effective after control power supply re-input.

### ■ General Parameter Group B [Setting related to sequence/alarms]

Page	Symbol	Name	Standard Value	Unit	Display Range	Reference page	Type
00	JOGVC	JOG Velocity Command	50	min <sup>-1</sup>	0~32767	5-25	S/C
10	DBOPE	Dynamic Brake Action Selection	04:_SB_Free	—	00~05	5-25	S/C
11	ACTOT	Over-Travel Action Selection	00:_CMDINH_SB_SON	—	00~06	5-25	S
12	ACTEMR	Emergency Stop Operation	00:_SERVO-BRAKE	—	00~01	5-25	S/C
13	BONDLY	Delay Time of Engaging Holding Brake (holding brake holding delay time)	300	ms	0~1000	5-26	S/C
14	BOFFDLY	Delay Time of Releasing Holding Brake (holding brake release delay time)	300	ms	0~1000	5-26	S/C
15	BONBGN	Brake Operation Beginning Time	0	ms	0~65535	5-26	S/C
16	PFDDLY	Power Failure Detection Delay Time	32	ms	20~1000	5-26	S/C
20	OFWLV	Following Error Warning Level	65535	X1024 pulse	1~65535	5-26	S/C
21	OFLV	Following Error Limit	500	X1024 pulse	1~65535	5-26	S/C
22	OLWLV	Overload Warning Level	90	%	20~100	5-27	S/C
23	VFBALM	Speed Feedback Error (ALM_C3) Detection	01:_Enabled	—	00~01	5-27	S/C
24	VCALM	Speed Control Error (ALM_C2) Detection	00:_Disabled	—	00~01	5-27	S/C

As for the parameter, setting becomes effective after control power supply re-input.

### ■ General Parameter Group C [Encoder related setting]

Page	Symbol	Name	Standard Value	Unit	Display Range	Reference page	Type
00	ABS/INCSYS	Position detection system choice	00:_Absolute	--	00~01	5-28	S/C
01	ENFIL	Motor Incremental Encoder, Digital Filter	01:_220nsec	—	00~07	5-28	S/C
02	EX-ENFIL	External Incremental Encoder, Digital Filter	01:_220nsec	—	00~07	5-28	S/C
03	EX-ENPOL	External Encoder Polarity Invert	00:_Type1	—	00~07	5-29	S/C
04	PULOUTSEL	Encoder Pulse Divided Output, Selection	00:_Motor_Enc.	—	00~01	5-29	(S/C)
05	ENRAT	Encoder Output Pulse, Divide Ratio	1/1	—	1/8192~1/1	5-29	(S/C)
06	PULOUTPOL	Encoder Pulse Divided output, Polarity	00:_Type1	—	00~03	5-29	(S/C)
07	PSOFORM	Encoder Signal Output (PS), Format	00:_Binary	—	00~02	5-30	(S/C)
08	ECLRFUNC	Abusolute Encoder Clear Function Selection	00:_Status_MultiTurn	—	00~01	5-30	S/C

NOTE) (S/C) in column 'Type' are only supported in AC400V Input type.

As for the parameter, setting becomes effective after control power supply re-input.

# 1. Prior to Use

# [Servo motor model number]

To the customers using “Absolute encoder for incremental system” with R motor;

Please set the setting of the parameter of the table below value to the servo amplifier.

Group	Page	Symbol	Name	Setting value	contents
C	00	ABS/INCSYS	Position detection system choice	00:_Absolute	Absolute system
C	08	ECLRFUNC	Abusolute Encoder Clear Function Selection	01:_Status	Clear Only Encoder Status

As for the parameter, setting becomes effective after control power supply re-input.




To the customers using “Battery backup method absolute encoder” with incremental system with Q motor;

Please set the setting of the parameter of the table below value to the servo amplifier.

Group	Page	Symbol	Name	Setting value	contents
C	00	ABS/INCSYS	Position detection system choice	01:_Incremental	Absolute system
C	08	ECLRFUNC	Abusolute Encoder Clear Function Selection	01:_Status	Clear Only Encoder Status

As for the parameter, setting becomes effective after control power supply re-input.

## Encoder specifications

Type	Within 1 rotation	Multiple rotation	Notes
PA035C	131072(17bit)	65536(16bit)	Battery backup method absolute encoder
PA035S	131072(17bit)	—	Absolute encoder for incremental system 



To the customers using “Battery backup method absolute encoder” with incremental system; See the parameter set values for your servo amplifier in the table below and make sure to use them.

### General parameter

Group	Page	Symbol	Name	Setting value	contents
C	00	ABS/INCSYS	Position detection system choice	01:_Incremental	Absolute system
C	08	ECLRFUNC	Abusolute Encoder Clear Function Selection	01:_Status	Clear Only Encoder Status

## System parameter [for Setup software - R-Setup]

Page	Name	Display Range	Reference page	Type
00	Main Power, Input Type	2 ways(depending on the hardware type)	5-30	S/C
01	Motor Encoder Type	2 ways (depending on the hardware type)	5-30	S/C
02	Incremental Encoder, Function Setting	2 ways(depending on the hardware type)	5-30	S/C
03	Incremental Encoder, Resolution Setting	500P/R ~ 65535P/R	5-30	S/C
04	Absolute Encoder, Function Setting	4 ways (depending on the hardware type)	5-30	S/C
05	Absolute Encoder, Resolution Setting	11ways	5-30	S/C
06	Motor Type	—	5-31	S/C
08	Control Mode	7 ways	5-31	S/C
09	Position Loop Control and Position Loop Encoder Selection	2ways (depending on the hardware type)	5-31	S/C
0A	External Encoder, Resolution Setting	500P/R ~ 65535P/R	5-31	S/C
0B	Regenerative Resistor Selection	3ways	5-31	S/C

## 5. Parameter [Parameter setting value [Group0] [Group1] 1

### ■ General parameter Group 0 [Auto-tuning settings]

Page	Contents																		
00	Tuning mode [TUNMODE]																		
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~02</td> <td>—</td> <td>00:_AutoTun</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~02	—	00:_AutoTun	<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_AutoTun</td> <td>Automatic Tuning</td> </tr> <tr> <td>01:_AutoTun_JRAT-Fix</td> <td>Automatic Tuning (JRAT Fixed)</td> </tr> <tr> <td>02:_ManualTun</td> <td>Manual Tuning</td> </tr> </tbody> </table>	Selection	Contents	00:_AutoTun	Automatic Tuning	01:_AutoTun_JRAT-Fix	Automatic Tuning (JRAT Fixed)	02:_ManualTun	Manual Tuning			
Setting range	Unit	Standard value																	
00~02	—	00:_AutoTun																	
Selection	Contents																		
00:_AutoTun	Automatic Tuning																		
01:_AutoTun_JRAT-Fix	Automatic Tuning (JRAT Fixed)																		
02:_ManualTun	Manual Tuning																		
01	Automatic Tuning Characteristic [ATCHA]																		
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~04</td> <td>—</td> <td>00:_Positioning1</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~04	—	00:_Positioning1	<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_Positioning1</td> <td>Positioning Control 1</td> </tr> <tr> <td>01:_Positioning2</td> <td>Positioning Control 2</td> </tr> <tr> <td>02:_Positioning3</td> <td>Positioning Control 3</td> </tr> <tr> <td>03:_Trajectory1</td> <td>Trajectory Control</td> </tr> <tr> <td>04:_Trajectory2</td> <td>Trajectory Control (KP Fixed)</td> </tr> </tbody> </table>	Selection	Contents	00:_Positioning1	Positioning Control 1	01:_Positioning2	Positioning Control 2	02:_Positioning3	Positioning Control 3	03:_Trajectory1	Trajectory Control	04:_Trajectory2
Setting range	Unit	Standard value																	
00~04	—	00:_Positioning1																	
Selection	Contents																		
00:_Positioning1	Positioning Control 1																		
01:_Positioning2	Positioning Control 2																		
02:_Positioning3	Positioning Control 3																		
03:_Trajectory1	Trajectory Control																		
04:_Trajectory2	Trajectory Control (KP Fixed)																		
02	Automatic Tuning Response [ATRES]																		
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~30</td> <td>—</td> <td>5</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~30	—	5	Sets the auto-tuning response. The larger the set value, the higher the response. Make the setting suitable for rigidity of the device.											
Setting range	Unit	Standard value																	
1~30	—	5																	
03	Automatic Tuning, Automatic Parameter Saving [ATSAVE]																		
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~01</td> <td>—</td> <td>00:_Auto_Saving</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~01	—	00:_Auto_Saving	<p>The parameter (JRAT) obtained from auto-tuning result is automatically saved.</p> <table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_Auto_Saving</td> <td>Saves Parameter Automatically in JRAT1.</td> </tr> <tr> <td>01:_No_Saving</td> <td>Automatic Saving is Invalidity</td> </tr> </tbody> </table>	Selection	Contents	00:_Auto_Saving	Saves Parameter Automatically in JRAT1.	01:_No_Saving	Automatic Saving is Invalidity					
Setting range	Unit	Standard value																	
00~01	—	00:_Auto_Saving																	
Selection	Contents																		
00:_Auto_Saving	Saves Parameter Automatically in JRAT1.																		
01:_No_Saving	Automatic Saving is Invalidity																		
10	Automatic Notch Filter Tuning, Torque Command [ANFILTC]																		
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>10~100</td> <td>%</td> <td>50</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	10~100	%	50	Sets the torque command value applied to the motor at the time of auto-notch filter tuning. Larger value makes the tuning more accurate; however, note that it also makes the move of the machine larger.											
Setting range	Unit	Standard value																	
10~100	%	50																	
20	Automatic Vibration Suppressor Frequency Tuning, Torque Command [ASUPTC]																		
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>10~100</td> <td>%</td> <td>25</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	10~100	%	25	Sets the torque command value applied to the motor at the time of auto-vibration suppressing frequency tuning. Larger value makes the tuning more accurate, however, note that it also makes the move of the machine larger.											
Setting range	Unit	Standard value																	
10~100	%	25																	
21	Automatic Vibration Suppressor Frequency Tuning, Friction Compensation Value [ASUPFC]																		
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0~50</td> <td>%</td> <td>5</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0~50	%	5	Sets the friction torque compensation added to the motor torque at the time of auto-vibration suppressing frequency tuning. Set this value close to actual friction torque, and vibration suppressing frequency tuning will be more accurate.											
Setting range	Unit	Standard value																	
0~50	%	5																	

### ■ General parameter Group 1 [Basic control parameter setting]

Page	Contents						
01	Position command filter [PCFIL]						
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0.0~2000.0</td> <td>ms</td> <td>0.0</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0.0~2000.0	ms	0.0
Setting range	Unit	Standard value					
0.0~2000.0	ms	0.0					
02	Position Loop Proportional Gain 1 [KP1]						
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~3000</td> <td>1/s</td> <td>30</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~3000	1/s	30
Setting range	Unit	Standard value					
1~3000	1/s	30					
03	Position Loop Integral Time Constant 1 [TP11]						
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0.5~1000.0</td> <td>ms</td> <td>1000.0</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0.5~1000.0	ms	1000.0
Setting range	Unit	Standard value					
0.5~1000.0	ms	1000.0					

## 5. Parameter [Parameter setting value [Group1] ]

Page	Contents		
04	Higher Tracking Control, Position Compensation Gain [TRCPGN]		
	Setting range	Unit	Standard value
	0~100	%	0
05	Feed Forward Gain [FFGN]		
	Setting range	Unit	Standard value
	0~100	%	0
08	Feed Forward Filter [FFFIL]		
	Setting range	Unit	Standard value
	1~2000	Hz	2000
10	Velocity Command Filter [VCFIL]		
	Setting range	Unit	Standard value
	1~2000	Hz	2000
12	Velocity Feedback Filter [VDFIL]		
	Setting range	Unit	Standard value
	1~2000	Hz	1500
13	Velocity Loop Proportional Gain 1 [KVP1]		
	Setting range	Unit	Standard value
	1~2000	Hz	50
14	Velocity Loop Integral Time Constant 1 [TVI1]		
	Setting range	Unit	Standard value
	0.5~1000.0	ms	20.0
15	Load Inertia Ratio (Load Mass Ratio) 1 [JRAT1]		
	Setting range	Unit	Standard value
	0~15000	%	100
16	Higher Tracking Control, Velocity Compensation Gain [TRCVGN]		
	Setting range	Unit	Standard value
	0~100	%	0
17	Acceleration Feedback Gain [AFBK]		
	Setting range	Unit	Standard value
	-100.0~100.0	%	0.0
18	Acceleration Feedback Filter [AFBFIL]		
	Setting range	Unit	Standard value
	1~2000	Hz	500
20	Torque Command Filter 1 [TCFIL1]		
	Setting range	Unit	Standard value
	1~2000	Hz	600
21	Torque Command Filter Order [TCFILOR]		
	Setting range	Unit	Standard value
	1~3	Order	2

# 5. Parameter [Parameter setting value [Group2] ]

## ■ General parameter Group 2

[vibration suppressing control / notch filter / disturbance observer settings]

Page	Contents							
00	Vibration Suppressor Frequency 1 [SUPFRQ1]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>5~500</td> <td>Hz</td> <td>500</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	5~500	Hz	500	<p>Parameter to set the frequency of restricting vibration. Inside the servo amplifier, vibration suppressing frequency from 5~99Hz is treated by 1HzUnit, and that from 100~500Hz is by 10HzUnit. Even when set by lower unit than these, operations do not change. Vibration suppressing control is disabled with the set value of 500Hz. When auto-frequency tuning is executed, the tuning result is automatically saved in this parameter. Change this while the motor stops.</p>
Setting range	Unit	Standard value						
5~500	Hz	500						
01	Vibration Suppressor Level Selection [SUPLV]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~03</td> <td>—</td> <td>00</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~03	—	00	<p>Parameter to set the size of vibration suppressing control effect. The smaller the value is, the greater the effect will be. Change this while the motor stops.</p>
Setting range	Unit	Standard value						
00~03	—	00						
10	Velocity Command,Notch Filter [VCNFIL]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>50~500</td> <td>Hz</td> <td>500</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	50~500	Hz	500	<p>Parameter to set notch filter to velocity command. Sets the center frequency. Inside the servo amplifier, the center frequency from 50~99Hz is treated by 1HzUnit and that from 100~500Hz is by 10HzUnit. Even when set by lower unit than these, operations do not change. Filter is disabled with the set value of 500Hz.</p>
Setting range	Unit	Standard value						
50~500	Hz	500						
20	Torque Command,Notch Filter A [TCNFILA]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>100~2000</td> <td>Hz</td> <td>2000</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	100~2000	Hz	2000	<p>Parameter to set notch filter to torque command. Sets the center frequency. Inside the servo amplifier, the center frequency is treated by 10HzUnit. Even when set by lower unit than 1HzUnit, operations do not change. Filter is disabled with the set value of 2000Hz. When auto-notch filter tuning is executed, the tuning result is automatically saved in this parameter.</p>
Setting range	Unit	Standard value						
100~2000	Hz	2000						
21	TCNFILA, Low Frequency Phase Delay Improvement [TCNFPA]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~02</td> <td>—</td> <td>00</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~02	—	00	<p>Parameter to improve phase delay at lower frequency than center frequency of torque command notch filter A. The larger the value is, the greater the effect is. Same characteristics as the standard notch filter with the set value of 0.</p>
Setting range	Unit	Standard value						
00~02	—	00						
22	Torque Command,Notch Filter B [TCNFILB]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>100~2000</td> <td>Hz</td> <td>2000</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	100~2000	Hz	2000	<p>Parameter to set notch filter to torque command. Sets the center frequency. Inside the servo amplifier, the center frequency is treated by 10HzUnit. Even when set by 1HzUnit, operations do not change. Filter is disabled with the set value of 2000Hz.</p>
Setting range	Unit	Standard value						
100~2000	Hz	2000						
23	TCNFILB, Depth Selection [TCNFDB]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~03</td> <td>—</td> <td>00</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~03	—	00	<p>Parameter to set the depth of torque command notch filter B. The larger the value is, the shallower.</p>
Setting range	Unit	Standard value						
00~03	—	00						
24	Torque Command, Notch Filter C [TCNFILC]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>100~2000</td> <td>Hz</td> <td>2000</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	100~2000	Hz	2000	<p>Parameter to set notch filter to torque command. Sets the center frequency. Inside the servo amplifier, the center frequency is treated by 10HzUnit. Even when set by 1HzUnit, operations do not change. Filter is disabled with the set value of 2000Hz.</p>
Setting range	Unit	Standard value						
100~2000	Hz	2000						
25	TCNFILC, Depth Selection [TCNFDC]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~03</td> <td>—</td> <td>00</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~03	—	00	<p>Parameter to set the depth of torque command notch filter C. The larger the value is, the shallower.</p>
Setting range	Unit	Standard value						
00~03	—	00						
26	Torque Command,Notch Filter D [TCNFILD]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>100~2000</td> <td>Hz</td> <td>2000</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	100~2000	Hz	2000	<p>Parameter to set notch filter to torque command. Sets the center frequency. Inside the servo amplifier, the center frequency is treated by 10HzUnit. Even when set by 1HzUnit, operations do not change. Filter is disabled with the set value of 2000Hz.</p>
Setting range	Unit	Standard value						
100~2000	Hz	2000						




## 5. Parameter [Parameter setting value [Group2] [Group3] 1



Page	Contents													
27	TCNFIL, Depth Selection [TCNFDD]													
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~03</td> <td>—</td> <td>00</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~03	—	00	Parameter to set the depth of torque command notch filter D. The greater the value is, the shallower the depth will be.						
Setting range	Unit	Standard value												
00~03	—	00												
30	Observer characteristic [OBCHA]													
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~01</td> <td>—</td> <td>00:_Low</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~01	—	00:_Low	Selects the observer characteristics. <table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_Low</td> <td>For Low Cycle</td> </tr> <tr> <td>01:_Middle</td> <td>For Middle Cycle</td> </tr> </tbody> </table>		Selection	Contents	00:_Low	For Low Cycle	01:_Middle
Setting range	Unit	Standard value												
00~01	—	00:_Low												
Selection	Contents													
00:_Low	For Low Cycle													
01:_Middle	For Middle Cycle													
31	Observer Compensation Gain [OBG]													
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0~100</td> <td>%</td> <td>0</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0~100	%	0	Observer compensation gain. The larger the value is, the higher the suppression characteristics will be. However, if this is too large, oscillation may sometimes occur.						
Setting range	Unit	Standard value												
0~100	%	0												
32	Observer Output, Low Pass Filter [OBLPF]													
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~2000</td> <td>Hz</td> <td>50</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~2000	Hz	50	Sets the cut off frequency of observer output low pass filter. Filter is disabled with the set value of 2000Hz. When the observer characteristics are "01: Middle (For Middle Cycle)", the function is disabled.						
Setting range	Unit	Standard value												
1~2000	Hz	50												
33	Observer Output, Notch Filter [OBNFIL]													
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>100~2000</td> <td>Hz</td> <td>2000</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	100~2000	Hz	2000	Sets the center frequency of observer output notch filter. Inside the servo amplifier, the center frequency is treated by 10HzUnit. Even when set by 1HzUnit, operations do not change. Filter is disabled with the set value of 2000Hz.						
Setting range	Unit	Standard value												
100~2000	Hz	2000												

### ■ General parameter Group 3

#### [Gain switching control / vibration suppressing frequency switching settings]

Page	Contents							
00	Position Loop Proportional Gain 2 [KP2]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~3000</td> <td>1/s</td> <td>30</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~3000	1/s	30	Proportional gain for position controller.
Setting range	Unit	Standard value						
1~3000	1/s	30						
01	Position Loop Integral Time Constant 2 [TPI2]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0.5~1000.0</td> <td>ms</td> <td>1000.0</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0.5~1000.0	ms	1000.0	Integral time constant for position controller. Integral term is disabled (proportional control) with the set value of 1000.0ms.  Cannot be used when the position loop proportional control switching function is enabled.
Setting range	Unit	Standard value						
0.5~1000.0	ms	1000.0						
02	Velocity Loop Proportional Gain 2 [KVP2]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~2000</td> <td>Hz</td> <td>50</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~2000	Hz	50	Proportional gain for velocity controller. When load inertia is the one set by load inertia moment ratio (load mass ratio) 2, the response is this set value.
Setting range	Unit	Standard value						
1~2000	Hz	50						
03	Velocity Loop Integral Time Constant 2 [TVI2]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0.5~1000.0</td> <td>ms</td> <td>20.0</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0.5~1000.0	ms	20.0	Integral time constant for velocity controller. Enabled when velocity loop proportional control switching function is disabled. Integral term is disabled (proportional control) with the set value of 1000.0ms.
Setting range	Unit	Standard value						
0.5~1000.0	ms	20.0						
04	Load Inertia Ratio (Load Mass Ratio) 2 [JRAT2]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0~15000</td> <td>%</td> <td>100</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0~15000	%	100	Sets the inertia moment of load device to the motor inertia moment. Set value=JL/JM × 100% JL : Load inertia moment JM : Motor inertia moment
Setting range	Unit	Standard value						
0~15000	%	100						
05	Torque Command Filter 2 [TCFIL2]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~2000</td> <td>Hz</td> <td>600</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~2000	Hz	600	Parameter to set low pass filter to torque command. Sets the cut off frequency.
Setting range	Unit	Standard value						
1~2000	Hz	600						

## 5. Parameter [Parameter setting value [Group3] ]

Page	Contents							
10	Position Loop Proportional Gain 3 [KP3]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~3000</td> <td>1/s</td> <td>30</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~3000	1/s	30	Proportional gain for position controller.
Setting range	Unit	Standard value						
1~3000	1/s	30						
11	Position Loop Integral Time Constant 3 [TPI3]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0.5~1000.0</td> <td>ms</td> <td>1000.0</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0.5~1000.0	ms	1000.0	Integral time constant for position controller. Integral term is disabled (proportional control) with the set value of 1000.0ms.  Cannot be used when position loop proportional control switching function is enabled.
Setting range	Unit	Standard value						
0.5~1000.0	ms	1000.0						
12	Velocity Loop Proportional Gain 3 [KVP3]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~2000</td> <td>Hz</td> <td>50</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~2000	Hz	50	Proportional gain for velocity controller. When load inertia is the one set by load inertia moment ratio (load mass ratio) 2, the response is this set value.
Setting range	Unit	Standard value						
1~2000	Hz	50						
13	Velocity Loop Integral Time Constant 3 [TVI3]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0.5~1000.0</td> <td>ms</td> <td>20.0</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0.5~1000.0	ms	20.0	Integral time constant for velocity controller. This setting is enabled when velocity loop proportional control switching function is disabled. Integral term is disabled (proportional control) with the set value of 1000.0ms.
Setting range	Unit	Standard value						
0.5~1000.0	ms	20.0						
14	Load Inertia Ratio (Load Mass Ratio) 3 [JRAT3]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0~15000</td> <td>%</td> <td>100</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0~15000	%	100	Sets the inertia moment of load device to the motor inertia moment. Set value=JL/JM × 100% JL : Load inertia moment JM : Motor inertia moment
Setting range	Unit	Standard value						
0~15000	%	100						
15	Torque Command Filter 3 [TCFIL3]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~2000</td> <td>%</td> <td>600</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~2000	%	600	Parameter to set low pass filter to torque command. Sets the cut off frequency.
Setting range	Unit	Standard value						
1~2000	%	600						
20	Position Loop Proportional Gain 4 [KP4]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~3000</td> <td>1/s</td> <td>30</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~3000	1/s	30	Proportional gain for position controller.
Setting range	Unit	Standard value						
1~3000	1/s	30						
21	Position Loop Integral Time Constant 4 [TPI4]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0.5~1000.0</td> <td>ms</td> <td>1000.0</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0.5~1000.0	ms	1000.0	Integral time constant for position controller. Integral term is disabled (proportional control) with the set value of 1000.0ms.  Cannot be used when position loop proportional control switching function is enabled.
Setting range	Unit	Standard value						
0.5~1000.0	ms	1000.0						
22	Velocity Loop Proportional Gain 4 [KVP4]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~2000</td> <td>Hz</td> <td>50</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~2000	Hz	50	Proportional gain for velocity controller. When load inertia is the one set by load inertia moment ratio (load mass ratio) 2, the response is this set value.
Setting range	Unit	Standard value						
1~2000	Hz	50						
23	Velocity Loop Integral Time Constant 4 [TVI4]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0.5~1000.0</td> <td>ms</td> <td>20.0</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0.5~1000.0	ms	20.0	Integral time constant for velocity controller. This setting is enabled when velocity loop proportional control switching function is disabled. Integral term is disabled (proportional control) with the set value of 1000.0ms.
Setting range	Unit	Standard value						
0.5~1000.0	ms	20.0						
24	Load Inertia Ratio (Load Mass Ratio) 4 [JRAT4]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0~15000</td> <td>%</td> <td>100</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0~15000	%	100	Sets the inertia moment of load device to the motor inertia moment. Set value=JL/JM × 100% JL : Load inertia moment JM : Motor inertia moment
Setting range	Unit	Standard value						
0~15000	%	100						
25	Torque Command Filter 4 [TCFIL4]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~2000</td> <td>%</td> <td>600</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~2000	%	600	Parameter to set low pass filter to torque command. Sets the cut off frequency.
Setting range	Unit	Standard value						
1~2000	%	600						
30	Low Pass Filter of Gain Switching [GCFIL]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0~100</td> <td>ms</td> <td>0</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0~100	ms	0	Parameter to set time constant for gain switching. The larger the value is, the gentler the switching is.
Setting range	Unit	Standard value						
0~100	ms	0						

# 5. Parameter

## [Parameter setting value [Group3] ]



Page	Contents						
40	Vibration Suppressor Frequency 2 [SUPFRQ2]						
	<table border="1" data-bbox="309 315 687 387"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>5~500</td> <td>Hz</td> <td>500</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	5~500	Hz	500
Setting range	Unit	Standard value					
5~500	Hz	500					
41	Vibration Suppressor Frequency 3 [SUPFRQ3]						
	<table border="1" data-bbox="309 629 687 701"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>5~500</td> <td>Hz</td> <td>500</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	5~500	Hz	500
Setting range	Unit	Standard value					
5~500	Hz	500					
42	Vibration Suppressor Frequency 4 [SUPFRQ4]						
	<table border="1" data-bbox="309 958 687 1030"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>5~500</td> <td>Hz</td> <td>500</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	5~500	Hz	500
Setting range	Unit	Standard value					
5~500	Hz	500					

## 5. Parameter [Parameter setting value [Group4] [Group5] ]

### ■ General parameter Group 4 [High setting control settings]



Page	Contents							
00	Command Velocity, Low Pass Filter [CVFIL]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~2000</td> <td>Hz</td> <td>1000</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~2000	Hz	1000	Sets the cut off frequency of low pass filter, when command velocity is calculated. When the position command resolution is low, lower the cut off frequency. Filter is disabled when the set value is 2000Hz.
Setting range	Unit	Standard value						
1~2000	Hz	1000						
01	Command Velocity Threshold [CVTH]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0~65535</td> <td>min<sup>-1</sup></td> <td>20</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0~65535	min <sup>-1</sup>	20	When the command velocity calculated from position command is larger than this threshold, acceleration or deceleration compensation will be performed.
Setting range	Unit	Standard value						
0~65535	min <sup>-1</sup>	20						
02	Acceleration Compensation [ACCCO]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>-9999~+9999</td> <td>× 50 Pulse</td> <td>0</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	-9999~+9999	× 50 Pulse	0	Compensation at acceleration.
Setting range	Unit	Standard value						
-9999~+9999	× 50 Pulse	0						
03	Deceleration Compensation [DECCO]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>-9999~+9999</td> <td>× 50 Pulse</td> <td>0</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	-9999~+9999	× 50 Pulse	0	Compensation at deceleration.
Setting range	Unit	Standard value						
-9999~+9999	× 50 Pulse	0						

### ■ General parameter Group 5 [CANopen mode control settings]


Page	Contents																											
00	CANopen Network,Communication Node ID[NODE ID]																											
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~127</td> <td>—</td> <td>1</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~127	—	1	<p>The Node-ID for communication with CANopen Network is set.</p> <p>If both rotary switch are set to 0FH, the selected value becomes effective.</p> <p> The selected value is enabled after turning ON control power again.</p>																				
Setting range	Unit	Standard value																										
1~127	—	1																										
01	CANopen Network communication Bitrate[BITRATE]																											
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~08</td> <td>—</td> <td>06:500Kbps</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~08	—	06:500Kbps	<p>The Bit-Rate for communication with CANopen Network is selected.</p> <p>The selected value is enabled after turning ON control power again.</p> <table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00</td> <td>00: 10Kbps</td> </tr> <tr> <td>01</td> <td>01: 20Kbps</td> </tr> <tr> <td>02</td> <td>02: 50Kbps</td> </tr> <tr> <td>03</td> <td>03: Reserved</td> </tr> <tr> <td>04</td> <td>04: 125Kbps</td> </tr> <tr> <td>05</td> <td>05: 250Kbps</td> </tr> <tr> <td>06</td> <td>06: 500Kbps</td> </tr> <tr> <td>07</td> <td>07: 800Kbps</td> </tr> <tr> <td>08</td> <td>08: 1Mbps</td> </tr> </tbody> </table> <p> The selected value is enabled after turning ON control power again.</p>		Selection	Contents	00	00: 10Kbps	01	01: 20Kbps	02	02: 50Kbps	03	03: Reserved	04	04: 125Kbps	05	05: 250Kbps	06	06: 500Kbps	07	07: 800Kbps	08
Setting range	Unit	Standard value																										
00~08	—	06:500Kbps																										
Selection	Contents																											
00	00: 10Kbps																											
01	01: 20Kbps																											
02	02: 50Kbps																											
03	03: Reserved																											
04	04: 125Kbps																											
05	05: 250Kbps																											
06	06: 500Kbps																											
07	07: 800Kbps																											
08	08: 1Mbps																											

# 5. Parameter [Parameter setting value [Group8] ]

## ■ General parameter Group 8 [Settings for control system]

Page	Contents																																		
00	Command Input Polarity [CMDPOL]																																		
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~07</td> <td>—</td> <td>00:_PC+_VC+_TC+</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~07	—	00:_PC+_VC+_TC+	Select the command polarity from the contents blow.																											
	Setting range	Unit	Standard value																																
	00~07	—	00:_PC+_VC+_TC+																																
	<table border="1"> <thead> <tr> <th>Input command</th> <th>Command polarity</th> <th>Rotation direction</th> <th>Selection</th> </tr> </thead> <tbody> <tr> <td>position command</td> <td>+</td> <td>Forward</td> <td rowspan="4">00:_PC+_VC+_TC+</td> </tr> <tr> <td>Velocity command</td> <td>+</td> <td>Forward</td> </tr> <tr> <td>Torque command</td> <td>+</td> <td>Forward</td> </tr> <tr> <td></td> <td></td> <td></td> </tr> </tbody> </table>	Input command	Command polarity	Rotation direction	Selection	position command	+	Forward	00:_PC+_VC+_TC+	Velocity command	+	Forward	Torque command	+	Forward				<table border="1"> <thead> <tr> <th>Input command</th> <th>Command polarity</th> <th>Rotation direction</th> <th>Selection</th> </tr> </thead> <tbody> <tr> <td>Position command</td> <td>+</td> <td>Reverse</td> <td rowspan="4">04:_PC+_VC+_TC+</td> </tr> <tr> <td>Velocity command</td> <td>+</td> <td>Forward</td> </tr> <tr> <td>Torque command</td> <td>+</td> <td>Forward</td> </tr> <tr> <td></td> <td></td> <td></td> </tr> </tbody> </table>	Input command	Command polarity	Rotation direction	Selection	Position command	+	Reverse	04:_PC+_VC+_TC+	Velocity command	+	Forward	Torque command	+	Forward		
Input command	Command polarity	Rotation direction	Selection																																
position command	+	Forward	00:_PC+_VC+_TC+																																
Velocity command	+	Forward																																	
Torque command	+	Forward																																	
Input command	Command polarity	Rotation direction	Selection																																
Position command	+	Reverse	04:_PC+_VC+_TC+																																
Velocity command	+	Forward																																	
Torque command	+	Forward																																	
<table border="1"> <thead> <tr> <th>Input command</th> <th>Command polarity</th> <th>Rotation direction</th> <th>Selection</th> </tr> </thead> <tbody> <tr> <td>Position</td> <td>+</td> <td>Forward</td> <td rowspan="4">01:_PC+_VC+_TC-</td> </tr> <tr> <td>Velocity</td> <td>+</td> <td>Forward</td> </tr> <tr> <td>Torque</td> <td>+</td> <td>Reverse</td> </tr> <tr> <td></td> <td></td> <td></td> </tr> </tbody> </table>	Input command	Command polarity	Rotation direction	Selection	Position	+	Forward	01:_PC+_VC+_TC-	Velocity	+	Forward	Torque	+	Reverse				<table border="1"> <thead> <tr> <th>Input command</th> <th>Command polarity</th> <th>Rotation direction</th> <th>Selection</th> </tr> </thead> <tbody> <tr> <td>Position</td> <td>+</td> <td>Reverse</td> <td rowspan="4">05:_PC+_VC+_TC-</td> </tr> <tr> <td>Velocity</td> <td>+</td> <td>Forward</td> </tr> <tr> <td>Torque</td> <td>+</td> <td>Reverse</td> </tr> <tr> <td></td> <td></td> <td></td> </tr> </tbody> </table>	Input command	Command polarity	Rotation direction	Selection	Position	+	Reverse	05:_PC+_VC+_TC-	Velocity	+	Forward	Torque	+	Reverse			
Input command	Command polarity	Rotation direction	Selection																																
Position	+	Forward	01:_PC+_VC+_TC-																																
Velocity	+	Forward																																	
Torque	+	Reverse																																	
Input command	Command polarity	Rotation direction	Selection																																
Position	+	Reverse	05:_PC+_VC+_TC-																																
Velocity	+	Forward																																	
Torque	+	Reverse																																	
<table border="1"> <thead> <tr> <th>Input command</th> <th>Command polarity</th> <th>Rotation direction</th> <th>Selection</th> </tr> </thead> <tbody> <tr> <td>Position</td> <td>+</td> <td>Forward</td> <td rowspan="4">02:_PC+_VC+_TC+</td> </tr> <tr> <td>Velocity</td> <td>+</td> <td>Reverse</td> </tr> <tr> <td>Torque</td> <td>+</td> <td>Forward</td> </tr> <tr> <td></td> <td></td> <td></td> </tr> </tbody> </table>	Input command	Command polarity	Rotation direction	Selection	Position	+	Forward	02:_PC+_VC+_TC+	Velocity	+	Reverse	Torque	+	Forward				<table border="1"> <thead> <tr> <th>Input command</th> <th>Command polarity</th> <th>Rotation direction</th> <th>Selection</th> </tr> </thead> <tbody> <tr> <td>Position</td> <td>+</td> <td>Reverse</td> <td rowspan="4">06:_PC+_VC+_TC+</td> </tr> <tr> <td>Velocity</td> <td>+</td> <td>Reverse</td> </tr> <tr> <td>Torque</td> <td>+</td> <td>Forward</td> </tr> <tr> <td></td> <td></td> <td></td> </tr> </tbody> </table>	Input command	Command polarity	Rotation direction	Selection	Position	+	Reverse	06:_PC+_VC+_TC+	Velocity	+	Reverse	Torque	+	Forward			
Input command	Command polarity	Rotation direction	Selection																																
Position	+	Forward	02:_PC+_VC+_TC+																																
Velocity	+	Reverse																																	
Torque	+	Forward																																	
Input command	Command polarity	Rotation direction	Selection																																
Position	+	Reverse	06:_PC+_VC+_TC+																																
Velocity	+	Reverse																																	
Torque	+	Forward																																	
<table border="1"> <thead> <tr> <th>Input command</th> <th>Command polarity</th> <th>Rotation direction</th> <th>Selection</th> </tr> </thead> <tbody> <tr> <td>Position</td> <td>+</td> <td>Forward</td> <td rowspan="4">03:_PC+_VC+_TC-</td> </tr> <tr> <td>Velocity</td> <td>+</td> <td>Reverse</td> </tr> <tr> <td>Torque</td> <td>+</td> <td>Reverse</td> </tr> <tr> <td></td> <td></td> <td></td> </tr> </tbody> </table>	Input command	Command polarity	Rotation direction	Selection	Position	+	Forward	03:_PC+_VC+_TC-	Velocity	+	Reverse	Torque	+	Reverse				<table border="1"> <thead> <tr> <th>Input command</th> <th>Command polarity</th> <th>Rotation direction</th> <th>Selection</th> </tr> </thead> <tbody> <tr> <td>Position</td> <td>+</td> <td>Reverse</td> <td rowspan="4">07:_PC+_VC+_TC-</td> </tr> <tr> <td>Velocity</td> <td>+</td> <td>Reverse</td> </tr> <tr> <td>Torque</td> <td>+</td> <td>Reverse</td> </tr> <tr> <td></td> <td></td> <td></td> </tr> </tbody> </table>	Input command	Command polarity	Rotation direction	Selection	Position	+	Reverse	07:_PC+_VC+_TC-	Velocity	+	Reverse	Torque	+	Reverse			
Input command	Command polarity	Rotation direction	Selection																																
Position	+	Forward	03:_PC+_VC+_TC-																																
Velocity	+	Reverse																																	
Torque	+	Reverse																																	
Input command	Command polarity	Rotation direction	Selection																																
Position	+	Reverse	07:_PC+_VC+_TC-																																
Velocity	+	Reverse																																	
Torque	+	Reverse																																	
01	Analog Input Dead Band [VC/TC-DB]																																		
<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~01</td> <td>—</td> <td>00:_Disabled</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~01	—	00:_Disabled	<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_Disabled</td> <td>Disabled</td> </tr> <tr> <td>01:_Enabled</td> <td>Enabled</td> </tr> </tbody> </table>	Selection	Contents	00:_Disabled	Disabled	01:_Enabled	Enabled																						
Setting range	Unit	Standard value																																	
00~01	—	00:_Disabled																																	
Selection	Contents																																		
00:_Disabled	Disabled																																		
01:_Enabled	Enabled																																		
02	Analog Input Dead Band Width [VCZDAT]																																		
<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0.0~6553.5</td> <td>mV</td> <td>0.0</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0.0~6553.5	mV	0.0	<p>Sets the width of Analog Input Dead Band. Consider that the analog input pressure within this limits is 0V. It is effective to both velocity and the torque commands. These value become effective if Analog Input Dead Band setting is valid.</p>																												
Setting range	Unit	Standard value																																	
0.0~6553.5	mV	0.0																																	
11	Position Command Pulse, Form Selection [PCPTYP]																																		
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~02</td> <td>—</td> <td>00:_F-PC_R-PC</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~02	—	00:_F-PC_R-PC	<p>Select the position command pulse type from the contents below.</p> <table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_F-PC_R-PC</td> <td>Positive Move Pulse + Negative Move Pulse</td> </tr> <tr> <td>01:_2PhasePulse</td> <td>Two-Phase Pulse Train of 90 Degrees Phase Difference</td> </tr> <tr> <td>02:_CODE_PC</td> <td>Code + Pulse Train</td> </tr> </tbody> </table> <p> The set value is enabled after control power is turned ON again.</p>	Selection	Contents	00:_F-PC_R-PC	Positive Move Pulse + Negative Move Pulse	01:_2PhasePulse	Two-Phase Pulse Train of 90 Degrees Phase Difference	02:_CODE_PC	Code + Pulse Train																			
Setting range	Unit	Standard value																																	
00~02	—	00:_F-PC_R-PC																																	
Selection	Contents																																		
00:_F-PC_R-PC	Positive Move Pulse + Negative Move Pulse																																		
01:_2PhasePulse	Two-Phase Pulse Train of 90 Degrees Phase Difference																																		
02:_CODE_PC	Code + Pulse Train																																		
12	Position Command Pulse, Count Polarity [PCPPOL]																																		
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~03</td> <td>—</td> <td>00:_Type1</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~03	—	00:_Type1	Select the position command pulse count polarity from the contents below.																											
Setting range	Unit	Standard value																																	
00~03	—	00:_Type1																																	
<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_Type1</td> <td>F-PC/ Count at the Rising Edge : R-PC/ Count at the Rising Edge</td> </tr> <tr> <td>01:_Type2</td> <td>F-PC/ Count at the Falling Edge : R-PC/ Count at the Rising Edge</td> </tr> <tr> <td>02:_Type3</td> <td>F-PC/ Count at the Rising Edge : R-PC/ Count at the Falling Edge</td> </tr> <tr> <td>03:_Type4</td> <td>F-PC/ Count at the Falling Edge : R-PC/ Count at the Falling Edge</td> </tr> </tbody> </table> <p> The set value is enabled after control power is turned ON again.</p>	Selection	Contents	00:_Type1	F-PC/ Count at the Rising Edge : R-PC/ Count at the Rising Edge	01:_Type2	F-PC/ Count at the Falling Edge : R-PC/ Count at the Rising Edge	02:_Type3	F-PC/ Count at the Rising Edge : R-PC/ Count at the Falling Edge	03:_Type4	F-PC/ Count at the Falling Edge : R-PC/ Count at the Falling Edge																									
Selection	Contents																																		
00:_Type1	F-PC/ Count at the Rising Edge : R-PC/ Count at the Rising Edge																																		
01:_Type2	F-PC/ Count at the Falling Edge : R-PC/ Count at the Rising Edge																																		
02:_Type3	F-PC/ Count at the Rising Edge : R-PC/ Count at the Falling Edge																																		
03:_Type4	F-PC/ Count at the Falling Edge : R-PC/ Count at the Falling Edge																																		

# 5. Parameter [Parameter setting value [Group8] ]

Page	Contents																								
13	Position Command Pulse, Digital Filter [PCPFIL]																								
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~07</td> <td>—</td> <td>00:_834nsec</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~07	—	00:_834nsec	<p>Select the setting of position command pulse digital filter from the contents below.</p> <p>As timing for command direction, observe the specifications of position command. When the pulse command form is "Two-Phase Pulse Train of 90 Degrees Phase Difference", observe the specifications of position command.</p> <table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_834nsec</td> <td>Minimum Pulse Width = 834nsec</td> </tr> <tr> <td>01:_250nsec</td> <td>Minimum Pulse Width = 250nsec</td> </tr> <tr> <td>02:_500nsec</td> <td>Minimum Pulse Width = 500nsec</td> </tr> <tr> <td>03:_1.8usec</td> <td>Minimum Pulse Width = 1.8 μ sec</td> </tr> <tr> <td>04:_3.6usec</td> <td>Minimum Pulse Width = 3.6 μ sec</td> </tr> <tr> <td>05:_7.2usec</td> <td>Minimum Pulse Width = 7.2 μ sec</td> </tr> <tr> <td>06:_125nsec</td> <td>Minimum Pulse Width = 125nsec</td> </tr> <tr> <td>07:_83.4nsec</td> <td>Minimum Pulse Width = 83.4nsec</td> </tr> </tbody> </table>	Selection	Contents	00:_834nsec	Minimum Pulse Width = 834nsec	01:_250nsec	Minimum Pulse Width = 250nsec	02:_500nsec	Minimum Pulse Width = 500nsec	03:_1.8usec	Minimum Pulse Width = 1.8 μ sec	04:_3.6usec	Minimum Pulse Width = 3.6 μ sec	05:_7.2usec	Minimum Pulse Width = 7.2 μ sec	06:_125nsec	Minimum Pulse Width = 125nsec	07:_83.4nsec
Setting range	Unit	Standard value																							
00~07	—	00:_834nsec																							
Selection	Contents																								
00:_834nsec	Minimum Pulse Width = 834nsec																								
01:_250nsec	Minimum Pulse Width = 250nsec																								
02:_500nsec	Minimum Pulse Width = 500nsec																								
03:_1.8usec	Minimum Pulse Width = 1.8 μ sec																								
04:_3.6usec	Minimum Pulse Width = 3.6 μ sec																								
05:_7.2usec	Minimum Pulse Width = 7.2 μ sec																								
06:_125nsec	Minimum Pulse Width = 125nsec																								
07:_83.4nsec	Minimum Pulse Width = 83.4nsec																								
14	Position Command, Pulse Multiplier [PCPMUL]																								
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~63</td> <td>—</td> <td>1</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~63	—	1	Parameter to multiply the command pulse by x1~x63. Values from 1 to 63 are set, which are always enabled.																	
Setting range	Unit	Standard value																							
1~63	—	1																							
15	Electric Gear Ratio 1 [GER1]																								
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1/32767~32767/1</td> <td>—</td> <td>1/1</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1/32767~32767/1	—	1/1	Setting of electronic gear to position command pulse.																	
Setting range	Unit	Standard value																							
1/32767~32767/1	—	1/1																							
16	Electric Gear Ratio 2 [GER2]																								
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1/32767~32767/1</td> <td>—</td> <td>1/1</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1/32767~32767/1	—	1/1	$f1 \longrightarrow \frac{N (1 \sim 32767)}{D (1 \sim 32767)} \longrightarrow f2 (f2 = f1 \times N/D)$ $1/32767 \leq N/D \leq 32767$																	
Setting range	Unit	Standard value																							
1/32767~32767/1	—	1/1																							
17	Positioning method [EDGEPOS]																								
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~01</td> <td>—</td> <td>00:_Pulse_Interval</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~01	—	00:_Pulse_Interval	<p>Select the encoder pulse positioning from the contents below.</p> <table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_Pulse_Interval</td> <td>Specify Pulse Interval</td> </tr> <tr> <td>01:_Pulse_Edge</td> <td>Specify Pulse Edge</td> </tr> </tbody> </table> <p> The set value is enabled after control power is turned ON again.</p>	Selection	Contents	00:_Pulse_Interval	Specify Pulse Interval	01:_Pulse_Edge	Specify Pulse Edge											
Setting range	Unit	Standard value																							
00~01	—	00:_Pulse_Interval																							
Selection	Contents																								
00:_Pulse_Interval	Specify Pulse Interval																								
01:_Pulse_Edge	Specify Pulse Edge																								
18	Inposition / Position Deviation Monitor [PDEVMON]																								
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~01</td> <td>—</td> <td>00:_After_Filter</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~01	—	00:_After_Filter	<p>Select the positioning complete signal ( I N P ) and position deviation monitor from the contents below.</p> <table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_After_Filter</td> <td>Compare "Position Command Value After Filter Passes by" with "Feedback Value"</td> </tr> <tr> <td>01:_Before_Filter</td> <td>Compare "Position Command Value Before Filter Passes by" with "Feedback Value"</td> </tr> </tbody> </table>	Selection	Contents	00:_After_Filter	Compare "Position Command Value After Filter Passes by" with "Feedback Value"	01:_Before_Filter	Compare "Position Command Value Before Filter Passes by" with "Feedback Value"											
Setting range	Unit	Standard value																							
00~01	—	00:_After_Filter																							
Selection	Contents																								
00:_After_Filter	Compare "Position Command Value After Filter Passes by" with "Feedback Value"																								
01:_Before_Filter	Compare "Position Command Value Before Filter Passes by" with "Feedback Value"																								
19	Deviation Clear Selection [CLR]																								
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~03</td> <td>—</td> <td>00:_Type1</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~03	—	00:_Type1	Select the position deviation clearing method from the contents below.																	
Setting range	Unit	Standard value																							
00~03	—	00:_Type1																							
	<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_Type1</td> <td>When SERVO-OFF/ Clear Deviation : Deviation Clear Input/ Level Detection : During servo OFF, deviation clear is always executed. While deviation clear input is ON, deviation clear is always executed.</td> </tr> <tr> <td>01:_Type2</td> <td>When SERVO-OFF/ Clear Deviation : Deviation Clear Input/ Edge Detection : At the edge of OFF→ON of deviation clear input, deviation clear is executed.</td> </tr> <tr> <td>02:_Type3</td> <td>When SERVO-OFF/ Not Clear Deviation : Deviation Clear Input/ Level Detection : During servo OFF, deviation clear is not executed. (After servo ON, the motor may operate suddenly.)</td> </tr> <tr> <td>03:_Type4</td> <td>When SERVO-OFF/ Not Clear Deviation : Deviation Clear Input/ Edge Detection : During servo OFF, deviation clear is not executed. (After servo ON, the motor may operate suddenly.)</td> </tr> </tbody> </table>		Selection	Contents	00:_Type1	When SERVO-OFF/ Clear Deviation : Deviation Clear Input/ Level Detection : During servo OFF, deviation clear is always executed. While deviation clear input is ON, deviation clear is always executed.	01:_Type2	When SERVO-OFF/ Clear Deviation : Deviation Clear Input/ Edge Detection : At the edge of OFF→ON of deviation clear input, deviation clear is executed.	02:_Type3	When SERVO-OFF/ Not Clear Deviation : Deviation Clear Input/ Level Detection : During servo OFF, deviation clear is not executed. (After servo ON, the motor may operate suddenly.)	03:_Type4	When SERVO-OFF/ Not Clear Deviation : Deviation Clear Input/ Edge Detection : During servo OFF, deviation clear is not executed. (After servo ON, the motor may operate suddenly.)													
Selection	Contents																								
00:_Type1	When SERVO-OFF/ Clear Deviation : Deviation Clear Input/ Level Detection : During servo OFF, deviation clear is always executed. While deviation clear input is ON, deviation clear is always executed.																								
01:_Type2	When SERVO-OFF/ Clear Deviation : Deviation Clear Input/ Edge Detection : At the edge of OFF→ON of deviation clear input, deviation clear is executed.																								
02:_Type3	When SERVO-OFF/ Not Clear Deviation : Deviation Clear Input/ Level Detection : During servo OFF, deviation clear is not executed. (After servo ON, the motor may operate suddenly.)																								
03:_Type4	When SERVO-OFF/ Not Clear Deviation : Deviation Clear Input/ Edge Detection : During servo OFF, deviation clear is not executed. (After servo ON, the motor may operate suddenly.)																								

# 5. Parameter [Parameter setting value [Group8] 1

Page	Contents		
20	Preset Velocity Command 1 [VC1] Refer to "Chapter 7, Adjustment · Functions Internal velocity command".		
	Setting range	Unit	Standard value
21	Preset Velocity Command 2 [VC2] Refer to "Chapter 7, Adjustment · Functions Internal velocity command".		
	Setting range	Unit	Standard value
22	Preset Velocity Command 3 [VC3] Refer to "Chapter 7, Adjustment · Functions Internal velocity command".		
	Setting range	Unit	Standard value
23	Velocity Compensation Command, Input Selection [VCOMSEL]		
	Setting range	Unit	Standard value
	Selection	Contents	
24	Preset Velocity Compensation Command [VCOMP]		
	Setting range	Unit	Standard value
25	Analog Velocity Command, Reference (Analog Velocity Compensation Command, Ref.) [VCGN]		
	Setting range	Unit	Standard value
26	Velocity Command, Acceleration Time Constant [TVACC]		
	Setting range	Unit	Standard value
27	Velocity Command, Deceleration Time Constant [TVDEC]		
	Setting range	Unit	Standard value
28	Velocity Limit [VCLM]		
	Setting range	Unit	Standard value
30	Torque Compensation Command, Input Selection [TCOMSEL]		
	Setting range	Unit	Standard value
	Selection	Contents	

# 5. Parameter [Parameter setting value [Group8] ]

Page	Contents								
31	Preset Torque Compensation Command 1 [TCOMP1]								
	<table border="1"> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> <tr> <td>-500~+500</td> <td>%</td> <td>0</td> </tr> </table>	Setting range	Unit	Standard value	-500~+500	%	0	Parameter for using torque addition command in a fixed value, when torque addition function is used.	
Setting range	Unit	Standard value							
-500~+500	%	0							
32	Preset Torque Compensation Command 2 [TCOMP2]								
	<table border="1"> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> <tr> <td>-500~+500</td> <td>%</td> <td>0</td> </tr> </table>	Setting range	Unit	Standard value	-500~+500	%	0	Parameter for using torque addition command in a fixed value, when torque addition function is used.	
Setting range	Unit	Standard value							
-500~+500	%	0							
33	Analog Torque Command, Reference [TCGN]								
	<table border="1"> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> <tr> <td>0~500</td> <td>%V</td> <td>50</td> </tr> </table>	Setting range	Unit	Standard value	0~500	%V	50	Parameter for setting analog torque command scaling.	
Setting range	Unit	Standard value							
0~500	%V	50							
34	Analog Torque Compensation Command, Reference [TCOMPGN]								
	<table border="1"> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> <tr> <td>0~500</td> <td>%V</td> <td>50</td> </tr> </table>	Setting range	Unit	Standard value	0~500	%V	50	Parameter for adjusting torque addition command input scaling.	
Setting range	Unit	Standard value							
0~500	%V	50							
35	Torque Limit, Input Selection [TLSEL]								
	<table border="1"> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> <tr> <td>00~03</td> <td>—</td> <td>00:_TCLM</td> </tr> </table>	Setting range	Unit	Standard value	00~03	—	00:_TCLM	Select the torque command limiting method from the contents below. The selection of limit is when torque command limit function is valid.	
	Setting range	Unit	Standard value						
	00~03	—	00:_TCLM						
36	Internal Torque Limit [TCLM]								
	<table border="1"> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> <tr> <td>10~500</td> <td>%</td> <td>100</td> </tr> </table>	Setting range	Unit	Standard value	10~500	%	100	Parameter for limiting output torque. Torque limit value is determined by comparing it with the rated output torque.(100%= rated torque ) Output torque is limited at the internal torque limit set value when the torque limit input signal is functioning. Output torque is restricted by TP if a value exceeding the peak output torque TP is selected.	
Setting range	Unit	Standard value							
10~500	%	100							
37	Torque Limit at Sequence Operation [SQTCLM]								
	<table border="1"> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> <tr> <td>10~500</td> <td>%</td> <td>120</td> </tr> </table>	Setting range	Unit	Standard value	10~500	%	120	Parameter for setting sequence operation torque limit value (JOG operation, holding brake operation waiting, and OT status, etc.) Torque limit value is determined by comparing it with the rated output torque. (100%=rated torque ) During sequence operation, output torque is restricted by this set value. Output torque is restricted by TP if a value exceeding the peak output torque TP is selected.	
Setting range	Unit	Standard value							
10~500	%	120							




## 5. Parameter [Parameter setting value [Group8] ]

Page	Contents							
40	In-Position Near Range [NEAR]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~65535</td> <td>Pulse</td> <td>500</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~65535	Pulse	500	Parameter for setting the output range of near range signal (near in-position complete). Near range signal is output when the deviation counter is lower than this set value. Encoder pulse is standard irrespective of electronic gear and command multiplication functions.
Setting range	Unit	Standard value						
1~65535	Pulse	500						
41	In-Position Window [INP]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~65535</td> <td>Pulse</td> <td>100</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~65535	Pulse	100	Parameter for setting output range of positioning complete signal. Positioning complete signal is output when the deviation counter is lower than this set value. Encoder pulse is standard irrespective of the electronic gear function or command multiplication function. Incremental encoder → Encoder pulse multiplied by 4 is standard. Absolute encoder (except for the ones absolute encoder with incremental output) → absolute value is standard.
Setting range	Unit	Standard value						
1~65535	Pulse	100						
42	Speed Zero Range [ZV]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>50~500</td> <td>min<sup>-1</sup></td> <td>50</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	50~500	min <sup>-1</sup>	50	Set value for detecting zero-speed status (motor stop). When the motor speed becomes lower than this value, zero-speed status is detected.
Setting range	Unit	Standard value						
50~500	min <sup>-1</sup>	50						
43	Low Speed Range [LOWV]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0~65535</td> <td>min<sup>-1</sup></td> <td>50</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0~65535	min <sup>-1</sup>	50	Parameter for setting low-speed output range. When the speed is lower than this value, low-speed range is output.
Setting range	Unit	Standard value						
0~65535	min <sup>-1</sup>	50						
44	Speed Matching Width [VCMP]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0~65535</td> <td>min<sup>-1</sup></td> <td>50</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0~65535	min <sup>-1</sup>	50	Parameter for setting the range of velocity matching output. Velocity matching is output when the speed deviation (difference between speed command and actual speed) is within the setting range.
Setting range	Unit	Standard value						
0~65535	min <sup>-1</sup>	50						
45	High Speed Range [VA]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0~65535</td> <td>min<sup>-1</sup></td> <td>1000</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0~65535	min <sup>-1</sup>	1000	Parameter for setting the value for speed attainment output. When the speed exceeds this set value, velocity attainment is output. If the motor speed exceeds the selected value during torque control operations, and when the control switching function is enabled, the torque command is always set to 0. Fixed speed cannot be controlled. Avoid continuous usage in this manner.
Setting range	Unit	Standard value						
0~65535	min <sup>-1</sup>	1000						

## 5. Parameter [Parameter setting value [Group9] 1

### ■ General parameter Group 9 [Condition settings for enabling functions]

Input signals and conditions to enable the functions of each page are set.

 Selection contents to be set are on the next page.

Page	Contents	
00	Positive Over-Travel Function [F-OT]	
	Setting range 00~27	Standard value 0D: CONT6_OFF
01	Negative Over-Travel Function [R-OT]	
	Setting range 00~27	Standard value 0B: CONT5_OFF
02	Alarm Reset Function [AL-RST]	
	Setting range 00~27	Standard value 10: CONT8_ON
03	Absolute Encoder Clear Function [ECLR]	
	Setting range 00~27	Standard value 06: CONT3_ON
04	Deviation Clear Function [CLR]	
	Setting range 00~27	Standard value 08: CONT4_ON
05	SERVO-ON Function [S-ON]	
	Setting range 00~27	Standard value 02: CONT1_ON
10	Control Mode Switching Function [MS]	
	Setting range 00~27	Standard value 00: Always_Disable
11	Position Command Pulse Inhibit Function and Velocity Command Zero Clamp Function [INH/Z-STP]	
	Setting range 00~27	Standard value 00: Always_Disable
12	Electric Gear Switching Function [GERS]	
	Setting range 00~27	Standard value 00: Always_Disable
13	Gain Switching Function, Select Input 1 [GC1]	
	Setting range 00~2F	Standard value 00: Always_Disable
14	Gain Switching Function, Select Input 2 [GC2]	
	Setting range 00~2F	Standard value 00: Always_Disable
15	Vibration Suppressor Frequency, Select Input 1 [SUPFSEL1]	
	Setting range 00~2F	Standard value 00: Always_Disable
16	Vibration Suppressor Frequency, Select Input 2 [SUPFSEL2]	
	Setting range 00~2F	Standard value 00: Always_Disable
17	Position Loop Proportional Control, Switching Function [PLPCON]	
	Setting range 00~2F	Standard value 01: Always_Enable
20	Preset Velocity Command, Select Input 1 [SP1]	
	Setting range 00~27	Standard value 00: Always_Disable

Page	Contents	
21	Preset Velocity Command, Select Input 2 [SP2]	
	Setting range 00~27	Standard value 00: Always_Disable
22	Preset Velocity Command, Direction of Move [DIR]	
	Setting range 00~27	Standard value 00: Always_Disable
23	Preset Velocity Command, Operation Start Signal Input [RUN]	
	Setting range 00~27	Standard value 00: Always_Disable
24	Preset Velocity Command, Positive Move Signal Input [RUN-F]	
	Setting range 00~27	Standard value 00: Always_Disable
25	Preset Velocity Command, Negative Move Signal Input [RUN-R]	
	Setting range 00~27	Standard value 00: Always_Disable
26	Velocity Loop Proportional Control, Switching Function [VLPCON]	
	Setting range 00~2F	Standard value 04: CONT2_ON
27	Velocity Compensation Function, Select Input [VCOMPS]	
	Setting range 00~27	Standard value 00: Always_Disable
30	Torque Compensation Function, Select Input 1 [TCOMPS1]	
	Setting range 00~27	Standard value 00: Always_Disable
31	Torque Compensation Function, Select Input 2 [TCOMPS2]	
	Setting range 00~27	Standard value 00: Always_Disable
32	Torque Limit, Input Selection [TL]	
	Setting range 00~27	Standard value 0E: CONT7_ON
33	Disturbance Observer [OBS]	
	Setting range 00~2F	Standard value 00: Always_Disable
40	External Error Input [EXT-E]	
	Setting range 00~27	Standard value 00: Always_Disable
41	Main Power Discharge Function [DISCHARG]	
	Setting range 00~27	Standard value 01: Always_Enable
42	Emergency Stop Function [EMR]	
	Setting range 00~27	Standard value 07: CONT3_OFF
50	Home Signal Input selection	
	Setting range 00~27	Standard value 00: Always_Disable
51	PROBE Signal Input selection	
	Setting range 00~27	Standard value 00: Always_Disable

## 5. Parameter [Parameter setting value [Group9] ]

- General parameter Group 9 List of selection contents

When functions are to be always enabled or disabled.	
Selection	Contents
00:_Always_Disable	Always disable the function.
01:_Always_Enable	Always enable the function.
When functions are to be used with the generic input signals.	
Selection	Contents
02:_CONT1_ON	Enable the function when general purpose input CONT1 is ON.
03:_CONT1_OFF	Enable the function when general purpose input CONT1 is OFF.
04:_CONT2_ON	Enable the function when general purpose input CONT2 is ON.
05:_CONT2_OFF	Enable the function when general purpose input CONT2 is OFF.
06:_CONT3_ON	Enable the function when general purpose input CONT3 is ON.
07:_CONT3_OFF	Enable the function when general purpose input CONT3 is OFF.
08:_CONT4_ON	Enable the function when general purpose input CONT4 is ON.
09:_CONT4_OFF	Enable the function when general purpose input CONT4 is OFF.
0A:_CONT5_ON	Enable the function when general purpose input CONT5 is ON.
0B:_CONT5_OFF	Enable the function when general purpose input CONT5 is OFF.
0C:_CONT6_ON	Enable the function when general purpose input CONT6 is ON.
0D:_CONT6_OFF	Enable the function when general purpose input CONT6 is OFF.
0E:_CONT7_ON	Enable the function when general purpose input CONT7 is ON.
0F:_CONT7_OFF	Enable the function when general purpose input CONT7 is OFF.
10:_CONT8_ON	Enable the function when general purpose input CONT8 is ON.
11:_CONT8_OFF	Enable the function when general purpose input CONT8 is OFF.
When functions are to be set with the conditions of servo motor rotation speed.	
Selection	Contents
12:_LOWV_IN	Enable the function during low speed status (speed is less than LOWV).
13:_LOWV_OUT	Enable the function while low speed status is not kept.
14:_VA_IN	Enable the function during high speed status (speed is more than VA).
15:_VA_OUT	Enable the function while high speed status is not kept.
16:_VCMP_IN	Enable the function during speed matching status (velocity deviation < VCMP).
17:_VCMP_OUT	Enable the function while speed matching status is not kept.
18:_ZV_IN	Enable the function during zero speed status (speed is less than ZV).
19:_ZV_OUT	Enable the function while zero speed status is not kept.
When functions are to be set with the conditions of positioning signals.	
Selection	Contents
20:_NEAR_IN	Enable the function during NEAR status (position deviation < NEAR).
21:_NEAR_OUT	Enable the function while NEAR status is not kept.
1A:_INP_IN	Enable the function during In-Position status (position deviation < INP).
1B:_INP_OUT	Enable the function while In-Position status is not kept.
26:_INPZ_IN	Enable the function during PCMD=0 and In-position Status.
27:_INPZ_OUT	Disable the function during PCMD=0 or In-position Status.
When functions are to be set with the conditions of torque / speed limit	
Selection	Contents
1C:_TLC_IN	Enable the function during torque limiting.
1D:_TLC_OUT	Enable the function while torque limiting is not performed.
1E:_VLC_IN	Enable the function during velocity limiting.
1F:_VLC_OUT	Enable the function while velocity limiting is not performed.
When functions are to be set with the servo motor rotation direction and stop status.	
Selection	Contents
22:_VMON_>_+LV	Enable the function when Moving Direction is Positive (VMON > LOWV).
23:_VMON_<=_+LV	Enable the function when Moving Direction is not Positive (VMON <= LOWV).
24:_VMON_<_-LV	Enable the function when Moving Direction is Negative (VMON < LOWV).
25:_VMON_>=_-LV	Enable the function when Moving Direction is not Negative (VMON >= LOWV).
When functions are to be set with the FILDBUS_INPUT.	
Selection	Contents
28:_FILDBUS_INPUT0	Enable the function when FILDBUS INPUT Bit0 is 1.
29:_FILDBUS_INPUT1	Enable the function when FILDBUS INPUT Bit1 is 1.
2A:_FILDBUS_INPUT2	Enable the function when FILDBUS INPUT Bit2 is 1.
2B:_FILDBUS_INPUT3	Enable the function when FILDBUS INPUT Bit3 is 1.
2C:_FILDBUS_INPUT4	Enable the function when FILDBUS INPUT Bit4 is 1.
2D:_FILDBUS_INPUT5	Enable the function when FILDBUS INPUT Bit5 is 1.
2E:_FILDBUS_INPUT6	Enable the function when FILDBUS INPUT Bit6 is 1.
2F:_FILDBUS_INPUT7	Enable the function when FILDBUS INPUT Bit7 is 1.


# 5. Parameter [Parameter setting value [GroupA] 1

## ■ General parameter Group A


[generic output terminal outputting condition/monitor output selection/setup software settings]

Page	Name and Contents																																													
00	General Purpose Output 1 [OUT1]																																													
	Setting range	Standard value																																												
01	General Purpose Output 2 [OUT2]																																													
	Setting range	Standard value																																												
02	General Purpose Output 3 [OUT3]																																													
	Setting range	Standard value																																												
03	General Purpose Output 4 [OUT4]																																													
	Setting range	Standard value																																												
04	General Purpose Output 5 [OUT5]																																													
	Setting range	Standard value																																												
05	General Purpose Output 6 [OUT6]																																													
	Setting range	Standard value																																												
06	General Purpose Output 7 [OUT7]																																													
	Setting range	Standard value																																												
07	General Purpose Output 8 [OUT8]																																													
	Setting range	Standard value																																												
10	Digital Monitor, Output Signal Selection [DMON]																																													
	Setting range	Standard value																																												
11	Analog Monitor 1, Output Signal Selection [MON1]																																													
	Setting range	Standard value																																												
12	Analog Monitor 2, Output Signal Selection [MON2]																																													
	Setting range	Standard value																																												
<table border="1"> <tbody> <tr> <td>00</td> <td>Reserved</td> </tr> <tr> <td>01: TMON_2V/TR</td> <td>Torque (thrust) monitor 2V/ rated torque (thrust)</td> </tr> <tr> <td>02: TCMON_2V/TR</td> <td>Torque (thrust) command monitor 2V/ rated torque (thrust)</td> </tr> <tr> <td>03: VMON_0.2mV/ min<sup>-1</sup></td> <td>Velocity monitor 0.2mV/ min<sup>-1</sup></td> </tr> <tr> <td>04: VMON_1mV/ min<sup>-1</sup></td> <td>Velocity monitor 1mV/ min<sup>-1</sup></td> </tr> <tr> <td>05: VMON_2mV/ min<sup>-1</sup></td> <td>Velocity monitor 2mV/ min<sup>-1</sup></td> </tr> <tr> <td>06: VMON_3mV/ min<sup>-1</sup></td> <td>Velocity monitor 3mV/ min<sup>-1</sup></td> </tr> <tr> <td>07: VCMON_0.2mV/ min<sup>-1</sup></td> <td>Velocity command monitor 0.2mV/ min<sup>-1</sup></td> </tr> <tr> <td>08: VCMON_1mV/ min<sup>-1</sup></td> <td>Velocity command monitor 1mV/ min<sup>-1</sup></td> </tr> <tr> <td>09: VCMON_2mV/ min<sup>-1</sup></td> <td>Velocity command monitor 2mV/ min<sup>-1</sup></td> </tr> <tr> <td>0A: VCMON_3mV/ min<sup>-1</sup></td> <td>Velocity command monitor 3mV/ min<sup>-1</sup></td> </tr> <tr> <td>0B: PMON_0.1mV/P</td> <td>Position deviation counter monitor 0.1mV/ Pulse</td> </tr> <tr> <td>0C: PMON_1mV/P</td> <td>Position deviation counter monitor 1mV/ Pulse</td> </tr> <tr> <td>0D: PMON_10mV/P</td> <td>Position deviation counter monitor 10mV/ Pulse</td> </tr> <tr> <td>0E: PMON_20mV/P</td> <td>Position deviation counter monitor 20mV/ Pulse</td> </tr> <tr> <td>0F: PMON_50mV/P</td> <td>Position deviation counter monitor 50mV/Pulse</td> </tr> <tr> <td>10: FMON_2mV/kP/s</td> <td>Position command pulse monitor (position command pulse input frequency)2mV/kPulse/s</td> </tr> <tr> <td>11: FMON_10mV/kP/s</td> <td>Position command pulse monitor (position command pulse input frequency)10mV/kPulse/s</td> </tr> <tr> <td>12: TLMON_EST_2V/TR</td> <td>Load torque (thrust) monitor (estimated value) 2V/ rated torque (thrust)</td> </tr> <tr> <td>13: Sine-U</td> <td>U phase electric angle Sin 8 V peak</td> </tr> <tr> <td>14: VBUS_1V/DC100V</td> <td>Main circuit DC voltage 1V/DC100V</td> </tr> <tr> <td>15: VBUS_1V/DC10V</td> <td>Main circuit DC voltage 1V/DC10V</td> </tr> </tbody> </table>			00	Reserved	01: TMON_2V/TR	Torque (thrust) monitor 2V/ rated torque (thrust)	02: TCMON_2V/TR	Torque (thrust) command monitor 2V/ rated torque (thrust)	03: VMON_0.2mV/ min <sup>-1</sup>	Velocity monitor 0.2mV/ min <sup>-1</sup>	04: VMON_1mV/ min <sup>-1</sup>	Velocity monitor 1mV/ min <sup>-1</sup>	05: VMON_2mV/ min <sup>-1</sup>	Velocity monitor 2mV/ min <sup>-1</sup>	06: VMON_3mV/ min <sup>-1</sup>	Velocity monitor 3mV/ min <sup>-1</sup>	07: VCMON_0.2mV/ min <sup>-1</sup>	Velocity command monitor 0.2mV/ min <sup>-1</sup>	08: VCMON_1mV/ min <sup>-1</sup>	Velocity command monitor 1mV/ min <sup>-1</sup>	09: VCMON_2mV/ min <sup>-1</sup>	Velocity command monitor 2mV/ min <sup>-1</sup>	0A: VCMON_3mV/ min <sup>-1</sup>	Velocity command monitor 3mV/ min <sup>-1</sup>	0B: PMON_0.1mV/P	Position deviation counter monitor 0.1mV/ Pulse	0C: PMON_1mV/P	Position deviation counter monitor 1mV/ Pulse	0D: PMON_10mV/P	Position deviation counter monitor 10mV/ Pulse	0E: PMON_20mV/P	Position deviation counter monitor 20mV/ Pulse	0F: PMON_50mV/P	Position deviation counter monitor 50mV/Pulse	10: FMON_2mV/kP/s	Position command pulse monitor (position command pulse input frequency)2mV/kPulse/s	11: FMON_10mV/kP/s	Position command pulse monitor (position command pulse input frequency)10mV/kPulse/s	12: TLMON_EST_2V/TR	Load torque (thrust) monitor (estimated value) 2V/ rated torque (thrust)	13: Sine-U	U phase electric angle Sin 8 V peak	14: VBUS_1V/DC100V	Main circuit DC voltage 1V/DC100V	15: VBUS_1V/DC10V	Main circuit DC voltage 1V/DC10V
00	Reserved																																													
01: TMON_2V/TR	Torque (thrust) monitor 2V/ rated torque (thrust)																																													
02: TCMON_2V/TR	Torque (thrust) command monitor 2V/ rated torque (thrust)																																													
03: VMON_0.2mV/ min <sup>-1</sup>	Velocity monitor 0.2mV/ min <sup>-1</sup>																																													
04: VMON_1mV/ min <sup>-1</sup>	Velocity monitor 1mV/ min <sup>-1</sup>																																													
05: VMON_2mV/ min <sup>-1</sup>	Velocity monitor 2mV/ min <sup>-1</sup>																																													
06: VMON_3mV/ min <sup>-1</sup>	Velocity monitor 3mV/ min <sup>-1</sup>																																													
07: VCMON_0.2mV/ min <sup>-1</sup>	Velocity command monitor 0.2mV/ min <sup>-1</sup>																																													
08: VCMON_1mV/ min <sup>-1</sup>	Velocity command monitor 1mV/ min <sup>-1</sup>																																													
09: VCMON_2mV/ min <sup>-1</sup>	Velocity command monitor 2mV/ min <sup>-1</sup>																																													
0A: VCMON_3mV/ min <sup>-1</sup>	Velocity command monitor 3mV/ min <sup>-1</sup>																																													
0B: PMON_0.1mV/P	Position deviation counter monitor 0.1mV/ Pulse																																													
0C: PMON_1mV/P	Position deviation counter monitor 1mV/ Pulse																																													
0D: PMON_10mV/P	Position deviation counter monitor 10mV/ Pulse																																													
0E: PMON_20mV/P	Position deviation counter monitor 20mV/ Pulse																																													
0F: PMON_50mV/P	Position deviation counter monitor 50mV/Pulse																																													
10: FMON_2mV/kP/s	Position command pulse monitor (position command pulse input frequency)2mV/kPulse/s																																													
11: FMON_10mV/kP/s	Position command pulse monitor (position command pulse input frequency)10mV/kPulse/s																																													
12: TLMON_EST_2V/TR	Load torque (thrust) monitor (estimated value) 2V/ rated torque (thrust)																																													
13: Sine-U	U phase electric angle Sin 8 V peak																																													
14: VBUS_1V/DC100V	Main circuit DC voltage 1V/DC100V																																													
15: VBUS_1V/DC10V	Main circuit DC voltage 1V/DC10V																																													

Output signals for Generic output OUT1~Generic output OUT8 are selected.

 Selection values to be set are on the next page.

Output signals for digital monitor output are selected.

 Selection values to be set are on the next page.

Output signals for analog monitor output 1, 2 are selected from the followings.

# 5. Parameter [Parameter setting value [GroupA] 1

## ● Generic output OUT1~Generic output OUT8, List of selection contents for digital monitor output



When functions are to be always enabled or disabled.																																																																																									
<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00: Always_OFF</td> <td>The output is always OFF.</td> </tr> <tr> <td>01: Always_ON</td> <td>The output is always ON.</td> </tr> </tbody> </table>	Selection	Contents	00: Always_OFF	The output is always OFF.	01: Always_ON	The output is always ON.																																																																																			
Selection	Contents																																																																																								
00: Always_OFF	The output is always OFF.																																																																																								
01: Always_ON	The output is always ON.																																																																																								
When Generic input signal status is to be output.																																																																																									
<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>3A: CONT1_ON</td> <td>The output is ON while general purpose input CONT 1 is ON.</td> </tr> <tr> <td>3B: CONT1_OFF</td> <td>The output is OFF while general purpose input CONT 1 is ON.</td> </tr> <tr> <td>3C: CONT2_ON</td> <td>The output is ON while general purpose input CONT 2 is ON.</td> </tr> <tr> <td>3D: CONT2_OFF</td> <td>The output is OFF while general purpose input CONT 2 is ON.</td> </tr> <tr> <td>3E: CONT3_ON</td> <td>The output is ON while general purpose input CONT 3 is ON.</td> </tr> <tr> <td>3F: CONT3_OFF</td> <td>The output is OFF while general purpose input CONT 3 is ON.</td> </tr> <tr> <td>40: CONT4_ON</td> <td>The output is ON while general purpose input CONT 4 is ON.</td> </tr> <tr> <td>41: CONT4_OFF</td> <td>The output is OFF while general purpose input CONT 4 is ON.</td> </tr> </tbody> </table>	Selection	Contents	3A: CONT1_ON	The output is ON while general purpose input CONT 1 is ON.	3B: CONT1_OFF	The output is OFF while general purpose input CONT 1 is ON.	3C: CONT2_ON	The output is ON while general purpose input CONT 2 is ON.	3D: CONT2_OFF	The output is OFF while general purpose input CONT 2 is ON.	3E: CONT3_ON	The output is ON while general purpose input CONT 3 is ON.	3F: CONT3_OFF	The output is OFF while general purpose input CONT 3 is ON.	40: CONT4_ON	The output is ON while general purpose input CONT 4 is ON.	41: CONT4_OFF	The output is OFF while general purpose input CONT 4 is ON.	<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>42: CONT5_ON</td> <td>The output is ON while general purpose input CONT 5 is ON.</td> </tr> <tr> <td>43: CONT5_OFF</td> <td>The output is OFF while general purpose input CONT 5 is ON.</td> </tr> <tr> <td>44: CONT6_ON</td> <td>The output is ON while general purpose input CONT 6 is ON.</td> </tr> <tr> <td>45: CONT6_OFF</td> <td>The output is OFF while general purpose input CONT6 is ON.</td> </tr> <tr> <td>46: CONT7_ON</td> <td>The output is ON while general purpose input CONT 7 is ON.</td> </tr> <tr> <td>47: CONT7_OFF</td> <td>The output is OFF while general purpose input CONT 7 is ON.</td> </tr> <tr> <td>48: CONT8_ON</td> <td>The output is ON while general purpose input CONT 8 is ON.</td> </tr> <tr> <td>49: CONT8_OFF</td> <td>The output is OFF while general purpose input CONT 8 is ON.</td> </tr> </tbody> </table>	Selection	Contents	42: CONT5_ON	The output is ON while general purpose input CONT 5 is ON.	43: CONT5_OFF	The output is OFF while general purpose input CONT 5 is ON.	44: CONT6_ON	The output is ON while general purpose input CONT 6 is ON.	45: CONT6_OFF	The output is OFF while general purpose input CONT6 is ON.	46: CONT7_ON	The output is ON while general purpose input CONT 7 is ON.	47: CONT7_OFF	The output is OFF while general purpose input CONT 7 is ON.	48: CONT8_ON	The output is ON while general purpose input CONT 8 is ON.	49: CONT8_OFF	The output is OFF while general purpose input CONT 8 is ON.																																																				
Selection	Contents																																																																																								
3A: CONT1_ON	The output is ON while general purpose input CONT 1 is ON.																																																																																								
3B: CONT1_OFF	The output is OFF while general purpose input CONT 1 is ON.																																																																																								
3C: CONT2_ON	The output is ON while general purpose input CONT 2 is ON.																																																																																								
3D: CONT2_OFF	The output is OFF while general purpose input CONT 2 is ON.																																																																																								
3E: CONT3_ON	The output is ON while general purpose input CONT 3 is ON.																																																																																								
3F: CONT3_OFF	The output is OFF while general purpose input CONT 3 is ON.																																																																																								
40: CONT4_ON	The output is ON while general purpose input CONT 4 is ON.																																																																																								
41: CONT4_OFF	The output is OFF while general purpose input CONT 4 is ON.																																																																																								
Selection	Contents																																																																																								
42: CONT5_ON	The output is ON while general purpose input CONT 5 is ON.																																																																																								
43: CONT5_OFF	The output is OFF while general purpose input CONT 5 is ON.																																																																																								
44: CONT6_ON	The output is ON while general purpose input CONT 6 is ON.																																																																																								
45: CONT6_OFF	The output is OFF while general purpose input CONT6 is ON.																																																																																								
46: CONT7_ON	The output is ON while general purpose input CONT 7 is ON.																																																																																								
47: CONT7_OFF	The output is OFF while general purpose input CONT 7 is ON.																																																																																								
48: CONT8_ON	The output is ON while general purpose input CONT 8 is ON.																																																																																								
49: CONT8_OFF	The output is OFF while general purpose input CONT 8 is ON.																																																																																								
When servo amplifier inner status is to be output.																																																																																									
<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>02: S-RDY_ON</td> <td>The output is ON during Servo Ready complete.</td> </tr> <tr> <td>03: S-RDY_OFF</td> <td>The output is OFF during Servo Ready complete.</td> </tr> <tr> <td>58: S-RDY2_ON</td> <td>The output is ON during Servo Ready complete.</td> </tr> <tr> <td>59: S-RDY2_OFF</td> <td>The output is OFF during Servo Ready complete.</td> </tr> <tr> <td>04: P-ON_ON</td> <td>The output is ON while the main power supply is turned on.</td> </tr> <tr> <td>05: P-ON_OFF</td> <td>The output is OFF while the main power supply is turned on.</td> </tr> <tr> <td>06: A-RDY_ON</td> <td>The output is ON during the main power supply ON permission.</td> </tr> <tr> <td>07: A-RDY_OFF</td> <td>The output is OFF during the main power supply ON permission.</td> </tr> <tr> <td>08: S-ON_ON</td> <td>The output is ON during motor excitation.</td> </tr> <tr> <td>09: S-ON_OFF</td> <td>The output is OFF during motor excitation.</td> </tr> <tr> <td>0A: MBR-ON_ON</td> <td>The output is ON while holding brake excitation signal outputs.</td> </tr> <tr> <td>0B: MBR-ON_OFF</td> <td>The output is OFF while holding brake excitation signal outputs.</td> </tr> <tr> <td>0C: TLC_ON</td> <td>The output is ON during torque limiting.</td> </tr> <tr> <td>0D: TLC_OFF</td> <td>The output is OFF during torque limiting.</td> </tr> <tr> <td>0E: VLC_ON</td> <td>The output is ON during velocity limiting.</td> </tr> <tr> <td>0F: VLC_OFF</td> <td>The output is OFF during velocity limiting.</td> </tr> <tr> <td>10: LOWV_ON</td> <td>The output is ON during low speed status (speed is less than LOWV).</td> </tr> <tr> <td>11: LOWV_OFF</td> <td>The output is OFF during low speed status (speed is less than LOWV).</td> </tr> <tr> <td>12: VA_ON</td> <td>The output is ON during high speed status (speed is more than VA).</td> </tr> <tr> <td>13: VA_OFF</td> <td>The output is OFF during high speed status (speed is more than VA).</td> </tr> <tr> <td>14: VCMP_ON</td> <td>The output is ON during speed matching status (velocity deviation &lt; VCMP).</td> </tr> <tr> <td>15: VCMP_OFF</td> <td>The output is OFF during speed matching status (velocity deviation &lt; VCMP).</td> </tr> </tbody> </table>	Selection	Contents	02: S-RDY_ON	The output is ON during Servo Ready complete.	03: S-RDY_OFF	The output is OFF during Servo Ready complete.	58: S-RDY2_ON	The output is ON during Servo Ready complete.	59: S-RDY2_OFF	The output is OFF during Servo Ready complete.	04: P-ON_ON	The output is ON while the main power supply is turned on.	05: P-ON_OFF	The output is OFF while the main power supply is turned on.	06: A-RDY_ON	The output is ON during the main power supply ON permission.	07: A-RDY_OFF	The output is OFF during the main power supply ON permission.	08: S-ON_ON	The output is ON during motor excitation.	09: S-ON_OFF	The output is OFF during motor excitation.	0A: MBR-ON_ON	The output is ON while holding brake excitation signal outputs.	0B: MBR-ON_OFF	The output is OFF while holding brake excitation signal outputs.	0C: TLC_ON	The output is ON during torque limiting.	0D: TLC_OFF	The output is OFF during torque limiting.	0E: VLC_ON	The output is ON during velocity limiting.	0F: VLC_OFF	The output is OFF during velocity limiting.	10: LOWV_ON	The output is ON during low speed status (speed is less than LOWV).	11: LOWV_OFF	The output is OFF during low speed status (speed is less than LOWV).	12: VA_ON	The output is ON during high speed status (speed is more than VA).	13: VA_OFF	The output is OFF during high speed status (speed is more than VA).	14: VCMP_ON	The output is ON during speed matching status (velocity deviation < VCMP).	15: VCMP_OFF	The output is OFF during speed matching status (velocity deviation < VCMP).	<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>16: ZV_ON</td> <td>The output is ON during zero speed status (speed is less than ZV).</td> </tr> <tr> <td>17: ZV_OFF</td> <td>The output is OFF during zero speed status (speed is less than ZV).</td> </tr> <tr> <td>1C: CMD-ACK_ON</td> <td>The output is ON while command can be accepted.</td> </tr> <tr> <td>1D: CMD-ACK_OFF</td> <td>The output is OFF while command can be accepted.</td> </tr> <tr> <td>1E: GC-ACK_ON</td> <td>The output is ON during gain switching.</td> </tr> <tr> <td>1F: GC-ACK_OFF</td> <td>The output is OFF during gain switching.</td> </tr> <tr> <td>20: PCON-ACK_ON</td> <td>The output is ON during velocity loop proportional control switching.</td> </tr> <tr> <td>21: PCON-ACK_OFF</td> <td>The output is OFF during velocity loop proportional control switching.</td> </tr> <tr> <td>22: GERS-ACK_ON</td> <td>The output is ON during electric gear switching.</td> </tr> <tr> <td>23: GERS-ACK_OFF</td> <td>The output is OFF during electric gear switching.</td> </tr> <tr> <td>24: MS-ACK_ON</td> <td>The output is ON during control mode switching.</td> </tr> <tr> <td>25: MS-ACK_OFF</td> <td>The output is OFF during control mode switching.</td> </tr> <tr> <td>26: F-OT_ON</td> <td>The output is ON during positive over-travel status.</td> </tr> <tr> <td>27: F-OT_OFF</td> <td>The output is OFF during positive over-travel status.</td> </tr> <tr> <td>28: R-OT_ON</td> <td>The output is ON during negative over-travel status.</td> </tr> <tr> <td>29: R-OT_OFF</td> <td>The output is OFF during negative over-travel status.</td> </tr> <tr> <td>4A: CHARGE_ON</td> <td>The output is ON while main power supply (capacitor) is charging.</td> </tr> <tr> <td>4B: CHARGE_OFF</td> <td>The output is OFF while main power supply (capacitor) is charging.</td> </tr> <tr> <td>4C: DB_OFF</td> <td>The output is OFF during dynamic braking.</td> </tr> <tr> <td>4D: DB_ON</td> <td>The output is ON during dynamic braking.</td> </tr> </tbody> </table>	Selection	Contents	16: ZV_ON	The output is ON during zero speed status (speed is less than ZV).	17: ZV_OFF	The output is OFF during zero speed status (speed is less than ZV).	1C: CMD-ACK_ON	The output is ON while command can be accepted.	1D: CMD-ACK_OFF	The output is OFF while command can be accepted.	1E: GC-ACK_ON	The output is ON during gain switching.	1F: GC-ACK_OFF	The output is OFF during gain switching.	20: PCON-ACK_ON	The output is ON during velocity loop proportional control switching.	21: PCON-ACK_OFF	The output is OFF during velocity loop proportional control switching.	22: GERS-ACK_ON	The output is ON during electric gear switching.	23: GERS-ACK_OFF	The output is OFF during electric gear switching.	24: MS-ACK_ON	The output is ON during control mode switching.	25: MS-ACK_OFF	The output is OFF during control mode switching.	26: F-OT_ON	The output is ON during positive over-travel status.	27: F-OT_OFF	The output is OFF during positive over-travel status.	28: R-OT_ON	The output is ON during negative over-travel status.	29: R-OT_OFF	The output is OFF during negative over-travel status.	4A: CHARGE_ON	The output is ON while main power supply (capacitor) is charging.	4B: CHARGE_OFF	The output is OFF while main power supply (capacitor) is charging.	4C: DB_OFF	The output is OFF during dynamic braking.	4D: DB_ON	The output is ON during dynamic braking.
Selection	Contents																																																																																								
02: S-RDY_ON	The output is ON during Servo Ready complete.																																																																																								
03: S-RDY_OFF	The output is OFF during Servo Ready complete.																																																																																								
58: S-RDY2_ON	The output is ON during Servo Ready complete.																																																																																								
59: S-RDY2_OFF	The output is OFF during Servo Ready complete.																																																																																								
04: P-ON_ON	The output is ON while the main power supply is turned on.																																																																																								
05: P-ON_OFF	The output is OFF while the main power supply is turned on.																																																																																								
06: A-RDY_ON	The output is ON during the main power supply ON permission.																																																																																								
07: A-RDY_OFF	The output is OFF during the main power supply ON permission.																																																																																								
08: S-ON_ON	The output is ON during motor excitation.																																																																																								
09: S-ON_OFF	The output is OFF during motor excitation.																																																																																								
0A: MBR-ON_ON	The output is ON while holding brake excitation signal outputs.																																																																																								
0B: MBR-ON_OFF	The output is OFF while holding brake excitation signal outputs.																																																																																								
0C: TLC_ON	The output is ON during torque limiting.																																																																																								
0D: TLC_OFF	The output is OFF during torque limiting.																																																																																								
0E: VLC_ON	The output is ON during velocity limiting.																																																																																								
0F: VLC_OFF	The output is OFF during velocity limiting.																																																																																								
10: LOWV_ON	The output is ON during low speed status (speed is less than LOWV).																																																																																								
11: LOWV_OFF	The output is OFF during low speed status (speed is less than LOWV).																																																																																								
12: VA_ON	The output is ON during high speed status (speed is more than VA).																																																																																								
13: VA_OFF	The output is OFF during high speed status (speed is more than VA).																																																																																								
14: VCMP_ON	The output is ON during speed matching status (velocity deviation < VCMP).																																																																																								
15: VCMP_OFF	The output is OFF during speed matching status (velocity deviation < VCMP).																																																																																								
Selection	Contents																																																																																								
16: ZV_ON	The output is ON during zero speed status (speed is less than ZV).																																																																																								
17: ZV_OFF	The output is OFF during zero speed status (speed is less than ZV).																																																																																								
1C: CMD-ACK_ON	The output is ON while command can be accepted.																																																																																								
1D: CMD-ACK_OFF	The output is OFF while command can be accepted.																																																																																								
1E: GC-ACK_ON	The output is ON during gain switching.																																																																																								
1F: GC-ACK_OFF	The output is OFF during gain switching.																																																																																								
20: PCON-ACK_ON	The output is ON during velocity loop proportional control switching.																																																																																								
21: PCON-ACK_OFF	The output is OFF during velocity loop proportional control switching.																																																																																								
22: GERS-ACK_ON	The output is ON during electric gear switching.																																																																																								
23: GERS-ACK_OFF	The output is OFF during electric gear switching.																																																																																								
24: MS-ACK_ON	The output is ON during control mode switching.																																																																																								
25: MS-ACK_OFF	The output is OFF during control mode switching.																																																																																								
26: F-OT_ON	The output is ON during positive over-travel status.																																																																																								
27: F-OT_OFF	The output is OFF during positive over-travel status.																																																																																								
28: R-OT_ON	The output is ON during negative over-travel status.																																																																																								
29: R-OT_OFF	The output is OFF during negative over-travel status.																																																																																								
4A: CHARGE_ON	The output is ON while main power supply (capacitor) is charging.																																																																																								
4B: CHARGE_OFF	The output is OFF while main power supply (capacitor) is charging.																																																																																								
4C: DB_OFF	The output is OFF during dynamic braking.																																																																																								
4D: DB_ON	The output is ON during dynamic braking.																																																																																								
When positioning signal is to be output.																																																																																									
<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>18: INP_ON</td> <td>The output is ON during In-Position status (position deviation &lt; INP).</td> </tr> <tr> <td>19: INP_OFF</td> <td>The output is OFF during In-Position status (position deviation &lt; INP).</td> </tr> <tr> <td>1A: NEAR_ON</td> <td>The output is ON during In-Position Near status (position deviation &lt; NEAR).</td> </tr> <tr> <td>1B: NEAR_OFF</td> <td>The output is OFF during In-Position Near status (position deviation &lt; NEAR).</td> </tr> <tr> <td>5A: INPZ_ON</td> <td>The output is ON during PCMD=0 and In-position Status.</td> </tr> <tr> <td>5B: INPZ_OFF</td> <td>The output is OFF during PCMD=0 and In-position Status.</td> </tr> </tbody> </table>	Selection	Contents	18: INP_ON	The output is ON during In-Position status (position deviation < INP).	19: INP_OFF	The output is OFF during In-Position status (position deviation < INP).	1A: NEAR_ON	The output is ON during In-Position Near status (position deviation < NEAR).	1B: NEAR_OFF	The output is OFF during In-Position Near status (position deviation < NEAR).	5A: INPZ_ON	The output is ON during PCMD=0 and In-position Status.	5B: INPZ_OFF	The output is OFF during PCMD=0 and In-position Status.	<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>2A: WNG-OFW_ON</td> <td>The output is ON during following warning status (position deviation &gt; OFWLW).</td> </tr> <tr> <td>2B: WNG-OFW_OFF</td> <td>The output is OFF during following warning status (position deviation &gt; OFWLW).</td> </tr> <tr> <td>2C: WNG-OLW_ON</td> <td>The output is ON during over-load warning status.</td> </tr> <tr> <td>2D: WNG-OLW_OFF</td> <td>The output is OFF during over-load warning status.</td> </tr> <tr> <td>2E: WNG-ROLW_ON</td> <td>The output is ON during regenerative over-load warning status.</td> </tr> <tr> <td>2F: WNG-ROLW_OFF</td> <td>The output is OFF during regenerative over-load warning status.</td> </tr> <tr> <td>30: WNG-BAT_ON</td> <td>The output is ON during battery warning.</td> </tr> <tr> <td>31: WNG-BAT_OFF</td> <td>The output is OFF during battery warning.</td> </tr> </tbody> </table>	Selection	Contents	2A: WNG-OFW_ON	The output is ON during following warning status (position deviation > OFWLW).	2B: WNG-OFW_OFF	The output is OFF during following warning status (position deviation > OFWLW).	2C: WNG-OLW_ON	The output is ON during over-load warning status.	2D: WNG-OLW_OFF	The output is OFF during over-load warning status.	2E: WNG-ROLW_ON	The output is ON during regenerative over-load warning status.	2F: WNG-ROLW_OFF	The output is OFF during regenerative over-load warning status.	30: WNG-BAT_ON	The output is ON during battery warning.	31: WNG-BAT_OFF	The output is OFF during battery warning.																																																								
Selection	Contents																																																																																								
18: INP_ON	The output is ON during In-Position status (position deviation < INP).																																																																																								
19: INP_OFF	The output is OFF during In-Position status (position deviation < INP).																																																																																								
1A: NEAR_ON	The output is ON during In-Position Near status (position deviation < NEAR).																																																																																								
1B: NEAR_OFF	The output is OFF during In-Position Near status (position deviation < NEAR).																																																																																								
5A: INPZ_ON	The output is ON during PCMD=0 and In-position Status.																																																																																								
5B: INPZ_OFF	The output is OFF during PCMD=0 and In-position Status.																																																																																								
Selection	Contents																																																																																								
2A: WNG-OFW_ON	The output is ON during following warning status (position deviation > OFWLW).																																																																																								
2B: WNG-OFW_OFF	The output is OFF during following warning status (position deviation > OFWLW).																																																																																								
2C: WNG-OLW_ON	The output is ON during over-load warning status.																																																																																								
2D: WNG-OLW_OFF	The output is OFF during over-load warning status.																																																																																								
2E: WNG-ROLW_ON	The output is ON during regenerative over-load warning status.																																																																																								
2F: WNG-ROLW_OFF	The output is OFF during regenerative over-load warning status.																																																																																								
30: WNG-BAT_ON	The output is ON during battery warning.																																																																																								
31: WNG-BAT_OFF	The output is OFF during battery warning.																																																																																								
When alarm signals are to be output.																																																																																									
<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>32: ALM5_ON</td> <td>Output alarm code, bit 5. (Positive logic).</td> </tr> <tr> <td>33: ALM5_OFF</td> <td>Output alarm code, bit 5. (Negative logic).</td> </tr> <tr> <td>34: ALM6_ON</td> <td>Output alarm code, bit 6. (Positive logic).</td> </tr> <tr> <td>35: ALM6_OFF</td> <td>Output alarm code, bit 6. (Negative logic).</td> </tr> <tr> <td>36: ALM7_ON</td> <td>Output alarm code, bit 7. (Positive logic).</td> </tr> <tr> <td>37: ALM7_OFF</td> <td>Output alarm code, bit 7. (Negative logic).</td> </tr> <tr> <td>38: ALM_ON</td> <td>The output is ON during alarm status.</td> </tr> <tr> <td>39: ALM_OFF</td> <td>The output is OFF during alarm status.</td> </tr> </tbody> </table>	Selection	Contents	32: ALM5_ON	Output alarm code, bit 5. (Positive logic).	33: ALM5_OFF	Output alarm code, bit 5. (Negative logic).	34: ALM6_ON	Output alarm code, bit 6. (Positive logic).	35: ALM6_OFF	Output alarm code, bit 6. (Negative logic).	36: ALM7_ON	Output alarm code, bit 7. (Positive logic).	37: ALM7_OFF	Output alarm code, bit 7. (Negative logic).	38: ALM_ON	The output is ON during alarm status.	39: ALM_OFF	The output is OFF during alarm status.	<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>50: PYALM1_ON</td> <td>Output PY compatible alarm code 1. (Positive logic).</td> </tr> <tr> <td>51: PYALM1_OFF</td> <td>Output PY compatible alarm code 1. (Negative logic).</td> </tr> <tr> <td>52: PYALM2_ON</td> <td>Output PY compatible alarm code 2. (Positive logic).</td> </tr> <tr> <td>53: PYALM2_OFF</td> <td>Output PY compatible alarm code 1. (Negative logic).</td> </tr> <tr> <td>54: PYALM4_ON</td> <td>Output PY compatible alarm code 4. (Positive logic).</td> </tr> <tr> <td>55: PYALM4_OFF</td> <td>Output PY compatible alarm code 4. (Negative logic).</td> </tr> <tr> <td>56: PYALM8_ON</td> <td>Output PY compatible alarm code 8. (Positive logic).</td> </tr> <tr> <td>57: PYALM8_OFF</td> <td>Output PY compatible alarm code 8. (Negative logic).</td> </tr> </tbody> </table>	Selection	Contents	50: PYALM1_ON	Output PY compatible alarm code 1. (Positive logic).	51: PYALM1_OFF	Output PY compatible alarm code 1. (Negative logic).	52: PYALM2_ON	Output PY compatible alarm code 2. (Positive logic).	53: PYALM2_OFF	Output PY compatible alarm code 1. (Negative logic).	54: PYALM4_ON	Output PY compatible alarm code 4. (Positive logic).	55: PYALM4_OFF	Output PY compatible alarm code 4. (Negative logic).	56: PYALM8_ON	Output PY compatible alarm code 8. (Positive logic).	57: PYALM8_OFF	Output PY compatible alarm code 8. (Negative logic).																																																				
Selection	Contents																																																																																								
32: ALM5_ON	Output alarm code, bit 5. (Positive logic).																																																																																								
33: ALM5_OFF	Output alarm code, bit 5. (Negative logic).																																																																																								
34: ALM6_ON	Output alarm code, bit 6. (Positive logic).																																																																																								
35: ALM6_OFF	Output alarm code, bit 6. (Negative logic).																																																																																								
36: ALM7_ON	Output alarm code, bit 7. (Positive logic).																																																																																								
37: ALM7_OFF	Output alarm code, bit 7. (Negative logic).																																																																																								
38: ALM_ON	The output is ON during alarm status.																																																																																								
39: ALM_OFF	The output is OFF during alarm status.																																																																																								
Selection	Contents																																																																																								
50: PYALM1_ON	Output PY compatible alarm code 1. (Positive logic).																																																																																								
51: PYALM1_OFF	Output PY compatible alarm code 1. (Negative logic).																																																																																								
52: PYALM2_ON	Output PY compatible alarm code 2. (Positive logic).																																																																																								
53: PYALM2_OFF	Output PY compatible alarm code 1. (Negative logic).																																																																																								
54: PYALM4_ON	Output PY compatible alarm code 4. (Positive logic).																																																																																								
55: PYALM4_OFF	Output PY compatible alarm code 4. (Negative logic).																																																																																								
56: PYALM8_ON	Output PY compatible alarm code 8. (Positive logic).																																																																																								
57: PYALM8_OFF	Output PY compatible alarm code 8. (Negative logic).																																																																																								

## 5. Parameter [Parameter setting value [GroupA] 1]

When CAN open object OUTPUT are to be output.


Selection	Contents
5C: CAN_OUTPUT1_ON	The Output is ON while CAN Object OUTPUT1 is 1.
5D: CAN_OUTPUT1_OFF	The Output is OFF while CAN Object OUTPUT1 is 1.
5E: CAN_OUTPUT2_ON	The Output is ON while CAN Object OUTPUT2 is 1.
5F: CAN_OUTPUT2_OFF	The Output is OFF while CAN Object OUTPUT2 is 1.
60: CAN_OUTPUT3_ON	The Output is ON while CAN Object OUTPUT3 is 1.
61: CAN_OUTPUT3_OFF	The Output is OFF while CAN Object OUTPUT3 is 1.
62: CAN_OUTPUT4_ON	The Output is ON while CAN Object OUTPUT4 is 1.
63: CAN_OUTPUT4_OFF	The Output is OFF while CAN Object OUTPUT4 is 1.
64: CAN_OUTPUT5_ON	The Output is ON while CAN Object OUTPUT5 is 1.
65: CAN_OUTPUT5_OFF	The Output is OFF while CAN Object OUTPUT5 is 1.
66: CAN_OUTPUT6_ON	The Output is ON while CAN Object OUTPUT6 is 1.
67: CAN_OUTPUT6_OFF	The Output is OFF while CAN Object OUTPUT6 is 1.
68: CAN_OUTPUT7_ON	The Output is ON while CAN Object OUTPUT7 is 1.
69: CAN_OUTPUT7_OFF	The Output is OFF while CAN Object OUTPUT7 is 1.
6A: CAN_OUTPUT8_ON	The Output is ON while CAN Object OUTPUT8 is 1.
6B: CAN_OUTPUT8_OFF	The Output is OFF while CAN Object OUTPUT8 is 1.

# 5. Parameter [Parameter setting value [GroupA] 1

Page	Contents																								
13	Analog monitor output polarity [MONPOL]																								
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~08</td> <td>00:_MON1+_MON2+</td> </tr> </tbody> </table>	Setting range	Standard value	00~08	00:_MON1+_MON2+	<p>The output polarity of analog monitor output MON1 and MON2 is selected from the contents below.</p> <table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_MON1+_MON2+</td> <td>MON1 : Output the positive voltage at forward rotation (positive direction). Output the positive/negative voltage. MON2 : Output the positive voltage at forward rotation (positive direction). Output the positive/negative voltage.</td> </tr> <tr> <td>01:_MON1-_MON2+</td> <td>MON1 : Output the negative voltage at forward rotation (positive direction). Output the positive/negative voltage. MON2 : Output the positive voltage at forward rotation (positive direction). Output the positive/negative voltage.</td> </tr> <tr> <td>02:_MON1+_MON2-</td> <td>MON1 : Output the positive voltage at forward rotation (positive direction). Output the positive/negative voltage. MON2 : Output the negative voltage at forward rotation (positive direction). Output the positive/negative voltage.</td> </tr> <tr> <td>03:_MON1-_MON2-</td> <td>MON1 : Output the negative voltage at forward rotation (positive direction). Output the positive/negative voltage. MON2 : Output the negative voltage at forward rotation (positive direction). Output the positive/negative voltage.</td> </tr> <tr> <td>04:_MON1ABS_MON2+</td> <td>MON1 : Output the positive voltage at both forward rotation (positive direction) and reverse rotation (reverse direction). MON2 : Output the positive voltage at forward rotation (positive direction). Output the positive/negative voltage.</td> </tr> <tr> <td>05:_MON1ABS_MON2-</td> <td>MON1 : Output the positive voltage at both forward rotation (positive direction) and reverse rotation (reverse direction). MON2 : Output the negative voltage at forward rotation (positive direction). Output the positive/negative voltage.</td> </tr> <tr> <td>06:_MON1+_MON2ABS</td> <td>MON1 : Output the positive voltage at forward rotation (positive direction). Output the positive/negative voltage. MON2 : Output the positive voltage at both forward rotation (positive direction) and reverse rotation (reverse direction).</td> </tr> <tr> <td>07:_MON1-_MON2ABS</td> <td>MON1 : Output the negative voltage at forward rotation (positive direction). Output the positive/negative voltage. MON2 : Output the positive voltage at both forward rotation (positive direction) and reverse rotation (reverse direction).</td> </tr> <tr> <td>08:_MON1ABS_MON2ABS</td> <td>MON1 : Output the positive voltage at both forward rotation (positive direction) and reverse rotation (reverse direction). MON2 : Output the positive voltage at both forward rotation (positive direction) and reverse rotation (reverse direction).</td> </tr> </tbody> </table>	Selection	Contents	00:_MON1+_MON2+	MON1 : Output the positive voltage at forward rotation (positive direction). Output the positive/negative voltage. MON2 : Output the positive voltage at forward rotation (positive direction). Output the positive/negative voltage.	01:_MON1-_MON2+	MON1 : Output the negative voltage at forward rotation (positive direction). Output the positive/negative voltage. MON2 : Output the positive voltage at forward rotation (positive direction). Output the positive/negative voltage.	02:_MON1+_MON2-	MON1 : Output the positive voltage at forward rotation (positive direction). Output the positive/negative voltage. MON2 : Output the negative voltage at forward rotation (positive direction). Output the positive/negative voltage.	03:_MON1-_MON2-	MON1 : Output the negative voltage at forward rotation (positive direction). Output the positive/negative voltage. MON2 : Output the negative voltage at forward rotation (positive direction). Output the positive/negative voltage.	04:_MON1ABS_MON2+	MON1 : Output the positive voltage at both forward rotation (positive direction) and reverse rotation (reverse direction). MON2 : Output the positive voltage at forward rotation (positive direction). Output the positive/negative voltage.	05:_MON1ABS_MON2-	MON1 : Output the positive voltage at both forward rotation (positive direction) and reverse rotation (reverse direction). MON2 : Output the negative voltage at forward rotation (positive direction). Output the positive/negative voltage.	06:_MON1+_MON2ABS	MON1 : Output the positive voltage at forward rotation (positive direction). Output the positive/negative voltage. MON2 : Output the positive voltage at both forward rotation (positive direction) and reverse rotation (reverse direction).	07:_MON1-_MON2ABS	MON1 : Output the negative voltage at forward rotation (positive direction). Output the positive/negative voltage. MON2 : Output the positive voltage at both forward rotation (positive direction) and reverse rotation (reverse direction).	08:_MON1ABS_MON2ABS
Setting range	Standard value																								
00~08	00:_MON1+_MON2+																								
Selection	Contents																								
00:_MON1+_MON2+	MON1 : Output the positive voltage at forward rotation (positive direction). Output the positive/negative voltage. MON2 : Output the positive voltage at forward rotation (positive direction). Output the positive/negative voltage.																								
01:_MON1-_MON2+	MON1 : Output the negative voltage at forward rotation (positive direction). Output the positive/negative voltage. MON2 : Output the positive voltage at forward rotation (positive direction). Output the positive/negative voltage.																								
02:_MON1+_MON2-	MON1 : Output the positive voltage at forward rotation (positive direction). Output the positive/negative voltage. MON2 : Output the negative voltage at forward rotation (positive direction). Output the positive/negative voltage.																								
03:_MON1-_MON2-	MON1 : Output the negative voltage at forward rotation (positive direction). Output the positive/negative voltage. MON2 : Output the negative voltage at forward rotation (positive direction). Output the positive/negative voltage.																								
04:_MON1ABS_MON2+	MON1 : Output the positive voltage at both forward rotation (positive direction) and reverse rotation (reverse direction). MON2 : Output the positive voltage at forward rotation (positive direction). Output the positive/negative voltage.																								
05:_MON1ABS_MON2-	MON1 : Output the positive voltage at both forward rotation (positive direction) and reverse rotation (reverse direction). MON2 : Output the negative voltage at forward rotation (positive direction). Output the positive/negative voltage.																								
06:_MON1+_MON2ABS	MON1 : Output the positive voltage at forward rotation (positive direction). Output the positive/negative voltage. MON2 : Output the positive voltage at both forward rotation (positive direction) and reverse rotation (reverse direction).																								
07:_MON1-_MON2ABS	MON1 : Output the negative voltage at forward rotation (positive direction). Output the positive/negative voltage. MON2 : Output the positive voltage at both forward rotation (positive direction) and reverse rotation (reverse direction).																								
08:_MON1ABS_MON2ABS	MON1 : Output the positive voltage at both forward rotation (positive direction) and reverse rotation (reverse direction). MON2 : Output the positive voltage at both forward rotation (positive direction) and reverse rotation (reverse direction).																								
20	Setup Software, Communication Axis Number [COMAXIS]																								
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>01~0F</td> <td>01: #1</td> </tr> </tbody> </table>	Setting range	Standard value	01~0F	01: #1	<p>The axis number for communication with PC is selected from the contents below.</p> <p> The selected value is enabled after turning ON the control power again.</p>																			
Setting range	Standard value																								
01~0F	01: #1																								
	<table border="1"> <thead> <tr> <th>Selection</th> <th>Selection</th> <th>Selection</th> <th>Selection</th> </tr> </thead> <tbody> <tr> <td>01: #1</td> <td>05: #5</td> <td>09: #9</td> <td>0D: #D</td> </tr> <tr> <td>02: #2</td> <td>06: #6</td> <td>0A: #A</td> <td>0E: #E</td> </tr> <tr> <td>03: #3</td> <td>07: #7</td> <td>0B: #B</td> <td>0F: #F</td> </tr> <tr> <td>04: #4</td> <td>08: #8</td> <td>0C: #C</td> <td></td> </tr> </tbody> </table>	Selection	Selection	Selection	Selection	01: #1	05: #5	09: #9	0D: #D	02: #2	06: #6	0A: #A	0E: #E	03: #3	07: #7	0B: #B	0F: #F	04: #4	08: #8	0C: #C					
Selection	Selection	Selection	Selection																						
01: #1	05: #5	09: #9	0D: #D																						
02: #2	06: #6	0A: #A	0E: #E																						
03: #3	07: #7	0B: #B	0F: #F																						
04: #4	08: #8	0C: #C																							
21	Setup Software, Communication Baud Rate [COMBAUD]																								
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~05</td> <td>05:_38400bps</td> </tr> </tbody> </table>	Setting range	Standard value	00~05	05:_38400bps	<p>The baud rate for communication with PC is selected from the contents below.</p> <p> The selected value is enabled after turning ON the control power again.</p>																			
Setting range	Standard value																								
00~05	05:_38400bps																								
	<table border="1"> <thead> <tr> <th>Selection</th> <th>Selection</th> </tr> </thead> <tbody> <tr> <td>00: _1200bps</td> <td>03: _9600bps</td> </tr> <tr> <td>01: _2400bps</td> <td>04: _19200bps</td> </tr> <tr> <td>02: _4800bps</td> <td>05: _38400bps</td> </tr> </tbody> </table>	Selection	Selection	00: _1200bps	03: _9600bps	01: _2400bps	04: _19200bps	02: _4800bps	05: _38400bps																
Selection	Selection																								
00: _1200bps	03: _9600bps																								
01: _2400bps	04: _19200bps																								
02: _4800bps	05: _38400bps																								


# 5. Parameter [Parameter setting value [GroupB] 1]

## ■ General parameter Group B [sequence/alarm related settings]

Page	Contents																
00	JOG Velocity Command [JOGVC]																
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0~32767</td> <td>min<sup>-1</sup></td> <td>50</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0~32767	min <sup>-1</sup>	50	Velocity command for test run and adjustment JOG operation is set.									
Setting range	Unit	Standard value															
0~32767	min <sup>-1</sup>	50															
10	Dynamic Brake Action Selection [DBOPE]																
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~05</td> <td>—</td> <td>04:_SB_Free</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~05	—	04:_SB_Free	Dynamic brake operation when shifted from servo ON → servo OFF, and during servo OFF is selected from the contents below.   When the main circuit power is shut OFF, the dynamic brake will operate irrespective of this setting.									
Setting range	Unit	Standard value															
00~05	—	04:_SB_Free															
11	Over-Travel Action Selection [ACTOT]																
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~06</td> <td>—</td> <td>00:_CMDINH_SB_SON</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~06	—	00:_CMDINH_SB_SON	Operations at over travel are selected from the contents below.									
Setting range	Unit	Standard value															
00~06	—	00:_CMDINH_SB_SON															
11	Selection																
	<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_Free_Free</td> <td>When Servo-OFF, Free-Run is operated. After stops, Motor-Free is operated.</td> </tr> <tr> <td>01:_Free_DB</td> <td>When Servo-OFF, Free-Run is operated. After stops, Dynamic-Braking is performed.</td> </tr> <tr> <td>02:_DB_Free</td> <td>When S-OFF, Dynamic-Braking is performed. After stops, Motor-Free is operated.</td> </tr> <tr> <td>03:_DB_DB</td> <td>When S-OFF, Dynamic-Braking is performed. After stops, Dynamic-Braking.</td> </tr> <tr> <td>04:_SB_Free</td> <td>When Servo-OFF, Servo-Braking is performed. After stops, Motor-Free is operated.</td> </tr> <tr> <td>05:_SB_DB</td> <td>When Servo-OFF, Servo-Braking is performed. After stops, Dynamic-Braking.</td> </tr> </tbody> </table>	Selection	Contents	00:_Free_Free	When Servo-OFF, Free-Run is operated. After stops, Motor-Free is operated.	01:_Free_DB	When Servo-OFF, Free-Run is operated. After stops, Dynamic-Braking is performed.	02:_DB_Free	When S-OFF, Dynamic-Braking is performed. After stops, Motor-Free is operated.	03:_DB_DB	When S-OFF, Dynamic-Braking is performed. After stops, Dynamic-Braking.	04:_SB_Free	When Servo-OFF, Servo-Braking is performed. After stops, Motor-Free is operated.	05:_SB_DB	When Servo-OFF, Servo-Braking is performed. After stops, Dynamic-Braking.		
Selection	Contents																
00:_Free_Free	When Servo-OFF, Free-Run is operated. After stops, Motor-Free is operated.																
01:_Free_DB	When Servo-OFF, Free-Run is operated. After stops, Dynamic-Braking is performed.																
02:_DB_Free	When S-OFF, Dynamic-Braking is performed. After stops, Motor-Free is operated.																
03:_DB_DB	When S-OFF, Dynamic-Braking is performed. After stops, Dynamic-Braking.																
04:_SB_Free	When Servo-OFF, Servo-Braking is performed. After stops, Motor-Free is operated.																
05:_SB_DB	When Servo-OFF, Servo-Braking is performed. After stops, Dynamic-Braking.																
11	Selection																
	<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_CMDINH_SB_SON</td> <td>PC is inhibited and Servo-Braking is performed. After stops, S-ON is operated.</td> </tr> <tr> <td>01:_CMDINH_DB_SON</td> <td>PC is inhibited and Dynamic-Braking is performed. After stops, S-ON is operated.</td> </tr> <tr> <td>02:_CMDINH_Free_SON</td> <td>PC is inhibited and Free-Run is performed. After stops, Servo-ON is operated.</td> </tr> <tr> <td>03:_CMDINH_SB_SOFF</td> <td>PC is inhibited and Servo-Braking is performed. After stops, S-OFF is operated.</td> </tr> <tr> <td>04:_CMDINH_DB_SOFF</td> <td>PC is inhibited and Dynamic-Braking is performed. After stops, S-OFF is operated.</td> </tr> <tr> <td>05:_CMDINH_Free_SOFF</td> <td>PC is inhibited and Free-Run is performed. After stops, Servo-OFF is operated.</td> </tr> <tr> <td>06:_CMDACK_VCLM=0</td> <td>****</td> </tr> </tbody> </table>	Selection	Contents	00:_CMDINH_SB_SON	PC is inhibited and Servo-Braking is performed. After stops, S-ON is operated.	01:_CMDINH_DB_SON	PC is inhibited and Dynamic-Braking is performed. After stops, S-ON is operated.	02:_CMDINH_Free_SON	PC is inhibited and Free-Run is performed. After stops, Servo-ON is operated.	03:_CMDINH_SB_SOFF	PC is inhibited and Servo-Braking is performed. After stops, S-OFF is operated.	04:_CMDINH_DB_SOFF	PC is inhibited and Dynamic-Braking is performed. After stops, S-OFF is operated.	05:_CMDINH_Free_SOFF	PC is inhibited and Free-Run is performed. After stops, Servo-OFF is operated.	06:_CMDACK_VCLM=0	****
Selection	Contents																
00:_CMDINH_SB_SON	PC is inhibited and Servo-Braking is performed. After stops, S-ON is operated.																
01:_CMDINH_DB_SON	PC is inhibited and Dynamic-Braking is performed. After stops, S-ON is operated.																
02:_CMDINH_Free_SON	PC is inhibited and Free-Run is performed. After stops, Servo-ON is operated.																
03:_CMDINH_SB_SOFF	PC is inhibited and Servo-Braking is performed. After stops, S-OFF is operated.																
04:_CMDINH_DB_SOFF	PC is inhibited and Dynamic-Braking is performed. After stops, S-OFF is operated.																
05:_CMDINH_Free_SOFF	PC is inhibited and Free-Run is performed. After stops, Servo-OFF is operated.																
06:_CMDACK_VCLM=0	****																
12	Emergency Stop Operation [ACTEMR]																
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~01</td> <td>—</td> <td>00:_SERVO-BRAKE</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~01	—	00:_SERVO-BRAKE	Forced stop operations (EMR) are selected from the contents below.									
Setting range	Unit	Standard value															
00~01	—	00:_SERVO-BRAKE															
12	Selection																
	<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_SERVO-BRAKE</td> <td>When EMR is input, motor is stopped by servo brake operations.</td> </tr> <tr> <td>01:_DINAMIC-BRAKE</td> <td>When EMR is input, motor is stopped by dynamic brake operations.</td> </tr> </tbody> </table>	Selection	Contents	00:_SERVO-BRAKE	When EMR is input, motor is stopped by servo brake operations.	01:_DINAMIC-BRAKE	When EMR is input, motor is stopped by dynamic brake operations.										
Selection	Contents																
00:_SERVO-BRAKE	When EMR is input, motor is stopped by servo brake operations.																
01:_DINAMIC-BRAKE	When EMR is input, motor is stopped by dynamic brake operations.																




## 5. Parameter [Parameter setting value [GroupB] 1]

Page	Contents							
13	Delay Time of Engaging Holding Brake (holding brake holding delay time) [BONDLY]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0~1000</td> <td>ms</td> <td>300</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0~1000	ms	300	Holding brake operation delay time when shifted from servo ON to servo OFF is set. When shifted from servo ON to servo OFF, motor excitation is kept during this time. (Velocity command is Zero.)
Setting range	Unit	Standard value						
0~1000	ms	300						
14	Delay Time of Releasing Holding Brake (holding brake release delay time) [BOFFDLY]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0~1000</td> <td>ms</td> <td>300</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0~1000	ms	300	Holding brake operation release delay time when shifted from servo OFF to servo ON is set. When shifted from servo OFF to servo ON, motor is excited during this time. (Velocity Command is Zero.)
Setting range	Unit	Standard value						
0~1000	ms	300						
15	Brake Operation Beginning Time [BONBGN]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>0~65535</td> <td>ms</td> <td>0</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	0~65535	ms	0	Parameter for setting motor free operation time, dynamic brake operation time and servo brake operation time. When shifted from servo ON to Servo OFF, holding brake and dynamic brake start to operate after this set time. When motor does not stop even after servo OFF at gravity axis or else, motor is stopped by holding brake and dynamic brake. In the system where motor speed becomes lower than Speed Zero Range (ZV) within the set time, this setting does not function. If set to 0msec, brake operation start time is disabled (=infinite).
Setting range	Unit	Standard value						
0~65535	ms	0						
16	Power Failure Detection Delay Time [PFDDLY]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>20~1000</td> <td>ms</td> <td>32</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	20~1000	ms	32	The delay time from control power OFF to control power error detection is set. The larger value makes the detection of instantaneous stop slower. (Larger set value will only result in slower detection of error. In case of power failure of internal logic circuit, operation is the same as when control power is turned ON again. In case of energy shortage of main circuit power, other errors, such as main circuit power loss, may be detected.) In this setting, actual detection delay time varies by 12ms and +6ms.  The selected value is enabled after control power is turned ON again.
Setting range	Unit	Standard value						
20~1000	ms	32						
20	Following Error Warning Level [OFWLVL]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~65535</td> <td>× 1024 Pulse</td> <td>65535</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~65535	× 1024 Pulse	65535	Parameter to output warning before excessive position deviation alarm (following error) is output.
Setting range	Unit	Standard value						
1~65535	× 1024 Pulse	65535						
21	Following Error Limit [OFLV]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1~65535</td> <td>× 1024 Pulse</td> <td>500</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1~65535	× 1024 Pulse	500	Parameter for setting the value to output position excessive deviation alarm (following error). Encoder pulse is the standard irrespective of electronic gear and command multiplication function.
Setting range	Unit	Standard value						
1~65535	× 1024 Pulse	500						


# 5. Parameter

## [Parameter setting value [GroupB] 1]


Page	Contents												
22	Overload Warning Level [OLWLV]												
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>20~100</td> <td>%</td> <td>90</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	20~100	%	90	<p>Parameter for outputting warnings before overload alarm is output. The possible level to be set is ranged from 20%~99%, assuming that the overload alarm level is 100%. When set to 100%, overload warning and overload alarm are output at one time.</p> <p>Overload detection is assumed and set as 75% of a rated load when control power is turned ON (hot start). Therefore, if this is set to below 75%, overload warning may be output when control power is turned ON.</p> <p> The set value is enabled after control power is turned ON again.</p>					
Setting range	Unit	Standard value											
20~100	%	90											
23	Speed Feedback Error (ALM_C3) Detection [VFBALM]												
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~01</td> <td>—</td> <td>01:_Enabled</td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_Disabled</td> <td>Disabled</td> </tr> <tr> <td>01:_Enabled</td> <td>Enabled</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~01	—	01:_Enabled	Selection	Contents	00:_Disabled	Disabled	01:_Enabled	Enabled
Setting range	Unit	Standard value											
00~01	—	01:_Enabled											
Selection	Contents												
00:_Disabled	Disabled												
01:_Enabled	Enabled												
24	Speed Control Error (ALM_C2) Detection [VCALM]												
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~01</td> <td>—</td> <td>00:_Disabled</td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_Disabled</td> <td>Disabled</td> </tr> <tr> <td>01:_Enabled</td> <td>Enabled</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~01	—	00:_Disabled	Selection	Contents	00:_Disabled	Disabled	01:_Enabled	Enabled
Setting range	Unit	Standard value											
00~01	—	00:_Disabled											
Selection	Contents												
00:_Disabled	Disabled												
01:_Enabled	Enabled												

# 5. Parameter [Parameter setting value [GroupC] 1




## ■ General parameter Group C [ Encoder related settings]

Page	Contents																						
00	Position detection system choice [ABS/INCSYS]																						
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~01</td> <td>—</td> <td>00:_Absolute</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~01	—	00:_Absolute	Position detection system is selected from the contents below.															
Setting range	Unit	Standard value																					
00~01	—	00:_Absolute																					
01	Motor Incremental Encoder, Digital Filter [ENFIL]																						
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~07</td> <td>—</td> <td>01_220nsec</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~07	—	01_220nsec	Settings for motor incremental encoder digital filter are selected from the contents below.															
Setting range	Unit	Standard value																					
00~07	—	01_220nsec																					
02	External Encoder, Digital Filter [EX-ENFIL]																						
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~07</td> <td>—</td> <td>01_220nsec</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~07	—	01_220nsec	Settings for external encoder digital filter are selected from the contents below.															
Setting range	Unit	Standard value																					
00~07	—	01_220nsec																					
00	<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_Absolute</td> <td>Absolute System</td> </tr> <tr> <td>01:_Incremental</td> <td>Incremental System</td> </tr> </tbody> </table>			Selection	Contents	00:_Absolute	Absolute System	01:_Incremental	Incremental System	Selecting "incremental system" enables the use similar to incremental encoder without installing backup battery in absolute encoder.  Please set it to "00:_Absolute" when you use absolute encoder for incremental system.													
	Selection	Contents																					
00:_Absolute	Absolute System																						
01:_Incremental	Incremental System																						
01	<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_110nsec</td> <td>Minimum Pulse Width = 110nsec (Minimum Pulse Phase Difference = 37.5nsec)</td> </tr> <tr> <td>01:_220nsec</td> <td>Minimum Pulse Width = 220nsec</td> </tr> <tr> <td>02:_440nsec</td> <td>Minimum Pulse Width = 440nsec</td> </tr> <tr> <td>03:_880nsec</td> <td>Minimum Pulse Width = 880nsec</td> </tr> <tr> <td>04:_75nsec</td> <td>Minimum Pulse Width = 75nsec (Minimum Pulse Phase Difference = 37.5nsec)</td> </tr> <tr> <td>05:_150nsec</td> <td>Minimum Pulse Width = 150nsec</td> </tr> <tr> <td>06:_300nsec</td> <td>Minimum Pulse Width = 300nsec</td> </tr> <tr> <td>07:_600nsec</td> <td>Minimum Pulse Width = 600nsec</td> </tr> </tbody> </table>			Selection	Contents	00:_110nsec	Minimum Pulse Width = 110nsec (Minimum Pulse Phase Difference = 37.5nsec)	01:_220nsec	Minimum Pulse Width = 220nsec	02:_440nsec	Minimum Pulse Width = 440nsec	03:_880nsec	Minimum Pulse Width = 880nsec	04:_75nsec	Minimum Pulse Width = 75nsec (Minimum Pulse Phase Difference = 37.5nsec)	05:_150nsec	Minimum Pulse Width = 150nsec	06:_300nsec	Minimum Pulse Width = 300nsec	07:_600nsec	Minimum Pulse Width = 600nsec		
	Selection	Contents																					
00:_110nsec	Minimum Pulse Width = 110nsec (Minimum Pulse Phase Difference = 37.5nsec)																						
01:_220nsec	Minimum Pulse Width = 220nsec																						
02:_440nsec	Minimum Pulse Width = 440nsec																						
03:_880nsec	Minimum Pulse Width = 880nsec																						
04:_75nsec	Minimum Pulse Width = 75nsec (Minimum Pulse Phase Difference = 37.5nsec)																						
05:_150nsec	Minimum Pulse Width = 150nsec																						
06:_300nsec	Minimum Pulse Width = 300nsec																						
07:_600nsec	Minimum Pulse Width = 600nsec																						
02	<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_110nsec</td> <td>Minimum pulse width = 110nsec (Minimum phase difference = 37.5nsec)</td> </tr> <tr> <td>01:_220nsec</td> <td>Minimum pulse width = 220nsec</td> </tr> <tr> <td>02:_440nsec</td> <td>Minimum pulse width = 440nsec</td> </tr> <tr> <td>03:_880nsec</td> <td>Minimum pulse width = 880nsec</td> </tr> <tr> <td>04:_75nsec</td> <td>Minimum pulse width = 75nsec (Minimum phase difference = 37.5nsec)</td> </tr> <tr> <td>05:_150nsec</td> <td>Minimum pulse width = 150nsec</td> </tr> <tr> <td>06:_300nsec</td> <td>Minimum pulse width = 300nsec</td> </tr> <tr> <td>07:_600nsec</td> <td>Minimum pulse width = 600nsec</td> </tr> </tbody> </table>			Selection	Contents	00:_110nsec	Minimum pulse width = 110nsec (Minimum phase difference = 37.5nsec)	01:_220nsec	Minimum pulse width = 220nsec	02:_440nsec	Minimum pulse width = 440nsec	03:_880nsec	Minimum pulse width = 880nsec	04:_75nsec	Minimum pulse width = 75nsec (Minimum phase difference = 37.5nsec)	05:_150nsec	Minimum pulse width = 150nsec	06:_300nsec	Minimum pulse width = 300nsec	07:_600nsec	Minimum pulse width = 600nsec		
	Selection	Contents																					
00:_110nsec	Minimum pulse width = 110nsec (Minimum phase difference = 37.5nsec)																						
01:_220nsec	Minimum pulse width = 220nsec																						
02:_440nsec	Minimum pulse width = 440nsec																						
03:_880nsec	Minimum pulse width = 880nsec																						
04:_75nsec	Minimum pulse width = 75nsec (Minimum phase difference = 37.5nsec)																						
05:_150nsec	Minimum pulse width = 150nsec																						
06:_300nsec	Minimum pulse width = 300nsec																						
07:_600nsec	Minimum pulse width = 600nsec																						

# 5. Parameter [Parameter setting value [GroupC] 1

Page	Contents														
03	External Encoder Polarity Invert [EX-ENPOL]														
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~07</td> <td>—</td> <td>00:_Type1</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~07	—	00:_Type1	External encoder signal polarity is selected from the contents below.   The set value is enabled after control power is turned ON again. When full close controlled and the motor encoder is absolute encoder, this setting is invalid. (Set at Type1.)							
Setting range	Unit	Standard value													
00~07	—	00:_Type1													
04	Encoder Pulse Divided Output, Selection [PULOUTSEL]														
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~01</td> <td>—</td> <td>00:_Motor_Enc.</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~01	—	00:_Motor_Enc.	Encoder pulse division output signal is selected from the contents below.  When full close controlled and the motor encoder is absolute encoder, external encoder pulse is output by selecting any of these.							
Setting range	Unit	Standard value													
00~01	—	00:_Motor_Enc.													
05	Encoder Output Pulse, Divide Ratio [ENRAT]														
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>1/1~1/64 2/3~2/64 1/8192~8191/8192</td> <td>—</td> <td>1/1</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	1/1~1/64 2/3~2/64 1/8192~8191/8192	—	1/1	Parameter for setting division ratio of encoder pulse dividing output. Division ratio is set. (Signal polarity can be set at amplifier function selection.)							
Setting range	Unit	Standard value													
1/1~1/64 2/3~2/64 1/8192~8191/8192	—	1/1													
06	Encoder Pulse Divided output, Polarity [PULOUTPOL]														
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~03</td> <td>—</td> <td>00:_Type1</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~03	—	00:_Type1	Encoder pulse dividing output polarity is selected from the followings.							
Setting range	Unit	Standard value													
00~03	—	00:_Type1													
06	<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_Type1</td> <td>A-Phase Signal / Not Reversed : Z-Phase Signal Logic / High Active</td> </tr> <tr> <td>01:_Type2</td> <td>A-Phase Signal / Reversed : Z-Phase Signal Logic / High Active</td> </tr> <tr> <td>02:_Type3</td> <td>A-Phase Signal / Not Reversed : Z-Phase Signal Logic / Low Active</td> </tr> <tr> <td>03:_Type4</td> <td>A-Phase Signal / Reversed : Z-Phase Signal Logic / Low Active</td> </tr> </tbody> </table>			Selection	Contents	00:_Type1	A-Phase Signal / Not Reversed : Z-Phase Signal Logic / High Active	01:_Type2	A-Phase Signal / Reversed : Z-Phase Signal Logic / High Active	02:_Type3	A-Phase Signal / Not Reversed : Z-Phase Signal Logic / Low Active	03:_Type4	A-Phase Signal / Reversed : Z-Phase Signal Logic / Low Active		
	Selection	Contents													
00:_Type1	A-Phase Signal / Not Reversed : Z-Phase Signal Logic / High Active														
01:_Type2	A-Phase Signal / Reversed : Z-Phase Signal Logic / High Active														
02:_Type3	A-Phase Signal / Not Reversed : Z-Phase Signal Logic / Low Active														
03:_Type4	A-Phase Signal / Reversed : Z-Phase Signal Logic / Low Active														

## 5. Parameter [Parameter setting value (system parameter)] 1

Page	Contents							
07	Encoder Signal Output (PS), Format [PSOFORM]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~02</td> <td>—</td> <td>00:_Binary</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~02	—	00:_Binary	<p>Signal format of encoder signal output(P S) is selected from the followings.</p> <p> The set value is enabled after control power is turned ON again.</p>
Setting range	Unit	Standard value						
00~02	—	00:_Binary						
08	Absolute Encoder Clear Function Selection [ECLRFUNC]							
	<table border="1"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>00~01</td> <td>—</td> <td>00:_Status_MultiTurn</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	00~01	—	00:_Status_MultiTurn	<p>Used for clearing some absolute encoder warnings which are not automatically restored.</p> <p> Valid when battery backup method absolute encoder and absolute encoder without battery is used.</p> <p> Please set it to "01:_Status" when you use absolute encoder for incremental system.</p>
Setting range	Unit	Standard value						
00~01	—	00:_Status_MultiTurn						
	<table border="1"> <thead> <tr> <th>Selection</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_Status_MultiTurn</td> <td>Clear Encoder Status (Alarm and Warning) and Multi Turn Data</td> </tr> <tr> <td>01:_Status</td> <td>Clear Only Encoder Status</td> </tr> </tbody> </table>		Selection	Contents	00:_Status_MultiTurn	Clear Encoder Status (Alarm and Warning) and Multi Turn Data	01:_Status	Clear Only Encoder Status
Selection	Contents							
00:_Status_MultiTurn	Clear Encoder Status (Alarm and Warning) and Multi Turn Data							
01:_Status	Clear Only Encoder Status							


# 5. Parameter [Parameter setting value (system parameter)] 1

## ■ System parameter

Page	Description		
00	Main Power, Input Type		
	Selects the input mode for power supplied to the main circuit power supply. Setting range varies depending on the hardware type.		
	Setting value	Description	
	00:_AC_3-phase	3 phase AC power is supplied to the main circuit.	
	01:_AC_Single-phase	Single phase AC power is supplied to the main circuit.	
01	Motor Encoder Type		
	Motor encoder type in use is selected. Setting range varies depending on the hardware type.		
	Setting value	Description	
	00 : _Incremental_ENC	Incremental Encoder	
	01 : _Absolute_ENC	Absolute Encoder	
02	Incremental Encoder, Function Setting		
	Incremental encoder type is selected when an incremental encoder is used for the motor encoder. Setting range varies depending on the hardware type.		
	Setting value	Description	
	00 : _Standard	Wiring-Save Incremental Encoder [Standard (4-Pairs)]	
	01 : _7Pairs_INC-E	Incremental Encoder with CS Signal. [7-Pairs]	
03	Incremental Encoder, Resolution Setting		
	Pulse number per motor shaft rotation is set when an incremental encoder is used for the motor encoder.		
	Setting range	Unit	Standard value
	500~65535	P/R	—
04	Absolute Encoder, Function Setting		
	Absolute encoder type is selected when an absolute encoder is used for the motor encoder. Setting range varies depending on the hardware type. Can only be selected when 01:_Absolute_ENC is selected at Page 0 1 (motor encoder type) .		
	Setting	Description	
	04 : _PA035C-2.5MH_Manu	PA035, Asynchronous, 2.5Mbps, Half Duplex (Manual Setting)	
	05 : _PA035C-4MH_Manu	PA035, Asynchronous, 4Mbps, Half Duplex (Manual Setting)	
	06 : _RA062C-2.5MH_Manu	RA062, Asynchronous, 2.5Mbps, Half Duplex (Manual Setting)	
	07 : _RA062C-4MH_Manu	RA062, Asynchronous, 4Mbps, Half Duplex (Manual Setting)	
	80 : _RA062M-1MF	RA062, Manchester, 1Mbps, Full Duplex	
	81 : _RA062M-2MF	RA062, Manchester, 2Mbps, Full Duplex	
	82 : _ABS-RII-1M	ABS-R II 1Mbps	
83 : _ABS-RII-2M	ABS-R II 2Mbps		
	84 : _ABS-E	ABS-E, 1Mbps (Absolute Encoder with Incremental Signal)	
05	Absolute Encoder, Resolution Setting		
	Divisions per motor shaft rotation are set when absolute encoder is used for the motor encoder. Can only be selected when 01:_Absolute_ENC is selected at Page 01 (motor encoder type) .		
	Setting	Description	
	00 : _2048_FMT	2048 divisions	
	01 : _4096_FMT	4096 divisions	
	02 : _8192_FMT	8192 divisions	
	03 : _16384_FMT	16384 divisions	
	04 : _32768_FMT	32768 divisions	
	05 : _65536_FMT	65536 divisions	
	06 : _131072_FMT	131072 divisions	
	07 : _262144_FMT	262144 divisions	
	08 : _524288_FMT	524288 divisions	
	09 : _1048576_FMT	1048576 divisions	
0A : _2097152_FMT	2097152 divisions		

## 5. Parameter [Parameter setting value (system parameter)] 1

Page	Description																				
06	Combined motor model number <span style="float: right;">Note 1)</span>	In "The set up software", model numbers of combined motor and their codes are shown. When combined motor is to be changed, change the motor parameter setting of "The set up software". ⚠ Combined motor cannot be changed. ⚠ Page contents are different for digital operator. Refer to Note 1).																			
08	Control Mode	Selects control mode.																			
	<table border="1" style="width: 100%;"> <thead> <tr> <th>Setting</th> <th>Description</th> <th>Setting</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>00 : _Torque</td> <td>Torque Control Mode</td> <td>03 : _Velo—Torq</td> <td>Velocity - Torque Switch Mode</td> </tr> <tr> <td>01 : _Velocity</td> <td>Velocity Control Mode</td> <td>04 : _Posi—Torq</td> <td>Position - Torque Switch Mode</td> </tr> <tr> <td>02 : _Position</td> <td>Position Control Mode</td> <td>05 : _Posi—Velo</td> <td>Position - Velocity Switch Mode</td> </tr> <tr> <td></td> <td></td> <td>06 : _CANopen</td> <td>CANopen mode</td> </tr> </tbody> </table> <p>⚠ when the switching type between [03:_Velo-Torq] [04 : _Posi—Torq] and [05 : _Posi—Velo] is used, there is a possibility that "auto-notch frequency tuning", "auto-vibration suppressing frequency tuning" and "JOG operation" cannot be used. To use these, switch the control mode to the base side (Velo(velocity control) in case of [03 : _Velo—Torq]).</p>	Setting	Description	Setting	Description	00 : _Torque	Torque Control Mode	03 : _Velo—Torq	Velocity - Torque Switch Mode	01 : _Velocity	Velocity Control Mode	04 : _Posi—Torq	Position - Torque Switch Mode	02 : _Position	Position Control Mode	05 : _Posi—Velo	Position - Velocity Switch Mode			06 : _CANopen	CANopen mode
Setting	Description	Setting	Description																		
00 : _Torque	Torque Control Mode	03 : _Velo—Torq	Velocity - Torque Switch Mode																		
01 : _Velocity	Velocity Control Mode	04 : _Posi—Torq	Position - Torque Switch Mode																		
02 : _Position	Position Control Mode	05 : _Posi—Velo	Position - Velocity Switch Mode																		
		06 : _CANopen	CANopen mode																		
09	Position Loop Control and Position Loop Encoder Selection	Position loop encoder is selected used for position loop control method and position loop control. Setting range varies depending on the hardware type.																			
	<table border="1" style="width: 100%;"> <thead> <tr> <th>Setting</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>00 : _Motor_encoder</td> <td>Semi-Closed Control / Motor Encoder</td> </tr> <tr> <td>01 : _Ext—ENC</td> <td>Fully Closed Control / External Encoder</td> </tr> </tbody> </table>	Setting	Description	00 : _Motor_encoder	Semi-Closed Control / Motor Encoder	01 : _Ext—ENC	Fully Closed Control / External Encoder														
Setting	Description																				
00 : _Motor_encoder	Semi-Closed Control / Motor Encoder																				
01 : _Ext—ENC	Fully Closed Control / External Encoder																				
0A	External Encoder, Resolution Setting	Sets the resolution of the external encoder under full closed control. Sets the number of converted pulses for each rotation of the motor shaft.																			
	<table border="1" style="width: 100%;"> <thead> <tr> <th>Setting range</th> <th>Unit</th> <th>Standard value</th> </tr> </thead> <tbody> <tr> <td>500~65535</td> <td>P/R</td> <td>—</td> </tr> </tbody> </table>	Setting range	Unit	Standard value	500~65535	P/R	—														
Setting range	Unit	Standard value																			
500~65535	P/R	—																			
0B	Regenerative Resistor Selection	Selects the type of regenerative resistance to be connected.																			
	<table border="1" style="width: 100%;"> <thead> <tr> <th>Setting</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>00 : _Not_connect</td> <td>Regenerative Resistor is not Connected</td> </tr> <tr> <td>01 : _Built-in_R</td> <td>Use Built-In Regenerative Resistor</td> </tr> <tr> <td>02 : _External_R</td> <td>Use External Regenerative Resistor</td> </tr> </tbody> </table>	Setting	Description	00 : _Not_connect	Regenerative Resistor is not Connected	01 : _Built-in_R	Use Built-In Regenerative Resistor	02 : _External_R	Use External Regenerative Resistor												
Setting	Description																				
00 : _Not_connect	Regenerative Resistor is not Connected																				
01 : _Built-in_R	Use Built-In Regenerative Resistor																				
02 : _External_R	Use External Regenerative Resistor																				

 The set value is enabled after control power is turned ON again.

## [Operations]

◆	Procedure prior to operation .....	6-1
◆	Confirmation of Installation and Wiring .....	6-3
◆	Confirmation and Change of servo amplifier specification ·	6-4
◆	JOG operation .....	6-5
◆	Confirmation of I/O signal .....	6-7
◆	Confirmation of I/O signals / Confirmation of	
	device operation .....	6-8
◆	Operation sequence .....	6-9



## 6. Operations

### [Procedure prior to operation]

- After wiring, test run will begin. Please do not connect the shaft of the servo motor with the machine.
  - Confirm installation and wiring of the servo amplifier and servo motor.

#### [Confirmation of installation and wiring]

Procedure	Item	Contents
1	Installation	Referring to [Chapter 2. Installation], install the servo amplifier and the servo motor. Do not connect the shaft of the servo motor into the machine to keep the status of no load.
2	Wiring and connection	Referring to [Chapter 3. Wiring], perform wirings for the power supply, the servo motor, and the upper device. However, please do not connect CN1 with the servo amplifier after wiring has been done.
3	Power supply turning on	Please turn on the power supply. Please confirm the alarm code is not being displayed at a digital operator of the servo amplifier. When it is displayed, follow the instructions in [Chapter 8 Maintenance].

- Confirm the specifications and the combination of the servo amplifier servo motor encoders.

#### [Confirmation and Change of specification]

Procedure	Item	Contents
4	Confirmation of servo amplifier specification	Use the AC servo system supporting tool R-Setup to confirm and set the specifications of the servo amplifier. <ul style="list-style-type: none"> <li>• Amplifier Capacity</li> <li>• Control power supply input voltage</li> <li>• Control power supply input type</li> <li>• Main circuit power supply input voltage</li> <li>• Main Power, Input Type</li> <li>• Control mode</li> <li>• Encoder selection for full close control</li> <li>• Regenerative Resistor Selection</li> </ul>
5	Confirmation of servo motor encoder specification	Use the AC servo system supporting tool R-Setup to confirm and set the specifications of the servo motor encoder. <ul style="list-style-type: none"> <li>• Motor Encoder Type</li> <li>• Incremental encoder function selection</li> <li>• Incremental Encoder, Resolution Setting</li> <li>• Absolute encoder function selection</li> <li>• Absolute Encoder, Resolution Setting</li> <li>• Confirmation of external encoder specification</li> </ul>
6	Confirmation of combined servo motor	At the time of shipment, the smallest servo motor is combined with the servo amplifier of each capacity. Confirm the servo motor model number and change the parameter for the one in use.
7	Power supply re-turning on	Turn off the power once and turn it on again. Parameter will have been changed by turning off the power supply. Without turning off the power, even if a parameter is changed here, the parameter change will not complete.
8	Reconfirmation	Please check again the specification changes of servo amplifier and servo encoder, and combination with servo motor. Many of the troubles at test run, such as servo motor not operating, are caused by mistakes in parameter setting.

## 6. Operations

### [Procedure prior to operation]

- The movement of the servo amplifier servo motor is confirmed by driving JOG. [JOG driving]

Procedure	Item	Contents
9	JOG driving	Do not connect the shaft of the servo motor into the machine to keep the status of no load, and perform JOG operation. Confirm that the servo motor rotates forwards and backwards.

- Connect the upper device with CN1, and set the parameter of the I/O signal.[I/O signal confirmation]

Procedure	Item	Contents
10	Setting of generic I/O signal	The generic I/O signal (CN1) has been set to standard at the time of shipment. Set I/O signals necessary to the servo amplifier.
11	Confirmation of input signal	Confirm the I/O signal status using the monitoring function inside the servo amplifier. Please confirm that there are protecting functions such as emergency stop, over travel, and alarm reset.
12	The servo on signal is input.	The servo on signal is input, and the servo motor is excited. Please confirm the digital operator on the servo amplifier front is displaying a shape of "8".
13	Command input	Input the command matched with the control mode in use. Confirm the command input at the servo amplifier monitoring function. Confirm that command input and the rotation direction are correct.
14	Power supply shut off	After the servo on signal is turned off, turn the power supply off.

- Connect the servo motor shaft with the machine and confirm the operation.

### [Confirmation of machine's operation function ]

Procedure	Item	Contents
15	Command input (low-speed)	Input the command (low-speed) matched with the control mode in use. Confirm the normal operation of moving direction, moving distance, emergency stop, over travel (F-OT · R-OT), etc.

- Input the operation pattern in use and start to operate the machine.

### [Operation]




Procedure	Item	Contents
16	Operation	At the time of shipment, real time auto-tuning (automatic adjustment for servo gain and filter) has been set. There is no need for manual tuning unless operations and characteristics are appropriate.

So far, overall procedure is shown.

More detailed procedure is described in the following pages.

# 6. Operations [Confirmation of installation and wiring]

■ [Procedure 1~Procedure 3] Confirmation of installation and wiring

Procedure	Item	Contents
1	<p><b>Installation</b></p> <p>Install the servo amplifier and servo motor referring to [Chapter 2, Installation].</p> <p>Do not connect the servo motor shaft to the machine to keep the status of no load.</p>	
2	<p><b>Wiring · Connecting</b></p> <p>Wire the power supply, servo motor and upper device referring to [Chapter 3, Wiring].</p> <p>Confirm the correct wiring.</p> <p>If the servo motor does not rotate or is in a state of runaway / overload in test run, wrong wiring may be the cause of it.</p> <p>Do not connect CN1 to servo amplifier after wiring.</p>	
3	<p><b>Turning on the power supply</b></p> <p>Turn on the power supply. Confirm that there is no alarm code displayed on the digital operator of servo amplifier. If there is one, follow the instructions in [Chapter 8, Maintenance].</p>	

## 6. Operations [Confirmation and change of servo amplifier specifications]

- [Procedure 4~Procedure 8] Confirming specifications and combination of servo amplifier · servo motor · encoder

Procedure	Item and Contents																	
4	<p><b>Confirming servo amplifier specifications</b> <span style="float: right;"><b>System parameter settings</b></span></p> <p>Use the AC servo system supporting tool R-Setup to confirm and set the specifications of the servo amplifier. For how to use [the setup software R-Setup], refer to [R-SETUP Instruction Manual].</p>																	
	Item																	
	<b>Amplifier Capacity</b>	Capacity of the servo amplifier.																
	<b>Motor Motion</b>	Structure of the motor that can be combined.																
	<b>Control power input voltage</b>	Voltage to be supplied to the control power.																
	<b>Input type of control power supply</b>	Input type of the control power supply.																
	<b>Main Power, Input Voltage</b>	Power voltage to be supplied to main circuit.																
	<b>Main Power, Input Type</b>	Selects the input type supplied to main circuit power. Change the set value to 01 : _AC_Single-phase for single phase use.																
	<b>Control Mode</b>	Selects the control mode. Change the control mode suitable for upper device.																
	<b>Full flossed control encoder selection</b>	No change is necessary for other than full closed system. Confirm that this is set to standard value, at the time of shipment, of 00 : _Motor_encoder.																
<b>Regenerative Resistor Selection</b>	Selects the regeneration resistance to be connected.																	
	Setting cannot be changed.																	
	Make sure that the contents being displayed are suitable for the machine specifications.																	
		<table border="1" style="width: 100%;"> <thead> <tr> <th style="text-align: center;">Set value</th> <th style="text-align: center;">Contents</th> </tr> </thead> <tbody> <tr> <td>00 : _AC_3-phase</td> <td>Provide 3-phase AC Power Supply to the Main Power Supply</td> </tr> <tr> <td>01 : _AC_Single-phase</td> <td>Provide Single-Phase AC Power Supply to the Main Power Supply</td> </tr> </tbody> </table>	Set value	Contents	00 : _AC_3-phase	Provide 3-phase AC Power Supply to the Main Power Supply	01 : _AC_Single-phase	Provide Single-Phase AC Power Supply to the Main Power Supply										
Set value	Contents																	
00 : _AC_3-phase	Provide 3-phase AC Power Supply to the Main Power Supply																	
01 : _AC_Single-phase	Provide Single-Phase AC Power Supply to the Main Power Supply																	
		<table border="1" style="width: 100%;"> <thead> <tr> <th style="text-align: center;">Setting</th> <th style="text-align: center;">Contents</th> </tr> </thead> <tbody> <tr> <td>00 : _Torque</td> <td>Torque Control Mode</td> </tr> <tr> <td>01 : _Velocity</td> <td>Velocity Control Mode</td> </tr> <tr> <td>02 : _Position</td> <td>Position Control Mode</td> </tr> <tr> <td>03 : _Velo—Torq</td> <td>Velocity - Torque Switch Mode</td> </tr> <tr> <td>04 : _Posi—Torq</td> <td>Position - Torque Switch Mode</td> </tr> <tr> <td>05 : _Posi—Velo</td> <td>Position - Velocity Switch Mode</td> </tr> <tr> <td>06 : _CANopen</td> <td>CANopen - Mode</td> </tr> </tbody> </table>	Setting	Contents	00 : _Torque	Torque Control Mode	01 : _Velocity	Velocity Control Mode	02 : _Position	Position Control Mode	03 : _Velo—Torq	Velocity - Torque Switch Mode	04 : _Posi—Torq	Position - Torque Switch Mode	05 : _Posi—Velo	Position - Velocity Switch Mode	06 : _CANopen	CANopen - Mode
Setting	Contents																	
00 : _Torque	Torque Control Mode																	
01 : _Velocity	Velocity Control Mode																	
02 : _Position	Position Control Mode																	
03 : _Velo—Torq	Velocity - Torque Switch Mode																	
04 : _Posi—Torq	Position - Torque Switch Mode																	
05 : _Posi—Velo	Position - Velocity Switch Mode																	
06 : _CANopen	CANopen - Mode																	
	This is to be set when the system is full closed control.	<table border="1" style="width: 100%;"> <thead> <tr> <th style="text-align: center;">Setting</th> <th style="text-align: center;">Contents</th> </tr> </thead> <tbody> <tr> <td>00 : _Motor_encoder</td> <td>Semi-Closed Control / Motor Encoder</td> </tr> <tr> <td>01 : _Ext—ENC</td> <td>Fully Closed Control / External Encoder</td> </tr> </tbody> </table>	Setting	Contents	00 : _Motor_encoder	Semi-Closed Control / Motor Encoder	01 : _Ext—ENC	Fully Closed Control / External Encoder										
Setting	Contents																	
00 : _Motor_encoder	Semi-Closed Control / Motor Encoder																	
01 : _Ext—ENC	Fully Closed Control / External Encoder																	
		<table border="1" style="width: 100%;"> <thead> <tr> <th style="text-align: center;">Setting</th> <th style="text-align: center;">Contents</th> </tr> </thead> <tbody> <tr> <td>00 : _Not_connect</td> <td>Regenerative Resistor is not Connected</td> </tr> <tr> <td>01 : _Built-in_R</td> <td>Use Built-In Regenerative Resistor</td> </tr> <tr> <td>02 : _External_R</td> <td>Use External Regenerative Resistor</td> </tr> </tbody> </table>	Setting	Contents	00 : _Not_connect	Regenerative Resistor is not Connected	01 : _Built-in_R	Use Built-In Regenerative Resistor	02 : _External_R	Use External Regenerative Resistor								
Setting	Contents																	
00 : _Not_connect	Regenerative Resistor is not Connected																	
01 : _Built-in_R	Use Built-In Regenerative Resistor																	
02 : _External_R	Use External Regenerative Resistor																	

# 6. Operations

## [JOG operation]

Procedure	Item and Contents																												
5	<p><b>Confirming servo motor encoder specifications</b> <span style="float: right;"><b>System parameter setting</b></span></p> <p>Use the AC servo system supporting tool R-Setup to confirm and set the specifications of the encoder. For how to use [the setup software R-Setup], refer to [R-SETUP Instruction Manual].</p>																												
	<p style="text-align: center;">Item</p> <p><b>Motor Encoder Type</b> Selects the servo motor encoder type.</p>	<table border="1" style="width: 100%;"> <thead> <tr> <th style="width: 50%;">Setting value</th> <th style="width: 50%;">Contents</th> </tr> </thead> <tbody> <tr> <td>00 : _Incremental_ENC</td> <td>Incremental Encoder</td> </tr> <tr> <td>01 : _Absolute_ENC</td> <td>Absolute Encoder</td> </tr> </tbody> </table>	Setting value	Contents	00 : _Incremental_ENC	Incremental Encoder	01 : _Absolute_ENC	Absolute Encoder																					
	Setting value	Contents																											
	00 : _Incremental_ENC	Incremental Encoder																											
	01 : _Absolute_ENC	Absolute Encoder																											
	<p><b>Incremental Encoder, Function Setting</b> Selects detailed function of incremental encoder.</p>	<p style="text-align: center;">This is set when motor encoder type is "incremental encoder".</p> <table border="1" style="width: 100%;"> <thead> <tr> <th style="width: 50%;">Setting value</th> <th style="width: 50%;">Contents</th> </tr> </thead> <tbody> <tr> <td>00 : _Standard</td> <td>Wiring-Save Incremental Encoder [Standard (4-Pairs)]</td> </tr> <tr> <td>01 : _7pairs_INC-E</td> <td>Incremental Encoder with CS Signal. [7-Pairs]</td> </tr> </tbody> </table>	Setting value	Contents	00 : _Standard	Wiring-Save Incremental Encoder [Standard (4-Pairs)]	01 : _7pairs_INC-E	Incremental Encoder with CS Signal. [7-Pairs]																					
	Setting value	Contents																											
00 : _Standard	Wiring-Save Incremental Encoder [Standard (4-Pairs)]																												
01 : _7pairs_INC-E	Incremental Encoder with CS Signal. [7-Pairs]																												
<p><b>Incremental Encoder, Resolution Setting</b> Sets the incremental encoder resolution.</p>	<p>Sets the pulse number of motor shaft one rotation. 500P/R ~ 65535P/R Setting unit=Pulse/Rev.</p>																												
<p><b>Absolute Encoder, Function Setting</b> Selects detailed function of absolute encoder.</p>	<p style="text-align: center;">This is set when the motor encoder type is "absolute encoder".</p> <table border="1" style="width: 100%;"> <thead> <tr> <th style="width: 50%;">setting</th> <th style="width: 50%;">Contents</th> </tr> </thead> <tbody> <tr> <td>04:PA035C-2.5MH_Manu</td> <td>PA035, Asynchronous, 2.5Mbps, Half Duplex (Manual Setting)</td> </tr> <tr> <td>05:PA035C-4MH_Manu</td> <td>PA035, Asynchronous, 4Mbps, Half Duplex (Manual Setting)</td> </tr> <tr> <td>06:RA062C-2.5MH_Manu</td> <td>RA062, Asynchronous, 2.5Mbps, Half Duplex (Manual Setting)</td> </tr> <tr> <td>07:RA062C-4MH_Manu</td> <td>RA062, Asynchronous, 4Mbps, Half Duplex (Manual Setting)</td> </tr> <tr> <td>80:RA062M-1MF</td> <td>RA062, Manchester, 1Mbps, Full Duplex</td> </tr> <tr> <td>81:RA062M-2MF</td> <td>RA062, Manchester, 2Mbps, Full Duplex</td> </tr> <tr> <td>84:ABS-E</td> <td>ABS-E, 1Mbps (Absolute Encoder with Incremental Signal)</td> </tr> </tbody> </table>	setting	Contents	04:PA035C-2.5MH_Manu	PA035, Asynchronous, 2.5Mbps, Half Duplex (Manual Setting)	05:PA035C-4MH_Manu	PA035, Asynchronous, 4Mbps, Half Duplex (Manual Setting)	06:RA062C-2.5MH_Manu	RA062, Asynchronous, 2.5Mbps, Half Duplex (Manual Setting)	07:RA062C-4MH_Manu	RA062, Asynchronous, 4Mbps, Half Duplex (Manual Setting)	80:RA062M-1MF	RA062, Manchester, 1Mbps, Full Duplex	81:RA062M-2MF	RA062, Manchester, 2Mbps, Full Duplex	84:ABS-E	ABS-E, 1Mbps (Absolute Encoder with Incremental Signal)												
setting	Contents																												
04:PA035C-2.5MH_Manu	PA035, Asynchronous, 2.5Mbps, Half Duplex (Manual Setting)																												
05:PA035C-4MH_Manu	PA035, Asynchronous, 4Mbps, Half Duplex (Manual Setting)																												
06:RA062C-2.5MH_Manu	RA062, Asynchronous, 2.5Mbps, Half Duplex (Manual Setting)																												
07:RA062C-4MH_Manu	RA062, Asynchronous, 4Mbps, Half Duplex (Manual Setting)																												
80:RA062M-1MF	RA062, Manchester, 1Mbps, Full Duplex																												
81:RA062M-2MF	RA062, Manchester, 2Mbps, Full Duplex																												
84:ABS-E	ABS-E, 1Mbps (Absolute Encoder with Incremental Signal)																												
<p><b>Absolute Encoder, Resolution Setting</b> Sets the absolute encoder resolution. Sets the pulse number of motor shaft one rotation.</p>	<p style="text-align: center;">This is set when the motor encoder type is "absolute encoder".</p> <table border="1" style="width: 100%;"> <thead> <tr> <th style="width: 25%;">Setting</th> <th style="width: 25%;">Contents</th> <th style="width: 25%;">Setting</th> <th style="width: 25%;">Contents</th> </tr> </thead> <tbody> <tr> <td>00:_2048 division</td> <td>2048 division</td> <td>06:_131072 division</td> <td>131072 division</td> </tr> <tr> <td>01:_4096 division</td> <td>4096 division</td> <td>07:_262144 division</td> <td>262144 division</td> </tr> <tr> <td>02:_8192 division</td> <td>8192 division</td> <td>08:_524288 division</td> <td>524288 division</td> </tr> <tr> <td>03:_16384 division</td> <td>16384 division</td> <td>09:_1048576 division</td> <td>1048576 division</td> </tr> <tr> <td>04:_32768 division</td> <td>32768 division</td> <td>0A:_2097152 division</td> <td>2097152 division</td> </tr> <tr> <td>05:_65536 division</td> <td>65536 division</td> <td></td> <td></td> </tr> </tbody> </table>	Setting	Contents	Setting	Contents	00:_2048 division	2048 division	06:_131072 division	131072 division	01:_4096 division	4096 division	07:_262144 division	262144 division	02:_8192 division	8192 division	08:_524288 division	524288 division	03:_16384 division	16384 division	09:_1048576 division	1048576 division	04:_32768 division	32768 division	0A:_2097152 division	2097152 division	05:_65536 division	65536 division		
Setting	Contents	Setting	Contents																										
00:_2048 division	2048 division	06:_131072 division	131072 division																										
01:_4096 division	4096 division	07:_262144 division	262144 division																										
02:_8192 division	8192 division	08:_524288 division	524288 division																										
03:_16384 division	16384 division	09:_1048576 division	1048576 division																										
04:_32768 division	32768 division	0A:_2097152 division	2097152 division																										
05:_65536 division	65536 division																												
<p><b>External encoder resolution</b> Sets the resolution of external encoder in use.</p>	<p style="text-align: center;">This is set when the system is full closed control or something.</p> <p>Sets the pulse number converted to motor shaft one rotation. 500P/R ~ 65535P/R Setting unit=Pulse/Rev.</p>																												

# 6. Operations

[JOG operation]

Procedure	Item and Contents	
6	<u>Confirming the combined servo motor</u> <span style="float: right;"><u>System parameter setting</u></span> Use the AC servo system supporting tool R-Setup to confirm and set the model type of combined servo motor. For how to use [the setup software R-Setup], refer to [R-SETUP Instruction Manual].	
	Item	Ex: <u>Q2AA07030D</u> (0000-0064) ↑ <u>Model number of combined motor is displayed.</u>  Combined motor can be changed at <u>Motor parameter setting.</u>

Procedure	Item and Contents	
7	<u>Turning ON the power again</u> <span style="float: right;"><u>Power shut off→turn ON again</u></span> Turn OFF the power of servo amplifier and turn it ON again. Turning OFF the power makes the parameter re-written. Without turning OFF the power, the parameter cannot be changed. Make sure to turn OFF→turn ON again.	

Procedure	Item and Contents	
8	<u>Reconfirming the specifications</u> <span style="float: right;"><u>Reconfirmation</u></span> Reconfirm the specifications and combination of the changed servo amplifier, servo motor encoder and servo motor. <u>Many of the troubles at test run, such as servo motor not operating, are caused by mistakes in parameter setting.</u>	

Procedure	Item and Contents	
9	<u>JOG driving</u> Use the AC servo system supporting tool R-Setup to JOG drive.	



# 6. Operations

## [Confirmation of I/O signal]

■[Procedure 10~14] Connection of upper device with CN1, parameter setting for I/O signals

Procedure	Item	Contents																											
10	I/O signal setting	Settings for generic I/O signals (CN1) are standard ones set at the time of shipment. Necessary I/O signals are set at the servo amplifier.																											
	Generic input signal Standard setting at the time of shipment	<p>General parameter Group 9</p> <table border="1"> <thead> <tr> <th>Input signal</th> <th>Name</th> <th>Set value</th> </tr> </thead> <tbody> <tr> <td>CONT1</td> <td>SERVO-ON Function</td> <td>02:_CONT1_ON</td> </tr> <tr> <td>CONT2</td> <td>Velocity Loop Proportional Control, Switching Function</td> <td>04:_CONT2_ON</td> </tr> <tr> <td>CONT3</td> <td>Absolute Encoder Clear Function</td> <td>06:_CONT3_ON</td> </tr> <tr> <td>CONT4</td> <td>Deviation Clear Function</td> <td>08:_CONT4_ON</td> </tr> <tr> <td>CONT5</td> <td>Negative Over-Travel Function</td> <td>0B:_CONT5_OFF</td> </tr> <tr> <td>CONT6</td> <td>Positive Over-Travel Function</td> <td>0D:_CONT6_OFF</td> </tr> <tr> <td>CONT7</td> <td>Torque Limit, Input Selection</td> <td>0E:_CONT7_ON</td> </tr> <tr> <td>CONT8</td> <td>Alarm Reset Function</td> <td>10:_CONT8_ON</td> </tr> </tbody> </table> <p> Generic input signals (CONT1 TO CONT8) shall be allocated to functions necessary to the device, referring to [Chapter 5, Parameter][Parameter setting value Group9].</p>	Input signal	Name	Set value	CONT1	SERVO-ON Function	02:_CONT1_ON	CONT2	Velocity Loop Proportional Control, Switching Function	04:_CONT2_ON	CONT3	Absolute Encoder Clear Function	06:_CONT3_ON	CONT4	Deviation Clear Function	08:_CONT4_ON	CONT5	Negative Over-Travel Function	0B:_CONT5_OFF	CONT6	Positive Over-Travel Function	0D:_CONT6_OFF	CONT7	Torque Limit, Input Selection	0E:_CONT7_ON	CONT8	Alarm Reset Function	10:_CONT8_ON
	Input signal	Name	Set value																										
CONT1	SERVO-ON Function	02:_CONT1_ON																											
CONT2	Velocity Loop Proportional Control, Switching Function	04:_CONT2_ON																											
CONT3	Absolute Encoder Clear Function	06:_CONT3_ON																											
CONT4	Deviation Clear Function	08:_CONT4_ON																											
CONT5	Negative Over-Travel Function	0B:_CONT5_OFF																											
CONT6	Positive Over-Travel Function	0D:_CONT6_OFF																											
CONT7	Torque Limit, Input Selection	0E:_CONT7_ON																											
CONT8	Alarm Reset Function	10:_CONT8_ON																											
Generic output signal Standard setting at the time of shipment	<p>General parameter Group A</p> <table border="1"> <thead> <tr> <th>Page</th> <th>Name</th> <th>Standard set value</th> </tr> </thead> <tbody> <tr> <td>00</td> <td>General Purpose Output 1</td> <td>18:_INP_ON</td> </tr> <tr> <td>01</td> <td>General Purpose Output 2</td> <td>0C:_TLC_ON</td> </tr> <tr> <td>02</td> <td>General Purpose Output 3</td> <td>02:_S-RDY_ON</td> </tr> <tr> <td>03</td> <td>General Purpose Output 4</td> <td>0A:_MBR_ON</td> </tr> <tr> <td>04</td> <td>General Purpose Output 5</td> <td>33:_ALM5_OFF</td> </tr> <tr> <td>05</td> <td>General Purpose Output 6</td> <td>35:_ALM6_OFF</td> </tr> <tr> <td>06</td> <td>General Purpose Output 7</td> <td>37:_ALM7_OFF</td> </tr> <tr> <td>07</td> <td>General Purpose Output 8</td> <td>39:_ALM_OFF</td> </tr> </tbody> </table> <p> Generic output signals (OUT1 TO OUT8) shall be allocated to functions necessary to the device, referring to [Chapter 5, Parameter][Parameter setting value Group A].</p>	Page	Name	Standard set value	00	General Purpose Output 1	18:_INP_ON	01	General Purpose Output 2	0C:_TLC_ON	02	General Purpose Output 3	02:_S-RDY_ON	03	General Purpose Output 4	0A:_MBR_ON	04	General Purpose Output 5	33:_ALM5_OFF	05	General Purpose Output 6	35:_ALM6_OFF	06	General Purpose Output 7	37:_ALM7_OFF	07	General Purpose Output 8	39:_ALM_OFF	
Page	Name	Standard set value																											
00	General Purpose Output 1	18:_INP_ON																											
01	General Purpose Output 2	0C:_TLC_ON																											
02	General Purpose Output 3	02:_S-RDY_ON																											
03	General Purpose Output 4	0A:_MBR_ON																											
04	General Purpose Output 5	33:_ALM5_OFF																											
05	General Purpose Output 6	35:_ALM6_OFF																											
06	General Purpose Output 7	37:_ALM7_OFF																											
07	General Purpose Output 8	39:_ALM_OFF																											

Procedure	Item	Contents
11	Confirmation of input signals	<p>Input signal status is monitored by the monitoring function inside the servo amplifier. Confirm that there are protective functions such as emergency stop, over travel and alarm reset.</p> <p> Confirm that every I/O signal is properly functioning using generic input (CONT8 TO CONT1) monitor and generic output (OUT8 TO OUT1) monitor, referring to [Chapter 4, Digital operator][How to operate monitor mode].</p>

Procedure	Item	Contents
12	Servo ON signal is input.	<p>Servo ON signal is input and the servo motor is excited. Confirm that the digital operator on the servo amplifier front is drawing the character "8" .</p> <p> The display shown below indicates over travel status. When there is nothing wrong with the device, check again the above procedure 10 TO 11 and [Chapter 3, Wiring] [Generic input wiring example].</p> <p>Over travel {  </p>


## 6. Operations

### [Confirmation of I/O signals /Confirmation of device operation]

Procedure	Item	Contents						
13	Command input	<p>Input the command suitable for the control mode in use. Check that the rotation direction matches the command input. Confirm the command input using monitoring function inside the servo amplifier.</p> <ul style="list-style-type: none"> <li>● When velocity controlled, torque controlled.  <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <div style="background-color: #e0e0e0; padding: 2px;">Monitor mode 0D</div> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">Analog velocity command /</td> <td style="width: 50%;">Command voltage being input is displayed.</td> </tr> <tr> <td>Analog torque command input voltage</td> <td></td> </tr> </table> </div> </li> <li>● When position controlled.  <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <div style="background-color: #e0e0e0; padding: 2px;">Monitor mode 0E</div> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">Position pulse monitor (Position command pulse input frequency)</td> <td style="width: 50%;">Command pulse frequency being input is displayed.</td> </tr> </table> </div> </li> </ul> <p> Many of the cases when monitor values do not change with command input are resulted from wrong wiring. Check the wiring again, referring to [Chapter3, Wiring] [Terminal layout] [Wiring example of input circuit].</p>	Analog velocity command /	Command voltage being input is displayed.	Analog torque command input voltage		Position pulse monitor (Position command pulse input frequency)	Command pulse frequency being input is displayed.
Analog velocity command /	Command voltage being input is displayed.							
Analog torque command input voltage								
Position pulse monitor (Position command pulse input frequency)	Command pulse frequency being input is displayed.							

Procedure	Item	Contents
14	Power shut off	Turns OFF the servo ON signal, then turns OFF the power supply.

■ [Procedure 15] Connect the servo motor shaft with the machine and check the operation.

Procedure	Item	Contents
15	Command input (low speed)	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;">           Connect the servo motor shaft with the machine            </div> <p>Input the command (low speed) suitable for the control mode in use. Check the operation direction, distance, emergency stop and over travel (F-OT · R-OT) so that they are properly operating.</p>

■ [Procedure 16 ] Input the command of the operation pattern in use and start the machine.

Procedure	Item	Contents
16	Operation	At the time of shipment, auto-tuning (auto-adjustment for servo gain and filter, etc.) has been set. If there is nothing wrong with operation, manual tuning is not necessary.




# 6. Operations


## [Confirmation of I/O signals /Confirmation of device operation]

■ Operation sequence from power turn ON to power shut OFF at the standard shipment setting

● [Power ON → Servo ON]



● [Servo OFF → Power OFF]




# 6. Operations

## [Operation sequence]


### Alarm sequence

When an alarm rings, the servo motor is stopped by dynamic brake or servo brake. Which brake is used depends on the alarm. Refer to [Chapter 8, Maintenance] [Alarm list].

#### Stop by dynamic brake at alarm



#### Stop by servo brake at alarm




Install a protective circuit referring to [Chapter 3, Wiring] [Wiring example of high voltage circuit, protective circuit]. The above sequence is the one when protective circuit is installed.

# 6. Operations

## [Operation sequence]


### ■ Sequence at alarm reset

Alarms can be reset by inputting alarm reset signal from generic input signal.



Some alarms cannot be reset unless the power is reset (control power is turned OFF and ON again) or encoder is cleared. Refer to [Chapter 8, Maintenance] [Alarm list].

### ■ Sequence when power is turned OFF during operation (During servo ON)



## [Adjustment · Functions]


◆	Servo gain tuning .....	7-1
◆	Functions of Group8 .....	7-7
◆	Functions of Group9 .....	7-25
◆	Functions of GroupB .....	7-31
◆	Functions of GroupC .....	7-36
◆	Functions of monitors .....	7-39

# 7. Adjustment - Functions

## [Servo gain tuning]

### ■ Structure of tuning «General parameter Group 0»

At “parameter Group 0”, tuning structure of the R series servo amplifier is as follows.



#### ● Tuning Mode [page 00]

##### 00:\_AutoTun auto-tuning

The servo amplifier estimates the load inertia moment ratio of the machine and equipment at real time and automatically tunes the servo gain so that it will become the best one. The parameters for the servo amplifier to automatically tune vary depending on the selected auto-tuning characteristics.

※The servo amplifier estimates the load inertia moment ratio at the time of acceleration/deceleration. Therefore, for operations with only excessively low acceleration/deceleration time constant or with only low torque with low velocity, this mode cannot be used. Also, operations with large disturbance torque or with large mechanical clearance, this mode cannot be used, either.

01:\_AutoTun\_JRAT-Fix Usage at Auto-tuning [JRAT manual setting].

##### 01:\_AutoTun\_JRAT-Fix Automatic Tuning (JRAT Fixed)

Based on the load inertia moment ratio (JRAT1) which was set, the servo amplifier automatically tunes and makes the servo gain the best one. The parameters for the servo amplifier to automatically tune vary depending on the selected auto-tuning characteristics.

##### 02:\_ManualTun Manual Tuning

This is used in order for adjusting the servo gain to the machine and equipment to ensure the maximum response, and when characteristics in auto-tuning are insufficient.

#### ● Automatic Tuning Characteristic [page 01]

Characteristics adjusted to machines and equipment are selected when **Automatic Tuning** and **Automatic Tuning (JRAT Fixed)** are used.

When **Manual Tuning** is used, this does not function.

#### ● Automatic Tuning Response [page 02]

Set this when **Automatic Tuning** and **Automatic Tuning (JRAT Fixed)** are used. The larger set value makes the response higher. Set this suitable for the equipment rigidity.

When **Manual Tuning** is used, this does not function.

#### ● Automatic Tuning, Automatic Parameter Saving [load inertia moment ratio] [page 0 3]


The “load inertia moment ratio” obtained from auto-tuning is automatically saved in parameter JRAT1 at every 2 hours. The set value is enabled when **Automatic Tuning** is used.

When **Automatic Tuning (JRAT Fixed)** and **Manual Tuning** are used, this does not function.

# 7. Adjustment - Functions

## [Servo gain tuning]

### ■ Tuning method selecting procedure



※The flow chart in the left shows selecting method of tuning mode and tuning characteristics. Settings for auto-tuning response are not indicated here. Auto-tuning response shall be tuned at each status.

# 7. Adjustment - Functions

## [Servo gain tuning]

### ■ Monitoring servo gain adjustment parameter

The following parameters can be monitored when auto-tuning is used.

#### ● R-SETUP

#1	Page	Symbol	Name	Present Value	Unit
#2	0B	EX-APMON	External Actual Position Monitor (External Encoder)	0	Pulse
#3	0C	CPMON	Command Position Monitor	0	Pulse
#4	0D	V/C/TC-IN	Analog Velocity Command/Analog Torque Command Input Voltage	0	mV
#5	0E	FMON	Position Command Pulse Input Frequency Monitor	0	1/Pulse/s
#6	0F	CSU	U-Phase Electric Angle Monitor	240	deg
#7	10	PS-H	Absolute Encoder PS Data (High)	00000000 H	×2 <sup>22</sup> P
#8	11	PS-L	Absolute Encoder PS Data (Low)	00000000 H	Pulse
#9	12	RegP	Regenerative Resistor Operation Percentage	0.00	%
#10	13	OPRT	Motor Operating Rate Monitor	64	%
#11	14	PROPR1	Predicted Motor Operating Rate Monitor	0	%
#12	15	JRAT_MON	Control Loop Parameter - Load Inertia (Mass) Ratio Monitor	368	%
#13	16	KVP_MON	Control Loop Parameter - Position Loop Proportional Gain Monit	30	1/s
#14	17	TVI_MON	Control Loop Parameter - Position Loop Integral Time Constant	1000.0	ms
#15	18	KVP_MON	Control Loop Parameter - Velocity Loop Proportional Gain Monit	60	Hz
#16	19	TVI_MON	Control Loop Parameter - Velocity Loop Integral Time Constant	35.0	ms
#17	1A	TCFIL_MON	Control Loop Parameter - Torque (Force) Command Filter Monit	150	Hz
#18	1B	INC_E_MON	Incremental Encoder Signal Monitor	0111-0100	
#19	1C	TLMON_EST	Load Torque (Force) Monitor (Estimate Value)	0	%
#20	1D	P_MON	Power Monitor	2	V
#21	1E	OPF_TM	Servo Amplifier Operation Time	10	×2 hour

For how to operate these, refer to “R-SETUP Instruction Manual”.

### ■ Using auto-tuning result at manual tuning.

At manual tuning, auto-tuning result is saved as a batch or by selection using R-SETUP, and can be used as controlling parameter.

**Save Result of Automatic Tuning [ #1 : R51L01AA ]**

Tuning Mode  
 TUNMODE : Manual Tuning  
 ATCHA : Positioning Control 1

Setting  
 Setting Parameter : KP1,KVP1,TVI1,TCFIL1,JRAT1  
 ATRES : 20

Parameter Monitor Value of Automatic Tuning  
 KP : 98 [1/s]  
 KVP : 93 [Hz]  
 TVI : 10.7 [ms]  
 TCFIL : 689 [Hz]  
 JRAT : 100 [%]

Parameter Setting Value  
 KP1 : 30 [1/s]  
 KVP1 : 50 [Hz]  
 TVI1 : 20.0 [ms]  
 TCFIL1 : 600 [Hz]  
 JRAT1 : 100 [%]

Save Monitor Value

ATRES can be changed on this window. However, the changed value is not saved as a parameter. ATRES returns to former setting value when this window is closed.

Data type of Monitor Value is changed by Tuning Mode (TUNMODE) and Automatic Tuning Characteristic (ATCHA).  
 Manual Tuning : Proper gain by Automatic Tuning Function.  
 Automatic Tuning : Real using gain in control loop.  
 JRAT, KVP, TVI, TCFIL : Proper gain by Automatic Tuning Function.  
 KP : When ATCHA is not Trajectory Control 2, Proper gain by Automatic Tuning Function.  
 When ATCHA is Trajectory Control 2, KP1 setting value.  
 Automatic Tuning (JRAT fixed) : Real using gain in control loop.  
 JRAT : JRAT1 setting value.  
 KVP, TVI, TCFIL : Proper gain according to JRAT1.  
 KP : When ATCHA is not Trajectory Control 2, Proper gain according to JRAT1.  
 When ATCHA is Trajectory Control 2, KP1 setting Value.

For how to operate these, refer to “ R-SETUP Instruction Manual”.


Note) In the setting of TUNMODE=02:\_ManualTun, parameter setting value is used in the control loop. When auto-tuning result saving is executed, the gain parameter being used will change (except during gain switch over). Therefore, the motor operation may change suddenly. Execute auto-tuning result saving while servo OFF or motor stoppage.

# 7. Adjustment - Functions

## [Servo gain tuning]

### ■ Servo system structure

Servo system consists of 3 subsystems; the position loop, the velocity loop and the current loop. High response is required for the internal loops. If this structure is compromised, it could result in instability, low response, vibration or oscillation.



The response of the current loop is ensured internally in the servo amplifier, there is no need for the user to make additional adjustments.

### ■ Servo adjustment parameters

#### Position Command Filter [PCFIL]

When the position command resolution is low, set this parameter to suppress the ripples contained in the position command. The larger value of this will make the ripple suppressing effect greater, however, delay will be greater.

※ When high tracking control position compensation gain is set to other than 0%, this parameter is automatically set.

#### Position Loop Proportional Gain [KP]

Set this equivalent to  $KP_{[1/S]} = KVP_{[Hz]} / 4 \cdot 2\pi$ .

#### Higher Tracking Control, Position Compensation Gain [TRCPGN]

When tracking effect needs to be improved under high resolution of position command, increase this parameter after adjustment of high tracking control velocity compensation gain.

#### Feed Forward Gain [FFGN]

Tracking effect of position command can be improved by increasing this gain.

Under positioning control, set this to approximately 30 ~ 40%.

※ When high tracking control position compensation gain is set to other than 0%, this parameter is automatically set.

#### Feed Forward Filter [FFFIL]

When position command resolution is low, set this parameter to suppress ripples.

#### Velocity Command Filter [VCFIL]

Under velocity control, when there is a big noise component contained in velocity command, set this parameter to suppress the noise.

#### Velocity Loop Proportional Gain [KVP]

Set this as high as possible within such a stable operation range as not to cause vibration or oscillation of the machine. If JRAT is accurately set, the set value of KVP becomes the velocity loop response zone.



## Velocity Loop Integral Time Constant [TVI]

Set this equivalent to  $TVI_{[ms]} = 1000 / (KVP_{[Hz]})$ .

## Load Inertia Ratio [JRAT]

Set the value calculated as shown below.

$$JRAT = \frac{\text{Motor axis converted load inertia moment} \quad \text{【JL】}}{\text{Motor inertia moment} \quad \text{【JM】}} \times 100\%$$

## Higher Tracking Control, Velocity Compensation Gain [TRCVGN]

Tracking effect can be improved by increasing compensation gain.

Adjust this so as to shorten the positioning setting time.

※Set the value of JRAT properly to use this function.

## Torque Command Filter 1 [TCFIL]

When rigidity of the mechanical device is high, set this value high and the velocity loop proportional gain can be set to high. When rigidity of the mechanical device is low, set this value low and resonance in high frequency zone and abnormal sound can be suppressed. For normal usage, set this below 1200 Hz.

### ■ Adjustment method of vibration suppressing control

Set vibration suppressing frequency to suppress the low frequency vibration at the tip or the body of the machine. Vibration suppressing frequency is obtained by executing auto-tuning of vibration suppressing frequency or by calculating vibration frequency of vibrating point at positioning and its reciprocal. When vibration does not stop with the vibration suppressing control, there is a possibility that the gain for control system may be too high. In this case, lower the control system gain. Also, when used together with high tracking control velocity compensation gain, vibration suppressing effect may be greater.

※Vibration suppressing control function can be used together with auto-tuning.

### ■ Adjustment method of notch filter

Set the torque command notch filter to suppress high frequency resonance resulted from coupling and rigidity of the device mechanism. Notch filter center frequency can be obtained by executing auto-notch filter tuning or by system analysis.

※Torque command notch filter function can be used together with auto-tuning.

※When resonance of the device mechanism does not stop even after this parameter is set, there may be two or more resonance points. In this case, insert notch filters B, C and D to suppress each of them. If not yet suppressed, there is a possibility that auto-tuning response or control gain is too high. If so, lower the auto-tuning response or control gain.

### ■ Adjustment method of disturbance observer

Set the disturbance observer to suppress the disturbance applied to the motor.

At first, use the low frequency observer characteristics. If not suppressed by that, use that for medium frequency. Gradually increase the observer compensation gain.

The higher the observer compensation gain becomes, the more the disturbance suppressing characteristics will be improved.

However, if it is excessively high, oscillation may result. Use this within the range not causing oscillation.


※Disturbance observer cannot be used with auto-tuning.

# 7. Adjustment - Functions

■ Adjustment method of gain switch over

When tracking effect is insufficient even if basic parameters of high tracking control position compensation gain and high tracking control velocity compensation gain are set, set the gain switch over so that tracking effect can be improved.

(Example)Gain is increased near positioning complete.



The value of gain 2 shall be set to 1.2 times the value of gain 1.

※Gain switch over function cannot be used with auto-tuning.

■ Adjustment method of high setting control

When tracking effect is insufficient even after gain switch over, set the high setting control parameter and in-position setting characteristics can be improved. When position command resolution is low, set the value of command velocity calculation low pass filter low. Set the acceleration compensation so that the position deviation near acceleration conclusion becomes small. Set the deceleration compensation so that the position deviation near deceleration conclusion (positioning complete) becomes small.

※This function cannot be used together with auto-tuning.

■ How to make R series control characteristics equal to Q series standard characteristics

Parameter change as follows can make the status equal to Q series standard characteristics.

Group	Page		Before change	After change
0	00	Tuning Mode	00:_AutoTun	02:ManualTun
1	16	Higher Tracking Control, Velocity Compensation Gain	0%	100%

# 7. Adjustment · Functions

## [Functions of Group 8]

### [Position command pulse]

#### ■ Functions of Group 8

[ Group 8 ] 00


Command Input Polarity [CMDPOL]    Velocity control mode    Position control mode    Torque control mode

The rotation direction of the servo motor can be reversed without modifying the input command wiring or the servo motor wiring.

Input command	Command polarity	Rotation direction	Selected value
Position command	+	Forward	00:_PC+_VC+_T C+
Velocity command	+	Forward	
Torque command	+	Forward	
Position command	+	Reverse	04:_PC-_VC+_ TC+
Velocity command	+	Forward	
Torque command	+	Forward	
Position command	+	Forward	01:_PC+_VC+_T C-
Velocity command	+	Forward	
Torque command	+	Reverse	
Position command	+	Reverse	05:_PC-_VC+_ TC-
Velocity command	+	Forward	
Torque command	+	Reverse	
Position command	+	Forward	02:_PC+_VC-_T C+
Velocity command	+	Reverse	
Torque command	+	Forward	
Position command	+	Reverse	06:_PC-_VC-_T C+
Velocity command	+	Reverse	
Torque command	+	Forward	
Position command	+	Forward	03:_PC+_VC-_T C-
Velocity command	+	Reverse	
Torque command	+	Reverse	
Position command	+	Reverse	07:_PC-_VC-_T C-
Velocity command	+	Reverse	
Torque command	+	Reverse	

\* Using the initial factory settings, the servo motor rotates in the forward (CCW) direction with a positive (+) input, and in the reverse (CW) direction with a negative (-) input.


#### Standard command input polarity setting



+input=forward (CCW)    -input=reverse(CW)



#### Modified command input polarity setting



+input=reverse (CW)    -input=forward (CCW)



# 7. Adjustment · Functions

## [Functions of Group 8]

### [Position command pulse]

[Group 8] 11

Position Command Pulse, Form Selection [PCPTYP]

Position control mode

3 types of location command pulse can be selected; make this selection per the specifications of the host unit.


Selected value	Contents
00: _F-PC_R-PC	Positive Move Pulse + Negative Move Pulse
01: _2PhasePulse	Two-Phase Pulse Train of 90 Degrees Phase Difference
02: _CODE_PC	Code + Pulse Train

The location command pulse input command is the input command used for location control. Connect to CN1 location command pulse input.

Forward	Reverse
Positive Move Pulse (F-PC) : CN1-26	Negative Move Pulse (R-PC) : CN1-28
Positive Move Pulse (F-PC) : CN1-27	Negative Move Pulse (R-PC) : CN1-29
Positive Move Pulse SG : CN1-47	Negative Move Pulse SG : CN1-48

There are 2 output types for the host unit, the “Line driver output” and the “Open collector output”.


#### Using line driver output



\* Always connect SG.

\* Line Receiver : HD26C32 or equivalent

#### Using open collector output



\* Always connect SG.

\* Line Receiver : HD26C32 or equivalent

# 7. Adjustment · Functions

[Functions of Group 8]

[Position command pulse]

[Group 8 ] 12

Position Command Pulse, Count Polarity [PCPPOL]

Position control mode

Position command pulse count polarity can be selected from the following 4 types. Select the one suitable for the host unit.

Selected value	Contents
00:_Type1	F-PC/ Count at the Rising Edge: R-PC/ Count at the Rising Edge
01:_Type2	F-PC/ Count at the Falling Edge: R-PC/ Count at the Rising Edge
02:_Type3	F-PC/ Count at the Rising Edge: R-PC/ Count at the Falling Edge
03:_Type4	F-PC/ Count at the Falling Edge: R-PC/ Count at the Falling Edge

[Group 8 ] 13

Position Command Pulse, Digital Filter [PCPFIL]

Position control mode

When the time for minimum pulse width at position command input maximum frequency is less than the digital filter set value, alarm "AL D2" will be issued. Set the smaller value for digital filter than the time of minimum pulse width at the time of position command input maximum frequency. Select the position command pulse digital filter setting from the followings according to the command pulse type of the unit in use.

Forward pulse string + Reverse pulse string

Selected value	Minimum pulse width [t]	Position command input maximum frequency[f]
00	t > 834 nsec	f < 599 Kpps
01	t > 250 nsec	f < 2.0 Mpps
02	t > 500 nsec	f < 1.0 Mpps
03	t > 1.8 μsec	f < 277 Kpps
04	t > 3.6 μsec	f < 138 Kpps
05	t > 7.2 μsec	f < 69 Kpps
06	t > 125 nsec	f < 4 Mpps
07	t > 83.4 nsec	f < 5.9 Mpps

90° phase difference 2 phase pulse

Selected value	A phase · B phase Minimum edge interval [t]	Position command input maximum frequency[f]
00	t > 834 nsec	f < 599 Kpps
01	t > 250 nsec	f < 2.0 Mpps
02	t > 500 nsec	f < 1.0 Mpps
03	t > 1.8 μsec	f < 277 Kpps
04	t > 3.6 μsec	f < 138 Kpps
05	t > 7.2 μsec	f < 69 Kpps
06	t > 164 nsec	f < 1.5 Mpps
07	t > 164 nsec	f < 1.5 Mpps

Code + pulse string

Selected value	Minimum pulse width [t]	Position command input maximum frequency[f]
00	t > 834 nsec	f < 599 Kpps
01	t > 250 nsec	f < 2.0 Mpps
02	t > 500 nsec	f < 1.0 Mpps
03	t > 1.8 μsec	f < 277 Kpps
04	t > 3.6 μsec	f < 138 Kpps
05	t > 7.2 μsec	f < 69 Kpps
06	t > 125 nsec	f < 4 Mpps
07	t > 83.4 nsec	f < 5.9 Mpps

# 7. Adjustment · Functions

[Functions of Group 8]

[Position command pulse]

Command pulse	Command pulse timing		
Positive Move Pulse + Negative Move Pulse			
Two-Phase Pulse Train of 90 Degrees Phase Difference			
Code + Pulse Train			
	Positive Move Pulse + Negative Move Pulse	Two-Phase Pulse Train of 90 Degrees Phase Difference	Code + Pulse Train
t1 · t8	$\leq 0.1 \mu s$	$\leq 0.1 \mu s$	$\leq 0.1 \mu s$
t2 · t9	$\leq 0.1 \mu s$	$\leq 0.1 \mu s$	$\leq 0.1 \mu s$
ts1 · ts2 ts3 · ts4	$> T$	$> T$	$> T$
t4 · t5 · t6 · t7	—	$> 250ns$	—
(t3/T)x100	50%	50%	50%

# 7. Adjustment · Functions

## [Functions of Group 8]

### [Electronic gear · Positioning method]


[Group 8] 15,16

#### Electric Gear Ratio \* [GER\*]

Position control mode

This function allows a distance setting on the servo motor in reference to the location command pulse from the unit.

Setting range	Unit	Standard set value
1/32767~32767/1	—	1/1



$$\text{Electronic gear setting range: } \frac{1}{32767} \leq \frac{N}{D} \leq \frac{32767}{1}$$

Refer to "Materials; Electronic Gear".


[Group 8] 17

#### Positioning Method [EDGEPOS]

Position control mode

The location of positioning stop is selected; between encoder pulses or at edge.

Selected value	Contents
00: _Pulse_Interval	Specify Pulse Interval
01: _Pulse_Edge	Specify Pulse Edge




[Group 8] 18

#### Inposition / Position Deviation Monitor [PDEVMON]

Position control mode

Positioning complete signal when the position control mode is used, and position command used for outputting position deviation monitor can be selected from before or after the position command filter passes.

Selected value	Contents
00: _After_Filter	Compare "Position Command Value After Filter Passes by" with "Feedback Value"
01: _Before_Filter	Compare "Position Command Value Before Filter Passes by" with "Feedback Value"



# 7. Adjustment · Functions

## [Functions of Group 8]

### [Deviation clear]

[Group 8 ] 19

#### Deviation Clear Selection [CLR]

Position control mode

This function is used for changing the location deviation counter in the servo amplifier from the host unit to zero.

Selection		Description
0H	When SERVO-OFF/ Clear Deviation : Deviation Clear Input/ Level Detection	<ul style="list-style-type: none"> <li>Deviation is always cleared when servo is off.</li> </ul> <p>Logic can be changed</p> <ul style="list-style-type: none"> <li>Deviation is always cleared when deviation clear input is ON.</li> </ul> <p>Logic cannot be changed</p>
1H	When SERVO-OFF/ Clear Deviation : Deviation Clear Input/ Edge Detection	<ul style="list-style-type: none"> <li>Deviation is always cleared when servo is off.</li> </ul> <p>Logic can be changed</p> <ul style="list-style-type: none"> <li>Deviation is cleared in the edge when deviation clear input becomes OFF/ON.</li> </ul> <p>Logic can be changed</p>
2H	When SERVO-OFF/ Not Clear Deviation : Deviation Clear Input/ Level Detection	<ul style="list-style-type: none"> <li>Deviation is not cleared when servo is OFF.</li> <li>The motor may start suddenly after servo is turned ON with location deviation detected.</li> </ul> <p>Logic can be changed</p> <ul style="list-style-type: none"> <li>Deviation is always cleared when deviation clear input is ON.</li> </ul> <p>Logic cannot be changed</p>
3H	When SERVO-OFF/ Not Clear Deviation : Deviation Clear Input/ Edge Detection	<ul style="list-style-type: none"> <li>Deviation is not cleared when servo is OFF.</li> <li>The motor may start suddenly after servo is turned ON with location deviation detected.</li> </ul> <p>Logic can be changed</p> <ul style="list-style-type: none"> <li>Deviation is cleared in the edge when deviation clear input becomes OFF/ON.</li> </ul> <p>Logic cannot be changed</p>

Select the conditions for enabling deviation clear.

Parameter Group9 page04

CLR :Deviation Clear Function



# 7. Adjustment - Functions

## [Functions of Group 8]

### [Internal velocity command]

[Group 8 ] 20 to 22

Preset Velocity Command1 to 3 [VC\*]

Velocity control mode

The servo motor can be controlled using Preset Velocity Command. Preset Velocity Command settings have 3 ways. Preset Velocity Command and rotation direction can be selected via conditions of generic input CONT1 to CONT8.

1. Set the Preset Velocity Command value.

Parameter Group8Page20	VC1: Preset Velocity Command 1	0 to 32767min <sup>-1</sup>
Parameter Group8Page21	VC2: Preset Velocity Command 2	0 to 32767min <sup>-1</sup>
Parameter Group8Page22	VC3: Preset Velocity Command 3	0 to 32767min <sup>-1</sup>

2. Select the conditions for enabling the Preset Velocity Command. The Preset Velocity Command requires the selection of valid conditions.

Parameter Group9Page20	SP1: Preset Velocity Command, Select Input 1
Parameter Group9Page21	SP2: Preset Velocity Command, Select Input 2

SP1 : Preset Velocity Command, Select Input 1 SP2 : Preset Velocity Command, Select Input 2	Valid Invalid	→	VC1: internal velocity command 1
SP1 : Preset Velocity Command, Select Input 1 SP2 : Preset Velocity Command, Select Input 2	Invalid Valid	→	VC2: internal velocity command 2
SP1 : Preset Velocity Command, Select Input 1 SP2 : Preset Velocity Command, Select Input 2	Valid Valid	→	VC3: internal velocity command 3
SP1 : Preset Velocity Command, Select Input 1 SP2 : Preset Velocity Command, Select Input 2	Invalid Invalid	→	Analog velocity command

3. Begin operation with the Preset Velocity Command and select the conditions for rotation direction.

Parameter Group9Page22	DIR: Preset Velocity Command, Direction of Move
Parameter Group9Page23	RUN: Preset Velocity Command, Operation Start Signal Input
Parameter Group9Page24	RUN-F: Preset Velocity Command, Positive Move Signal Input
Parameter Group9Page25	RUN-R: Preset Velocity Command, Negative Move Signal Input

4 If the above conditions are valid, run the servo motor with the selection combinations listed below.

RUN: Preset Velocity Command, Operation Start Signal Input	Valid	Servo motor moves forward
DIR: Preset Velocity Command, Direction of Move	Invalid	
RUN: Preset Velocity Command, Operation Start Signal Input	Valid	Servo motor in reverse
DIR: Preset Velocity Command, Direction of Move	Valid	
RUN-F: Preset Velocity Command, Positive Move Signal Input	Valid	Servo motor moves forward
RUN-R: Preset Velocity Command, Negative Move Signal Input	Valid	Servo motor in reverse

# 7. Adjustment · Functions

[Functions of Group 8]


[Internal velocity command]

Examples of setting and operation pattern at the Preset Velocity Command operation.

VC1: Preset Velocity Command 1	1000min <sup>-1</sup>
VC2: Preset Velocity Command 2	2000min <sup>-1</sup>
VC3: Preset Velocity Command 3	3500min <sup>-1</sup>

SP1: Preset Velocity Command, Select Input 1	Enable the function when general purpose input CONT3 is ON.
SP2: Preset Velocity Command, Select Input 2	Enable the function when general purpose input CONT4 is ON.

RUN-F: Preset Velocity Command, Positive Move Signal Input	Enable the function when general purpose input CONT5 is ON.
RUN-R: Preset Velocity Command, Negative Move Signal Input	Enable the function when general purpose input CONT5 is OFF.



# 7. Adjustment · Functions

## [Functions of Group 8]

### [Velocity addition command]

[Group 8 ] 23 to 25

Velocity Compensation Command, Input Selection [VCOMSEL] /

Preset Velocity Compensation Command [VCOMP]

Position control mode

Analog Velocity (Compensation) Command, Reference [VCGN]

The velocity compensation addition function is the fast-forward function in the velocity control system. The Velocity Compensation Command, Input Selection has 2 settings: the Preset Velocity Compensation Command and the Analog Velocity Compensation Command. The Preset Velocity Compensation Command is used when the velocity compensation command value is a fixed value. The Analog Velocity Compensation Command is used when setting the velocity compensation command input value from the host unit.

1. Set the Preset Velocity Compensation Command value.

Parameter Group8 Page24	VCOMP : Preset Velocity Compensation Command	-9999 to +9999 min <sup>-1</sup>
-------------------------	--	----------------------------------

2. Select the Velocity Compensation Command input method.

Parameter Group8 Page23	VCOMSEL : Velocity Compensation Command, Input Selection
-------------------------	--

Selection		Description
01:_Analog_Input	Apply Analog Velocity Compensation Command	Use analog velocity addition command value when velocity addition function is valid.
02:_VCOMP	Apply Preset Velocity Compensation Command	Use internal velocity addition command value when velocity addition function is valid.

3. Select the condition for enabling the Velocity Compensation Function and then input the setting.

Parameter Group9 Page27	VCOMPS : Velocity Compensation Function, Select Input
-------------------------	---


1. Set the Analog Velocity Compensation Command, Reference. (This is shared with Analog Velocity Command, Reference.)

Parameter group 8 page 25	VCGN : Analog Velocity Command, Reference	0 to 4000 min <sup>-1</sup> /V
---------------------------	---	--------------------------------

The input used in the Analog Velocity Compensation Command is the same as the Analog Velocity Command / Analog Torque Command input.

Analog Velocity Compensation Command input : CN1-21 【Input voltage range -10V to +10V】

Analog Velocity Compensation Command input SG : CN1-20



2. Select the Velocity Compensation Command input method.

Parameter Group8 Page23	VCOMSEL : Velocity Compensation Command Input Selection
-------------------------	---

Selection		Description
01:_Analog_Input	Apply Analog Velocity Compensation Command	Use Analog Velocity Compensation Command value when Velocity Compensation Function is valid.
02:_VCOMP	Apply Preset Velocity Compensation Command	Use Preset Velocity Compensation Command value when Velocity Compensation Function is valid.

3. Select the conditions for enabling the velocity addition function.

Parameter Group9 Page27	VCOMPS : Velocity Compensation Function, Select Input
-------------------------	---

# 7. Adjustment · Functions

[Functions of Group 8]

## [Velocity addition command]

[Group 8 ] 26 to 27

Velocity Command, Acceleration Time Constant. [TVCACC]


Velocity Command, Deceleration Time Constant. [TVCDEC]

Velocity control mode

The step input velocity command can be changed to a constant acceleration/deceleration velocity command using the Velocity Command, Acceleration/Deceleration Time Constant.

Acceleration/deceleration time per  $\pm 1000\text{min}^{-1}$  is set.

Parameter Group8Page26	TVCACC : Velocity Command, Acceleration Time Constant.	0~16000 ms
Parameter Group8Page27	TVCDEC : Velocity Command, Deceleration Time Constant.	0~16000 ms



The Analog Velocity Command, Preset Velocity Command, and JOG operation can be used together.

[Group 8 ] 28


Velocity Limit [VCLM]

Velocity control mode Position control mode

An host limit value can be locked in with the velocity limit command.

This value cannot be set to exceed the velocity capabilities of the adjoining motor.

Parameter Group8Page28	VCLM : Velocity Limit	1~65535 $\text{min}^{-1}$
------------------------	-----------------------	---------------------------



# 7. Adjustment - Functions

## [Functions of Group 8]

### [Torque addition command]

[Group 8 ] 30 to 34

Torque Compensation Command, Input Selection

[TCOMSEL] Analog Torque Compensation Command, Reference [TCOMPGN]

Preset Torque Compensation Command 1

[TCOMP1] Preset Torque Compensation Command 2 [TCOMP2]

Torque Compensation Function, Select Input 1

[TCOMPS1] Torque Compensation Function, Select Input 2 [TCOMPS2]

Velocity control mode Position control mode

The torque addition function is the fast-forward function of the torque control system. There are 2 types of settings for the torque addition command input function: the internal torque addition command and the analog torque addition command. The internal torque addition command can be used when using the torque addition command value as a fixed value. The analog torque addition command can be used when setting the torque addition command input value from the host unit.

1. Sets the internal torque addition command value.

Parameter Group8Page31	TCOMP : Preset Torque Compensation Command 1	-500 to +500 %
Parameter Group8Page32	TCOMP : Preset Torque Compensation Command 2	-500 to +500 %

2. Select the torque addition command input method.

Parameter Group8Page30	TCOMSEL : Torque Compensation Command, Input Selection
------------------------	--

Selection	Description
0 H	Torque addition function disabled
1 H	Apply Analog Torque Compensation Command Use analog torque addition command value when torque addition function is valid.
2 H	Apply Preset Torque Compensation Command Use internal torque addition command value when torque addition function is valid.

3. Select the condition for enabling the torque addition function and then input the setting.


Parameter Group9Page30	TCOMPS1 : Torque Compensation Function, Select Input 1
Parameter Group9Page31	TCOMPS2 : Torque Compensation Function, Select Input 2

1. Sets the analog torque addition command scaling.

Parameter Group8Page34	TCOMPGN : Analog Torque Compensation Command, Reference	0~500 %
------------------------	---	---------

2. The input used in the analog torque addition command provides the signal analog torque addition command input of CN1.

Analog torque addition command input : CN1-22 【Input voltage range -10V~+10V】  
 Analog torque addition command input SG : CN1-23



3. Select the torque addition command input method.

Parameter Group8Page30	TCOMSEL : Torque Compensation Command, Input Selection
------------------------	--

Selection	Description
0H	Torque addition function disabled
1H	Apply Analog Torque Compensation Command Use analog torque addition command value when torque addition function is valid.
2H	Apply Preset Torque Compensation Command Use internal torque addition command value when torque addition function is valid.

4. Select the conditions for enabling the torque addition function.

Parameter Group9Page30	TCOMPS1 : Torque Compensation Function, Select Input 1
Parameter Group9Page31	TCOMPS2 : Torque Compensation Function, Select Input 2

[Group 8 ]35 to 36

Torque Limit, Input Selection [TLSEL] Internal Torque Limit [TCLM]

Velocity control mode Position control mode Torque control mode

There are two areas where selections for the torque limit function can be made: the internal torque limit and the external torque limit. The two selections have different settings, and affect the operation of the unit in different ways.

#### Internal torque limit

The internal torque limit (constant) can be used to limit the maximum torque and protect the machine and equipment. Set these parameters according to the following table.

Parameter Group8 Page35 TLSEL: Torque Limit, Input Selection

Selection value		Description
00:_TCLM	Apply Internal Torque Limit Value. (TCLM)	Forward (positive direction) : limited by internal constant. Reverse (reverse direction) : limited by internal constant.

#### 2. Internal torque limit value setting

Parameter Group8 Page36 TCLM : Internal Torque Limit 10~500%

#### 3. Torque limit function enable

Parameter Group9 Page32 TL: Torque limit function


Conditions for enabling torque limit permission function are selected. When conditions are valid, torque limit is permitted and operation starts.

- \* If the value is set higher than the maximum output torque ( $T_P$ ) of the servo motor, it will be limited by ( $T_P$ ).
- \* Set this value after considering the acceleration time. Too low of a setting can result in insufficient acceleration torque and poor control.
- \* The internal torque limit should be set higher than the acceleration torque.
- \* The internal torque limit is identical for forward and reverse rotation. Separate torque limits cannot be set.

#### External torque limit

With the external torque limit function, separate torque limits can be set for forward and reverse rotation. There is a designated input for external torque limit on the CN1 input signal.

Forward torque limit input (F-TLA) : CN1-18 【Input voltage range 0V~+10V】  
 Reverse torque limit input (R-TLA) : CN1-19 【Input voltage range -10V~+10V】  
 SG : CN1-17



# 7. Adjustment · Functions

## [Functions of Group 8]


### [Torque limit]

The input voltage specification and the input signal specification can be used in three ways.


Parameter Group8Page35 TLSEL: Torque Limit, Input Selection

Selection value		Description
01:_Analog_1	Apply External Input: Positive Move/ F-TLA. Negative Move/ R-TLA (- Volt Input).	<ul style="list-style-type: none"> <li>• Forward: The limit will be the positive voltage input to F-TLA.</li> <li>• Reverse: The limit will be the negative voltage input to R-TLA.</li> </ul>
02:_Analog_2	Apply External Input: Positive Move/ F-TLA. Negative Move/ R-TLA (+ Volt Input).	<ul style="list-style-type: none"> <li>• Forward: The limit will be the positive voltage input to F-TLA.</li> <li>• Reverse: The limit will be the positive voltage input to R-TLA.</li> </ul>
03:_Analog_3	Apply External Input: Positive Move/ F-TLA. Negative Move/ F-TLA.	<ul style="list-style-type: none"> <li>• Forward: The limit will be the positive voltage input to F-TLA.</li> <li>• Reverse: The limit will be the positive voltage input to F-TLA.</li> </ul>


01:\_Analog\_1




02:\_Analog\_2



03:\_Analog\_3



Connect the voltage corresponding to the torque limit to the external torque input pin. The relationship between the input voltage and the limitable torque is the rated torque (TR) = 2V for the type of servo motor used.



Torque limit function enable

Parameter Group9Page32 TL: Torque Limit, Input Selection

Conditions for enabling torque limit permission function are selected. When conditions are valid, torque limit is permitted and operation starts.

## 7. Adjustment - Functions

[Functions of Group 8]

### [Sequence operation torque limit]

[Group 8 ] 37

Torque Limit at Sequence Operation [SQTCLM]    Velocity control mode    Position control mode    Torque control mode

During the sequence operation the output torque is limited. Limiting the output torque protects the unit mechanism.

The torque limits during sequence operation support the following sequence operations:

- JOG operation
- Over travel operation
- Securing brake standby time
- Servo brake operation

Sequence operation torque limit value setting

Parameter Group 8 Page37	SQTCLM : Torque Limit at Sequence Operation	10~500%
--------------------------	---	---------

If this value is set higher than the maximum output torque (TP) of the servo motor, it will be limited by (TP).



# 7. Adjustment · Functions

## [Functions of Group 8]

### [Near range]

[Group 8 ] 40

#### In-Position Near Range [NEAR]

Position control mode

Outputs signal indicating proximity to position completion.

This is used together with positioning complete signal (INP) and near range of positioning complete is output.


Parameter Group8Page40	NEAR : In-Position Near Range	1~65535	Pulse
------------------------	-------------------------------	---------	-------

Parameter GroupAPage0 *	OUT* : General Purpose Output *
-------------------------	---------------------------------

Selection		Description
1A	NEAR_ON	The output is ON during In-Position Near status (position deviation < NEAR).
1B	NEAR_OFF	The output is OFF during In-Position Near status (position deviation < NEAR).

Determine the logical status of the NEAR signal output, and to which output terminal to assign the positioning completion signal output. The assignment of the output terminal is the same location as the positioning completion signals (above).

If set to a value greater than the positioning completion range settings, the host unit receives the NEAR signal before receiving the positioning completion signal (INP), and transition to the positioning completion operations is enabled.



# 7. Adjustment · Functions

[Functions of Group 8]

## [Positioning complete range]

[Group 8 ] 41

In-Position Window [INP]

Position control mode

The positioning completion signal is output from the selected output terminal when servo motor movement is completed (reaches the set deviation counter value) during location control mode.

Setting the positioning completion range

Parameter Group8Page41	INP : In-Position Window	1~65535 Pulse
------------------------	--------------------------	---------------

Set the deviation counter value with positioning completion signals. The encoder pulse is standard, irrespective of the command pulse multiplication and electronic gear settings.

Incremental encoder: 4 times (4x) encoder pulses is standard.


Absolute encoder: absolute value is standard.

Setting the positioning completion signal

Parameter GroupA Page0 *	OUT* : General Purpose Output *
--------------------------	---------------------------------

Selection	Description
18 INP_ON	The output is ON during In-Position status (position deviation < INP).
19 INP_OFF	The output is OFF during In-Position status (position deviation < INP).

Determine the logical status of the positioning completion signal output, and to which output terminal to assign the positioning completion signal output.



# 7. Adjustment - Functions

## [Functions of Group 8]

### [Velocity setting]

[Group 8] 43 to 45

Low Speed Range [LOWV]    Speed Matching Width [VCMP]    High Speed Range [VA]  
 Position control mode    Velocity control mode    Torque control mode

This parameter affects settings for the speed output range. The signal can be output from general output (OUT1~OUT8) and used as a valid condition for all functions. However, the speed coincidence range is invalid in torque control mode.


To direct signals to the host unit, make assignments to the signals in parameter Group 9. Use the general output terminal (OUT1~OUT8) of the connected CN1.

Parameter GroupA Page0 \*    OUT\* : General Purpose Output \*

Selection	Description
10	LOWV_ON    The output is ON during low speed status (speed is less than LOWV).
11	LOWV_OFF    The output is OFF during low speed status (speed is less than LOWV).
12	VA_ON    The output is ON during high speed status (speed is more than VA).
13	VA_OFF    The output is OFF during high speed status (speed is more than VA).
14	VCMP_ON    The output is ON during speed matching status (speed deviation < VCMP).
15	VCMP_OFF    The output is OFF during speed matching status (speed deviation < VCMP).


Low speed range: Low speed signal is sent if speed goes below the set value.

Parameter Group8 Page43    LOWV : Low speed range    0~65535min<sup>-1</sup>




Speed Matching Width: Speed coincidence range signal is given if speed deviation reaches the set range.

Parameter Group8 Page44    VCMP : Speed Matching Width    0~65535min<sup>-1</sup>



Speed transport settings: Speed transport signal is given if speed exceeds the set value.

Parameter Group8 Page45    VA : High Speed Range    0~65535min<sup>-1</sup>



# 7. Adjustment · Functions

## [Functions of Group 8]


### [Velocity setting]

Various functions can be made valid without output signals taken into the host unit when this is used together with Group9 function enabling conditions (input signals).

Selection	Description
12 LOWV_IN	Enable the function during low speed status (speed is less than LOWV).
13 LOWV_OUT	Enable the function while low speed status is not kept.
14 VA_IN	Enable the function during high speed status (speed is more than VA).
15 VA_OUT	Enable the function while high speed status is not kept.
16 VCMP_IN	Enable the function during speed matching status (speed deviation < VCMP).
17 VCMP_OUT	Enable the function while speed matching status is not kept.


Low speed status [LOWV\_IN]: Function is enabled during low speed status (speed below LOWV set value).

Low speed status [LOWV\_OUT]: Function is enabled outside of low speed status (speed below LOWV set value).




Speed coincidence status [VCMP\_IN]: Function is enabled during speed coincidence status (speed deviation below VCMP set value).

Speed coincidence status [VCMP\_OUT]: Function is enabled outside of speed coincidence status (speed deviation below VCMP set value).



Speed transport status [VA\_IN]: Function is enabled during speed transport status (speed above VA set value).

Speed transport status [VA\_OUT]: Function is enabled outside of speed transport status (speed above VA set value).



# 7. Adjustment - Functions [Functions of Group 9] [Over travel]

## ■ Functions of Group 9

[Group 9] 00 to 01

### Positive Over-Travel Function [F-OT]


Position control mode   Velocity control mode   Torque control mode

### Negative Over-Travel Function [R-OT]

The over travel function uses a limit switch to prevent damage to the unit. It stops the unit when the movement range of the moving part is exceeded.

1. Allocate the over travel input signal to CONT1~CONT8.

Parameter Group9 Page00	F-OT : Positive Over-Travel Function
Parameter Group9 Page01	R-OT : Negative Over-Travel Function



2. If the over travel function is used, select the operating conditions of “Position command input, Servo motor stop operation and Servo ON signal” in the case of over travel.

Parameter GroupB Page11	ACTOT : Over-Travel Action Selection
-------------------------	--------------------------------------

Selected value	Contents
00:_CMDINH_SB_SON	· PC is inhibited and Servo-Braking is performed. After stops, S-ON is operated. (At OT, command disabled = velocity limit command = 0)
01:_CMDINH_DB_SON	· PC is inhibited and Dynamic-Braking is performed. After stops, S-ON is operated. (At OT, command disabled = velocity limit command = 0)
02:_CMDINH_Free_SON	· PC is inhibited and Free-Run is performed. After stops, Servo-ON is operated. (At OT, command disabled = velocity limit command = 0)
03:_CMDINH_SB_SOFF	· PC is inhibited and Servo-Braking is performed. After stops, S-OFF is operated.
04:_CMDINH_DB_SOFF	· PC is inhibited and Dynamic-Braking is performed. After stops, S-OFF is operated
05:_CMDINH_Free_SOFF	· PC is inhibited and Free-Run is performed. After stops, Servo-OFF is operated.
06:_CMDACK_VCLM=0	· Position Command is accepted and Velocity Limit is zero.

If “the motor is stopped by servo brake operation” [00:\_CMDINH\_SB\_SON][ 03:\_CMDINH\_SB\_SOFF] is selected when over travel occurs, torque at the time of servo brake operation can be set at the sequence torque operation limit value.

Parameter Group8 Page37	SQTCLM: Torque Limit at Sequence Operation	10~500%
-------------------------	--	---------

If the value is set higher than the maximum output torque (TP) of the servo motor, it will be limited by (TP).

# 7. Adjustment · Functions

## [Functions of Group 9]

### [Alarm reset · Servo ON]

[Group 9 ] 02

Alarm Reset Function [AL-RST]


Position control mode Velocity control mode Torque control mode

This function enables the sending of an alarm reset signal from the host unit. An alarm is cleared by enabling alarm reset function (AL-RST).

The conditions for enabling alarm reset function are assigned. The alarm is cleared if the AL-RST signal is valid.

Parameter Group9 Page02 AL-RST : Alarm Reset Function

The following circuit is created when valid conditions are assigned to CONT2. The logic can also be modified by the allocation of valid conditions.



\* Note that any alarm not cleared by simply turning OFF the control power supply cannot be cleared with the alarm reset signal.

[Group 9 ] 05

SERVO-ON Function [S-ON]


Position control mode Velocity control mode Torque control mode

This function enables the sending of a servo ON signal from the host unit. The servo motor can be set to “ready” status by enabling the servo ON function (SON).

The conditions for enabling the Servo ON function are assigned. The servo motor is set to “ready” status when the SON signal is enabled.

Parameter Group9 Page05 S-ON : SERVO-ON Function

The following circuit is created when valid conditions are assigned to CONT1. The logic can also be modified by the allocation of valid conditions.



# 7. Adjustment · Functions

## [Functions of Group 9]

### [Control mode switch over · Position command pulse inhibit/Zero velocity stop]

[Group 9] 10

Control Mode Switching Function [MS] Position control mode Velocity control mode Torque control mode

2 types of control mode can be switched and used. The control mode to be combined is selected by system parameter and can be switched with control mode switch over function.

Control mode is selected from system parameter Page 08.

Page	Name	Setting range
08	Control Mode	7 ways

Setting	Contents
03 : _Velo—Torq	Velocity Control Mode — torque control switching type
04 : _Posi—Torq	Position Control Mode — torque control switching type
05 : _Posi—Velo	Position control — velocity control switching type

After setting has been changed →The value becomes valid when control power is turned ON again.

Conditions enabling control mode switch over function are allocated. When MS signal is valid, control mode is switched.

Parameter Group9 Page10	MS : Control Mode Switching Function
-------------------------	--------------------------------------



When control mode switch over type is in use, there is a possibility that “auto-notch frequency tuning”, “auto-vibration suppressing frequency tuning”, and “JOG operation” cannot be used. Switch the control mode to the base side (disable MS) prior to using “auto-notch frequency tuning”, “auto-vibration suppressing frequency tuning”, and “JOG operation”.

[Group 9] 11

Position Command Pulse Inhibit Function and Velocity Command Zero Clamp Function [INH/Z-STP]

Velocity control mode Position control mode

This can be used as position command pulse inhibit function (INHIBIT function) in the position control type, and as zero velocity stop function in the velocity control type.

When the function is enabled while servo motor is operating, input command is inhibited and the servo motor stops at servo motor excitation status. In the position control type, even if position command pulse is input, the input pulse is not counted in the servo amplifier.

Conditions enabling position command pulse inhibit/zero velocity stop function are allocated. When signals of INH/Z-STP are valid, this will function.

Parameter Group9 Page11	INH/Z-STP : Position Command Pulse Inhibit Function / Velocity Command Zero Clamp Function
-------------------------	---

# 7. Adjustment - Functions

## [Functions of Group 9]

### [Gain switch over]

Group 9 ]13 , 14														
Gain Switching Function, Select Input 1 [GC1]    Gain Switching Function, Select Input 2 [GC2]														
Position control mode    Velocity control mode    Torque control mode														
4 types of gains can be switched and used.														
Conditions enabling gain switch over are allocated. When the signal of GC1 and GC2 combination is valid, the set value of corresponding GAIN becomes enabled.														
Parameter Group9 Page13	GC1 : Gain Switching Function, Select Input 1													
Parameter Group9 Page14	GC2 : Gain Switching Function, Select Input 2													
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;">GC1 : Gain Switching Function, Select Input 1</td> <td style="width: 12.5%;">Disabled</td> <td style="width: 12.5%;">Enabled</td> <td style="width: 12.5%;">Disabled</td> <td style="width: 12.5%;">Enabled</td> </tr> <tr> <td>GC2 : Gain Switching Function, Select Input 2</td> <td>Disabled</td> <td>Disabled</td> <td>Enabled</td> <td>Enabled</td> </tr> </table>					GC1 : Gain Switching Function, Select Input 1	Disabled	Enabled	Disabled	Enabled	GC2 : Gain Switching Function, Select Input 2	Disabled	Disabled	Enabled	Enabled
GC1 : Gain Switching Function, Select Input 1	Disabled	Enabled	Disabled	Enabled										
GC2 : Gain Switching Function, Select Input 2	Disabled	Disabled	Enabled	Enabled										
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;"></td> <td style="width: 12.5%; text-align: center;">↓</td> <td style="width: 12.5%; text-align: center;">↓</td> <td style="width: 12.5%; text-align: center;">↓</td> <td style="width: 12.5%; text-align: center;">↓</td> </tr> <tr> <td style="text-align: center;">Gain to be enabled</td> <td style="text-align: center;">GAIN 1</td> <td style="text-align: center;">GAIN 2</td> <td style="text-align: center;">GAIN 3</td> <td style="text-align: center;">GAIN 4</td> </tr> </table>						↓	↓	↓	↓	Gain to be enabled	GAIN 1	GAIN 2	GAIN 3	GAIN 4
	↓	↓	↓	↓										
Gain to be enabled	GAIN 1	GAIN 2	GAIN 3	GAIN 4										

[Group 9 ]15 , 16														
Position control mode    Velocity control mode    Torque control mode														
Vibration Suppressor Frequency, Select Input 1 [SUPFSEL1]														
Vibration Suppressor Frequency, Select Input 2 [SUPFSEL2]														
4 types of vibration suppressing frequency can be switched and used.														
Conditions for enabling vibration suppressing frequency selection input are allocated. When the signal of SUPFSEL1 and SUPFSEL2 combination is valid, the set value of corresponding vibration frequency becomes enabled.														
Parameter Group9 Page15	SUPFSEL1 : Vibration Suppressor Frequency, Select Input 1													
Parameter Group9 Page16	SUPFSEL2 : Vibration Suppressor Frequency, Select Input 2													
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;">SUPFSEL1 : Vibration Suppressor Frequency, Select Input 1</td> <td style="width: 12.5%;">Disabled</td> <td style="width: 12.5%;">Enabled</td> <td style="width: 12.5%;">Disabled</td> <td style="width: 12.5%;">Enabled</td> </tr> <tr> <td>SUPFSEL2 : Vibration Suppressor Frequency, Select Input 2</td> <td>Disabled</td> <td>Disabled</td> <td>Enabled</td> <td>Enabled</td> </tr> </table>					SUPFSEL1 : Vibration Suppressor Frequency, Select Input 1	Disabled	Enabled	Disabled	Enabled	SUPFSEL2 : Vibration Suppressor Frequency, Select Input 2	Disabled	Disabled	Enabled	Enabled
SUPFSEL1 : Vibration Suppressor Frequency, Select Input 1	Disabled	Enabled	Disabled	Enabled										
SUPFSEL2 : Vibration Suppressor Frequency, Select Input 2	Disabled	Disabled	Enabled	Enabled										
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;"></td> <td style="width: 12.5%; text-align: center;">↓</td> <td style="width: 12.5%; text-align: center;">↓</td> <td style="width: 12.5%; text-align: center;">↓</td> <td style="width: 12.5%; text-align: center;">↓</td> </tr> <tr> <td style="text-align: center;">Vibration suppressing frequency to be enabled</td> <td style="text-align: center;">Vibration Suppressor Frequency 1 Group2 Page 00</td> <td style="text-align: center;">Vibration Suppressor Frequency 2 Group 3 Page 40</td> <td style="text-align: center;">Vibration Suppressor Frequency 3 Group 3 Page 41</td> <td style="text-align: center;">Vibration Suppressor Frequency 4 Group 3 Page 42</td> </tr> </table>						↓	↓	↓	↓	Vibration suppressing frequency to be enabled	Vibration Suppressor Frequency 1 Group2 Page 00	Vibration Suppressor Frequency 2 Group 3 Page 40	Vibration Suppressor Frequency 3 Group 3 Page 41	Vibration Suppressor Frequency 4 Group 3 Page 42
	↓	↓	↓	↓										
Vibration suppressing frequency to be enabled	Vibration Suppressor Frequency 1 Group2 Page 00	Vibration Suppressor Frequency 2 Group 3 Page 40	Vibration Suppressor Frequency 3 Group 3 Page 41	Vibration Suppressor Frequency 4 Group 3 Page 42										



# 7. Adjustment · Functions

## [Functions of group 9]

### [Position · velocity loop proportional control switch over]

[Group 9 ] 17

Position Loop Proportional Control, Switching Function [PLPCON]

Position control mode

Switching between position loop PI control ↔ P control is possible. Switching is possible when position loop proportional control switchover function (PPCON) is enabled.

Conditions for enabling position loop proportional control switchover function are allocated. Switches to proportional control when the signal of PPCON is valid.

Parameter Group9 Page17

PLPCON : Position Loop Proportional Control, Switching Function

P I control (proportional · integral control) · · · · Position loop proportional gain (KP) · Integral time constant (TPI)

P control (Proportional control) · · · · Position loop proportional gain (KP)

\* Position loop integral time constant (TPI) is 1000.0ms at standard setting, therefore, integral function is invalid.

[Group 9 ] 26

Velocity Loop Proportional Control, Switching Function [VLPCON]

Velocity control mode

Position

control mode

Velocity loop PI control / P control can be used alternatively. Activate switching by enabling the velocity loop comparison control switching function (PCON)

The conditions for enabling the velocity loop comparison control switching function are assigned. Change the comparison control when the PCON signal is valid.

Parameter Group9 Page26

VLPCON : Velocity Loop Proportional Control, Switching Function

PI control (comparison / integral control): Velocity loop comparison gain (KVP) / Velocity loop reset time constant (TVI)

P control (Comparison control): Velocity loop comparison gain (KVP)

\* When set to comparison control, servo gain is reduced and the servo system is made stable.

\* When the velocity loop reset time constant (TVI) is set to 1000.0ms, it is not necessary to use this function, since the reset time constant in use is invalid (Comparison control)

## 7. Adjustment · Functions

[Functions of Group 9]

### [External trip · Forced discharge · Emergency stop]

[Group 9 ] 40
External Error Input [EXT-E]      Position control mode   Velocity control mode   Torque control mode
This function can output a contact input (such as external thermal) as an alarm (AL55H) in the servo amplifier.
The conditions for enabling the external trip function are assigned. An alarm (AL55H) is given if the EXT-E signal is valid.
Parameter Group9 Page40      EXT-E : External Error Input

[Group 9 ] 41
Main Power Discharge Function [DISCHARG]   Position control mode   Velocity control mode   Torque control mode
This function forcefully discharges voltage charged in the condenser for the main circuit power supply in the servo amplifier when power supply to the main circuit is cut. However, discharge is not possible when the main circuit power supply is ON.
The conditions for enabling forced discharge function are assigned. Forced discharge is possible when the DISCHARGE signal is valid.
Parameter Group9 Page41      DISCHARGE : Main Power Discharge Function

[Group 9 ] 42
Emergency Stop Function [EMR]      Position control mode   Velocity control mode   Torque control mode
This function enables an emergency stop of the servo motor after receiving an emergency stop signal in the servo amplifier.
The conditions for enabling the unit emergency stop signal are assigned. The unit emergency stop function is executed when the EMR signal is valid.
Parameter Group9 Page42      EMR : Emergency Stop Function

## 7. Adjustment - Functions

[Functions of Group B]

### [Dynamic brake - Forced stop]

#### ■ Functions of Group B

[GroupB] 10														
Dynamic Brake Action Selection [DBOPE]    Position control mode    Velocity control mode    Torque control mode														
Conditions for stop at servo OFF can be selected from Servo brake/dynamic brake/free run. Conditions after servo motor stop can be selected from dynamic brake/free run.														
Parameter GroupB Page10    DBOPE: Dynamic Brake Action Selection														
<table border="1"> <thead> <tr> <th colspan="2">Selected value</th> </tr> </thead> <tbody> <tr> <td>00:_Free_Free</td> <td>When Servo-OFF, Free-Run is operated. After stops, Motor-Free is operated.</td> </tr> <tr> <td>01:_Free_DB</td> <td>When Servo-OFF, Free-Run is operated. After stops, Dynamic-Braking is performed.</td> </tr> <tr> <td>02:_DB_Free</td> <td>When S-OFF, Dynamic-Braking is performed. After stops, Motor-Free is operated.</td> </tr> <tr> <td>03:_DB_DB</td> <td>When S-OFF, Dynamic-Braking is performed. After stops, Dynamic-Braking.</td> </tr> <tr> <td>04:_SB_Free</td> <td>When Servo-OFF, Servo-Braking is performed. After stops, Motor-Free is operated.</td> </tr> <tr> <td>05:_SB_DB</td> <td>When Servo-OFF, Servo-Braking is performed. After stops, Dynamic-Braking.</td> </tr> </tbody> </table>	Selected value		00:_Free_Free	When Servo-OFF, Free-Run is operated. After stops, Motor-Free is operated.	01:_Free_DB	When Servo-OFF, Free-Run is operated. After stops, Dynamic-Braking is performed.	02:_DB_Free	When S-OFF, Dynamic-Braking is performed. After stops, Motor-Free is operated.	03:_DB_DB	When S-OFF, Dynamic-Braking is performed. After stops, Dynamic-Braking.	04:_SB_Free	When Servo-OFF, Servo-Braking is performed. After stops, Motor-Free is operated.	05:_SB_DB	When Servo-OFF, Servo-Braking is performed. After stops, Dynamic-Braking.
Selected value														
00:_Free_Free	When Servo-OFF, Free-Run is operated. After stops, Motor-Free is operated.													
01:_Free_DB	When Servo-OFF, Free-Run is operated. After stops, Dynamic-Braking is performed.													
02:_DB_Free	When S-OFF, Dynamic-Braking is performed. After stops, Motor-Free is operated.													
03:_DB_DB	When S-OFF, Dynamic-Braking is performed. After stops, Dynamic-Braking.													
04:_SB_Free	When Servo-OFF, Servo-Braking is performed. After stops, Motor-Free is operated.													
05:_SB_DB	When Servo-OFF, Servo-Braking is performed. After stops, Dynamic-Braking.													

[GroupB] 12						
Forced stop operation [ACTEMR]    Position control mode    Velocity control mode    Torque control mode						
When forced stop is executed by power shut off while servo motor is operating (servo motor is not stopped), conditions for servo motor stop can be selected from servo brake/dynamic brake.						
Parameter GroupB Page12    ACTEMR : Emergency Stop Operation						
<table border="1"> <thead> <tr> <th>Selected value</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>00:_SERVO-BRAKE</td> <td>When EMR is input, motor is stopped by servo brake operation.</td> </tr> <tr> <td>01:_DINAMIC-BRAKE</td> <td>When EMR is input, motor is stopped by dynamic brake operation.</td> </tr> </tbody> </table>	Selected value	Contents	00:_SERVO-BRAKE	When EMR is input, motor is stopped by servo brake operation.	01:_DINAMIC-BRAKE	When EMR is input, motor is stopped by dynamic brake operation.
Selected value	Contents					
00:_SERVO-BRAKE	When EMR is input, motor is stopped by servo brake operation.					
01:_DINAMIC-BRAKE	When EMR is input, motor is stopped by dynamic brake operation.					

# 7. Adjustment · Functions

[Functions of Group B]


## [Securing brake operation delay time]

[GroupB] 13

Position control mode   Velocity control mode   Torque control mode


### Delay Time of Engaging Holding Brake [BONDLY]

This function is enabled during servo brake operation at servo OFF. It is disabled for dynamic brake and free-run.



Set the delay time for the securing brake operation

Parameter GroupB Page13	BONDLY : Delay Time of Engaging Holding Brake	0~1000ms
-------------------------	---	----------



• The setting increment is 4 msec.    If the setting is 0 msec, the command is disabled (forced zero) for 4 msec after SON.

• The securing brake excitation signal can be output through the generic outputs (OUT1~OUT8).

Parameter GroupA Page0 *	OUT* : General Purpose Output*
--------------------------	--------------------------------

0A: _MBR-ON_ ON	The output is ON while holding brake excitation signal outputs.
0B: _MBR-ON_ OFF	The output is OFF while holding brake excitation signal outputs.

# 7. Adjustment - Functions


## [Functions of Group B]

### [Securing brake release delay time]

[GroupB] 14

Position control mode
Velocity control mode
Torque control mode


#### Delay Time of Releasing Holding Brake [BOFFDLY]



If there is a delay between the motor start and the securing brake release, the motor operates with the securing brake on, and will damage the brake.

- Set the delay time for the securing brake release

Parameter GroupB Page14	BOFFDLY : Delay Time of Releasing Holding Brake	0~1000ms
-------------------------	---	----------



Damage to the securing brake due to this delay can be prevented by lengthening the time of the command-receive permission.

- The setting increment is 4 msec. If the setting is 0 msec, the command is disabled (forced zero) for 4 msec after SON.
- The securing brake excitation signal can be output through the generic outputs (OUT1~OUT8).

Parameter Group9 Page0 *	OUT* : General Purpose Output *
--------------------------	---------------------------------

0A: MBR-ON_ON	The output is ON while holding brake excitation signal outputs.
0B: MBR-ON_OFF	The output is OFF while holding brake excitation signal outputs.

[GroupB] 15

#### Brake Operation Beginning Time [BONBGN]

Position control mode
Velocity control mode
Torque control mode

If the motor does not stop within the time frame set for the brake operation start (BONBGN) when the servo is turned OFF, the securing brake and the dynamic brake force the motor to stop. The function can be disabled by setting the value to "0"ms. The setting increment is 4 msec; therefore, set the value to 4 msec or higher.

Parameter GroupB Page15	BONBGN : Brake Operation Beginning Time	0~65535ms
-------------------------	---	-----------

- \* The term "motor does not stop" (above) means that the motor velocity does not fall below the zero velocity (ZV) range.
- \* The stop sequence is different depending on the condition settings of the emergency stop operation.
- \* When the brake operation start time (BONBGN) passes, the servo motor will be forced to stop by both the dynamic brake and the securing brake, which can cause damage to the securing brake. Therefore, use this function only after considering the specifications and the sequence of the unit.

# 7. Adjustment - Functions [Functions of Group B]

## [Power failure detection delay time]

[GroupB] 16	Power Failure Detection Delay Time [PFDDLY] <span style="border: 1px solid black; padding: 2px;">Position control mode</span> <span style="border: 1px solid black; padding: 2px;">Velocity control mode</span> <span style="border: 1px solid black; padding: 2px;">Torque control mode</span>	
<p>This function can set a delay period, after power off of the control power supply, for detecting problems in the control power supply. Detection of unexpected power failure is diminished when this value is increased. However, even if this value is increased and problem detection is delayed, when the power supply to the internal logic circuit is exhausted, routine operations at the time of control power supply cut off / restart will continue.</p>		
Parameter GroupB Page16	PFDDLY : Power Failure Detection Delay Time	20~1000 ms
<ul style="list-style-type: none"> <li>* When energy to the main circuit power supply is insufficient, problems like a reduction in main circuit power supply are also detected.</li> <li>* The actual anomaly detection delay time compared to the selected value can vary between -12ms and +6ms.</li> </ul>		

## 7. Adjustment · Functions [Excessive deviation warning · Deviation counter overflow · Overload warning]

[GroupB] 20		
Following Error Warning Level [OFWLV] <span style="float:right">Position control mode   Velocity control mode   Torque control mode</span>		
This function gives a warning before reaching excessive deviation alarm status. Set the deviation excessive warning value.		
Parameter GroupB Page20	OFWLV : Following Error Warning Level	1~65535 × 1024 pulse
For sending the signals to the host unit, assign the signals in parameter Group A. Output from general output number (OUT1~OUT8) of the connected CNs1.		
Parameter GroupA Page0 *	OUT* : General Purpose Output *	
2A: _WNG-OFW_ ON	The output is ON during following warning status (position deviation > OFWLV).	
2B: _WNG-OFW_ OFF	The output is OFF during following warning status (position deviation > OFWLV).	

[GroupB] 21		
Following Error Limit [OFLV] <span style="float:right">Position control mode   Velocity control mode   Torque control mode</span>		
Parameter to set the value for outputting excessive position deviation alarm. Encoder pulse is the standard irrespective of electronic gear or command multiplication functions. Deviation counter overflow value is set.		
Parameter GroupB Page21	OFLV : Following Error Limit	1 ~ 65535 × 1024 pulse

[GroupB] 22		
Overload Warning Level [OLWLV] <span style="float:right">Position control mode   Velocity control mode   Torque control mode</span>		
This function will send a warning before reaching overload alarm status. Set the ratio corresponding to the overload alarm value to 100%. When set to 100%, the overload warning and overload alarm are given simultaneously.		
Set the overload warning level.		
Parameter GroupB Page22	OLWLV : Overload Warning Level	20~100 %
For sending the signals to the host unit, assign the signals in parameter Group A. Output from general output terminal (OUT1~OUT8) of the connected CN1.		
Parameter GroupA Page0 *	OUT* : General Purpose Output *	
2C: _WNG-OLW_ ON	The output is ON during over-load warning status.	
2D: _WNG-OLW_ OFF	The output is OFF during over-load warning status.	
* The overload detection process is assumed to be 75% of the rated load at the time of starting the control power supply (hot start). At this time, if the overload warning level is set below 75%, an overload warning is given after starting the control power supply.		

# 7. Adjustment · Functions

## [Functions of Group C]

### [Digital filter · External encoder polarity]

#### ■ Functions of Group C

[GroupC] 01~02

Position control mode   Velocity control mode   Torque control mode

Motor Incremental Encoder, Digital Filter [ENFIL]

External Incremental Encoder Digital Filter [EX-ENFIL]


You can set the digital filter value of the incremental pulse for the selected incremental encoder. When noise is superimposed on the incremental encoder, the pulse below the set value is removed as noise. Set this value by considering the frequency of pulses from the selected encoder and the maximum number of rotations of the servo motor. If the input value is greater than the encoder frequency during the peak rotation of the servo motor, the encoder pulse is removed and the servo motor will stop.

The motor encoder and external encoder can be set separately.

Selection for motor incremental encoder digital filter

Parameter GroupC Page01	ENFIL : Motor Incremental Encoder, Digital Filter
Parameter GroupC Page02	EX-ENFIL : External Incremental Encoder Digital Filter

Selected value	Contents
00:_110nsec	Minimum Pulse Width=110nsec (Minimum Pulse Phase Difference = 37.5nsec)
01:_220nsec	Minimum Pulse Width=220nsec
02:_440nsec	Minimum Pulse Width=440nsec
03:_880nsec	Minimum Pulse Width=880nsec
04:_75nsec	Minimum Pulse Width=75nsec (Minimum Pulse Phase Difference = 37.5nsec)
05:_150nsec	Minimum Pulse Width=150nsec
06:_300nsec	Minimum Pulse Width=300nsec
07:_600nsec	Minimum Pulse Width=600nsec



[GroupC] 03

External Encoder Polarity Invert [EX-ENPOL]

Position control mode   Velocity control mode   Torque control mode

You can select external encoder pulse polarity.

Parameter GroupC Page03	EX-ENPOL : External Encoder Polarity Invert
-------------------------	---

Selected value	Contents		
00:_Type1	EX-Z / Not Reversed	EX-B / Not Reversed	EX-A / Not Reversed
01:_Type2	EX-Z / Not Reversed	EX-B / Not Reversed	EX-A / Reversed
02:_Type3	EX-Z / Not Reversed	EX-B / Reversed	EX-A / Not Reversed
03:_Type4	EX-Z / Not Reversed	EX-B / Reversed	EX-A / Reversed
04:_Type5	EX-Z / Reversed	EX-B / Not Reversed	EX-A / Not Reversed
05:_Type6	EX-Z / Reversed	EX-B / Not Reversed	EX-A / Reversed
06:_Type7	EX-Z / Reversed	EX-B / Reversed	EX-A / Not Reversed
07:_Type8	EX-Z / Reversed	EX-B / Reversed	EX-A / Reversed

This setting is disabled in case of full closed control and when motor encoder is absolute encoder.

(To be set at Type 1.)



# 7. Adjustment - Functions

## [Functions of Group C] [Encoder pulse division]

[GroupC] 04

Encoder Pulse Divided Output, Selection [PULOUTSEL] Position control mode Velocity control mode Torque control mode

Encoder pulse divider output can be selected from 2 types; motor encoder or external encoder.

Parameter GroupCPage04	PULOUTSEL : Encoder Pulse Divided Output, Selection
------------------------	---

Selected value	Contents
00: _Motor_Enc.	Motor Encoder
01: _External_Enc.	External Encoder

- For semi-closed control, select 00:Motor encoder.
- With semi-closed control. If the motor encoder is an absolute encoder other than the absolute encoder with incremental output, incremental pulse of 8192P/R will be input into the division circuit.
- When full-closed controlled and motor encoder is absolute encoder, external encoder pulse is output by selecting any.

[GroupC] 05

Encoder Output Pulse, Divide Ratio [ENRAT] Position control mode Velocity control mode Torque control mode

The encoder signals (Phase A/ Phase B) used in the host unit can be output according to a ratio formula. When using in the host unit's position loop control, input the result (obtained after dividing the number of encoder pulses) as an integer. However, when using this function to monitor the host unit, input a ratio that is as close to the setup value as possible.

The output of Z phase is not divided. Output can be sin Open Collector (CN1-11) .

Division ratio for the encoder pulse divider output is set.

Parameter GroupC Page05	ENRAT : Encoder Output Pulse, Divide Ratio	1/1~1/8192
-------------------------	--	------------

The following settings are possible.

When numerator is "1" : 1/1~1/64, 1/8192 can be set.

When numerator is "2" : 2/3~2/64, 2/8192 can be set.

When denominator is "8192" : 1/8192 ~ 8191/8192 can be set.

Frequency division 1/1 (Forward rotation)

Frequency division 1/2 (Forward rotation)

Frequency division 2/5 (Forward rotation)

\* Destabilizes for 1 sec after control power is supplied.

# 7. Adjustment - Functions

## [Functions of Group C]

### [Encoder division - Encoder clear]

[GroupC] 06

#### Encoder Pulse Divided output, Polarity [PULOUTPOL]

Position control mode   Velocity control mode   Torque control mode

The polarity of the encoder pulse frequency output can be selected.


Parameter GroupC Page06

PULOUTPOL : Encoder Pulse Divided output, Polarity

Selected value	Contents
00:_Type1	A-Phase Signal / Not Reversed : Z-Phase Signal Logic / High Active
01:_Type2	A-Phase Signal / Reversed : Z-Phase Signal Logic / High Active
02:_Type3	A-Phase Signal / Not Reversed : Z-Phase Signal Logic / Low Active
03:_Type4	A-Phase Signal / Reversed : Z-Phase Signal Logic / Low Active

Setting 00H (Frequency division ratio 1/1: with forward rotation)  
Using the incremental encoder

Setting 03H (Frequency division ratio 1/1: with forward rotation)  
Using the incremental encoder



[GroupC] 08

#### Abusolute Encoder Clear Function Selection [ECLRFUNC]

Position control mode   Velocity control mode   Torque control mode

Select the conditions for enabling absolute encoder clear.

Parameter Group9 Page03

ECLR : Abusolute Encoder Clear Function

When using a battery backup method absolute encoder and absolute encoder without battery, you can select the contents to be cleared.

Clear "Warning + multiple rotation data"

Clear only "Warning"

Parameter GroupC Page08

ECLRFUNC : Abusolute Encoder Clear Function Selection

Selected value	Contents
00:_Status_MultiTurn	Clear Encoder Status (Alarm and Warning) and Multi Turn Data
01:_Status	Clear Only Encoder Status

- \* These conditions are applicable only to the battery backup method absolute encoder and absolute encoder without battery.
- \* Do not input this while the servo motor is rotating. Confirm that the servo motor stops before inputting this.

# 7. Adjustment - Functions [Monitor] [Analog monitor]

## ■ Description of monitor

All signals and internal status of the servo amplifier can be monitored. There are 3 kinds of monitors.

1. Analog monitor
  2. Digital monitor
  3. Monitor in display
- Monitor box and dedicated monitor cable are needed. Refer to "Materials; Option, Monitor box".  
 Refer to "Chapter 1, Prior to Use, Servo Amplifier Part Names 1-6" for locations for connectors to be connected.  
 (Setup software-R-SETUP)

## ● Analog monitor (2 channels)

[Group A]11 to 13

Analog Monitor 1, Output Signal Selection [MON1]

Analog Monitor 2, Output Signal Selection [MON2]

Analog Monitor, Output Polarity [MONPOL]

Position control mode    Velocity control mode    Torque control mode

Analog monitor for use is selected.

Parameter GroupA Page11	MON1 : Analog Monitor 1, Output Signal Selection
Parameter GroupA Page12	MON2 : Analog Monitor 2, Output Signal Selection

Selected value	Contents
00	Reserved
01:_TMON_2V/TR	Torque Monitor    2V/ rated torque (thrust)
02:_TCMON_2V/TR	Torque Command Monitor    2V/ rated torque (thrust)
03:_VMON_0.2mV/ min <sup>-1</sup>	Velocity Monitor    0.2mV/ min <sup>-1</sup>
04:_VMON_1mV/ min <sup>-1</sup>	Velocity Monitor    1mV/ min <sup>-1</sup>
05:_VMON_2mV/ min <sup>-1</sup>	Velocity Monitor    2mV/ min <sup>-1</sup>
06:_VMON_3mV/ min <sup>-1</sup>	Velocity Monitor    3mV/ min <sup>-1</sup>
07:_VCMON_0.2mV/ min <sup>-1</sup>	Velocity Command Monitor    0.2mV/ min <sup>-1</sup>
08:_VCMON_1mV/ min <sup>-1</sup>	Velocity Command Monitor    1mV/ min <sup>-1</sup>
09:_VCMON_2mV/ min <sup>-1</sup>	Velocity Command Monitor    2mV/ min <sup>-1</sup>
0A:_VCMON_3mV/ min <sup>-1</sup>	Velocity Command Monitor    3mV/ min <sup>-1</sup>
0B:_PMON_0.1mV/P	Position Deviation Monitor    0.1mV/ Pulse
0C:_PMON_1mV/P	Position Deviation Monitor    1mV/ Pulse
0D:_PMON_10mV/P	Position Deviation Monitor    10mV/ Pulse
0E:_PMON_20mV/P	Position Deviation Monitor    20mV/ Pulse
0F:_PMON_50mV/P	Position Deviation Monitor    50mV/ Pulse
10:_FMON_2mV/kP/s	Position Command Pulse Input Frequency Monitor    2mV/kPulse/s
11:_FCMON_10mV/kP/s	Position Command Pulse Input Frequency Monitor    10mV/kPulse/s
12:_TLMON_EST_2V/TR	Load Torque Monitor (Estimate Value)    2V/ rated torque (thrust)
13:_Sine-U	Sine-U
14:_VBUS_1V/DC100V	Main Power Circuit D.C. Voltage    1V/DC100V
15:_VBUS_1V/DC10V	Main Power Circuit D.C. Voltage    1V/DC10V

Select this when polarity is to be changed.

Parameter GroupA Page12	MONPOL: Analog Monitor, Output Polarity
-------------------------	---

Selected value	Contents
00:_MON1+_MON2+	MON1 : Positive voltage output in forward rotation; output pos and neg voltage. MON2 : Positive voltage output in forward rotation; output pos and neg voltage.
01:_MON1-_MON2+	MON1 : Negative voltage output in forward rotation; output pos and neg voltage. MON2 : Positive voltage output in forward rotation; output pos and neg voltage.
02:_MON1+_MON2-	MON1 : Positive voltage output in forward rotation; output pos and neg voltage. MON2 : Negative voltage output in forward rotation; output pos and neg voltage.
03:_MON1-_MON2-	MON1 : Negative voltage output in forward rotation; output pos and neg voltage. MON2 : Negative voltage output in forward rotation; output pos and neg voltage.
04:_MON1ABS_MON2+	MON1 : Positive voltage output together in forward and reverse rotation MON2 : Positive voltage output in forward rotation; output pos and neg voltage.
05:_MON1ABS_MON2-	MON1 : Positive voltage output together in forward and reverse rotation MON2 : Negative voltage output in forward rotation; output pos and neg voltage.
06:_MON1+_MON2ABS	MON1 : Positive voltage output in forward rotation; output pos and neg voltage. MON2 : Positive voltage output together in forward and reverse rotation
07:_MON1-_MON2ABS	MON1 : Negative voltage output in forward rotation; output pos and neg voltage. MON2 : Positive voltage output together in forward and reverse rotation
08:_MON1ABS_MON2ABS	MON1 : Positive voltage output together in forward and reverse rotation MON2 : Positive voltage output together in forward and reverse rotation

# 7. Adjustment - Functions

[Monitor] [Digital monitor]

[Displayed monitor list]

- Digital monitor (1 channel)

[Group A] 10
Digital Monitor 1, Output Signal Selection [DMON]
Position control mode   Velocity control mode   Torque control mode
Digital monitor for use is selected.
Parameter GroupA Page10      DMON : Digital Monitor 1, Output Signal Selection
For selected values, refer to “Chapter 5, Parameter [Parameter setting value [GroupA] ] generic output OUT1~ generic output OUT8, and setting selection list of digital monitor output.

- List of monitors in display

[monitor] 00 to 1E			
Page	Name	Contents	Unit
00	Servo Amplifier Status	Displays the statuses of main circuit power being supplied, operation ready and servo ON.	---
01	Warning status 1	Displays warning status.	---
02	Warning status 2	Displays warning status.	---
03	General Purpose Input CONT8 to CONT1 Monitor	Displays generic input terminal status.	---
04	General Purpose Output OUT8 to OUT1 Monitor	Displays generic output terminal status.	---
05	Velocity Monitor	Displays motor rotation velocity.	min <sup>-1</sup>
06	Velocity Command Monitor	Displays velocity command value.	min <sup>-1</sup>
07	Torque Monitor	Displays motor output torque.	%
08	Torque Command Monitor	Displays torque command value.	%
09	Position Deviation Monitor	Displays position deviation values.	Pulse
0A	Actual Position Monitor	Displays current position compared with original position when the control power is turned ON. This is a free run counter. Therefore, when current position exceeds the displayed range, the display is maximum value of reversed polarity.	Pulse
0B	External Actual Position Monitor		
0C	Command Position Monitor		
0D	Analog Velocity Command/Analog Torque Command Input Voltage	Displays command voltage being input.	mV
0E	Position Command Pulse Input Frequency Monitor	Displays command pulse frequency being input.	k Pulse/s
0F	U-Phase Electric Angle Monitor	Displays electric angle of U phase. Except for encoder (sensor) error, this is always displayed.	deg
10	Absolute Encoder PS Data (High)	Displays absolute encoder position data PS.	x2 <sup>32</sup> P
11	Absolute Encoder PS Data (Low)	Displays absolute encoder position data PS.	Pulse
12	Regenerative Resistor Operation Percentage	Displays regeneration resistance operation status.	%
13	Motor Operating Rate Monitor	Displays exact values, however, it may take several hours for the value to become stable depending on the operation pattern.	%
14	Predicted Motor Operating Rate Monitor	Displays estimated value of servo motor usage ratio, which is estimated from a short period of operation. In an application where the same operation pattern repeats in a short period of time, the usage ratio can be confirmed fast.	%
15	Load Inertia (Mass) Ratio Monitor	Values can be confirmed when gain switch over and auto-tuning functions are used.	%
16	Position Loop Proportional Gain Monitor		1/s
17	Position Loop Integral Time Constant Monitor	Values can be confirmed when gain switch over function is used.	ms
18	Velocity Loop Proportional Gain Monitor	Values can be confirmed when gain switch over and auto-tuning function are used.	Hz
19	Velocity Loop Integral Time Constant Monitor		ms
1A	Torque Command Filter Monitor		Hz
1B	Incremental Encoder Signal Monitor	Incremental signal of CN2 is displayed.	----
1C	Load Torque Monitor (Estimate Value)	Load torque is displayed.	%
1D	Powre Monitor	Main circuit DC voltage is displayed.	V
1E	Servo Amplifier Operation Time	Counted while control power supply is ON. The time is displayed value × 2 hours.	× 2 hour

For displays of monitor by Setup Software, refer to “Setup Software R-SETUP”.

# [Maintenance]

◆	Trouble Shooting .....	8-1
◆	Alarm List .....	8-3
◆	Trouble Shooting When Alarm Occurs .....	8-6
◆	Inspection / Parts Overhaul .....	8-31

## ■ Corrective Actions for Problems During Operation

●When troubles occur without any alarm displayed, check and take corrective actions for them referring to the description below. When alarm rings, take corrective measures referring to “Trouble Shooting When Alarm Rings” .



When you do the work for correction processing, be sure to intercept power supply.

No	Problems	Investigation	Assumed causes and corrective actions
1	“≡” does not blink in 7-segment LED even if main power is ON.	Check the voltage at the power input terminal.	<ul style="list-style-type: none"> <li>If voltage is low, check the power supply.</li> <li>If there is no voltage, check that wires and screws are fastened properly.</li> </ul>
		Check if red “CHARGE” LED is lighting off.	<ul style="list-style-type: none"> <li>Internal power circuit of servo amplifier is defective. → Replace the servo amplifier.</li> </ul>
2	7-segment LED displays a rotating character “8” (Servo ON status), but motor does not rotate.	Check of command is input by the digital operator’s monitor. page 06 : Velocity Command Monitor page 08 : Torque Command Monitor page 0E : Position Command Monitor The monitor’s value is zero.	<ul style="list-style-type: none"> <li>Input a command.</li> </ul>
		Servo is not locked.	<ul style="list-style-type: none"> <li>Confirm that power line of motor is connected.</li> </ul>
		Check if torque limit is input.	<ul style="list-style-type: none"> <li>Because torque limit has been input, motor cannot rotate more than load torque.</li> </ul>
		Enter deviation clear to check if process is continued.	<ul style="list-style-type: none"> <li>Stop the input of deviation clear.</li> </ul>
3	Operation of the servomotor is unstable and velocity is lower than command.	Check if proportional control is entered.	<ul style="list-style-type: none"> <li>Stop the input of proportional control.</li> </ul>
		Check if torque limit is input.	Quit inputting torque limit.
4	Servo motor rotates only once, and stops.	Check motor power line.	<ul style="list-style-type: none"> <li>The motor power line is not connected.</li> </ul>
		Check the setup of encoder resolution. The digital operator’s system parameter page 05 : Absolute Encoder Resolution Setting. page 03 : Incremental Encoder Resolution Setting	<ul style="list-style-type: none"> <li>Change the settings and turn ON the power again.</li> </ul>

## 8. Maintenance

## [Trouble Shooting]

No	Problems	Investigation	Assumed causes and corrective actions
5	The servo motor runs recklessly.	Check the motor power line.	<ul style="list-style-type: none"> <li>Phase order of motor power line does not match.</li> </ul>
		Check the wiring of encoder cable.	<ul style="list-style-type: none"> <li>Wiring of A phase and B phase of the encoder is incorrect.</li> </ul>
6	Motor is vibrating with frequency above 200 Hz.	—	<ul style="list-style-type: none"> <li>Reduce the loop gain speed.</li> <li>Set the torque command low-pass filter and torque command notch filter.</li> </ul>
7	Overshoot and undershoot are generated during starting and stopping.	—	<ul style="list-style-type: none"> <li>Adjust the servo tuning “response”.</li> <li>Reduce the loop gain speed.</li> <li>Increase the integral time constant.</li> <li>Simplify the acceleration and deceleration command.</li> <li>Use position command low-pass filter.</li> </ul>
8	Abnormal sound occurs	Check that there is no defect in mechanical installation.	<ul style="list-style-type: none"> <li>Observe by operating one motor.</li> <li>Pay attention while coupling and confirm that there is no core shift or unbalance.</li> </ul>
		Check whether abnormal sound is random or periodic while operating at low speed.	<ul style="list-style-type: none"> <li>Confirm that the twisted pair and shield processing of encoder signal line are correct.</li> <li>Confirm that the wiring for encoder line and power line are installed in the same port.</li> <li>Confirm that the power supply voltage is sufficient.</li> </ul>

# 8. Maintenance

# [Alarm List]

## Alarm List

	Alarm code								Alarm title	Alarm contents	Detection Operations	Alarm Clear
	Display	3 bits output			PY compatible code							
		Bit7	Bit6	Bit5	ALM8	ALM4	ALM2	ALM1				
Abnormality related to drive	2 1 H	0	0	1	0	0	0	1	Power Module Error (Overcurrent)	• Over current of drive module • Abnormality in drive power source • Overheating of drive module	DB	V
	2 2 H				0	0	0	1	Current Detection Error 0	• Abnormality of electric current detection value	DB	V
	2 3 H				0	0	0	1	Current Detection Error 1	• Abnormality of Electric current detection circuit	DB	V
	2 4 H				0	0	0	1	Current Detection Error 2	• Abnormality in communication with Electric current detection circuit	DB	V
Abnormality related to load	4 1 H	0	1	0	0	0	1	0	Overload 1	• Excessive effective torque	SB	V
	4 2 H				0	0	1	0	Overload 2	• Stall over load	DB	V
	4 3 H				0	1	0	1	Regenerative Error	• Regeneration load ratio exorbitance	DB	V
	5 1 H				0	0	1	1	Amplifier Overheat	• Overheating detection of amplifier ambient temperature	SB	V
	5 2 H				0	0	1	1	RS Overheat	• Detection of in-rush prevention resistance overheating	SB	V
	5 3 H				0	0	1	1	Dynamic Brake Resistor Overheat	• Overheating detection of DB resistor	SB	V
	5 4 H				0	1	0	1	Internal Overheat	• Overheating detection of Internal regeneration resistor	DB	V
	5 5 H				0	0	1	1	External Error	• Overheating detection of External regeneration resistor	DB	V
	Alarm code								Alarm name	Alarm contents	Operations while detecting	Alarm clear
	Display	3 bits output			PY compatible code							
		Bit7	Bit6	Bit5	ALM8	ALM4	ALM2	ALM1				
Abnormality in power source	6 1 H	0	1	1	0	1	0	1	Overvoltage	• DC Excess voltage of main circuit	DB	V
	6 2 H				1	0	0	1	Main Circuit Undervoltage Note 1)	• DC Main circuit low voltage	DB	V
	6 3 H				1	0	1	0	Main Power Supply Fail Phase Note 1)	• 1 phase of the 3 phase main circuit power supply disconnected	SB	V
	7 1 H				0	1	1	1	Control Power Supply Undervoltage Note 3)	• Control power supply low voltage	DB	V Note 2)
	7 2 H				0	1	1	1	Control Power Error	• Under voltage of + 12 V	SB	V
Abnormality related to encoder wiring	8 1 H	1	0	0	1	0	0	0	Encoder Pulse Error 1 (A-phase, B-phase, Z-phase)	• Incremental encoder (A, B, Z) signal line break • Power supply break	DB	“ ”
	8 2 H				1	0	0	0	Absolute Encoder Signal Disconnect	• Absolute Encoder (PS) signal line break	DB	V
	8 3 H				1	0	0	0	External Encoder Pulse Error (CN-EXT: A-Phase, B-Phase, Z-Phase)	• Breaking of full close Encoder (A, B) signal line	DB	V
	8 4 H				1	0	0	0	Communication Error Between Encoder and Amplifier	• Encoder serial signal time out	DB	V Note 4)
	8 5 H				1	0	0	0	Encoder Initial Process Error	• Failed to read CS data of incremental encoder • Abnormality in initial process of absolute encoder • Cable break	—	“ ”
	8 7 H				1	0	0	0	CS Signal Disconnection	• CS signal line break	DB	“ ”
	9 1 H				1	0	0	0	Encoder Command Error	• Mismatch of transmission command and reception command	DB	V
	9 2 H				1	0	0	0	Encoder FORM Error	• Start, Stop bit Abnormality • Insufficient data length	DB	V
	9 3 H				1	0	0	0	Encoder SYNC Error	• Data cannot be received during the prescribed time after the command is sent.	DB	V
	9 4 H				1	0	0	0	Encoder CRC Error	• CRC generated from the received data and sent CRC does not match	DB	V

Note 1:Control power error or servo ready OFF is detected during instantaneous break of 1.5 to 2 cycles.

Detection of control power error and servo ready OFF can be delayed by setting larger value of PFDDLY (Group B Page 16) .

Note 2:When the main power voltage increases or decreases gradually or is suspended, main circuit low voltage or main power failed phase may be detected.

Note 3: When interruption of control power is long, it is regarded as power supply interception and re-input, and the detected error of control power is not left to an alarm history.

If interruption exceeds 1 second, it will be certainly judged as power supply interception.

Note 4:When the absolute encoder with incremental output is used, alarm resetting is prohibited.



# 8. Maintenance

# [Alarm List]

	Alarm code								Alarm name	Alarm contents	Operations while detecting	Alarm clear
	Display	3 bits output			PY compatible code							
		Bit7	Bit6	Bit5	ALM8	ALM4	ALM2	ALM1				
Abnormality in encoder main body	A 1 H	1	0	1	1	0	0	0	Encoder Error 1	• Breakdown of Encoder internal device	D B	Note 3)
	A 2 H				1	0	0	0	Absolute Encoder Battery Error	• Battery low voltage	D B	Note 3)
	A 3 H				1	0	0	0	Encoder Overheat	• Motor built-in Encoder Overheating	D B	Note 3)
	A 5 H				1	0	0	0	Encoder Error 3	• Error generation of multi-rotation data • Abnormality in operations of temperature sensor	D B	Note 3)
	A 6 H				1	0	0	0	Encoder Error 4	• Encoder internal EEPROM data is not set • Overflow of multi-rotation data	D B	Note 3)
	A 7 H				1	0	0	0	Encoder Error 5	• Resolver Abnormality • Light receiving abnormality in encoder	D B	Note 3)
	A 8 H				1	0	0	0	Encoder Error 6	• Resolver disconnection • Light receiving abnormality in encoder	D B	Note 3)
	A 9 H				1	0	0	0	Failure of Encoder	• Encoder failure	D B	Note 3)
	B 2 H				1	0	0	0	Encoder Error 2	• Position data incorrect	D B	Note 3)
	B 3 H				1	0	0	0	Absolute Encoder Multi-Turn Counter Error	• Detection of incorrect multiple rotations coefficient	D B	Note 3)
	B 4 H				1	0	0	0	Absolute Encoder Single-Turn Counter Error	• Detection of incorrect 1 rotation coefficient	D B	Note 3)
	B 5 H				1	0	0	0	Over-allowable Speed of Absolute Encoder at Turning ON	• Exceeds the permitted speed of motor rotation speed when the power is turned ON	D B	Note 3)
	B 6 H				1	0	0	0	Encoder Memory Error	• Access error of Encoder internal EEPROM	D B	Note 3)
B 7 H	1	0	0	0	Acceleration Error	• Exceeds the permitted speed for motor rotation	D B	Note 3)				
Control system abnormality	C 1 H	1	1	0	0	1	1	0	Overspeed	• Motor rotation speed is 120 % more than the highest speed limit	D B	V
	C 2 H				1	1	0	0	Speed Control Error	• Torque command and acceleration direction are not matching.	D B	V
	C 3 H				1	1	0	0	Speed Feedback Error	• Motor power disconnection (Note 2)	D B	V
	D 1 H				1	1	0	1	Following Error (Excessive Position Deviation)	• Position error exceeds setup value	D B	V
	D 2 H				1	1	0	1	Faulty Position Command Pulse Frequency 1	• Frequency of entered position command pulse is excessive	S B	V
	D 3 H				1	1	0	1	Faulty Position Command Pulse Frequency 2	• Position command frequency after electronic gear is high.	S B	V
	D E H				1	1	0	1	Wrap Around Error	• Internal coordination exceeded the limit	D B	V
	D F H				1	1	0	1	Test Run Close	• Detection in 'Test mode end' status	D B	V
Control system/Memory system abnormality	E 1 H	1	1	1	1	1	1	1	EEPROM Error	• Abnormality of amplifier with built-in EEPROM	D B	“ ”
	E 2 H				1	1	1	1	EEPROM Check Sum Error	• Error in check sum of EEPROM (entire area)	—	“ ”
	E 3 H				1	1	1	1	Internal RAM Error	• Access error in CPU built in RAM	—	“ ”
	E 4 H				1	1	1	1	Process Error between CPU and ASIC	• Access abnormality in CPU ~ ASIC	—	“ ”
	E 5 H				1	1	1	1	Parameter Error 1	• Detection when non-corresponding or undefined amplifier, motor, encoder code are specified.	—	“ ”
	E 6 H				1	1	1	1	Parameter Error 2	• Error in combining motor, encoder, and/or amplifier code set from system parameter	—	“ ”
	E D H				1	1	1	1	EEPROM Error (Sub CPU)	• Abnormality of amplifier with built-in EEPROM	—	“ ”
	E E H				1	1	1	1	RAM Error	• System parameter has been changed	—	“ ”
	E F H				1	1	1	1	DPRAM Initial Error	•	—	“ ”
	F 1 H				1	1	1	1	Task Process Error	• Error in interruption process of CPU	D B	“ ”
	F 2 H				1	1	1	1	Initial Process Time-Out	• Detection when initial process does not end within initial process time	—	“ ”
	F C H				1	1	1	1	Task Synchronous Error	• Task synchronization was slipped	—	“ ”
	F D H				1	1	1	1	Communication Initial Error	• There are something wrong with the communication settings.	—	“ ”
	F E H				1	1	1	1	Communication Error	• Communication error occurred.	—	V
F F H	1	1	1	1	Sub CPU Error	• Malfunction on interface processor.	—	“ ”				

Note 1: Alarm that rings in 'Test mode end' status is not recorded in the alarm history.

Note 2: When there is a rapid motor slow down simultaneous with servo ON, there is a possibility that a break in the motor's power line cannot be detected.

Note 3: Due to abnormality in encoder main body, encoder clear may sometimes be needed.

Note 4: "V" means it is possible to reset. " " means it is not possible to reset.

## ■ Warning List

	Warning Title	Warning Contents
Load system	Overload Warning	• When the effective torque exceeds the set torque
	Regenerated Overload Warning	• In case of overload of regenerative resistance
	Amplifier Overheating Warning	• Ambient temperature of the amplifier is out of range of the set temperature
Power supply system	Main circuit is charging	• Voltage of main circuit is above DC 105 V
External input system	Forward over travel	• While entering forward over travel
	Reverse over travel	• While entering reverse over travel
Encoder system	Absolute encoder battery warning	• Battery voltage is below 3.0 V
Control system	Restricting torque command	• While restricting the torque command by torque restriction value
	Restricting speed command	• While restricting the speed command by speed value.
	Excessive position deviation	• When position deviation warning setup value is outside the proscribed limits

## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code 21H (Power Module Error / Overcurrent)

Status at the time of alarm	Cause			
	1	2	3	4
Issued when control power is turned ON.	(V)		V	(V)
Issued at servo input.	V	V	V	
Issued while starting and stopping the motor.	(V)	(V)	(V)	
Issued after extended operating time.	(V)	(V)	(V)	V

#### Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> <li>U/V/W-phase of amplifier is short circuited due to the wiring in amplifier and motor. Also, U/V/W-phases are grounded in the earth.</li> </ul>	<ul style="list-style-type: none"> <li>Check the wiring between the amplifier and motor, and confirm that there is no error. If some error is detected, modify or change the wiring.</li> </ul>
2	<ul style="list-style-type: none"> <li>Short circuit or fault in U/V/W phases on servo motor side.</li> </ul>	<ul style="list-style-type: none"> <li>Replace the servo motor.</li> </ul>
3	<ul style="list-style-type: none"> <li>Defect in control print panel</li> <li>Defect in power device</li> </ul>	<ul style="list-style-type: none"> <li>Replace the servo amplifier.</li> </ul>
4	<ul style="list-style-type: none"> <li>Overheat is detected in Power device (IPM).</li> </ul>	<ul style="list-style-type: none"> <li>Confirm that the cooling fan motor for the servo amplifier is working. If it is not working, replace the servo amplifier.</li> <li>Confirm that the temperature of the control panel (ambient temperature of the servo amplifier) does not exceed 55°C. If in excess of 55(C, check the installation method of the servo amplifier, and confirm that the cooling temperature of the control panel is set to below 55°C</li> </ul>

### Alarm code 22H (Current Detection Error 0)

Status during alarm	Cause	
	1	2
Issued when the control power is turned ON.	V	(V)
Issued after the power is turned ON.	(V)	V

#### Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> <li>Defect in control print panel</li> <li>Defect in power device</li> </ul>	<ul style="list-style-type: none"> <li>Replace the servo amp.</li> </ul>
2	<ul style="list-style-type: none"> <li>Servo amplifier and motor are not combined properly</li> </ul>	<ul style="list-style-type: none"> <li>Confirm that the proper codes (per the specified Motor Codes) have been used for the servo motor; if not, replace the servo motor.</li> </ul>

Note) V means the cause number with high possibility.  
 (V) means the cause number with middle possibility.

## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code 23H (Current Detection Error 1)

### Alarm code 24H (Current Detection Error 2)

Status during alarm	Cause	
	1	2
Issued when the control power is turned ON.	V	
Issued during operation.	(V)	V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Defect in internal circuit of servo amplifier.	• Replace the servo amplifier.
2	• Malfunction due to noise	• Confirm proper grounding of the amplifier. • Add ferrite core or similar countermeasures against noise.

### Alarm code 41H (Overload 1)

Status during alarm	Cause								
	1	2	3	4	5	6	7	8	9
Issued when power supply control is turned ON.	V								
Issued at input of servo ON.	V	V							V
After command input, issued without rotating the motor.		V			V	V	V		V
After command input, brief motor rotation			V	V	V		(V)	V	

#### Corrective actions

Cause		Investigation and corrective actions
1	• Defect in servo amplifier control panel or power element peripheral	• Replace the servo amplifier.
2	• Defect in encoder circuit of servomotor	• Replace the servo motor.
3	• Effective torque exceeds the rated torque.	• Monitor the load status using motor usage ratio monitor (OPRT), and check if effective torque exceeds the rated value. • Or, calculate the motor effective torque from load conditions and operation conditions. → If the effective torque is excessive, check the operating or loading, or replace the capacity of the large motor.
4	• Defect in motor-amplifier combination	• Check if the motor in use matches with the recommended type, and replace if it is improper.
5	• Holding brake of servo motor does not release.	• Check that the wiring and voltage of the holding brake are acceptable; if not, repair. → If the above are OK, replace the servomotor.
6	• Wiring of U/V/W –phase between servo amplifier and motor do not match.	• Check the wiring conditions and restore if improper.
7	• One or all connections of U/V/W -phase wiring of servo amplifier / motor is disconnected	• Check the wiring conditions and restore if improper.
8	• Machines collided.	• Check the operating conditions and limit switch.
9	• Encoder pulse number setting does not match with the motor.	• Match the encoder pulse number with the motor.



During the alarm caused by conditions in #3 (above), if OFF→ON of power supply control is repeated, there is a risk of burning out the servo motor.

Wait for longer than 30 min. for cooling purposes after power shut OFF, and resume operations.

Note) V means the cause number with high possibility.

(V) means the cause number with middle possibility.

# 8. Maintenance [Trouble Shooting When Alarm Occurs]

## Alarm code 42H (Overload 2)

Status during alarm	Cause								
	1	2	3	4	5	6	7	8	9
Issued when power supply control is turned ON.	V								
Issued at input of servo ON.	V	V							V
After command input, issued without rotating the motor.		V			V	V	V		V
After command input, brief motor rotation			V	V	V		(V)	V	

### Corrective actions

Cause	Investigation and corrective actions
1 •Defect in servo amplifier control panel or power element peripheral	•Replace the servo amplifier.
2 •Defect in encoder circuit of servomotor	•Replace the servo motor.
3 • Rotation is less than 50min <sup>-1</sup> and torque command exceeds approx. 2 times of rated torque.	<ul style="list-style-type: none"> <li>• Check if torque command exceeds approx. 2 times of the rated torque by torque command monitor (TCMON).</li> <li>• Or, calculate the motor effective torque from load conditions and operation conditions. →If the effective torque is excessive, check the operating or loading, or replace the capacity of the large motor.</li> </ul>
4 •Defect in motor-amplifier combination	• Check the motor type setting and the motor in use are matching. If not, correct them.
5 •Holding brake of servo motor does not release.	<ul style="list-style-type: none"> <li>• Check that wirings and voltage for holding brake are correct. If not, repair them.</li> <li>→If they are appropriate, replace the servo motor.</li> </ul>
6 •Wiring of U/V/W –phase between servo amplifier and motor do not match.	• Check the wiring conditions and restore if improper.
7 •One or all connections of U/V/W -phase wiring of servo amplifier / motor is disconnected	• Check the wiring conditions and restore if improper.
8 •Machines collided.	•Check the operating conditions and limit switch.
9 •Encoder pulse number setting does not match with the motor.	•Match the encoder pulse number with the motor.

## Alarm code 43H (Regenerative Error)

Status during alarm	Cause							
	1	2	3	4	5	6	7	8
Issued when power supply control is turned ON.							V	
Issued when power supply of main circuit is turned ON.						V	V	V
Issued during operation.	V	V	V	V	V		(V)	

### Corrective actions

Cause	Investigation and corrective actions
1 • Exceeded permitted value of regenerating power in built-in regenerative resistance specifications. • Excessive load inertia, or tact time is short.	<ul style="list-style-type: none"> <li>• Check the load inertia and operating pattern.</li> <li>• Use an external regeneration resistor.</li> <li>• Set the load inertia within the specified range.</li> <li>• Increase the deceleration time.</li> <li>• Increase the tact time.</li> </ul>
2 • Regenerative resistance wiring conflicts with built-in regenerative resistance specifications.	• Check wiring and replace if incorrect.
3 • Regenerative resistance wiring conflicts with external regeneration resistor specifications.	• Check wiring and replace if incorrect.
4 • Regeneration resistor is disconnected.	<ul style="list-style-type: none"> <li>• For built-in regeneration resistor specifications, replace the servo amplifier.</li> <li>• For external regeneration resistor specifications, replace the regeneration resistor.</li> </ul>
5 • Resistance value of external regeneration resistor is excessive.	• Replace the current resistance value with a value matching the specifications.
6 • Input power supply voltage exceeds the specified range.	• Check the input power supply voltage level.
7 • Defect in control circuit of servo amplifier.	• Replace the servo amplifier.
8 • When external regenerative resistance is selected for system parameter Page OB and external regenerative resistance is not installed.	<ul style="list-style-type: none"> <li>• Install the external regenerative resistance.</li> <li>• Set to "Do not connect regenerative resistance".</li> </ul>



If the setting of system parameter page 0B regeneration resistance is incorrect, regeneration error is not detected properly, and the amplifier and surrounding circuit may be damaged or burnt.

Note) V means the cause number with high possibility.  
(V) means the cause number with middle possibility.

## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code 51H (Amplifier Overheat)

Status during alarm	Cause				
	1	2	3	4	5
Issued when power supply control is turned ON.	(V)		V	(V)	
Issued during operation.	(V)	V	V	V	
Issued after emergency stop.					V

### Corrective actions

Cause		Investigation and corrective actions
1	• Defect in internal circuit of servo amplifier.	• Replace the servo amplifier.
2	• Regenerating power exceeded.	• Check the operating conditions. • Use external regeneration resistor.
3	• Regenerating power is within the specified range but ambient temperature of servo amplifier is out of specified range.	• Confirm that the cooling method maintains the temperature of control panel between 0 ~ 55°C.
4	• Regenerating power is within the specified range but built-in cooling fan of servo amplifier is stopped.	• For an amplifier equipped with a fan motor, check that the fan motor is running; if not, replace the servo amplifier.
5	• Regeneration energy during emergency stop exceeded.	• Change the servo amp. • Check the loading condition.



Abnormalities are detected in the internal temperature of the amplifier regardless of its ambient temperature. When an amplifier ambient temperature warning is issued, please be sure to check the cooling method of the control panel.

### Alarm code 52H (RS Overheat) [only for RS 1 □ 3 0]

Status during alarm	Cause		
	1	2	3
Issued when power supply is turned ON.	V		
Issued when main circuit power supply is turned ON.		V	
Issued during operation.			V

### Corrective actions

Cause		Investigation and corrective actions
1	Defect in internal circuit of servo amplifier.	Replace the servo amplifier
2	• Power turning ON is repeated too frequently.	• Turn ON/OFF the power less frequently.
3	• Ambient temperature is high.	• For a servo amplifier equipped with a cooling fan motor, check that the fan motor is running properly. If not, replace the servo amplifier. • Check if the temperature inside the control panel (servo amplifier ambient temperature) exceeds 55°C. If it does, review the servo amplifier installing method and cooling method of control panel to make it below 55°C.

Note) V means the cause number with high possibility.  
(V) means the cause number with middle possibility.

## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code 53H (Dynamic Brake Resistor Overheat)

Status during alarm	Cause	
	1	2
Issued when power supply is turned ON.	V	
Issued during operation.	(V)	V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Defect in internal circuit of servo amplifier.	• Replace the servo amplifier.
2	• DB operation frequency exceeded.	• Use the dynamic brake so as not to exceed the permissive frequency.

### Alarm code 54H (Internal Overheat)

Status during alarm	Cause		
	1	2	3
Issued when power supply control is turned ON.	(V)		V
Issued during operation.	(V)	V	V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Defect in internal circuit of servo amplifier.	• Replace the servo amplifier.
2	• Regenerating power excessive.	• Check the built-in regenerative resistance absorption power. • Check the operating conditions, so that regenerating power is within permitted absorption power. • Use an external regeneration resistor.
3	• Improper wiring of built-in regeneration resistor.	• Confirm improper condition and repair if necessary.



When using a regeneration resistance built in the servo amplifier, make sure to set “built-in regeneration resistance” at system parameter Page 0 B [Regeneration resistance type]. This setting makes the judgment between enabled/disabled of the overheating protection detection treatment of the built-in regeneration resistance. When “No connected regenerative resistance or external regenerative resistance” is selected, overheating of built-in regenerative resistance is not detected. Therefore, there is a danger that built-in regenerative resistance will burn out or be damaged.

Note) V means the cause number with high possibility.  
(V) means the cause number with middle possibility.

## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code 55H (External Error)

- When external regenerative resistor and output terminal of upper device are not connected

Status during alarm	Cause	
	1	2
Issued when power supply control is turned ON.	V	(V)

#### Corrective actions

Cause		Investigation and corrective actions
1	• Validity condition for external trip function is set to 'Valid'.	When not used, set 00 : _Always_Disable at Group9 40.
2	• Defect in control panel of servo amplifier.	• Replace the servo amplifier.

- When external regenerative resistor is connected

Status during alarm	Cause		
	1	2	3
Issued when power supply control is turned ON.	V		(V)
Issued after operation.		V	(V)

#### Corrective actions

Cause		Investigation and corrective actions
1	• Improper wiring of external regenerative resistance.	• Check wiring and replace if necessary.
2	• External regeneration resistor is operating.	• Check the operating conditions. • Increase the capacity of the external regeneration resistor.
3	• Defect in control panel of servo amplifier.	• Replace the servo amplifier.

- When output terminal of upper level device is connected:  
Eliminate the alarm trigger of the upper level device.

Note) V means the cause number with high possibility.  
(V) means the cause number with middle possibility.



## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code 61H (Overvoltage)

Status during alarm	Cause			
	1	2	3	4
Issued when power supply control is turned ON.	V			
Issued when power supply of main circuit is turned ON.	V	V		
Issued at the time of motor start/stop.		(V)	V	V

### Corrective actions

Cause	Investigation and corrective actions
1 • Defect in control panel of servo amplifier.	• Replace the servo amplifier.
2 • The power supply voltage of main circuit exceeds the rated value.	• Reduce the power supply voltage to within the specified range.
3 • Excessive load inertia.	• Reduce the load inertia to within the specified range.
4 • Incorrect wiring for regeneration resistance • Built-in regeneration circuit is not functioning.	• Wire the regeneration resistance correctly. • While using the external regenerative resistance, check the wiring and resistance value. • Replace the servo amplifier if any abnormality occurs.

### Alarm code 62H (Main Circuit Undervoltage)

Status during alarm	Cause				
	1	2	3	4	5
Issued when power supply control is turned ON.				V	(V)
Issued after power supply of main circuit is turned ON.	V	V			
Issued during operation, alarm resetting is possible.		(V)	V		
Issued during operation, alarm resetting is not possible.		V			

### Corrective actions

Cause	Investigation and corrective actions
1 • Power supply voltage is below the specified range.	• Check the power supply and set it within the specified range.
2 • Rectifier of main circuit is broken.	• Replace the servo amplifier.
3 • Input voltage is reduced and/or blinking.	• Check the power supply and confirm that there is no blinking or low voltage.
4 • Low voltage outside of the specified range is supplied to the main circuit (R/S/T).	• Check the main circuit voltage. Confirm that there is no external power supply to R/S/T when the main circuit is OFF.
5 • Defect in internal circuit of the servo amplifier.	• Replace the servo amplifier.

Note) V means the cause number with high possibility.  
(V) means the cause number with middle possibility.

## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code 63H (Main Power Supply Fail Phase)

Status during alarm	Cause		
	1	2	3
Issued when power supply control is turned ON.		V	
Issued when power supply of main circuit is turned ON.	V		V
Issued during motor operations.	(V)		
Alarm issued during single-phase power input selection.			V

#### Corrective actions

Cause		Investigation and corrective actions
1	• One out of 3 phases (R/S/T) is not inserted.	• Check the wiring and repair if necessary.
2	• Defect in internal circuit of Servo amplifier.	• Replace the servo amplifier.
3	• Servo amplifier is not specified for single phase.	• Check the model number and delivery specifications of the servo amplifier and replace it with a servo amplifier for single-phase power supply. • Edit the parameters and use a single-phase specification amplifier.

### Alarm code 71H (Control Power Supply Undervoltage)

Status during alarm	Cause		
	1	2	3
Issued at the time of power on.	(V)	V	
Issued during operation.	(V)		V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Defect in internal circuit of the servo amplifier.	• Replace the servo amplifier.
2	• Power supply voltage is within the specified range.	• Confirm that the power supply is set within the specified range.
3	• Input voltage is fluctuating or stopped.	• Confirm that the power supply is not going to neither stop nor reduce the power.

### Alarm code 72H (Control Power Error)

Status during alarm	Cause	
	1	2
Issued when power supply control is turned ON.	(V)	V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Defect in internal circuit of the servo amplifier.	• Replace the servo amplifier.
2	• Defect in external circuit	• Restart the power supply after removing the connector; if alarm is not issued, check the external circuit. • Restart the power supply after replacing the motor; if alarm is not issued, there is defect in the encoder's internal circuit.

Note) V means the cause number with high possibility.

(V) means the cause number with middle possibility.

## 8. Maintenance [Trouble Shooting When Alarm Occurs]

**Alarm code 81H (Encoder Pulse Error 1 /A-phase, B-phase, Z-phase)**

**Alarm code 82H (Absolute Encoder Signal Disconnect)**

**Alarm code 83H (External encoder A phase/ B phase signal abnormality)**

**Alarm code 84H (Communication Error Between Encoder and Amplifier)**

**Alarm code 87H (CS Signal Disconnection)**

Status during alarm	Cause					
	1	2	3	4	5	6
Issued when power supply control is turned ON.	V	V	V	V	V	V
Issued after servo is turned ON.				V	V	
Issued during operation.	(V)			V	V	

### Corrective actions

Cause		Investigation and corrective actions
1	For encoder wiring: <ul style="list-style-type: none"> <li>•Improper wiring</li> <li>•Connector is removed</li> <li>•Loose connection</li> <li>•Encoder cable is too long</li> <li>•Encoder cable is too thin</li> </ul>	<ul style="list-style-type: none"> <li>• Check wiring and repair any abnormality.</li> <li>• Confirm that the encoder power supply voltage of the motor is above 4.75 V; increase it if below 4.75 V.</li> </ul>
2	• Wrong amplifier encoder type is selected.	•Select the correct encoder type.
3	•Motor encoder that does not match with amplifier encoder type is attached.	•Replace with servo motor equipped with proper encoder.
4	•Defect in servo amplifier control circuit	•Replace the servo amplifier.
5	•Defect in servo motor encoder	• Replace the servo motor.
6	•Parameter set to 'Full-close/Servo system'.	• Edit the parameter and set to 'Semi-close/System setup'.

### Alarm code 85H (Encoder Initial Process Error)

Status during alarm	Cause				
	1	2	3	4	5
Issued when power supply control is turned ON.	V	V	V	V	(V)

### Corrective actions

Cause		Investigation and corrective actions
1	For encoder wiring: <ul style="list-style-type: none"> <li>•Improper wiring</li> <li>•Connector is removed</li> <li>•Loose connection</li> <li>•Encoder cable is too long</li> <li>•Encoder cable is too thin</li> </ul>	<ul style="list-style-type: none"> <li>• Check wiring and repair any abnormality.</li> <li>• Confirm that the encoder power supply voltage of the motor is above 4.75 V; increase it if below 4.75 V.</li> </ul>
2	• Wrong parameter of amplifier encoder type or Group C Page 00 is selected.	•Select the correct parameter.
3	• Defect in servo amplifier control circuit	•Replace the servo amplifier.
4	•Defect in servo motor encoder	•Replace the servo motor.
5	•Initial position data could not be set, as the number of rotations of the motor is more than 250 min <sup>-1</sup> during power supply.	•Restart the power supply after motor is stopped. (Only when PA035C and PA035S encoder is used.)

Note) V means the cause number with high possibility.

(V) means the cause number with middle possibility.

## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code 91H (Encoder Command Error)

### Alarm code 92H (Encoder FORM Error)

### Alarm code 93H (Encoder SYNC Error)

### Alarm code 94H (Encoder CRC Error)

When abnormalities are detected in the internal part of the absolute position detector for the start-stop synchronization system.

Status during alarm	Cause		
	1	2	3
Issued when control power supply is turned ON.	(V)	V	V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Defect in encoder	• Replace the servo motor.
2	• Malfunction due to noise	• Confirm proper grounding of the amplifier. • Check the shielding of the encoder cable. • Add ferrite core or similar countermeasures against noise.
3	• Abnormality in encoder wiring.	• Check wiring between the encoder and amplifier.


### Alarm code A1H (Encoder Error 1)

When abnormalities are detected in the internal part of the absolute position detector (RA062M) for the Manchester encoding system.

Status during alarm	Cause
	1
Issued when power supply is turned ON.	V
Issued during operation.	V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Defect in internal circuit of encoder	• Turn ON the power supply again; if not restored, replace the motor.


 “Encoder clearing and alarm resetting methods” vary depending on the encoder in use.  
Refer to page 59 “Materials; Encoder Clear”.

### Alarm code A2H (Absolute Encoder Battery Error)

Status during alarm	Cause	
	1	2
Issued when control power is turned ON.	V	V
Issued during operation.		V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Loose connection of battery cable.	• Confirm the battery connection in the front ON/OFF switch of the amplifier.
2	• Low battery voltage	• Check the battery voltage.

 “Encoder clearing and alarm resetting methods” vary depending on the encoder in use.  
Refer to page 59 “Materials; Encoder Clear”.

Note) V means the cause number with high possibility.  
(V) means the cause number with middle possibility.

## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code A3H (Encoder Overheat)

When abnormalities are detected in the internal part of the absolute position detector for the start-stop synchronization system.

Status during alarm	Cause		
	1	2	3
Issued when control power supply is turned ON.	(V)	V	
Issued while stopping the motor.	(V)	V	
Issued during motor operations.		V	V

### Corrective actions

Cause		Investigation and corrective actions
1	• Defect in internal circuit of encoder	• Turn ON the power supply again; if not restored, replace the motor.
2	• Motor is not generating heat, but encoder ambient temperature is high.	• Confirm that the cooling method keeps the encoder ambient temperature below 80°C.
3	• Motor is overheated.	• Confirm the cooling procedure of the servo motor.



“Encoder clearing and alarm resetting methods” vary depending on the encoder in use.  
Refer to page 59 “Materials; Encoder Clear”.

### Alarm code A5H (Encoder Error 3)

When abnormalities are detected in the internal part of the absolute position detector for the start-stop synchronization system.

Status during alarm	Cause		
	1	2	3
Issued when power supply is turned ON.	(V)	V	V
Issued during motor operations.	(V)	V	

### Corrective actions

Cause		Investigation and corrective actions
1	• Defect in internal circuit of encoder	• Turn ON the power supply again; if not restored, replace the motor.
2	• Malfunction due to noise	• Confirm proper grounding of the amplifier. • Check the shielding of the encoder cable. • Add ferrite core or similar countermeasures against noise.
3	• Number of rotations exceeds the permitted number of rotations.	• Turn ON the power supply again, when motor is stopped.



“Encoder clearing and alarm resetting methods” vary depending on the encoder in use.  
Refer to page 59 “Materials; Encoder Clear”.

Note) V means the cause number with high possibility.  
(V) means the cause number with middle possibility.

## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code A6H (Encoder Error 4)

When abnormalities are detected in the internal part of the absolute position detector for the start-stop synchronization system.

Status when alarm rings.	Cause		
	1	2	3
Issued when power supply is turned ON.	V	V	
Issued during motor operations.		V	V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Defect in internal circuit of encoder	• Turn ON the power supply again; if not restored, replace the motor.
2	• Malfunction due to noise	• Confirm proper grounding of the amplifier. • Check the shielding of the encoder cable. • Add ferrite core or similar countermeasures against noise.
3	• Multi-rotation counter overflows.	• Correct the operation pattern, and avoid the continuous operation in a fixed direction.



“Encoder clearing and alarm resetting methods” vary depending on the encoder in use.  
Refer to page 59 “Materials; Encoder Clear”.

### Alarm code A7H (Encoder Error 5)

### Alarm code A8H (Encoder Error 6)

### Alarm code A9H (Failure of Encoder)

When abnormalities are detected in the internal part of the absolute position detector for the start-stop synchronization system.

Status during alarm	Cause	
	1	2
Issued when power supply is turned ON.	V	V
Issued during motor operations.	(V)	V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Defect in internal circuit of encoder	• Turn ON the power supply again; if not restored, replace the motor.
2	• Malfunction due to noise	• Confirm proper grounding of the amplifier. • Check the shielding of the encoder cable. • Add ferrite core or similar countermeasures against noise.



“Encoder clearing and alarm resetting methods” vary depending on the encoder in use.  
Refer to page 59 “Materials; Encoder Clear”.

Note) V means the cause number with high possibility.  
(V) means the cause number with middle possibility.

## 8. Maintenance [Trouble Shooting When Alarm Occurs]


### Alarm Code B2H (Encoder Error 2)

When abnormality is detected in the internal part of the absolute position detector (RAO62M) of the Manchester system.

Status during alarm	Cause	
	1	2
Issued during operation.	(V)	V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Defect in internal circuit of encoder	• Turn ON the power supply again; if not restored, replace the motor.
2	• Malfunction due to noise	• Confirm proper grounding of the amplifier. • Check the shielding of the encoder cable. • Add ferrite core or similar countermeasures against noise.

 "Encoder clearing and alarm resetting methods" vary depending on the encoder in use.  
Refer to page 59 "Materials; Encoder Clear".

### Alarm code B3H (Absolute Encoder Multi-Turn Counter Error)

### Alarm code B4H (Absolute Encoder Single-Turn Counter Error)


### Alarm code B6H (Encoder Memory Error)

When abnormalities are detected in the internal part of the absolute position detector for the start-stop synchronization system.

Status during alarm	Cause	
	1	2
Issued when control power supply is turned ON.	V	
Issued while operation.	(V)	V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Defect in internal circuit of encoder	• Turn ON the power supply again; if not restored, replace the motor.
2	• Malfunction due to noise	• Confirm proper grounding of the amplifier. • Check the shielding of the encoder cable. • Add ferrite core or similar countermeasures against noise.

 "Encoder clearing and alarm resetting methods" vary depending on the encoder in use.  
Refer to page 59 "Materials; Encoder Clear".

Note) V means the cause number with high possibility.  
(V) means the cause number with middle possibility.

## 8. Maintenance [Trouble Shooting When Alarm Occurs]


### Alarm code B5H (Over-allowable Speed of Absolute Encoder at Turning ON)

When abnormalities are detected in the internal part of the absolute position detector for the start-stop synchronization system.

Status during alarm	Cause		
	1	2	3
Issued when power supply is turned ON.	V		(V)
Issued while stopping the motor.	V	V	
Issued while rotating the motor.	(V)	V	V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Defect in internal circuit of encoder	• Turn ON the power supply again; if not restored, replace the motor.
2	• Malfunction due to noise	• Confirm proper grounding of the amplifier. • Check the shielding of the encoder cable. • Add ferrite core or similar countermeasures against noise.
3	• Number of motor rotations exceeds the permitted speed.	• Check the operation pattern and reduce the maximum number of rotations.

 "Encoder clearing and alarm resetting methods" vary depending on the encoder in use.  
Refer to page 59 "Materials; Encoder Clear".


### Alarm code B7H (Acceleration Error)

When abnormalities are detected in the internal part of the absolute position detector for the start-stop synchronization system.

Status during alarm	Cause		
	1	2	3
Issued while stopping the motor.	V	V	
Issued while rotating the motor.	(V)	V	V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Defect in internal circuit of encoder	• Turn ON the power supply again; if not restored, replace the motor.
2	• Malfunction due to noise	• Confirm proper grounding of the amplifier. • Check the shielding of the encoder cable. • Add ferrite core or similar countermeasures against noise.
3	• The acceleration of motor rotation exceeds the permitted acceleration	• Check the operation pattern, and extend the acceleration and deceleration time.

 "Encoder clearing and alarm resetting methods" vary depending on the encoder in use.  
Refer to page 59 "Materials; Encoder Clear".

Note) V means the cause number with high possibility.  
(V) means the cause number with middle possibility.



## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code C1H (Overspeed)

Status during alarm	Cause			
	1	2	3	4
Issued when control power supply is turned ON.	V	(V)		
Issued if command is entered after Servo ON	(V)	V		
Issued when the motor is started.			V	V
Issued other than operating and starting the motor		V	V	

### Corrective actions

Cause		Investigation and corrective actions
1	• Defect in control panel of servo amplifier.	• Replace the servo amplifier.
2	• Defect in the encoder of servo motor	• Replace the servo motor.
3	• Excessive overshoot while starting.	<ul style="list-style-type: none"> <li>• Monitor speed with the analog monitor.</li> <li>→ Adjust the servo parameters if overshoot is excessive.</li> <li>→ Simplify the acceleration and deceleration command pattern.</li> <li>→ Reduce the load inertia.</li> </ul>
4	• Wiring of U/V/W -phase between servo amplifier and motor do not match.	• Check the wiring and repair any irregularities.

Note) V means the cause number with high possibility.

(V) means the cause number with middle possibility.

## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code C2H (Speed Control Error)

Status during alarm	Cause				
	1	2	3	4	5
Issued when control power supply is turned ON.					V
Issued while due to input of Servo ON	V		V		
Issued if command is entered.	V	V	V		
Issued while starting and stopping the motor.				V	

#### Corrective actions

Cause		Investigation and corrective actions
1	• Wiring of U/V/W -phase between servo amplifier and motor do not match.	• Check the wiring and repair any irregularities.
2	• The wiring of A, B phase of INC-E and ABS-EI encoder connection is incorrect.	• Check the wiring and repair any irregularities.
3	• The motor is vibrating (oscillating).	• Adjust the servo parameters so that servo motor will not vibrate (oscillate).
4	• Excessive overshoot and undershoot.	• Monitor speed with the analog monitor. • Adjust the servo parameters to reduce overshoot and undershoot. • Increase acceleration and deceleration command time. Mask the alarm.
5	• Abnormality in servo amplifier control circuit	• Replace the servo amplifier.



For the speed control error alarm, an alarm may occur while starting and stopping when load inertia is excessive. For this reason, in the gravitational axis applications, "Do not detect" is selected as the standard setting. If its detection is needed, consult our representatives.

### Alarm code C3H (Speed Feedback Error)

Status during alarm	Cause		
	1	2	3
Issued when command is entered.	V	(V)	V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Motor is not rotating.	• Confirm that the power line is properly connected. • Replace the servo motor.
2	• Defect in internal circuit of servo amplifier.	• Replace the servo amplifier.
3	• The motor is vibrating (oscillating).	• Adjust the servo parameter so that servo motor will not vibrate (oscillate).

Note) V means the cause number with high possibility.  
(V) means the cause number with middle possibility.

## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code D1H (Following Error / Excessive Position Deviation)

Status during alarm	Cause											
	1	2	3	4	5	6	7	8	9	10	11	12
Issued when control power supply is turned ON.										V		
Issued when servo ON is stopped.						V					V	
Issued immediately after entering the command.	V	(V)	V	V	V		V	(V)	V		(V)	
Issued during starting or stopping at high speed.	V	V					V	V	V		(V)	V
Issued during the operations by lengthy command.		V					V	(V)			(V)	

### Corrective actions

	Cause	Investigation and corrective actions
1	• Position command frequency is high or acceleration and deceleration time is short.	• Correct the position command of the controller
2	• Excessive initial load or low motor capacity.	• Correct the load condition or increase the motor capacity
3	• Holding brake is not released.	• Check the wiring and repair any abnormalities. If specified voltage is applied, replace the servo motor.
4	• Motor is mechanically locked or machine is colliding.	• Check the machinery system.
5	• One or all phases of U/V/W -phase of the servo amplifier and motor has disconnected.	• Check and repair the wiring connections.
6	• Motor is being rotated by an external force (Gravity, etc.) during stopping (positioning completion).	• Check the load, and/or increase the motor capacity.
7	• Valid current limit command is entered by the controller, and the current limit setting is reduced. • Number of encoder pulses does not match with the motor.	• Increase the current limit value or disable the current limit. • Match the number of motor encoder pulses.
8	• Settings of servo parameters (Position loop gain, etc.) are not appropriate.	• Check the servo parameter settings (Raise the position loop gain, etc.)
9	• Excessive deviation setting value is reduced.	• Set a greater value for excessive deviation.
10	• Defect in control panel of servo amplifier.	• Replace the servo amplifier.
11	• Servo motor encoder is defective.	• Replace the servo motor.
12	• Power supply voltage is low.	• Check the power supply voltage.

### Alarm code D2H (Faulty Position Command Pulse Frequency 1)

Status during alarm	Cause
Issued after entering position command pulse.	V

### Corrective actions

	Cause	Investigation and corrective actions
1	• Command for the digital filter setting of the command pulse input is entered	• Decrease the frequency of the command pulse. • Increase the frequency of the digital filter.

Note) V means the cause number with high possibility.  
(V) means the cause number with middle possibility.

## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code D3H (Faulty Position Command Pulse Frequency 2)

Status during alarm	Cause	
	1	2
Issued after entering position command pulse.	V	V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Frequency of command pulse input is excessive.	• Reduce the frequency of command pulse input.
2	• Setting value of electronic gear is excessive.	• Decrease the electronic gear setting value.

### Alarm code DEH (Wrap Around Error)

Status during alarm	Cause	
	1	2
Occurred when control power supply is turned ON. (Absolute encoder combination)	V	
Occurred while operating.		V

#### Corrective actions

Cause		Investigation and corrective actions
1	Internal coordination exceeded the limit	- Execute Absolute encoder clear - Check and modify the position factor (6093h)
2	Internal coordination exceeded the limit	- Correct the position command of the host - Check and modify the position factor (6093h) - Disable the wrap around (2108h)

### Alarm code DFH (Test Run Close)

Status during alarm	Cause
	1
Occurred after execution of test mode.	V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Normal operation.	• Clear the alarm and restore operation. (After completion of test mode, to confirm any deviation in the controller).

## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code E1H (EEPROM Error)

Status during alarm	Cause	
	1	2
Issued when control power supply is turned ON.	V	(V)
Issued during display key operation or set up software operation.		V

#### Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> <li>Correct value not read by CPU by nonvolatile memory of built-in servo amplifier.</li> </ul>	<ul style="list-style-type: none"> <li>Replace the servo amplifier.</li> </ul>
2	<ul style="list-style-type: none"> <li>Defect in the servo amplifier control panel</li> </ul>	<ul style="list-style-type: none"> <li>Replace the servo amplifier.</li> </ul>

Note) V means the cause number with high possibility.  
(V) means the cause number with middle possibility.

### Alarm code E2H (EEPROM Check Sum Error)

Status during alarm	Cause	
	1	2
Issued when control power supply is turned ON.	(V)	V

#### Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> <li>Correct value not read by CPU by nonvolatile memory of built-in servo amplifier</li> </ul>	<ul style="list-style-type: none"> <li>Replace the servo amplifier.</li> </ul>
2	<ul style="list-style-type: none"> <li>Failed to write into the nonvolatile memory during last power supply cutoff.</li> </ul>	<ul style="list-style-type: none"> <li>Change the optional parameters, turn ON the power supply again, and confirm that alarm has cleared.</li> <li>→ If alarm is not cleared, replace the servo amplifier.</li> </ul>

### Alarm code E3H (Internal RAM Error)

### Alarm code E4H (Process Error between CPU and ASIC)

Status during alarm	Cause
	1
Issued when control power supply is turned ON.	V

#### Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> <li>Defect in the servo amplifier control panel</li> </ul>	<ul style="list-style-type: none"> <li>Replace the servo amplifier.</li> </ul>

## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code E5H (Parameter Error 1)

Status during alarm	Cause	
	1	2
Issued when control power supply is turned ON.	V	V
Issued after changing any of system parameters.	V	

#### Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> <li>Selected value is outside the specified range for a system parameter.</li> </ul>	<ul style="list-style-type: none"> <li>Confirm the model number of the servo amplifier.</li> <li>Confirm selected values of system parameters and modify if necessary.</li> <li>→ Turn ON the power again and confirm that alarm is cleared.</li> </ul>
2	<ul style="list-style-type: none"> <li>Defect in servo amplifier</li> </ul>	<ul style="list-style-type: none"> <li>Replace the servo amplifier.</li> </ul>

Note) V means the cause number with high possibility.

(V) means the cause number with middle possibility.

### Alarm code E6H (Parameter Error 2)

Status during alarm	Cause	
	1	2
Issued when control power supply is turned ON.	V	V
Issued after changing any of system parameters.	V	

#### Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> <li>Selected values of system parameters and actual hardware do not match</li> <li>Improper assembly of system parameter settings.</li> </ul>	<ul style="list-style-type: none"> <li>Confirm the model number of servo amplifier.</li> <li>Confirm selected values of system parameters and correct if necessary.</li> <li>→ Turn ON the power again and confirm that alarm is cleared.</li> </ul>
2	<ul style="list-style-type: none"> <li>Defect in servo amplifier</li> </ul>	<ul style="list-style-type: none"> <li>Replace the servo amplifier.</li> </ul>

### Alarm code EDH (EEPROM Error (Sub CPU))

Status during alarm	Cause	
	1	2
Occurred when control power supply is turned ON. (Absolute encoder combination)	V	
Occurred while operating. After 'save' or 'load' command via CAN communication		V

#### Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> <li>Abnormality in control circuit of servo amplifier.</li> </ul>	<ul style="list-style-type: none"> <li>Replace the servo amplifier.</li> </ul>
2	<ul style="list-style-type: none"> <li>Abnormality in control circuit of servo amplifier.</li> </ul>	<ul style="list-style-type: none"> <li>Replace the servo amplifier.</li> </ul>

## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code EEH (RAM Error)

Status during alarm	Cause
Occurred when write access via SDO.	V

#### Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> <li>The parameter which is necessary to be cycling of Control power supply was written via SDO.</li> </ul>	<ul style="list-style-type: none"> <li>Turn OFF the control power supply once.</li> </ul>

Parameters that cause this alarm are as follows.

- Motor Parameter: Object 22E0h sub-index 01h-36h
- System Parameter: Object 22F0h-22FBh
- Polarity: Object 607Eh
- Position Factor: Object 6093h sub-index 01h, 02h

### Alarm code EFH (DPRAM Initial Error)

Status during alarm	Cause
Occurred when control power supply is turned ON.	V

#### Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> <li>Abnormality in control circuit of servo amplifier.</li> </ul>	<ul style="list-style-type: none"> <li>Replace the servo amplifier.</li> </ul>

## **8. Maintenance [Trouble Shooting When Alarm Occurs]**

### **Alarm code F1H (Task Process Error)**

Status during alarm	Cause
Issued while operating.	V

#### **Corrective actions**

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> <li>Abnormality in control circuit of servo amplifier</li> </ul>	<ul style="list-style-type: none"> <li>Replace the servo amplifier</li> </ul>

### **Alarm code F2H (Initial Process Time-Out)**

Status during alarm	Cause	
	1	2
Issued when control power supply is turned ON.	V	V

#### **Corrective actions**

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> <li>Defect in internal circuit of servo amplifier</li> </ul>	<ul style="list-style-type: none"> <li>Replace the servo amplifier.</li> </ul>
2	<ul style="list-style-type: none"> <li>Malfunction due to noise</li> </ul>	<ul style="list-style-type: none"> <li>Confirm proper grounding of the amplifier.</li> <li>Add ferrite core or similar countermeasures against noise.</li> </ul>



## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code FCH (Task Synchronization Error)

Status during alarm	Cause	
	1	2
Occurred when control power supply is turned ON.	V	
Occurred while operating.		V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Abnormality in control circuit of servo amplifier	• Replace the servo amplifier.
2	• Task synchronization between control CPU and communication (sub) CPU was slipped.	• Confirm proper grounding of the amplifier. • Replace the servo amplifier.

### Alarm code FDH (Communication Initial Error)

Status during alarm	Cause
	1
Issued when control power supply is turned ON.	V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Setting of Node-ID is out of range. • Setting of Bit Rate is not correct.	• Check the setting of CAN Node-ID • Check the setting of CAN Bit Rate

### Alarm code FEH (Communication Error)

#### CANopen Error Code 8180H (Bus Off detected by CAN controller)

Status during alarm	Cause	
	1	2
Occurred when control power supply is turned ON.	V	
Occurred while CAN communication.		V

#### Corrective actions

Cause		Investigation and corrective actions
1	• Abnormality in control circuit of servo amplifier	• Replace the servo amplifier.
2	• Malfunction in CAN Communication due to cabling or noise	• Check the wiring of CAN Communication and repair any abnormalities. • Confirm proper grounding of the amplifier • Attach ferrite core or similar countermeasures against noise

## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code FEH (Communication Error)

#### CANopen Error Code 8181H (Rx Timeout detected)

Status during alarm	Cause	
	1	2
Occurred when control power supply is turned ON.	✓	
Occurred while CAN communication.	✓	✓

#### Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> <li>Timeout setting is too small against the message sending cycle.</li> </ul>	<ul style="list-style-type: none"> <li>Check 'Bus Break Error Detection Time (2121h)'</li> </ul>
2	<ul style="list-style-type: none"> <li>Malfunction in CAN Communication due to cabling or noise</li> </ul>	<ul style="list-style-type: none"> <li>Check the wiring of CAN Communication and repair any abnormalities.</li> <li>Confirm proper grounding of the amplifier</li> <li>Attach ferrite core or similar countermeasures against noise</li> </ul>

### Alarm code FEH (Communication Error)

#### CANopen Error Code 8182H (No Sync Message)

Status during alarm	Cause
	1
Occurred while CAN communication.	✓

#### Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> <li>One SYNC message missed</li> </ul>	<ul style="list-style-type: none"> <li>Correct the setting of communication cycle</li> </ul>

### Alarm code FEH (Communication Error)

#### CANopen Error Code 8183H (Driver can not generate demand position any more)

Status during alarm	Cause
	1
Occurred while CAN communication.	✓

#### Corrective actions

Cause		Investigation and corrective actions
1	<ul style="list-style-type: none"> <li>Driver could not receive two consecutive RPDO commands.</li> </ul>	<ul style="list-style-type: none"> <li>Correct SYNC related system.</li> <li>Correct RPDO related system.</li> </ul>

## 8. Maintenance [Trouble Shooting When Alarm Occurs]

### Alarm code FEH (Communication Error)

#### CANopen Error Code 8184H (Average SYNC message cycle is too small (-1%))

Status during alarm	Cause
	1
Occurred while CAN communication.	V

#### Corrective actions

Cause	Investigation and corrective actions
1 • Average cycle time of SYNC message is too small comparing to communication cycle period (Object 1006h).	<ul style="list-style-type: none"> <li>• Correct SYNC related system.</li> <li>• Correct the setting of communication cycle period.</li> </ul>

### Alarm code FEH (Communication Error)

#### CANopen Error Code 8185H (Average SYNC message cycle is too big (+1%))

Status during alarm	Cause
	1
Occurred while CAN communication.	V

#### Corrective actions

Cause	Investigation and corrective actions
1 • Average cycle time of SYNC message is too big comparing to communication cycle period (Object 1006h).	<ul style="list-style-type: none"> <li>• Correct SYNC related system.</li> <li>• Correct the setting of communication cycle period.</li> </ul>

### Alarm code FFH (Sub CPU Error)

Status during alarm	Cause
	1
Occurred when control power supply is turned ON. Occurred while drive operation.	V

#### Corrective actions

Cause	Investigation and corrective actions
1 • Abnormality in control circuit of servo amplifier.	• Replace the servo amplifier.





Note) V means the cause number with high possibility.  
(V) means the cause number with middle possibility.

# 8. Maintenance

## [Inspection/Parts overhaul]

### ■ Corrective Actions for Problems During Operation

- For maintenance purposes, a daily inspection is typically sufficient.  
Upon inspection, refer to the following description.

Inspection location	Testing conditions			Inspection Items	Inspection Methods	Solution if abnormal
	Time	During operation	While stopping			
Servo motor	Daily	V		Vibration	Check for excessive vibration.	Contact dealer/sales office.
	Daily	V		Sound	Check if there is no abnormal sound as compared to normal sound.	
	Periodic		V	Cleanliness	Check for dirt and dust.	Clean with cloth or air. →  1
	Yearly		V	Measure value of insulation resistance	Contact the dealer or sales office.	
	5000 hours →  2		V	Replacement of oil seal		
Servo amplifier	Periodic		V	Cleaning	Check for dust accumulated in the accessories.	Clean with air. →  1
	Yearly		V	Loose screws	Check for loose connections	Fasten the screws properly.
absolute encoder back up battery	Regularly →  3		V	Battery voltage	Confirm that battery voltage is more than DC3.6V.	Replace the battery.
Temperature	On demand	V		Measure temperature	Ambient temperature Motor frame temperature	Set the ambient temperature within the limit. Check the load condition pattern.



1. While cleaning with air, confirm that there is no oil content and/or moisture in the air.
2. This inspection and replacement period is when water- or oil-proof functions are required.
3. The life expectancy of the battery is approximately 2 years, when its power is OFF throughout the year. For replacement, a lithium battery (ER3V: 3.6V, 1000mAh) manufactured by Toshiba Corp. is recommended.

### ■ Parts Overhaul

Parts may deteriorate over time. Perform periodic inspection for preventive maintenance.

No.	Part name	Number of average replacement years	Corrective measures / usage conditions
1	Condenser for smoothing main circuit	5 Years	Replacement with new part is necessary. Load ratio : Less than 50% of rated output current of amplifier Usage condition: Average temp. 40°C year-round
2	Cooling Fan motor	5 Years	Replacement with new part is necessary. Usage condition: Average temp. 40°C year-round
3	Lithium battery for absolute encoder [ER3V]	3 Years	Replacement with new part is necessary.
4	Electrolysis condenser (other than condenser for smoothing main circuit)	5 Years	Replacement with new part is necessary. Usage condition: Average temp. 40°C year-round Annual usage period is 4800 hours
5	Fuse	10 Years	Replacement with new part is necessary.

#### 1. Condenser for smoothing the main circuit

- If the servo amplifier is in use for more than 3 years, contact the dealer or sales office.  
The capacity of the condenser for smoothing the main circuit is reduces due to the frequency of motor output current and power ON/ OFF during usage, and it may cause damage.

## 8. Maintenance

## [Inspection/Parts overhaul]

- When the condenser is used with an average 40°C through out the year, and exceeds more than 50% of the rated output current of servo amplifier, it is necessary to replace the condenser with a new part every 5 years.
- When used in an application where the power turn ON/OFF is repeated more than 30 times a day, consult our representatives.

### 2. Cooling Fan motor


- The R-Series Amplifier is set corresponding to the degree of pollution specified in EN50178 or IEC 664-1. As it is not dust proof or oil proof, use it in an environment above Pollution Degree 2 (i.e., Pollution Degree 1,2).
- R-Series servo amplifiers models RS1□03, RS1□05 RS1□02 (AC400V) RS1□05 (AC400V) and RS1□10 (AC400V) have a built-in cooling fan; therefore be sure to maintain a space of 50mm on the upper and lower side of the amplifier for airflow. Installation in a narrow space may cause damage due to a reduction in the static pressure of the cooling fan and/or degradation of electronic parts. Replacement is necessary if abnormal noise occurs, or oil or dust is observed on the parts. Also, at an average temperature of 40°C year-round, the life expectancy is 5 years.

### 3. Lithium battery

- The standard replacement period recommended by our company is the life expectancy of lithium battery based on normal usage conditions. However, if there is high frequency of turning the power ON/OFF, or the motor is not used for a long period, then the life of lithium battery is reduced. If the battery power is less than 3.6 V during inspection, replace it with new one.

#### ● How to replace absolute encoder back-up battery

- ① Turn ON the servo amplifier control power supply.
- ② Prepare the replacement lithium battery. [SANYO model number : AL-00494635-01]
- ③ Open the servo amplifier front cover.
- ④ Remove the battery connector.
- ⑤ Take out the used lithium battery and put in the new replacement one (prepared at ②).
- ⑥ Attach the connector in the right direction.
- ⑦ Close the servo amplifier front cover.



If the battery is replaced while the control power is OFF, multiple rotation counter (position data) of the absolute encoder may be instable. When the amplifier control power is turned ON in this status, an alarm (battery error) may be issued. For this, execute encoder clear and alarm reset to release the alarm status. Also, absolute encoder position data may be instable. Check and adjust the relations between position data and machine coordinate system.



At SANYO DENKI, the overhauled servo amplifier is shipped with the same parameters as the ones before overhauling. Be sure to confirm the parameters before use.

# [Specifications]

◆	Servo amplifier .....	9-1
◆	Pulse output .....	9-5
◆	Serial output .....	9-6
◆	Servo motor .....	9-14
◆	Rotation Direction Specifications .....	9-14
◆	Mechanical specifications .....	9-15
◆	Holding brake specifications .....	9-18

# 9. Specifications

## [Servo amplifier]

### ■ General specifications

#### [AC200V input type]

Model number		RS1□01□	RS1□03□	RS1□05□	
Basic specifications	Control function		CANopen interface		
	Control system		IGBT PWM control Sinusoidal drive		
	* <sup>1</sup> Input power	Main circuit	Three-phase AC200~230V+10, -15%, 50/60Hz±3Hz Single phase AC200~230V+10, -15%, 50/60Hz±3Hz* <sup>2</sup> Single phase AC100~115V+10, -15%, 50/60Hz±3Hz* <sup>3</sup>		
		Controlling circuit	Single phase AC200~230V+10, -15%, 50/60Hz±3Hz Single phase AC100~115V+10, -15%, 50/60Hz ±3Hz* <sup>3</sup> DC24V +15%、-15%		
	Environment	Ambient temperature * <sup>4</sup>		0~55°C	
		Storage temperature		-20~+65°C	
		Operating / storage humidity		Below 90%RH (no condensation)	
		Elevation		Below 2000 m from the sea level	
		Vibration		0.5G Frequency range 10~55HZ Test for 2H in each direction X.Y.Z	
	Shock		2G		
Structure		Built-in tray type power supply			
Mass	Kg	1.0	1.1	2.3	
Performance	In case of speed control specification	Speed control range * <sup>5</sup>	1:5000		
		Frequency characteristics * <sup>7</sup>	600Hz(JL=JM)		
Built-in functions	Protection functions		Over current, Current detection error, Overload, Regeneration error, Amplifier overheating, External overheating, Over voltage, Main circuit low voltage, Main circuit open-phase, Control power supply error, Encoder error, Over speed, Speed control error, Speed feedback error, Excessive position error, Position command pulse error, CPU error, Built-in memory error, Battery error, Parameter error		
	LED display		Status display, Monitor display, Alarm display, Parameter settings, Adjustment mode		
	Dynamic brake		Built-in		
	Regeneration process		Built-in		
	Applied load inertia		Within the applied load inertia of combined servo motor		
	Monitor output	Speed monitor (VMON)	2.0 V ±10% (at 1000min <sup>-1</sup> )		
		Torque monitor (TMON)	2.0 V ±10% (at 100%)		
	Sequence	Sequence input signal	Servo on, Alarm reset, Torque limit, Encoder clear, Forward rotation inhibition, Reverse rotation inhibition, Command inhibition, External trip, Forced discharge, Emergency stop, Change of control mode, Proportional control, Gain switch, Internal speed setting		
Sequence output signal		Servo ready, Power ON, Servo ON, Holding brake timing, Within torque limit, Within speed limit, Low speed, velocity attainment, Matching speed, Zero speed, Command acceptable, Status of gain switch, Speed loop proportional control status, Control mode switchover status, Forward OT, Reverse OT, Warning, Alarm code (3Bit)			
Position output signal (Pulse division)		N/8192 (N=1~8191), 1/N (N=1~64) or 2/N (N=3~64)			

**\*1** Source Voltage should be within the specified range.

AC200V Power input type Specified power supply range AC170V~AC253V

AC100V Power input type Specified power supply range AC85V~AC127V

Install a step-down transformer if power supply exceeds the specified power supply.

**\*2** AC200V single-phase input type corresponds only to RS1□01/RS1□03/RS1□05.

**\*3** AC100V single-phase input type corresponds only to RS1□01/RS1□03.

**\*4** When stored in the box, be sure that internal temperature does not exceed this range.

**\*5** Minimum rotational speed is determined as equivalent to the amplifier not stopping

for a load with maximum continuous torque.

# 9. Specifications

[Servo amplifier]

[AC400V input type]

Model number		RS1□02□	RS1□05□	RS1□10□	
Basic specifications	Control function		Speed control, torque control, or position control (Parameter change), CANopen I/F		
	Control system		IGBT PWM control Sinusoidal drive		
	*1 Input power	Main circuit	Three-phase AC380~480V+10, -15%, 50/60Hz±3Hz		
		Controlling circuit	DC24V+10, -10%		
	Environment	Ambient temperature *4	0~55°C		
		Storage temperature	-20~+65°C		
		Operating / storage humidity	Below 90%RH (no condensation)		
		Elevation	Below 2000 m from the sea level		
		Vibration	0.5G Frequency range 10~55HZ Test for 2H in each direction X.Y.Z		
	Shock		2G		
Structure		Built-in tray type power supply			
Mass	Kg	3.5	4.2	8.5	
Performance	In case of speed control specification	Speed control range *5	1:5000		
		Frequency characteristics *7	600Hz(JL=JM)		
Built-in functions	Protection functions		Over current, Current detection error, Overload, Regeneration error, Amplifier overheating, External overheating, Over voltage, Main circuit low voltage, Main circuit open-phase, Control power supply error, Encoder error, Over speed, Speed control error, Speed feedback error, Excessive position error, Position command pulse error, CPU error, Built-in memory error, Battery error, Parameter error		
	LED display		Status display, Monitor display, Alarm display, Parameter settings, Adjustment mode		
	Dynamic brake		Built-in		
	Regeneration process		Built-in		
	Applied load inertia		Within the applied load inertia of combined servo motor		
Monitor output	Speed monitor (VMON)	2.0V ±10% (at 1000min <sup>-1</sup> )			
	Torque monitor (TMON)	2.0V ±10% (at 100%)			
Input / Output signal	For speed/torque control specification	Speed command	Command voltage	DC±2.0V (at 1000min <sup>-1</sup> command, Forward motor rotation with positive command, maximum input voltage ±10V)	
			Input impedance	Approx. 10k Ω	
		Torque command	Command voltage	DC±2.0V (at 100% torque, Forward motor rotation with positive command)	
			Input impedance	Approx. 10k Ω	
	Torque limit input		DC±2.0V ±15% (at rated armature current)		
	Sequence input signal		Servo on, Alarm reset, Torque limit, Encoder clear, Forward rotation inhibition, Reverse rotation inhibition, Command inhibition, External trip, Forced discharge, Emergency stop, Change of control mode, Proportional control, Gain switch, Internal speed setting		
	Sequence output signal		Servo ready, Power ON, Servo ON, Holding brake timing, Within torque limit, Within speed limit, Low speed, velocity attainment, Matching speed, Zero speed, Command acceptable, Status of gain switch, Speed loop proportional control status, Control mode switchover status, Forward OT, Reverse OT, Warning, Alarm code (3Bit)		
	Position output signal (Pulse division)		N/8192 (N=1~8191), 1/N (N=1~64) or 2/N (N=3~64)		
	For position control specification	Position command	Maximum input pulse frequency	5M pulse/second (Reverse rotation Forward rotation pulse, symbol + Pulse), 1.25M pulse/second (90° phase difference Two phase pulse)	
			Input pulse type	Forward rotation+Reverse rotation command pulse or symbol+Pulse string command or 90° phase difference Two phase sequence command	
Electronic gear		N/D (N=1~32767, D=1~32767) however, 1/32767 ≤ N/D ≤ 32767			
Torque limit input		DC±2.0V ±15% (at Rated armature current)			
Sequence input signal		Servo ON, Warning reset, Torque limit, Clear encoder, Forward rotation inhibition, Reverse rotation inhibition, Command inhibition, External trip, Forced discharge, Emergency stop, Deviation Clear, Change of control mode, Proportional control, Gain switch, Change of electronic gear, Position loop proportional control			
Sequence output signal		Servo ready, Power ON, Servo ON, Holding brake timing, Within torque limit, Within speed limit, Low speed, velocity attainment, Matching speed, Zero speed, Position fixed, Near range, Command acceptable, Status of gain switch, Speed loop proportional control status, Changed status of electronic gear, Changed control mode status, Forward OT, Reverse OT, Warning, Alarm code (3 bit)			
Position output signal (Pulse division)		N/8192 (N=1~8191), 1/N (N=1~64) or 2/N (N=3~64)			



# 9. Specifications

## [Servo amplifier]

### ● Incoming current

#### 【AC200V input Type】

Input voltage	Amplifier model name	Control circuit (Maximum value between 1ms after input)*3	Main circuit (Maximum value between 1.2 seconds after input)
AC200V	RS1□01□	40A(O-P)	24A(O-P)*1
	RS1□03□		
	RS1□05□		
AC100V	RS1□01□	20A(O-P)	12A(O-P)*2
	RS1□03□		

\* 1 Incoming current value is the maximum value when AC230V is supplied.

\* 2 Incoming current value is the maximum value when AC115V is supplied.

\* 3 Use thermistor for incoming current prevention circuit of power supply control

For control power AC200V or AC100V input type.

When power is turned ON again after disconnection, power supply on/disconnection is repeated for short time, ambient temperature and temperature of thermistor is high, the incoming current exceeding the above mentioned table may pass.

#### 【AC400V input Type】

Input voltage	Amplifier model name	Main circuit (Maximum value between 1.2 seconds after input)
AC400V	RS1□02□	23A(O-P)*1
	RS1□05□	
	RS1□10□	

\* 1 Incoming current value is the maximum value when AC480V is supplied.

### ● Current leakage

Since “R series” Servo amplifier drives the motor by PWM control of IPM, electric current leakage of high frequency flows through the floating capacity of motor winding, power cable or amplifier. Malfunction in short circuit breaker and protective relay installed in power supply electric circuit may occur. Use the inverter as electricity leakage breaker, which provides countermeasures for wrong operations.

Main circuit	Model number	Electric current leakage per motor
AC200V	RS1□01□	0.5 mA
	RS1□03□	0.5 mA
	RS1□05□	1.5 mA
AC400V	RS1□02□	1.0 mA
	RS1□05□	1.0 mA
	RS1□10□	5.0 mA

- While using 2 or more motors, electric current leakage each motor is added.
- Tough-rubber sheath cable of 2mm is used as power line, in case of short system and long system of cable length, value of above table should be selected as far as possible.
- The machine is grounded (type D(3<sup>rd</sup> type)) so that the dangerous voltage on the main part of a machine, operation panel, etc. does not arise at the time of an emergency leakage.
- The value of current leaked is the measured value in ordinary leak checkers (Filter 700Hz).

# 9. Specifications

# [Servo amplifier]

● Calorific value

**[AC200V.input Type]**

Input voltage	Amplifier capacity	Motor model number	Total calorific value of Servo amplifier(W)	Input voltage	Amplifier capacity	Motor model number	Total calorific value of Servo amplifier(W)		
AC200V	RS1□01A	Q1AA04003D	11	AC100V	RS1□01A	Q1EA04003D	16		
		Q1AA04005D	15			Q1EA04005D	22		
		Q1AA04010D	18			Q1EA04010D	27		
		Q1AA06020D	24			Q2EA04006D	21		
		Q2AA04006D	12			Q2EA04010D	26		
		Q2AA04010D	19			Q2EA05005D	22		
		Q2AA05005D	16			Q2EA05010D	31		
								R2EA04003F	16
								R2EA04005F	19
								R2EA04008F	21
								R2EA06010F	25
								R2EA06010F	25
		Q2AA05010D	19			RS1□03A	Q1EA06020D	51	
		Q2AA05020D	26				Q2EA05020D	43	
		Q2AA07020D	32				Q2EA07020D	49	
		Q2AA07030D	32				R2EA06020F	41	
		R2AA04003F	11						
		R2AA04005F	13						
	R2AA04010F	15							
	R2AA06010F	16							
	R2AA06020F	24							
	R2AA08020F	25							
	Q1AA06040D	44							
	Q1AA07075D	66							
	Q2AA07040D	45							
	Q2AA07050D	62							
	Q2AA08050D	55							
	Q2AA13050H	65							
	R2AA06040F	43							
	R2AA08040F	40							
	R2AA08075F	67							
	Q1AA10100D	47							
	Q1AA10150D	61							
Q1AA12100D	47								
Q2AA08075D	43								
Q2AA08100D	45								
Q2AA10100H	50								
Q2AA10150H	62								
Q2AA13100H	58								
Q2AA13150H	63								
RS1□03A	RS1□03A	Q1AA07075D	66						
		Q2AA07040D	45						
		Q2AA07050D	62						
		Q2AA08050D	55						
		Q2AA13050H	65						
		R2AA06040F	43						
		R2AA08040F	40						
		R2AA08075F	67						
		Q1AA10100D	47						
Q1AA10150D	61								
RS1□05A	RS1□05A	Q1AA12100D	47						
		Q2AA08075D	43						
		Q2AA08100D	45						
		Q2AA10100H	50						
		Q2AA10150H	62						
		Q2AA13100H	58						
		Q2AA13150H	63						


**[AC400V.input Type]**

Input voltage	Amplifier capacity	Motor model number	Total calorific value of Servo amplifier(W)
AC400V	RS1□02A	Q2CA08050H	59
		Q2CA10100H	89
		Q2CA13150H	71
	RS1□05A	Q2CA13200H	92
		Q2CA18350H	117
	RS1□10A	Q2CA18450H	185
		Q2CA22550H	253
		Q2CA22700H	313

- Generation of heat built-in regeneration resistance is not included in the numerical value given in the table, it is necessary to add it if needed.
- If external regeneration resistance is used, change the additional items of calorific value of external regeneration resistance as per the place where it is installed.
- Follow the installation method of the “clause 2. for installation”.

## ■ Pulse output

Outputs 90° phase difference two phase pulse (Phase A, Phase B) and Original pulse (Phase Z) from CN 1-3~8



- ✎ After turning ON the system, the power supply is not fixed for about 1 sec.
- ✎ Absolute encoder Pulse (Increment) output delays for about 250  $\mu$ s.  
Moreover 1 pulse is output for every change (once for 1 rotation) of rotations for Phase Z.  
(Does not decide position relation of Phase Z and Phase A & B. 1 pulse width is output based on leading or trailing edge of Phase A or Phase B)
- ✎ When other than 1/1 are set as division ratio, Phase A and Phase B are divided but Phase Z is output by original pulse width. In this case, does not set position relation of Phase Z and Phase A & Phase B.

■ Serial output (Battery backup method absolute encoder )  
 (Absolute encoder without battery )  
 (Absolute encoder for incremental system)

Encoder signal output (PS) format can be selected from 3 transmission methods.

Select from selection values of [GroupC 07 encoder signal output (PS) format].

The specifications are shown below.

Selection values 00: _Binary	Binary code output
Transmission method	Asynchronous
Baud rate	9600bps
Transfer frame	8 frames (11 bit / frame )
Transfer format	Refer to page 9-7
Transmission error check	( 1 bit ) even number parity
Transfer time	9.2ms (Typ.)
Transfer period	Approx.11ms Refer to page 9-11
Increase method	Increase during forward rotation

Selection value 01: _Decimal	ASC I I in decimal code output
Transmission method	Asynchronous
Baud rate	9600bps
Transfer frame	16 frame (10 bit / frame )
Transfer format	Refer to page 9-8
Transmission error check	( 1 bit ) even number parity
Transfer time	16.7ms (Type.)
Transfer period	Approx.40ms Refer to page 9-11
Increase method	Increase during forward rotation

Selection value 02: _Encoder_Signal	Encoder signal direct output
Transmission method	Asynchronous
Baud rate	2.5Mbps、 4.0Mbps
Transfer frame	3 or 4 frame (18 bit / frame )
Transfer format	Refer to page 9-9
Transmission error check	( 8 bit ) CRC error check
Transfer time	21.6 μ s or 28.8 μ s (Typ.) 2.5Mbps 13.5 μ s or 18.0 μ s (Typ.) 4.0Mbps
Transfer period	125 μ s Refer to page 9-11
Increase method	Increase when forward rotation




Forward rotation means anticlockwise rotation as seen from motor shaft.

Moreover, if absolute value is increased up to maximum, minimum value becomes 0.

## ● Transfer format

Selection value 00: Binary Binary code output

### 1 Structure of frame 1



### Structure of each frame

	Start signal	Position signal					Address signal			Parity signal	Stop signal
• 1 <sup>st</sup> frame	0	D0	D1	D2	D3	D4	0	0	0	0/1	1
		(LSB)									
• 2 <sup>nd</sup> frame	0	D5	D6	D7	D8	D9	1	0	0	0/1	1
• 3 <sup>rd</sup> frame	0	D10	D11	D12	D13	D14	0	1	0	0/1	1
• 4 <sup>th</sup> frame	0	D15	D16	0/D17	0/D18	0/D19	1	1	0	0/1	1
• 5 <sup>th</sup> frame	0	0/D20	0/D21	0/D22	0/D23	0/D24	0	0	1	0/1	1
• 6 <sup>th</sup> frame	0	0/D25	0/D26	D27	0/D28	0/D29	1	0	1	0/1	1
• 7 <sup>th</sup> frame	0	0/D30	0/D31	0/D32	0	0	0	1	1	0/1	1
		(MSB)			(MSB)						
• 8 <sup>th</sup> frame	0	0	0	0	0	0	1	1	1	0/1	1

For PA035C

D0 ~D16 . . . Absolute value of 1 rotation  
D17~D32 . . . Absolute value of many rotations

For RA062C

D0 ~D16 . . . Absolute value of 1 rotation  
D17~D30 . . . Absolute value of many rotations

For PA035S


D0 ~D16 . . . Absolute value of 1 rotation

# 9. Specifications

## [Serial output]

Selection value 01: Decimal ASC I I in decimal code output

### Structure of Frame 1



### Structure of each Frame

Frame number	Transmission character	Data contents
1	“P”(ASCII code 50H)	Indicates that transmission data is position data
2	“+”(ASCII code 2BH)	Symbol of multiple rotations data
3	“0”(ASCII code 30H)	Multiple rotations data (5 digits)
4	Highest rank	
5	0000~8191	
6		
7	Lowest rank	
8	“,”(ASCII code 2CH)	End characters
9	“0”(ASCII code 30H)	Absolute value data in 1 rotation (7digits)
10	Highest rank	
11	000000~131071	
12		
13		
14		
15	Lowest rank	
16	“CR”(ASCII code 0DH)	Carriage return

For PA035C      1 rotation data      : 000000~131071  
 Multiple rotation data      : 00000~65535

For RA062C      1 rotation data      : 000000~131071  
 Multiple rotation data      : 00000~ 16383


For PA035S      1 rotation data      : 000000~131071

# 9. Specifications

[Serial output]


Selection value 02: Encoder\_Signal Encoder signal direct output

Structure of Frame 1



Frame structure

Information field (IF)



Command code CC [4:0]

CC[4:0]	Command contents
00000	Absolute full data request
00011	Encoder status request
01000	Status clear request
01010	Status+data clear request with multiple rotations <span style="float: right;">Note)</span>

Note) PA035S doesn't have this command.


Encoder status ES [3:0]

ES[3:0]	Status contents	
ES0	PA035C	Accessing encoder, accessing memory in the encoder
	RA062C	Memory operation in the encoder
	PA035S	Accessing encoder, accessing memory in the encoder
ES1	PA035C	Battery warning
	RA062C	"0" fixed
	PA035S	"0" fixed
ES2	PA035C	Encoder overheat, abnormal memory, overspeed
	RA062C	Encoder overheat, abnormal memory, overspeed, abnormal encoder
	PA035S	Encoder overheat, abnormal memory, overspeed
ES3	PA035C	Battery alarm, single / multiple rotations counter error / single rotation counter error
	RA062C	Multiple rotations counter error
	PA035S	single rotation counter error

# 9. Specifications

## [Serial output]

Data field (DF0~DF2)



Compatibility table of command and data

Command CC[4:0]	Data			Frame length
	DF0 D0[0:15]	DF1 D1[0:15]	DF2 D2[0:15]	
00000	D0[0:15]=ABS[0:15]	D1[0:15]=ABS[16:31]	D2[0:7]=ABS[32:39] D2[8:15]=CRC[0:7]	4 frames
00011	D0[0:15]=ALM[0:15]	D1[0:7]="00000000"	-	3 frames
01000		D2[8:15]=CRC[0:7]		
01010 Note)				

Note) PA035S doesn't have this command.

CRC [0:7] CRC generator polynomial  $P(x) = X^8 + X^4 + X^3 + X^2 + 1$

Applicable range is other than start bit and stop bit of each frame

ALM [0:15] The contents differ as per the types of Encoder.

Check Encoder specifications for details.




# 9. Specifications


## [Serial output]

### ● Transfer period


Selection value 00: Binary Binary code output



Selection value 01: Decimal ASCII in decimal code output



Selection value 02: Encoder\_Signal Encoder signal direct output



Power supply control is not fixed for 1s after booting.

Communication may not necessarily start from the first frame after 1s.

# 9. Specifications

## [Serial output]

### ■ Serial output [Wire-saving Incremental encoder]

While using incremental encoder, output actual position monitor value, irrespective of setting value of parameter Group C 07 encoder signal output (PS) format.


When using wire-saving incremental encoder	
Selection value : invalid	_____
Transmission method	Asynchronous
Baud rate	9600bps
Number of transferred frames	8 frames (11bit/frame)
Transfer format	Chart below
Transmission error check	(1bit) Even number parity
Transfer time	9.2ms(Type.)
Transfer period	Apprx.11ms Refer to page9-13
Increasing direction	Increasing at normal rotation



Normal rotation means anticlockwise one as seen from motor shaft axis.  
Absolute value will be minimum value (0) if it increases to maximum.

### ● Transfer format


#### Structure of Frame 1



#### Structure of each frame

	Start Signal	Signal position					Address Signal			Parity Signal	Stop Signal
·Frame 1	0	D0	D1	D2	D3	D4	0	0	0	0/1	1
		(LSB)									
·Frame 2	0	D5	D6	D7	D8	D9	1	0	0	0/1	1
·Frame 3	0	D10	D11	D12	D13	D14	0	1	0	0/1	1
·Frame 4	0	D15	D16	D17	D18	D19	1	1	0	0/1	1
·Frame 5	0	D20	D21	D22	D23	D24	0	0	1	0/1	1
·Frame 6	0	D25	D26	D27	D28	D29	1	0	1	0/1	1
·Frame 7	0	D30	D31	0	0	0	0	1	1	0/1	1
		(MSB)									
·Frame 8	0	0	0	0	0	0	1	1	1	0/1	1

## ● Transfer period



# 9. Specifications


[Servo motor]

## ■ Servo motor general specifications

Series Name	Q1	Q2	R2
Time Rating	Continuous		
Insulation Classification	Type F		
Dielectric Strength Voltage	AC1500/3000V 1 minute (AC200V / AC400V Input type)		
Insulation Resistance	DC500V/1000V, more than 10MΩ (AC200V /AC400V Input type)		
Protection Method	Fully closed, Auto cooling		
	IP67 (However, Q1□A04,06 and 07 is IP40)  It conforms to IP67 by using a waterproof connector, conduit, shell, clamp, etc.	IP67 (However, Q2□A04 is IP40)	IP67 (Excluding shaft passages and cable ends)
Sealing	Sealed(except Q1□A04,06,07)	Sealing (Except Q2□A04)	Not sealed (Optional)
Ambient Temperature	0 ~ +40°C		
Storage Temperature	-20 ~ +65°C		
Ambient Humidity	20 ~ 90% (Without condensation)		
Vibration Classification	V15		
Coating Color	Munsell N1.5 equivalent		
Excitation Method	Permanent-magnet type		
Installation Method	Flange mounting		


## ■ Rotation Direction Specifications

- When a command to increase the position command is entered, the servo motor rotates in a counterclockwise direction from the load side




### ● Encoder Signal Phases

<Normal rotation>



<Reverse rotation>



When the Z-Phase is high, both A- and B- Phases cross the low level, once every revolution.

Absolute encoder


Normal (forward) rotation: Position data incremental output

Reverse rotation: Position data decreased output

## ■ Mechanical specifications


### ● Vibration Resistance

Install the servo motor in a horizontal direction (as shown in the following figure), so that when vibration is applied in any 3 directions (up/down, back/forward, left/right) it can withstand the vibration acceleration up to  $24.5\text{m/s}^2$ .



### ● Shock Resistance

Install the shaft of the servo motor in a horizontal direction (as shown in the following figure). It should withstand shock acceleration up to  $98\text{m/s}^2$  (when shocks are applied in an Up/down direction) for 2 rotations. However, since a precision detector is fixed to the counter-load side of the motor, any shock applied to the shaft may cause damage the detector; therefore, do not subject the shaft to shock under any circumstances.



### ● Working accuracy

The following table shows the accuracy of the servo motor output shaft and precision (Total Indicator Reading) of the parts surrounding the shaft.


Items	* 1 T.I.R.	Reference Figure
Vibrations of output shaft terminal $\alpha$	0.02	
Eccentricity of the external diameter of the flange on output shaft M ( $\beta$ )	0.06 (Below $\square 86$ )	
	0.08 (Above $\square 100$ )	
Perpendicularity of the flange face to output shaft M ( $\gamma$ )	0.07 (Below $\square 86$ )	
	0.08 (Above $\square 100$ )	

\*1 T.I.R (Total Indicator Reading)

# 9. Specifications [Mechanical specifications of servo motor]

## ● Vibration Classification

The vibration classification of the servo motor is V15 or less, at the maximum rotation speed for a single servo motor unit, and is measured in the manner pictured below.



## ● Mechanical Strength

The output strength of the servo motor can withstand instantaneous maximum torque.

## ● Oil seal

A Type S oil seal (as described in the following table) is fixed to the output shaft of the servo motor. This oil seal is produced by NOK Corporation; please contact your dealer or sales representative for replacement of the oil seal.

### 【AC200V input type】

Servo Motor Model	Oil Seal type (Type S)	Servo Motor Model	Oil Seal type (Type S)
Q1□A04○○○□	N/A	Q2AA13○○○□	AC1677E1
Q1□A06○○○□		Q2AA18○○○□	AC2368E0
Q1AA07○○○□		Q2AA18550□	AC2651A8
Q1AA10○○○□	AC1306E0	Q2AA18750□	
Q1AA12○○○□	AC1677E1	Q2AA22○○○□	AC2368E0
Q1AA13○○○□	AC1677E1	Q2AA22550□	AC3152E0
Q1AA18450□	AC2368E0	Q2AA22700□	AC3152E0
Q1AA18750□	AC2651A8	Q2AA2211K□	
Q2□A04○○○□	N/A	Q2AA2215K□	
Q2□A05○○○□	AC0382A0	R2□A04○○○□	N/A (Optional)
Q2□A07○○○□	AC0687A0	R2□A06○○○□	
Q2AA08○○○□	AC0875A0	R2AA08○○○□	
Q2AA10○○○□	AC1306E0		

### 【AC400V input type】

Servo Motor Model	Oil Seal type (Type S)	Servo Motor Model	Oil Seal type (Type S)
Q2CA08050□	AC0875A0	Q2CA18350□	AC2368E0
Q2CA10100□	AC1306E0	Q2CA18450□	AC2651A8
Q2CA13150□	AC1677E1	Q2CA22550□	AC3152E0
Q2CA13200□	AC1677E1	Q2CA22700□	AC3152E0

## 9. Specifications [Mechanical specifications of servo motor]

- Degree of decrease rating : R2AA Motor fixed oil seal and brake

About oil seal and brake fixed, considering of a rise in heat, continuous zone should apply the following degree of decrease rating.

	Oil seal		
Brake		non-fixed oil seal	fixed oil seal
with no brake		No decrease rating	decrease rating 2
with brake		decrease rating 1	decrease rating 2

Decrease rating 1	Servo Motor Model R2AA	04010F	06040F
	degree of decrease rating %	90	

Decrease rating 2	Servo Motor Model R2AA	04005F	04010F	06040F	08075F
	degree of decrease rating %	90	85	80	90

# 9. Specifications

## [Holding brake specifications]

### ■ Holding brake specifications

An optional holding brake is available for each motor. Since this brake is used for holding, it cannot be used for braking, except for an emergency. Turn brake excitation ON or OFF by using the holding brake timing signal output. When using this signal, set the command for brake release time to 0min<sup>-1</sup> for the servo amplifier.

To externally control the holding brake, a response time (as shown in the following table) is required. When using a motor with a brake, determine a time sequence that takes this delay time into account.

#### [AC200V input type]

	Model	Static friction torque N.m	Release time msec	Braking delay time msec	
				Varistor	Diode
Q1	Q1AA04003D	0.098	25	15	100
	Q1AA04005D	0.157			
	Q1AA04010D	0.320			
	Q1AA06020D	0.637	30	20	120
	Q1AA06040D	1.274			
	Q1AA07075D	2.38	40	20	200
	Q1AA10100D	3.92	40	30	120
	Q1AA10150D	7.84	100	30	140
	Q1AA10200D	7.84			
	Q1AA10250D	9.80	100	30	140
	Q1AA12100D	3.92	100	30	140
	Q1AA12200D	7.84	100	30	140
	Q1AA12300D	11.8	100	30	140
	Q1AA13400D	19.6	120	50	150
	Q1AA13500D	19.6			
	Q1AA18450M	32.0	150	40	250
Q1AA18750H	54.9	300	140	400	
Q2	Q2AA04006D	0.191	25	15	100
	Q2AA04010D	0.319			
	Q2AA05005D	0.167	15	10	100
	Q2AA05010D	0.353			
	Q2AA05020D	0.353			
	Q2AA07020D	0.69	25	15	100
	Q2AA07030D	0.98			
	Q2AA07040D	1.372	30	20	200
	Q2AA07050D	1.85			
	Q2AA08050D	1.96	30	20	200
	Q2AA08075D	2.94			
	Q2AA08100D	2.94	40	30	120
	Q2AA10100H	3.92			
	Q2AA10150H	7.84	100	30	140
	Q2AA13050H	3.50	40	30	120
	Q2AA13100H	9.0	70	30	130
	Q2AA13150H	9.0	100	30	140
	Q2AA13200H	12.0			
	Q2AA18200H	12.0	100	30	140
	Q2AA18350H	32.0	120	40	150
	Q2AA18450H	32.0	150	40	250
	Q2AA18550R	54.9	300	140	400
	Q2AA18550H				
	Q2AA18750L				
	Q2AA22250H	32.0	300	140	400
	Q2AA22350H	32.0	300	140	400
	Q2AA22450H	32.0	300	140	400
	Q2AA22550B	90.0	300	140	400
	Q2AA22700S	90.0	300	140	400
	Q2AA2211KV				
Q2AA2215KV					



# 9. Specifications

## [Holding brake specifications]

Model		Static friction torque N.m	Release time msec	Braking delay time msec	
				Varistor	Diode
Q1	Q1EA04003D	0.098	25	15	100
	Q1EA04005D	0.157			
	Q1EA04010D	0.32			
	Q1EA06020D	0.637	30	20	120
Q2	Q2EA04006D	0.191	25	15	100
	Q2EA04010D	0.319			
	Q2EA05005D	0.167			
	Q2EA05010D	0.353	15	10	100
	Q2EA05020D	0.353			
	Q2EA07020D	0.69			
R2	R2AA04003F	0.32	25	15	100
	R2AA04005F	0.32			
	R2AA04010F	0.32			
	R2AA06010F	0.36	30	20	120
	R2AA06020F	1.37			
	R2AA08020F	2.55			
	R2AA06040F	1.37	30	20	120
	R2AA08040F	2.55			
	R2AA08075F	2.55			
	R2EA04003F	0.32	25 30	15 20	100 120
	R2EA04005F	0.32			
	R2EA04008F	0.32			
	R2EA06010F	0.36			
	R2EA06020F	1.37			



### [AC400V input type]

Model		Static friction torque N.m	Release time msec	Braking delay time msec	
				Varistor	Diode
Q2	Q2CA08050H	1.96	30	20	200
	Q2CA10100H	3.92	40	30	120
	Q2CA13150H	9.0	100	30	140
	Q2CA13200H	12.0	100	30	140
	Q2CA18350H	32.0	300	140	400
	Q2CA18450H	32.0	300	140	400
	Q2CA22550H	90.0	300	140	400
	Q2CA22700H	90.0	300	140	400

# 9. Specifications

## [Holding brake specifications]

Brake operating time is measured in the following circuit.



The brake release time and braking delay time refer to those mentioned in the above tables. The brake release time is the same for both the varistor and diode.

# Materials

---

## [Selection Details]

◆	Time of Acceleration and Deceleration/Permitted Repetition	1
◆	Permitted Repetition	2
◆	Permitted Repetition/Loading Precaution	3
◆	Dynamic Brake	4
◆	Regeneration Process	7
◆	Calculation Method of Regeneration Power by Operations along Horizontal Axis	8
◆	Calculation Method of Regeneration Power by Operations along Vertical Axis	9
◆	Confirmation Method of Regeneration Power	10
◆	External Regenerative Resistor	11
◆	External Regenerative Resistor Dimension	15

## [International Standards]

◆	International standards Conformity	18
◆	Compliance with EC Directives	20

## [Dimension]

◆	Servo amplifier	24
◆	Servo motor	33

## [Servo Motor Data Sheet]

◆	Characteristics table	39
◆	Velocity – Torque characteristics	44
◆	Over load characteristics	51

## [Option]

◆	Connectors	55
◆	Monitor Box	57
◆	Lithium battery · EMCKit	58

## [Encoder Clear]

◆	Encoder clear/ reset method	59
---	-----------------------------	----

## [Electronic Gear]

◆	Usage	60
---	-------	----


# Materials Selection Details [Time of Acceleration and Deceleration/Permitted Repetition]

## Time of Acceleration and Deceleration


- The motor's acceleration time ( $t_a$ ) and deceleration time ( $t_b$ ) when under a constant load is calculated by following method.


$$\text{Acceleration time : } t_a = (J_M + J_L) \cdot (2\pi / 60) \cdot \{(N_2 - N_1) / (T_P - T_L)\} \text{ [S]}$$

$$\text{Deceleration time : } t_b = (J_M + J_L) \cdot (2\pi / 60) \cdot \{(N_2 - N_1) / (T_P - T_L)\} \text{ [S]}$$

 These expressions are for the rated speed values, but exclude the viscous torque and friction torque of the motor.

- $t_a$ : Acceleration time(S)
- $t_b$ : Deceleration time(S)
- $J_M$ : Motor inertia( $\text{kg} \cdot \text{m}^2$ )
- $J_L$ : Load inertia( $\text{kg} \cdot \text{m}^2$ )
- $N_1, N_2$ : Rotational speed of motor( $\text{min}^{-1}$ )
- $T_P$ : Instantaneous maximum stall torque ( $\text{N} \cdot \text{m}$ )
- $T_L$ : Load torque( $\text{N} \cdot \text{m}$ )



 When determining  $t_a$  and  $t_b$ , it is recommended to do so by calculating the load margin and decreasing the instantaneous maximum instant stall torque value (TP) to 80%.

## Permitted repetitions

- There are separate limitations on repetitive operations for both the servo motor and servo amplifier, and the conditions of both must be fulfilled simultaneously.

### Permitted repetitions for the servo amplifier


When START / STOP sequences are repeated frequently, confirm in advance that they are within the allowed range. Allowed repetitions differ depending on the type, capacity, load inertia, adjustable-speed current value and motor rotation speed of the motor in use. If the load inertia = motor inertia  $\times m$  times, and when the permitted START / STOP repetitions (up until the maximum rotation speed) exceed  $\frac{20}{m+1}$  times/min, contact your dealer or sales office for assistance, as precise calculation of effective torque and regenerating power is critical.

### Permitted repetitions for the motor

Permitted START / STOP repetitions differ according to the motor's usage conditions, such as the load condition and time of operation.

## ■ When continuous-speed status and motor stop status is repeated

- In operating conditions such as those shown below, and the motor should be used at a frequency in which its effective torque is less than the rated torque ( $T_R$ ).



If the operating cycle is considered as 't', the usable range can be determined as follows:

$$t \geq \frac{T_a^2 t_a + T_L^2 t_s + T_b^2 t_b}{T_R^2} \quad [s]$$

$T_a$  : Acceleration torque  
 $T_b$  : Deceleration torque  
 $T_L$  : Load torque  
 $T_{rms}$  : Effective torque  
 $T_R$  : Rated torque


When cycle time (t) is predetermined,  $T_a, T_b, t_a, t_b$  appropriate in the above formula are required.



When actually determining the system drive mode, it is recommended to calculate the load margin and suppress it to  $T_{rms} \leq 0.7T_R$

## ■ When the motor repeats acceleration, deceleration, and stop status

- For the operating status shown below, the value of permitted repetitions n (times/min) is displayed by following equation.




$$n = 2.86 \times 10^2 \times \frac{1}{N(J_M + J_L)} \times \frac{T_P^2 - T_L^2}{T_P^3} \times T_R^2$$

[times/min]  
 $T_R$ : Rated torque

# Materials Selection Details [Permitted Repetition/Loading Precaution]

## ■ When the motor repeats acceleration, constant speed operation, and deceleration status

- For the operating status shown below, the value of permitted repetitions 'n' (times/min) is displayed by following equation.



$$n = 2.86 \times 10^2 \times \frac{1}{N(J_M + J_L)} \times \frac{T_R^2 - T_L^2}{T_P} \quad [\text{times/min}]$$

## ■ Loading Precautions

- Negative load

The servo amplifier cannot perform continuous operations by negative load from the servo motor for more than several seconds.

When using the amplifier with a negative load, contact your dealer or sales representative.

- Downward motor drive (when there is no counter weight.)
- When using like a generator, such as the wind-out spindle of a winder.

- Load Inertia ( $J_L$ )


When the servo amplifier is used with a load inertia exceeding the allowable load inertia calculated in terms of the motor shaft, a main circuit power overvoltage detection or regenerative error function may be issued at the time of deceleration.

The following measures must be taken in this case. For more details, please consult with your dealer or sales representative.

- Reduce the torque limit
- Extend the acceleration and deceleration time (Slow down)
- Reduce the maximum motor speed
- Install an external regenerative resistor

## ■ Slowing down the revolution angle by the dynamic brake

- Slowing down the revolution angle by the dynamic brake is as follows:



N: Motor speed ( $\text{min}^{-1}$ )  
 $I_1$ : Slow-down revolution angle (rad) by amplifier internal process time  $t_D$ .  
 $I_2$ : Slow-down revolution angle (rad) by on dynamic brake operation  
 $t_D$ : Delay time from signal display to operation start (s)  
 (Depending on amplifier capacity; Refer to following)

【AC200V input type】

Servo Amplifier Model Name	Delay Time $t_D$ (S)
RS1□01 □=L/A/N/E	$10 \times 10^{-3}$
RS1□03 □=L/A/N/E	$10 \times 10^{-3}$
RS1□05 □=A/L	$10 \times 10^{-3}$

【AC400V input type】

Servo Amplifier Model Name	Delay Time $t_D$ (S)
RS1□02	$10 \times 10^{-3}$
RS1□05	$10 \times 10^{-3}$
RS1□10	$10 \times 10^{-3}$

[Standard formula] When load torque ( $T_L$ ) is considered as zero.

$$I = I_1 + I_2$$

$$= \frac{2 \pi N \cdot t_D}{60} + (J_M + J_L) \times (\alpha N + \beta N^3)$$

I: Integrated slow-down rotation angle (rad)

$J_m$ : Motor inertia ( $\text{kg} \cdot \text{m}^2$ )

$J_L$ : Load inertia (Motor axis conversion) ( $\text{kg} \cdot \text{m}^2$ )

$\alpha \cdot \beta$  : Refer to the constant table of the dynamic brake

## ■ Instantaneous tolerance of dynamic brake

- If the load inertia ( $J_L$ ) substantially exceeds the applicable load inertia, abnormal heat can be generated due to dynamic brake resistance. Take precautions against situations such as an overheat alarm or the failure of dynamic break resistance, and consult your dealer or sales representative if such a situation occurs.

The energy ( $E_{RD}$ ) consumed by dynamic brake resistance in 1 dynamic brake operation is as follows:

$$E_{RD} = \frac{2.5}{R\phi + 2.5} \times \left\{ \frac{1}{2} (J_M + J_L) \times \left( \frac{2\pi}{60} N \right)^2 - I \times T_L \right\}$$

$R\phi$  : Motor phase winding resistance ( $\Omega$ )


$J_M$  : Motor inertia ( $\text{kg}\cdot\text{m}^2$ )

$J_L$  : Load inertia (Motor shaft conversion) ( $\text{kg}\cdot\text{m}^2$ )

$N$  : Number of motor rotations ( $\text{min}^{-1}$ ) in feed rate  $V$

$I$  : Integrated slow-down rotating angle (rad)

$T_L$  : Load torque (N/m)

-  Dynamic brake resistance may fail if the energy  $E_{RD}$  consumed by dynamic brake resistance during dynamic brake operation exceeds the energy shown in the following table. Consult with the dealer or sales representative if such a situation is anticipated.

【AC200V input type】


Amplifier Model Name	$E_{RD}$ (J)
RS1□01 □=L/A/N/E	360
RS1□03 □=L/A/N/E	360
RS1□5 □=A/L	1800

【AC400V input type】

Amplifier Model Name	$E_{RD}$ (J)
RS1□02	1100
RS1□05	2100
RS1□10	19000

## ■ Allowable frequency of dynamic brake

- The allowable frequency (main circuit power ON/OFF) of the dynamic brake is less than 10 rotations per hour and 50 rotations per day under the conditions of maximum speed. However the load inertia is within the applicable one.

-  In basic terms, operation of the dynamic brake in six-minute intervals between two operations is permissible at maximum speed, but if the brake is to be operated with greater frequency, the motor speed must be reduced.

Use the following ratio to determine allowable frequency:

$$\frac{6 \text{ min}}{(\text{Number of rated rotations} / \text{maximum number of rotations for usage})^2}$$



## ■ Dynamic brake constant table.

### [AC200V input type]

Amplifier capacity	Motor model number	$\alpha$	$\beta$	$J_m(\text{kg}\cdot\text{m}^2)$
RS1A01 RS1L01	Q1AA04003D	204	$92.0 \times 10^{-7}$	$0.01 \times 10^{-4}$
	Q1AA04005D	130	$34.3 \times 10^{-7}$	$0.0134 \times 10^{-4}$
	Q1AA04010D	53	$35.0 \times 10^{-7}$	$0.0233 \times 10^{-4}$
	Q1AA06020D	13	$32 \times 10^{-7}$	$0.141 \times 10^{-4}$
	Q2AA04006D	87.8	$25.6 \times 10^{-7}$	$0.057 \times 10^{-4}$
	Q2AA04010D	55.2	$8.4 \times 10^{-7}$	$0.086 \times 10^{-4}$
	Q2AA05005D	132	$10.7 \times 10^{-7}$	$0.067 \times 10^{-4}$
	Q2AA05010D	45.2	$7.93 \times 10^{-7}$	$0.13 \times 10^{-4}$
	Q2AA05020D	19.0	$46.9 \times 10^{-7}$	$0.25 \times 10^{-4}$
	Q2AA07020D	25.9	$11.7 \times 10^{-7}$	$0.38 \times 10^{-4}$
	Q2AA07030D	11.0	$13.9 \times 10^{-7}$	$0.45 \times 10^{-4}$
	R2AA04003F	227	$4.29 \times 10^{-8}$	$0.0247 \times 10^{-4}$
	R2AA04005F	119	$2.96 \times 10^{-8}$	$0.0376 \times 10^{-4}$
	R2AA04010F	41.2	$1.56 \times 10^{-8}$	$0.0627 \times 10^{-4}$
	R2AA06010F	32.6	$5.04 \times 10^{-8}$	$0.117 \times 10^{-4}$
	R2AA06020F	14.5	$2.46 \times 10^{-8}$	$0.219 \times 10^{-4}$
R2AA08020F	11.3	$1.13 \times 10^{-8}$	$0.52 \times 10^{-4}$	
RS1A03 RA1L03	Q1AA06040D	9.13	$13.1 \times 10^{-7}$	$0.247 \times 10^{-4}$
	Q1AA07050D	5.24	$7.75 \times 10^{-7}$	$0.636 \times 10^{-4}$
	Q2AA07040D	10.2	$7.08 \times 10^{-7}$	$0.75 \times 10^{-4}$
	Q2AA07050D	10.6	$3.84 \times 10^{-7}$	$0.85 \times 10^{-4}$
	Q2AA08050D	7.71	$4.51 \times 10^{-7}$	$1.30 \times 10^{-4}$
	Q2AA13050H	5.34	$6.99 \times 10^{-7}$	$2.80 \times 10^{-4}$
	R2AA06040F	8.82	$1.00 \times 10^{-8}$	$0.412 \times 10^{-4}$
	R2AA08040F	6.91	$4.25 \times 10^{-8}$	$1.04 \times 10^{-4}$
R2AA08075F	5.84	$9.10 \times 10^{-8}$	$1.82 \times 10^{-4}$	
RS1A05 RS1L05	Q1AA10100D	6.50	$6.89 \times 10^{-7}$	$1.29 \times 10^{-4}$
	Q1AA10150D	3.95	$3.60 \times 10^{-7}$	$1.61 \times 10^{-4}$
	Q2AA08075D	9.23	$1.71 \times 10^{-7}$	$2.07 \times 10^{-4}$
	Q2AA08100D	5.30	$1.62 \times 10^{-7}$	$2.7 \times 10^{-4}$
	Q2AA10100H	2.78	$1.50 \times 10^{-7}$	$5.4 \times 10^{-4}$
	Q2AA10150H	2.03	$0.92 \times 10^{-7}$	$8.0 \times 10^{-4}$
	Q2AA13100H	2.81	$3.35 \times 10^{-7}$	$5.40 \times 10^{-4}$
	Q2AA13150H	1.79	$2.33 \times 10^{-7}$	$7.94 \times 10^{-4}$

### [AC100V input type]

Amplifier capacity	Motor model number	$\alpha$	$\beta$	$J_m(\text{kg}\cdot\text{m}^2)$
RS1E01 RS1N01	Q1EA04003D	276	$68.1 \times 10^{-7}$	$0.01 \times 10^{-4}$
	Q1EA04005D	205	$39.7 \times 10^{-7}$	$0.0134 \times 10^{-4}$
	Q1EA04010D	82.3	$26.1 \times 10^{-7}$	$0.0233 \times 10^{-4}$
	Q2EA04006D	129	$7.40 \times 10^{-7}$	$0.057 \times 10^{-4}$
	Q2EA04010D	72.5	$4.91 \times 10^{-7}$	$0.086 \times 10^{-4}$
	Q2EA05005D	212	$3.48 \times 10^{-7}$	$0.067 \times 10^{-4}$
	Q2EA05010D	71.6	$2.55 \times 10^{-7}$	$0.13 \times 10^{-4}$
	R2EA04003F	305	$3.19 \times 10^{-8}$	$0.0247 \times 10^{-4}$
	R2EA04005F	171	$2.06 \times 10^{-8}$	$0.0376 \times 10^{-4}$
	R2EA04008F	69.7	$1.06 \times 10^{-8}$	$0.0627 \times 10^{-4}$
	R2EA06010F	59.1	$2.84 \times 10^{-8}$	$0.117 \times 10^{-4}$
	R2EA06020F	38.8	$1.13 \times 10^{-8}$	$0.52 \times 10^{-4}$
RS1E03 RS1N03	Q1EA06020D	56.3	$9.57 \times 10^{-7}$	$0.141 \times 10^{-4}$
	Q2EA05020D	46.4	$0.99 \times 10^{-7}$	$0.25 \times 10^{-4}$
	Q2EA07020D	57.0	$5.22 \times 10^{-7}$	$0.38 \times 10^{-4}$
	R2EA06020F	38.8	$9.10 \times 10^{-7}$	$0.219 \times 10^{-4}$

### [AC400V input type]

Amplifier capacity	Motor model number	$\alpha$	$\beta$	$J_m(\text{kg}\cdot\text{m}^2)$
RS1C02	Q2CA08050H	1.8	$7.41 \times 10^{-7}$	$1.84 \times 10^{-4}$
	Q2CA10100H	0.68	$5.40 \times 10^{-7}$	$5.40 \times 10^{-4}$
	Q2CA13150H	0.41	$9.03 \times 10^{-7}$	$8.80 \times 10^{-4}$
RS1C05	Q2CA13200H	0.40	$5.03 \times 10^{-7}$	$11.8 \times 10^{-4}$
	Q2CA18350H	0.32	$1.57 \times 10^{-7}$	$37.9 \times 10^{-4}$
RS1E03 RS1N03	Q2CA18450H	0.30	$1.16 \times 10^{-7}$	$46.5 \times 10^{-4}$
	Q2CA22550H	0.24	$0.77 \times 10^{-7}$	$114.0 \times 10^{-4}$
	Q2CA22700H	0.24	$0.19 \times 10^{-7}$	$185.0 \times 10^{-4}$



The values for  $\alpha$  and  $\beta$  are based on an assumed resistance value of the power line of  $0 \Omega$ .  
If the combination with an amplifier is different than those shown above, consult your dealer or sales office.

# Materials Selection Details

# [Regeneration Process]

## ■ Regeneration Process

● The regeneration capacity of the servo amplifier depends on the allowable power of the regenerative resistor. When using the servo amplifier with built-in regeneration resistor, be sure to calculate regeneration resistance **PM** and confirm that **PM<PRI** (the allowable power for the built-in regeneration resistor) is fulfilled.


When regeneration power **PM** exceeds the permitted power (**PRI**) of the built-in regeneration resistor, you can operate by conducting regeneration resistance (PM) calculation, confirming that **PM<PRO** (the maximum allowable power of the exterior regeneration resistor) is fulfilled, and connecting the optional external regeneration resistor

### 【AC200V input type】


	Built-in regeneration resistor is available [PRI]	Regeneration resistor connecting number	External regeneration resistor is available [PRO]	Regeneration resistor connecting number	Contact us in case below
RS1□01	PM= 2W and below	I	PM=220W and below	Refer to "Materials" page 11	PM=220W and up
RS1□03	PM= 5W and below	I	PM=220W and below		PM=220W and up
RS1□05	PM= 20W and below	I	PM=500W and below		PM=500W and up

### 【AC400V input type】

	External regeneration resistor is available [PRO]	Regeneration resistor connecting number	Contact us in case below
RS1□02	PM=220W and below	Refer to "Materials" page 11	PM=220W and up
RS1□05	PM=220W and below		PM=220W and up
RS1□10	PM=550W and below		PM=500W and up

 If using the built-in regeneration resistor, please specify the model number of the servo amplifier with built-in regeneration resistor in reference to "Section 1: Prior to Use – Servo Amplifier Model Number"

If using the exterior regeneration resistor, please specify the model number of the servo amplifier without built-in regeneration resistor.

 When regeneration power **PM** exceeds the maximum permitted power (**PRO**) of the external regeneration resistor, reconsider the acceleration constant, load inertia, etc.

## ● Resistance Value of Servo Amplifier Built-in Regeneration Resistor

AC200V input type	
Model Number of Servo Amplifier with Built-in Regeneration Resistor	Resistance Value of Built-in Regeneration Resistor
RS1□01AL/U	100Ω
RS1□03AL/U	50Ω
RS1□10AL/U	17Ω

AC400V input type	
Model Number of Servo Amplifier	Resistance Value of external regeneration Resistor
RS1□02AL/U	100Ω
RS1□05AL/U	50Ω
RS1□10AL/U	20Ω


# Materials Selection Details      [Calculation Method Of Regeneration Power by Operations along Horizontal Axis]

■ Regeneration Power (PM) by Operations along Horizontal Axis

- Regeneration energy is calculated.

$$EM = EHB = \frac{1}{2} \times N \times 3 \cdot KE \phi \times \frac{Tb}{KT} \times tb - \left( \frac{Tb}{KT} \right)^2 \times 3 \cdot R \phi \times tb$$

- EM : Regeneration energy during operations along horizontal axis .....[J]
- EHB : Regeneration energy during deceleration .....[J]
- KE φ : Induced voltage constant .....[Vrms/min<sup>-1</sup>] (Motor constant)
- KT : Torque constant .....[N·m/Arms] (Motor constant)
- N : Motor rotation speed .....[min<sup>-1</sup>]
- R φ : Armature resistance .....[Ω] ( Motor constant)
- Tb : Deceleration time .....[s]
- Tb : Torque during deceleration .....[N·m] (Tb= Tc - TF)
- Tc : Adjustable speed torque .....[N·m]
- TF : Friction torque .....[N·m]



- Effective regeneration power is calculated.

$$PM = \frac{EM}{t_0}$$

- PM : Effective regeneration power [W]
- EM : Regeneration energy during deceleration [J]
- To : Cycle time [s]

# Materials Selection Details [Calculation Method of Regeneration Power by Operations along Vertical Axis]

■ Regeneration Power (PM) by Operations along Vertical Axis (With a Gravitational Load)

- Regenerative energy is calculated.

$$EM = EVUb + EVD + EVDb$$


$$= \frac{1}{2} N \times 3 \cdot K E \phi \times \frac{TUb}{KT} \times tUb - \left( \frac{TUb}{KT} \right)^2 \times 3 \cdot R \phi \times tUb$$

$$+ N \times 3 \cdot K E \phi \times \frac{TD}{KT} \times tD - \left( \frac{TD}{KT} \right)^2 \times 3 \cdot R \phi \times tD$$

$$+ \frac{1}{2} N \times 3 \cdot K E \phi \times \frac{TDb}{KT} \times tDb - \left( \frac{TDb}{KT} \right)^2 \times 3 \cdot R \phi \times tDb$$

EM	: Regeneration energy during operations along vertical axis	.....[J]
EVUb	: Regeneration energy during increased deceleration	.....[J]
EVD	: Regeneration energy during descending run	.....[J]
EVDb	: Regeneration energy during decreased deceleration	.....[J]
TUb	: Torque during increased deceleration	.....[N·m]
tUb	: Increased deceleration time	.....[s]
TD	: Torque during descending run	.....[N·m] (TD=TM – TF)
tD	: Descending run time	.....[s]
TDb	: Torque during decreased deceleration	.....[N·m] (TDb=TC – TF+TM)
tDb	: Decreased deceleration time	.....[s]
TM	: Gravitational load torque	.....[N·m]

📎 When the calculation result of either of **EVUb**, **EVD**, or **EVDb** is negative, calculate **EM** by considering the value of those variables as 0.



- Effective regeneration power is calculated.


$$PM = \frac{EM}{t_o}$$

PM	: Effective regeneration power [W]
EM	: Regeneration energy during increased deceleration/ descending / decreased deceleration [J]
$t_o$	: Cycle time [s]

## ■ Confirmation method of regeneration power PM in actual operation

- Regeneration power **PM** can be easily confirmed by Q-SETUP setup software.

Setup software ··· Monitor display Page 12 · Reg P · Regeneration circuit operating rate

 The monitor value of the regeneration circuit operating rate shows the operating rate of regeneration circuit. The display range is 0.01%~99.99%.

- The actual regeneration power **PM** can be calculated from this monitor value by following equation.

Input Supply Voltage : In case of AC200V specification

$$\text{Regeneration power PM (W)} = \frac{400 \text{ (V)} \times 400 \text{ (V)}}{\text{Regeneration resistance } (\Omega)} \times \frac{\text{regeneration circuit operating rate (\%)}}{100 \text{ (\%)}}$$

Input Supply Voltage : In case of AC400V specification

$$\text{Regeneration power PM (W)} = \frac{780 \text{ (V)} \times 780 \text{ (V)}}{\text{Regeneration resistance } (\Omega)} \times \frac{\text{regeneration circuit operating rate (\%)}}{100 \text{ (\%)}}$$

Input Supply Voltage : In case of AC100V specification

$$\text{Regeneration power PM (W)} = \frac{200 \text{ (V)} \times 200 \text{ (V)}}{\text{Regeneration resistance } (\Omega)} \times \frac{\text{regeneration circuit operating rate (\%)}}{100 \text{ (\%)}}$$

- Calculation Example


Servo Amplifier Model Number : RS1L01AA\*


[With built-in regeneration resistance/Input Supply Voltage : AC200V Specification]

Regeneration resistance value : 100Ω [Built-in Regeneration Resistance]

Monitor Value : 0.12% [Reg P]

$$\text{Regeneration power PM (W)} = \frac{400 \text{ (V)} \times 400 \text{ (V)}}{100 \text{ } (\Omega)} \times \frac{0.12 \text{ (\%)}}{100 \text{ (\%)}} = \boxed{1.92 \text{ (W)}}$$

 The regeneration power calculated from this monitor value continues to be the target until the end of operations. Regeneration power varies with the voltage fluctuation of the input power supply and changes across the ages of the servo amplifier and the loading device.

 Select regeneration resistance by calculating regeneration power **PM** from the operation pattern, as per the **calculation method of regeneration power PM**.

# Materials Selection Details [External Regenerative Resistor]

## ■ Selection of Optional External Regenerative Resistor

- You can select the combination of external regenerative resistors based on effective regenerative power [PM] sought by the regeneration calculation.

### 【AC200V input type】

Amplifier Model Number	[PM]	Up to 10W	Up to 30W	Up to 55W	Up to 60W	Up to 110W	Below 220W	220W and over
RS1□01	Resistor Sign	A × 1	C × 1	E × 1	D × 2	F × 2	E × 4	Contact
	Connection Number	Ⅲ	Ⅲ	Ⅲ	Ⅳ	Ⅳ	Ⅵ	
RS1□03	Resistor Sign	B × 1	D × 1	F × 1	C × 2	E × 2	F × 4	Contact
	Connection Number	Ⅲ	Ⅲ	Ⅲ	V	V	Ⅵ	

Amplifier Model Number	[PM]	Up to 55W	Up to 125W	Up to 250W	Below 500W	500W and over
RS1□05	Resistor Sign	G × 1	H × 1	I × 2	H × 4	Contact
	Connection Number	Ⅲ	Ⅲ	Ⅳ	Ⅵ	

### 【AC400V input type】

Amplifier Model Number	[PM]	Up to 30W	Up to 55W	Up to 110W	Below 220W	220W and over
RS1□02	Resistor Sign	C × 1	E × 1	F × 2	E × 4	Contact
	Connection Number	Ⅲ	Ⅲ	Ⅳ	Ⅵ	
RS1□05	Resistor Sign	D × 1	F × 1	E × 2	F × 4	Contact
	Connection Number	Ⅲ	Ⅲ	V	Ⅵ	

Amplifier Model Number	[PM]	Up to 55W	Up to 125W	Below 500W	500W and over
RS1□10	Resistor Sign	G × 1	H × 1	H × 4	Contact
	Connection Number	Ⅲ	Ⅲ	Ⅵ	

The above resistor sign of a combination of an external regenerative resistor correspond to the following table.

Please select a resistor model name corresponding to a resistor sign.



The above connection number of a combination of an external regenerative resistor is on the next page.

Please connect based on the connection number.


Resistor Sign	Resistor Model Number	Resistance Value	Thermostat	Permissible Effective Power	Outline Drawing
A	REGIST-080W100	100 Ω	b Contact	10W	Refer to 'Materials 15'
B	REGIST-080W50B	50 Ω		10W	
C	REGIST-120W100	100 Ω		30W	
D	REGIST-120W50B	50 Ω		30W	
E	REGIST-220W100	100 Ω		55W	
F	REGIST-220W50B	50 Ω		55W	
G	REGIST-220W20B	20 Ω		55W	
H	REGIST-500W20B	20 Ω		125W	Refer to 'Materials16'
I	REGIST-500W10B	10 Ω		125W	
J	REGIST-500W7B	7 Ω		125W	
K	REGIST-500W14B	14 Ω		125W	
L	REGIST-1000W6R	6.7 Ω		250W	

# Materials Selection Details [External Regenerative Resistor]


## ■ Connection of Regenerative Resistance

[AC200V input type]



(Control power AC200V input type)



(Control power DC24V input type)



[AC400V input type]



Please make sure to install the external regenerative resistor with twisted wires and use as a short wire which is up to 5 meters long as possible.




Use nonflammable electric wire or perform non-combustible processing (silicon tube, etc.) for connecting cable and wired, and install wiring so as to not come in contact with the built-in unit.



Please make sure to change the set-up of "System Parameter" and "Regenerative Resistance Selection" in line with the kind of regenerative resistor you connect.

## ■ Connection of the Thermostat of a Regenerative Resistor

● Please use any of these general-purpose input [CONT1~CONT6].



Please allocate the connected general-purpose input ( any of [CONT1~CONT6]) to [Group9 40 External Trip Input Function of General Parameter].







**Parameter Set-up Example : When connecting the thermostat to CONT6**

The external trip function will be valid when [0DH:CONT6\_OFF] CONT6 is turned off in [Grop6 40 External Trip Input Function]

Alarm (ALM-55) will be output from the servo amplifier when the thermostat of a generative resistor trips (the contact point comes off) because of heating.

# Materials Selection Details [External Regenerative Resistor]

## ■ Connection Number of External Regenerative Resistor combination

<p><b>Connection I</b></p>  <p>Built-in Regenerative</p> <p>CNB</p> <p>RB1</p> <p>RB2</p>	<p><b>Connection II</b></p>  <p>Terminal Block</p> <p>RB4—RB1 Terminal Short Bar</p> <p>RB4</p> <p>RB1</p> <p>RB2</p>
<p><b>Connection III</b></p>  <p>Terminal Block</p> <p>RB1</p> <p>RB2</p> <p>CN1</p> <p>Twisted Wire</p>	<p><b>Connection IV</b>     [ × 2 ] Series Connection</p>  <p>Terminal Block</p> <p>RB1</p> <p>RB2</p> <p>CN1</p> <p>Twisted Wire</p>
<p><b>Connection V</b>     [ × 2 ] Parallel Connection</p>  <p>Terminal Block</p> <p>RB1</p> <p>RB2</p> <p>CN1</p> <p>Twisted Wire</p>	<p><b>Connection VI</b>     [ × 4 ] Series/Parallel Connection</p>  <p>Terminal Block</p> <p>RB1</p> <p>RB2</p> <p>CN1</p> <p>Twisted Wire</p>



# Materials Selection Details [External Regenerative Resistor]

## ■ Protection Function of Regenerative Resistance

With the R series servo amplifier, the regenerative resistance protection function is specified by parameter selections. Appropriate protection for regenerative resistance is applied by setting parameters according to the type of regenerative resistance to be connected. Set the appropriate parameters by following the instructions given below.

### ● The protection functions are divided into three main types:

- ① Protection for a short-time, high load factor (using built-in or external regenerative resistance): An error is detected when the power absorption of regenerative resistance is extremely high over a short time period (100msec to 10 seconds). A 'Regenerative Error' alarm ("ALM\_43") is issued when this error is detected.
- ② Protection when allowable power absorption is exceeded for long time (using built-in regenerative resistance): An error is detected when the power absorption of the built-in regenerative resistance exceeds the allowable power absorption over a long time period (from a few seconds to a few minutes). An 'Internal Overheat' alarm ("ALM\_54") is issued when this error is detected.
- ③ Protection during thermostat operation of the external regenerative resistor: An error is detected when the external trip function is started. An 'External error / external trip' alarm ("ALM\_55") is issued when this error is detected.

### ● The two parameters requiring settings are given below.

①	Regenerative resistance selection	Regenerative resistance built-in type	[0B]
②	External trip input function	General parameter	[Group9 40]

### ● Relationship between parameter settings and protection functions

Regenerative resistance in use		Parameter setting		Protection function operation		
Resistor	Thermostat	Regenerative resistance selection	External trip input function	Regenerative error [ALM_43]	Internal overheat [ALM_54]	External Alarm External Trip [ALM_55]
Not Connecting	—	00:_Not_Connect	—	Invalid	Invalid	—
Built-in Regenerative Resistance	—	01:_Built-in_R	—	Valid	Valid	—
External Regenerative Resistance	—	02:_External_R	—	Valid	Invalid	—
External Regenerative Resistance	Connect to servo amplifier	02:_External_R	Setting	Valid	Invalid	Valid



Make appropriate settings to regenerative resistance [System parameter/Page0B] when using built-in regenerative resistance.



If these parameter settings are incorrect, normally detected errors related to built-in regenerative resistance may not be detected, possibly causing the burning/fuming of regenerative resistance. The built-in/ external regenerative resistance may generate heat even if the overheat alarm etc. has not been generated.



Do not touch the servo amplifier for 30 minutes after power is disconnected in the case of a power failure, as there is a risk of burn.




Incorrect parameter settings may cause irregular operation of the protection functions. Upon an alarm, confirm its cause and adjust the settings appropriately.


# Materials Selection Details [External Regenerative Resistor Dimension]

Unit : mm


## External Dimension of Regenerative Resistor



	Model number	Thermostat
1	REGIST-080W100B	Normal close contact
2	REGIST-080W50B	Normal close contact




	Model number	Thermostat
1	REGIST-120W100B	Normal close contact
2	REGIST-120W50B	Normal close contact



	Model number	Thermostat
1	REGIST-220W50B	Normal close contact
2	REGIST-220W20B	Normal close contact
3	REGIST-220W100B	Normal close contact

# Materials Selection Details [External Regenerative Resistor Dimension]






	Model number	Thermostat
1	REGIST-500W20B	Normal close contact
2	REGIST-500W20	None
3	REGIST-500W10B	Normal close contact
4	REGIST-500W10	None
5	REGIST-500W7B	Normal close contact
6	REGIST-500W7	None
7	REGIST-500W14B	Normal close contact
8	REGIST-500W14	None

Crimping terminal A=M5

B=700mm±15

C=350mm±15

# Materials Selection Details [External Regenerative Resistor Dimension]





Connection Diagram

	Model number	Thermostat
1	REGIST-1000W6R7B	b Contact Point



# Materials International Standards [International standards Conformity]


## ■ Outline of International Standards Conformity


- RS1 servo amplifier conforms to the international standards below.

Mark	International standards	Standard number	Certification Organization
	UL standard	UL508C (File No.E179775)	UL (Underwriters Laboratories inc.)
	CSA standard	UL508C	
	EN standard	EN50178 EN61000-6-2 EN61800-3	TÜV (TÜV Product Service Japan, Ltd.)

- Q and R servomotor conforms to the international standards below.

Display	International standards	Standard number	Certification Organization
	UL standard	UL1004 UL1446 (File No.E179832)	UL (Underwriters Laboratories inc.)
	EN standards	IEC-34-1 IEC34-5	TÜV (TÜV Product Service Japan, Ltd.)

 For products conforming to international standards, some specifications may differ from the standard product due to prerequisites necessary for obtaining approval. Contact the manufacturer for more details.

 The file number of UL is available at the UL homepage: <http://www.ul.com/database/>.


 Please contact your dealer or sales representative if you need the above certification.

## ● Precautions for conformity standards


- ① Make sure to use servo amplifier and servo motor in a proper combination. Check "Section 1 : Prior to use --- Servo amplifier type number."
- ② Make sure to install the servo amplifier in your control panel in an environment where the pollution level specified in EN50178 and IEC664 is no less than 2 ( pollution level 1, 2). The control panel installation configuration (under IP54) must exclude exposure to water, oil, carbon, dust, etc.
- ③ The servo amplifiers must be used under the conditions specified in overvoltage category III, EN50178. For the interface, use a DC power supply with reinforced and insulated input and outputs.

# **Materials International Standards** [International standards Conformity]

- ④ Always ground the protective earth terminals of the servo amplifier to the power supply earth. (☹)
- ⑤ When connecting grounding wire to the protective earth terminal, always connect one wire in one terminal; never connect jointly with multiple wires or terminals.
- ⑥ When connecting the leakage stopper, make sure to connect the protective earth terminal to the power supply earth. (☹)
- ⑦ Connect earthing wire by using a crimping terminal with insulated tube, so that the connected wire will not touch the neighboring terminals.



- ⑧ For wire relays, use a fixed terminal block to connect wires; never connect wires directly.




- ⑨ Connect an EMC filter to the input power supply of the unit.
- ⑩ Use an EN/ IEC-standard compatible no-fuse circuit breaker and electromagnetic contactor.


# Materials International Standards [Compliance with EC Directives]

## ■ Compliance with EC Directives

Our company has performed the requisite low voltage and EMC testing in accordance with EC Directives related to CE marking through a separate, third-party certifying authority.

Directive classification	Classification	Test	Test standard
Low voltage Directive (Servo amplifier)	—	—	EN50178: 1997
EMC Directive (Servo amplifier / servo motor)	Emission	Conducted emission	EN55011: A1/1999
		Radiated emission	EN55011: A1/1999
	Immunity test	Electrostatic discharge immunity	EN61000-4-2: A2/2001
		Radiated electromagnetic field immunity	EN61000-4-3: A2/2001
		Electrical first transient/ burst immunity	EN61000-4-4: A2/2001
		Conducted disturbance immunity	EN61000-4-6: A1/2001
		Surge immunity	EN61000-4-5: A1/2001
		Voltage Dips & Interruptions immunity	EN61000-4-11: A1/2001
		Adjustable speed electrical power drive system	EN61800-3/1996 :A11/2000
Low voltage Directive (Servo motor)	—	Rotating electrical machines- Part1: Rating and performance	IEC-34-1
		Rotating electrical machines-Part5:Classification of degrees of protection provided by enclosures of rotating electrical machines(IP code)	IEC34-5

 For the EMC Directives, tests are performed by general installation and countermeasure methods, in our company as machines and configurations differ depending on customers' needs.

 This servo amplifier has been authorized to display CE marking based on the recognition certificate issued by a separate, third-party certifying authority. Accordingly, customers are instructed to perform the final conformity tests for all instruments and devices in use.


# Materials International Standards [Compliance with EC Directives]

## ● Precautions for EMC Directives

Use the following guidelines below for the RS1 servo system in order to conform the customer's equipment and devices to the EMC Directives.


- ① A metallic material must be used for the door and main body of control panel.
- ② The joints of the top and side panels must be masked and welded.
- ③ Parts joined with screws must be welded to prevent noise from leaking out from joints.
- ④ When joining parts with screws or spot welding, the welding space must be within 10cm.
- ⑤ Use an EMI gasket so that there is zero clearance between the door and control panel.
- ⑥ Install EMI gasket uniformly to the contact points between door and main body of control panel.
- ⑦ Perform conductivity processing on the EMI gasket, door and main body of control panel to confirm their conductivity.
- ⑧ Ground the noise filter frame to the control panel.
- ⑨ Ground the servo amplifier chassis provided by the customer.
- ⑩ Use shield cables for the motor power line and encoder cable.
- ⑪ Ground the shield of motor power wire and encoder cable to the control panel with the clamp.
- ⑫ Ground and clamp the shield of motor power line and encoder cable to the frame of the servo amplifier.
- ⑬ Use a conducting metal P clip or U clip to ground and clamp the shield wire, and fix it directly with metal screws. Do not ground by soldering electric wire to the shield wire.

Good




Grounding by U clip or P clip

No



Grounding by soldering

- ⑭ Wrap the zero-phase reactor four times around the primary side of the noise filter.




- ⑮ Wire the servo amplifier at a short distance from the secondary side of noise filter.
- ⑯ Wire the primary side and secondary side of the noise filter separately.




# Materials International Standards [Compliance with EC Directives]





## ■ Installation of noise filter and servo amplifier

### ● Three-phase power supply



### ● Single-phase power supply



-  Always ground the frame of the noise filter.
-  Install wiring by separating the primary and secondary wiring of the noise filter as much as possible.
-  Keep wiring from the noise filter to servo amplifier as short as possible.
-  Connect the servo amplifier to the secondary side of noise filter.

# Materials International Standards [Compliance with EC Directives]

## ■ Recommended prevention components

### ● Noise filter

Model Number	Specifications	Manufacturer
3SUP-HK30-ER-6B	Rated voltage : Line-Line 500 V Rated current : 30 A	Okaya Electric Industries Co. Ltd.
3SUP-HK50-ER-6B	Rated voltage : Line-Line 500 V Rated current : 50 A	Okaya Electric Industries Co. Ltd.
RF3020-DLC	Rated voltage : Line-Line 440 to 550 V Rated current : 20 A	RASMI ELECTRONICS LTD.
RF3030-DLC	Rated voltage : Line-Line 440 to 550 V Rated current : 30 A	RASMI ELECTRONICS LTD.
RF3070-DLC	Rated voltage : Line-Line 440 to 550 V Rated current : 70 A	RASMI ELECTRONICS LTD.
RF1010-DLC	Rated voltage : Line-Neutral 250 V Rated current : 10 A	RASMI ELECTRONICS LTD.
FS5559-35-33	Rated voltage : Line-Line 480 V Rated current : 35 A	SCHAFFNER

### ● Toroidal core

Model Number	External diameter	Internal diameter	Manufacturer
251-211	65 mm	36 mm	SCHAFFNER

Okaya Electric Industries Co. Ltd.: <http://www.okayaelec.co.jp/>

RASMI ELECTRONICS LTD. : <http://www.rasmi.com/>

SCHAFFNER : <http://www.schaffner.com/>



Please inquire the order for the RASMI product of our company.

## ■ Implementation of check test


EMC testing of equipment and devices which the RS1 servo system is built-in should meet the emission and immunity (electromagnetic compatibility) standards for the usage environment / and operating conditions.

It is necessary to follow the instructions mentioned above and conduct a final conformity check test after review.

# Materials Dimension [AC200V input type]

[RS1□01]


【Control Power AC200V input type】



# Materials Dimension [AC200V input type]

[RS1□01]


【Control Power DC24V input type】



# Materials Dimension [AC200V input Type]

[RS1□03]


[Control Power AC200V input type]



# Materials Dimension [AC200V input Type]

[RS1□03]


[Control Power DC24V input type]



# Materials Dimension [AC200V input Type]

[RS1□05]


[Control Power AC200V input type]








# Materials Dimension [AC200V input Type]






[RS1□05]

[Control Power DC24V input type]











Cooling fan

Wind direction




# Materials Dimension

[Q1 □40~□76]



MODEL	Wire-saving incremental encoder [PP031]		Battery backup method absolute encoder [PA035C]		LG	KL	LA	LB	LE	LH	LC	LZ	LR	S	Q	QE	LT	D1	[PP031]	[PA035C]	Oil seal
	Without Brake	With Brake	Without Brake	With Brake															D2	D2	
Q1□A04003△□◇	75±2	121.5±2	80.3±2	125.3±2				0						6-0.008		-	-	7	4.7	5	Option
Q1□A04005△□◇	81±2	127.5±2	87.3±2	131.3±2	5	30	46	0 30-0.021	2.5	54	40	4.5	25	0 8-0.009		-	-				
Q1□A04010△□◇	100±2	146.5±2	106.3±2	150.3±2				0						0 14-0.011		M5	12	7.5			
Q1□A06020△□◇	111±2	140±2	116±2	145±2	6	41	70	0 50-0.025	3	81	60	5.5	30	0 16-0.011		M5	12	7.5			
Q1AA06040△□◇	140±2	169±2	145±2	174±2				0						0 16-0.011	35	M5	12	7.5			
Q1AA07075△□◇	154±2	177.5±2	163.6±2	187±2	8	50	90	0 70-0.030	3	100	76	5.5	40								



MODEL	Wire-saving incremental encoder [PP031]			Battery backup method absolute encoder [PA035C]			Connector Note 1		[PP 031]	[PA 035C]	LA	LB			
	Without Brake	Without Brake	Without Brake	Without Brake	Without Brake	Motor, Earth	Brake (only when brake is installed) Note2								
Q1AA10100△□◇	184	219	193	229											
Q1AA10150△□◇	209	244	218	254	125	51	20-15P	10SL-3PEB	10	78	19	63	63	115	0
Q1AA10200△□◇	234	269	243	279											95-0.035
Q1AA10250△□◇	259	294	268	304											
Q1AA12100△□◇	168	204	183	219											
Q1AA12200△□◇	205	241	220	256	123	45	24-11P	10SL-3PE-B	12	93	21	67	63	135/145	0
Q1AA12300△□◇	242	278	257	293											110-0.035
Q1AA13300△□◇	205	254	220	270											
Q1AA13400△□◇	232	281	247	297	134	-	24-11P		12	98	21	80	63	145	0
Q1AA13500△□◇	269	318	284	334											110-0.035
Q1AA18450△□◇	288	338	304	354	134	-	24-11P		16	123	21	80	63	200	0
Q1AA18750△□◇	384	434	400	450	139	54	32-17P	10SL-3PE-B	19	144	22	80	63	200	114.3-0.035


MODEL	LE	LH	LC	LZ1	LZ2	LR	S	Q	QA	QK	W	T	U	KB1	α	β	γ	QE	LT	IE	IF	IL1	IL2	
Q1AA10100△□◇	3	130	100	9	-	45	0 22-0.013	40	3	32	0 6-0.030	6	2.5	84	0.02	0.08	0.08	M6	20	-	-	-	-	-
109																								
134																								
159																								
Q1AA12100△□◇	3	162	120	9	-	45	0 22-0.013	40	3	32	0 6-0.030	6	2.5	76	0.02	0.08	0.08	M6	20	-	-	-	-	-
113																								
150																								
Q1AA12300△□◇	4	165	130	9	M6	55	0 28-0.013	50	3	42	0 8-0.036	7	3	117	0.02	0.08	0.08	M8	25	-	-	-	-	-
144																								
181																								
200																								
Q1AA18450△□◇	3	230	180	13.5	M8	65	0 35-0.016	60	3	50	0 10-0.036	8	3	200	0.02	0.08	0.08	M8	25	124	50	93	50	50
291																								
Q1AA18750△□◇	3	230	180	13.5	M8	79	0 42-0.016	75	3	67	0 12-0.043	8	3	291	0.02	0.08	0.08	M10	25	124	50	85	145	145
291																								

Note 1) Connector becomes a waterproof specification when intuition is combined, and use the connector of the waterproof specification for the receiving side plug for IP67, please.

Note 2) All the brake connectors become JL04V-2E70SL-3PE-B for CE of the A DC24V brake.

# Materials Dimension

[Q2 □42~□86]



MODEL	Wire-saving incremental encoder [PP031]		Battery backup method absolute encoder [PA035C]		LG	KL	LA	LB	LE	LH	LC	LZ	LR
	Without Brake	With Brake	Without Brake	With Brake									
Q2□A04006△□◇	80±2	112±2	88±2	120±2	5	31	48	0	2	57	42	3.5	24
Q2□A04010△□◇	94±2	126±2	102±2	134±2				34-0.025					
Q2□A05005△□◇	79±2	108±2	88±2	110.5±2				0					
Q2□A05010△□◇	87±2	115±2	96±2	118.5±2	5	38	60	50-0.025	2.5	71.5	54	4.5	24
Q2□A05020△□◇	103±2	131±2	112±2	134.5±2				30					
Q2□A07020△□◇	96±2	121±2	105±2	131±2	8	50	90	0	3	100	76	5.5	30
Q2AA07030△□◇	103±2	128±2	113±2	138±2				70-0.030					
Q2AA07040△□◇	110±2	135±2	120±2	145±2									
Q2AA07050△□◇	118±2	143±2	128±2	153±2									
Q2AA08050△□◇	128±2	164±2	136.5±2	172.5±2	8	55	100	0	3	115	86	6.6	35
Q2AA08075△□◇	145±2	181±2	153.5±2	189.5±2				80-0.030					
Q2AA08100△□◇	164±2	198±2	170.5±2	206.5±2									

MODEL	[PP031]									[PA035C]		Oil seal									
	S	Q	QA	QK	W	T	U	QE	LT	D1	D2		D2								
Q2AA04006△□◇	0 7-0.009	20	-	15	6.5±0.2	-	-	-	-	7	4.7	5	Without Note 1								
Q2AA04010△□◇																					
Q2AA05005△□◇	0 8-0.009	20	-	15	7.5±0.2	-	-	M3	8	7.5				4.7	5	With					
Q2AA05010△□◇																					
Q2AA05020△□◇	0 11-0.011	25	2	20	4	4	1.5	M4	10								7.5	4.7	5	With	
Q2AA07020△□◇	0 14-0.011	25	2	20	5	5	2	M5	12												
Q2AA07030△□◇																					
Q2AA07040△□◇																					
Q2AA07050△□◇																					
Q2AA08050△□◇	0 16-0.011	30	2	25	5	5	2	M5	21												7.5
Q2AA08075△□◇																					
Q2AA08100△□◇																					


(Unit:mm)

Note 1) If an oil seal is needed for Q2AA04\*, the overall motor length is different.



# Materials Dimension

[R2 □40~□80]




MODEL	Without Oil Seal		Without Oil Seal Note1		LG	KL	LA	LB	LE	LH	LC	LZ	LR
	Battery backup method absolute encoder		Battery backup method absolute encoder										
	Without Brake	With Brake	Without Brake	With Brake									
R2□A04003△□◇	51.5	87.5	56.5	92.5	5	35.3	46	0 30-0.021	2.5	56	40	4.5	25
R2EA04005△□◇	56.5	92.5	61.5	97.5									
R2EA04008△□◇	72	108	77	113									
R2AA04010△□◇	72	108	77	113	6	44.6	70	0 50-0.025	3	82	60	5.5	25
R2□A06010△□◇	58.5	82.5	65.5	89.5									
R2□A06020△□◇	69.5	97.5	76.5	104.5									
R2AA08020△□◇	66.3	102	73.3	109	8	54.4	90	0 70-0.030	3	108	80	6.6	30
R2AA06040△□◇	95.5	123.5	102.5	130.5									
R2AA08040△□◇	78.3	114	85.3	121									
R2AA08075△□◇	107.3	143	114.3	150	8	54.4	90	0 70-0.030	3	108	80	6.6	40

MODEL	S	Q	QE	LT	D1	D2	Absolute
							D3
R2AA04003△□◇	0 6 -0.008	20	—	—	6	5	5
R2AA04005△□◇	0						
R2EA04008△□◇	8 -0.009						
R2AA04010△□◇	0	25	M5	12	6	5	5
R2□A06010△□◇	8 -0.009						
R2□A06020△□◇	0						
R2AA08020△□◇	14 -0.011	35	M5	12	6	5	5
R2AA06040△□◇	0						
R2AA08040△□◇	0						
R2AA08075△□◇	16 -0.011						

Note 1) If an oil seal is needed, the motor whole length differs.

Note 2) For the one without brake, there is no brake connector (or cable) attached.





MODEL	Incremental					Connector Note1)								
	Without Brake		With Brake			Motor, Ground								
	LL	KB2	LL	KB2	KB3	JL04V-2E	LG	KL1	KL2	KL3	LA	LB		
Q2CA08050	193	59	228	95	47	18-10PE	8	74	19	66	100	0 80-0.030		
Q2CA10100	196	77	231	113	51	18-10PE	10	78	19	67	115	0 95-0.035		
Q2CA13150	169	67	205	104	44	22-22PE	12	98	19	80	145	0 110-0.035		
Q2CA13200	187	67	227	107	48	22-22PE	12	98	19	80	145	0 110-0.035		
Q2CA18350	203	67	253	117	49	22-22PE	16	123	19	80	200	0 114.3-0.035		
Q2CA18450	218	67	268	117	49	22-22PE	16	123	19	80	200	0 114.3-0.035		
Q2CA22550	252	83	309	141	83	32-17PE	19	162	22	80	235	0 200-0.046		
Q2CA22700	310	83	368	141	83	32-17PE	19	162	22	80	235	0 200-0.046		

MODEL	LE	LH	LC	LZ1	LZ2	LR	S	Q	QA	QK	W	T	U	KB1	α	β	γ	QE	LT	IE	IF	IL1	IL2
Q2CA08050	3	115	86	6.6	-	35	0 16-0.011	30	2	25	0 5-0.030	5	2	96	0.02	0.06	0.07	M5	12	-	-	-	-
Q2CA10100	3	130	100	9	-	45	0 22-0.013	40	3	32	0 6-0.030	6	2.5	98	0.02	0.08	0.08	M6	20	-	-	-	-
Q2CA13150	4	165	130	9	M6	55	0 22-0.013	50	3	42	0 6-0.030	6	2.5	81	0.02	0.08	0.08	M6	20	-	-	-	-
Q2CA13200	4	165	130	9	M6	55	0 28-0.013	50	3	42	0 8-0.036	7	3	99	0.02	0.08	0.08	M8	25	-	-	-	-
Q2CA18350	3	230	180	13.5	M8	65	0 35-0.016	60	3	50	0 10-0.036	8	3	115	0.02	0.08	0.08	M8	25	124	50	61	20
Q2CA18450	3	230	180	13.5	M8	65	0 35-0.016	60	3	50	0 10-0.036	8	3	130	0.02	0.08	0.08	M8	25	124	50	61	35
Q2CA22550	4	270	220	13.5	M10	79	0 55-0.019	75	3	67	0 16-0.043	10	4	148	0.03	0.08	0.10	M10	25	142	60	55	50
Q2CA22700	4	270	220	13.5	M10	79	0 55-0.019	75	3	67	0 16-0.043	10	4	206	0.03	0.08	0.10	M10	25	142	60	55	110

Note 1) Connector becomes a waterproof specification when intuition is combined, and use the connector of the waterproof specification for the receiving side plug for IP67, please.

# Materials Servo motor data sheet [Characteristics table]

Three-phase AC200V Input specification

Servo Motor model Q1AA			04003D	04005D	04010D	06020D	06040D	07075D	10100D
Servo Amplifier model RS1□			01*	01*	01*	01*	03*	03*	05*
*Rated output	$P_R$	kW	0.03	0.05	0.1	0.2	0.4	0.75	1
*Rated speed	$N_R$	$\text{min}^{-1}$	3000	3000	3000	3000	3000	3000	3000
*Maximum speed	$N_{\text{max}}$	$\text{min}^{-1}$	5000	5000	5000	5000	5000	5000	5000
*Rated torque	$T_R$	N·m	0.098	0.159	0.318	0.637	1.27	2.38	3.19
*Continuous stall torque	$T_S$	N·m	0.108	0.159	0.318	0.637	1.27	2.38	3.92
*Peak torque	$T_P$	N·m	0.322	0.477	0.955	1.91	3.82	7.16	10.5
*Rated current	$I_R$	Arms	0.49	0.80	1	1.5	2.9	4.5	6.5
*Continuous stall current	$I_S$	Arms	0.53	0.80	1	1.5	2.9	4.5	7.8
*Peak current	$I_P$	Arms	2.2	2.9	3.6	5.8	10.5	15	24.5
Torque constant	$K_T$	N·m/Arms	0.220	0.23	0.360	0.49	0.510	0.61	0.55
Voltage constant for each phase	$K_{E\phi}$	m V/min <sup>-1</sup>	7.68	8.0	12.6	17.2	17.8	21.4	19.3
Phase resistance	$R_\phi$	$\Omega$	15	8.1	7.6	2.5	1.3	0.63	0.34
*Rated power rate	$Q_R$	k W/s	9.60	18.8	43.4	28.7	65.3	89.6	78.9
Inertia (Including Wiring INC)	$J_M$	$\text{kg}\cdot\text{m}^2(\text{GD}^2/4) \times 10^{-4}$	0.01	0.0134	0.0233	0.141	0.247	0.636	1.29
Aluminium plate		mm	t6 × 250	t6 × 250	t6 × 250	t12 × 250	t12 × 250	t12 × 250	t20 × 400

Servo Motor model Q1AA			10150D	12100D					
Servo Amplifier model RS1□			05*	05*					
*Rated output	$P_R$	1	1.5	1					
*Rated speed	$N_R$	$\text{min}^{-1}$	3000	3000					
*Maximum speed	$N_{\text{max}}$	$\text{min}^{-1}$	4500	5000					
*Rated torque	$T_R$	N·m	4.79	3.19					
*Continuous stall torque	$T_S$	N·m	4.9	3000					
*Peak torque	$T_P$	N·m	14.7	5000					
*Rated current	$I_R$	Arms	8.2	3.19					
*Continuous stall current	$I_S$	Arms	8.2	3000					
*Peak current	$I_P$	Arms	26.5	24.5					
Torque constant	$K_T$	N·m/Arms	0.705	0.578					
Voltage constant for each phase	$K_{E\phi}$	m V/min <sup>-1</sup>	24.6	20.2					
Phase resistance	$R_\phi$	$\Omega$	0.272	0.190					
*Rated power rate	$Q_R$	k W/s	143	45.2					
Inertia (Including Wiring INC)	$J_M$	$\text{kg}\cdot\text{m}^2(\text{GD}^2/4) \times 10^{-4}$	1.61	2.25					
Aluminium plate		mm	t20 × 400	t20 × 400					

- Constants are values at the time of installing on the aluminum board in the table. They indicate 'thickness' × 'side of square'.
- Items with \* and velocity – torque characteristics indicate values after temperature rise saturation. The others indicate values at 20°C. Each value indicates TYP.

# Materials Servo motor data sheet [Characteristics table]

AC100V Input specification

Servo Motor model Q1EA			04003D	04005D	04010D	06020D			
Servo Amplifier model RS1□			01*	01*	01*	03*			
*Rated output	$P_R$	kW	0.03	0.05	0.1	0.2			
*Rated speed	$N_R$	$\text{min}^{-1}$	3000	3000	3000	3000			
*Maximum speed	$N_{\text{max}}$	$\text{min}^{-1}$	5000	5000	5000	5000			
*Rated torque	$T_R$	N·m	0.098	0.159	0.318	0.637			
*Continuous stall torque	$T_S$	N·m	0.108	0.159	0.318	0.637			
*Peak torque	$T_P$	N·m	0.322	0.477	0.955	1.91			
*Rated current	$I_R$	Arms	0.9	1.9	2.2	4.5			
*Continuous stall current	$I_S$	Arms	0.95	1.9	2.2	4.5			
*Peak current	$I_P$	Arms	4	7	7.9	15.5			
Torque constant	$K_T$	N·m/Arms	0.115	0.096	0.176	0.161			
Voltage constant for each phase	$K_{E\phi}$	$\text{m V}/\text{min}^{-1}$	4.03	3.3	6.13	5.63			
Phase resistance	$R_\phi$	$\Omega$	4.28	1.4	2.2	0.33			
*Rated power rate	$Q_R$	$\text{k W}/\text{s}$	9.6	18.8	43.5	28.7			
Inertia (Including Wiring INC)	$J_M$	$\text{kg}\cdot\text{m}^2(\text{GD}^2/4) \times 10^{-4}$	0.01	0.0134	0.0233	0.141			
Aluminium plate		mm	t6 × 305	t6 × 305	t6 × 305	t6 × 305			

- Constants are values at the time of installing on the aluminum board in the table. They indicate 'thickness' × 'side of square'.
- Items with \* and velocity – torque characteristics indicate values after temperature rise saturation. The others indicate values at 20°C. Each value indicates TYP.

# Materials Servo motor data sheet [Characteristics table]

Three-phase AC200V Input specification

Servo Motor model Q2AA			04006D	04010D	05005D	05010D	05020D	07020D	07030D
Servo Amplifier model RS1□			01*	01*	01*	01*	01*	01*	01*
*Rated output	PR	kW	0.06	0.1	0.05	0.1	0.2	0.2	0.3
*Rated speed	NR	min-1	3000	3000	3000	3000	3000	3000	3000
*Maximum speed	Nmax	min-1	5000	5000	5000	5000	5000	5000	5000
*Rated torque	TR	N·m	0.191	0.318	0.159	0.318	0.637	0.637	0.955
*Continuous stall torque	TS	N·m	0.216	0.353	0.167	0.353	0.686	0.686	0.98
*Peak torque	TP	N·m	0.65	1	0.518	1.06	2.05	2.1	3.4
*Rated current	IR	Arms	0.67	1.1	0.86	1.1	1.6	2.1	2.1
*Continuous stall current	IS	Arms	0.67	1.2	0.88	1.2	1.7	2.2	2.5
*Peak current	IP	Arms	2.7	3.6	3.3	4.3	5.9	7.5	7.9
Torque constant	KT	N·m/Arms	0.314	0.325	0.21	0.33	0.435	0.34	0.519
Voltage constant for each phase	KE φ	mV/min-1	10.97	11.34	7.26	11.4	15.2	11.8	18.1
Phase resistance	R φ	Ω	11.3	6.77	4.72	4.05	3.24	1.88	2.22
*Rated power rate	QR	kW/s	6.46	11.8	3.78	7.78	16.2	10.6	20.3
Inertia (Including Wiring INC)	JM	kg·m <sup>2</sup> (GD <sup>2</sup> /4) × 10 <sup>-4</sup>	0.057	0.086	0.067	0.13	0.25	0.38	0.45
Aluminium plate		mm	t6 × 250	t6 × 250	t6 × 250	t6 × 305	t6 × 305	t6 × 305	t6 × 305

Servo Motor model Q2AA			07040D	07050D	08050D	08075D	08100D	10100H	10150H
Servo Amplifier model RS1□			03*	03*	03*	05*	05*	05*	05*
*Rated output	PR	kW	0.4	0.5	0.5	0.75	1	1	1.5
*Rated speed	NR	min-1	3000	3000	3000	3000	3000	2000	2000
*Maximum speed	Nmax	min-1	5000	5000	5000	5000	5000	3500	3000
*Rated torque	TR	N·m	1.273	1.59	1.589	2.387	3.18	5	7.2
*Continuous stall torque	TS	N·m	1.372	1.85	1.96	2.941	3.92	6	8
*Peak torque	TP	N·m	4.1	5.2	6.56	9	12.5	16.6	20.5
*Rated current	IR	Arms	3.0	4.3	3.7	5.9	6	6.8	8.6
*Continuous stall current	IS	Arms	3.1	5.0	4.3	7	6.9	8.1	9.4
*Peak current	IP	Arms	12	15	15	23.7	25	24.5	25.5
Torque constant	KT	N·m/Arms	0.482	0.442	0.52	0.441	0.59	0.814	0.94
Voltage constant for each phase	KE φ	mV/min-1	16.8	15.4	18.1	15.4	20.5	28.4	32.7
Phase resistance	R φ	Ω	1.26	0.8	0.800	0.358	0.410	0.477	0.34
*Rated power rate	QR	kW/s	21.6	27.3	19.4	27.5	37.0	46.0	65
Inertia (Including Wiring INC)	JM	kg·m <sup>2</sup> (GD <sup>2</sup> /4) × 10 <sup>-4</sup>	0.75	0.85	1.3	2.07	2.7	5.4	8.0
Aluminium plate		mm	t6 × 305	t6 × 305	t6 × 305	t6 × 305	t20 × 305	t20 × 400	t20 × 400

Servo Motor model Q2AA			13050H	13100H	13150H				
Servo Amplifier model RS1□			03*	05*	05*				
*Rated output	PR	kW	1.5	1.0	1.5				
*Rated speed	NR	min-1	2000	2000	2000				
*Maximum speed	Nmax	min-1	3500	3000	3500				
*Rated torque	TR	N·m	7.5	5	7.5				
*Continuous stall torque	TS	N·m	9	6	9				
*Peak torque	TP	N·m	7.1	15	20.3				
*Rated current	IR	Arms	4.6	7	8.7				
*Continuous stall current	IS	Arms	5.2	8.3	10.2				
*Peak current	IP	Arms	15	23.7	26.5				
Torque constant	KT	N·m/Arms	0.607	0.803	0.981				
Voltage constant for each phase	KE φ	mV/min-1	21.2	28.0	34.2				
Phase resistance	R φ	Ω	0.442	0.276	0.266				
*Rated power rate	QR	kW/s	22.3	46	64				
Inertia (Including Wiring INC)	JM	kg·m <sup>2</sup> (GD <sup>2</sup> /4) × 10 <sup>-4</sup>	2.8	5.4	7.94				
Aluminium plate		mm	t20 × 305	t20 × 400	t20 × 400				

- Constants are values at the time of installing on the aluminum board in the table. They indicate 'thickness' × 'side of square'.
- Items with \* and velocity - torque characteristics indicate values after temperature rise saturation. The others indicate values at 20°C. Each value indicates TYP.

# Materials Servo motor data sheet [Characteristics table]

## AC100V Input specification

Servo Motor model Q2EA			04006D	04010D	05005D	05010D	05020D	07020D	
Servo Amplifier model RS1□			01*	01*	01*	01*	03*	03*	
*Rated output	P <sub>R</sub>	kW	0.06	0.1	0.05	0.1	0.2	0.2	
*Rated speed	N <sub>R</sub>	min <sup>-1</sup>	3000	3000	3000	3000	3000	3000	
*Maximum speed	N <sub>max</sub>	min <sup>-1</sup>	5000	5000	5000	5000	5000	5000	
*Rated torque	T <sub>R</sub>	N·m	0.191	0.318	0.159	0.318	0.637	0.637	
*Continuous stall torque	T <sub>S</sub>	N·m	0.216	0.353	0.167	0.353	0.686	0.686	
*Peak torque	T <sub>P</sub>	N·m	0.65	1	0.518	1.03	2.1	2.1	
*Rated current	I <sub>R</sub>	Arms	1.9	2.0	1.5	2.1	3.9	4.4	
*Continuous stall current	I <sub>S</sub>	Arms	1.9	2.2	1.5	2.3	4.1	4.6	
*Peak current	I <sub>P</sub>	Arms	7.9	7	5.6	7.9	15.5	15.5	
Torque constant	K <sub>T</sub>	N·m/Arms	0.117	0.188	0.12	0.169	0.184	0.162	
Voltage constant for each phase	K <sub>E</sub> φ	mV/min <sup>-1</sup>	4.09	6.55	4.2	5.9	6.41	5.67	
Phase resistance	R φ	Ω	1.5	1.9	1.8	1.22	0.64	0.5	
*Rated power rate	Q <sub>R</sub>	kW/s	6.46	11.8	3.78	7.8	16.2	10.6	
Inertia (Including Wiring INC)	J <sub>M</sub>	kg·m <sup>2</sup> (GD <sup>2</sup> /4) × 10 <sup>-4</sup>	0.057	0.086	0.067	0.13	0.25	0.38	
Aluminium plate		mm	t6 × 305	t6 × 305	t6 × 305	t6 × 305	t6 × 305	t6 × 305	

- Constants are values at the time of installing on the aluminum board in the table. They indicate 'thickness' × 'side of square'.
- Items with \* and velocity – torque characteristics indicate values after temperature rise saturation. The others indicate values at 20°C. Each value indicates TYP.

## Three-phase AC200V Input specification

Servo Motor model R2AA			04003F	04005F	04010F	06010F	06020F	08020F
Servo Amplifier model RS1□			01*	01*	01*	01*	01*	01*
*Rated output	P <sub>R</sub>	kW	0.03	0.05	0.1	0.1	0.2	0.2
*Rated speed	N <sub>R</sub>	min <sup>-1</sup>	3000	3000	3000	3000	3000	3000
*Maximum speed	N <sub>max</sub>	min <sup>-1</sup>	6000	6000	6000	6000	6000	6000
*Rated torque	T <sub>R</sub>	N·m	0.098	0.159	0.318	0.318	0.637	0.637
*Continuous stall torque	T <sub>S</sub>	N·m	0.108	0.167	0.318	0.353	0.686	0.686
*Peak torque	T <sub>P</sub>	N·m	0.37	0.59	1.18	1.13	2.2	2.2
*Rated current	I <sub>R</sub>	Arms	0.51	0.67	0.81	0.86	1.5	1.4
*Continuous stall current	I <sub>S</sub>	Arms	0.56	0.69	0.81	0.86	1.6	1.5
*Peak current	I <sub>P</sub>	Arms	2.15	2.8	3.3	3.5	5.6	4.8
Torque constant	K <sub>T</sub>	N·m/Arms	0.201	0.246	0.424	0.375	0.476	0.516
Voltage constant for each phase	K <sub>E</sub> φ	mV/min <sup>-1</sup>	7	8.6	14.8	13.1	16.6	18.0
Phase resistance	R φ	Ω	12	9	9.3	4.8	2.7	2.3
*Rated power rate	Q <sub>R</sub>	kW/s	3.9	6.7	16	8.6	19	8
Inertia (Including Battery backup method absolute encoder)	J <sub>M</sub>	kg·m <sup>2</sup> (GD <sup>2</sup> /4) × 10 <sup>-4</sup>	0.028	0.0409	0.066	0.120	0.222	0.523
Aluminium plate		mm	t6 × 250	t6 × 250	t6 × 250	t6 × 250	t6 × 250	t6 × 250

Servo Motor model R2AA			06040F	08040F	08075F
Servo Amplifier model RS1□			03*	03*	03*
*Rated output	P <sub>R</sub>	kW	0.4	0.4	0.75
*Rated speed	N <sub>R</sub>	min <sup>-1</sup>	3000	3000	3000
*Maximum speed	N <sub>max</sub>	min <sup>-1</sup>	6000	6000	6000
*Rated torque	T <sub>R</sub>	N·m	1.27	1.27	2.39
*Continuous stall torque	T <sub>S</sub>	N·m	1.37	1.37	2.55
*Peak torque	T <sub>P</sub>	N·m	4.8	4.4	8.5
*Rated current	I <sub>R</sub>	Arms	2.8	2.6	4.6
*Continuous stall current	I <sub>S</sub>	Arms	2.8	2.6	4.6
*Peak current	I <sub>P</sub>	Arms	10.8	8.9	15.5
Torque constant	K <sub>T</sub>	N·m/Arms	0.524	0.559	0.559
Voltage constant for each phase	K <sub>E</sub> φ	mV/min <sup>-1</sup>	18.3	19.5	19.5
Phase resistance	R φ	Ω	1.36	0.93	0.4
*Rated power rate	Q <sub>R</sub>	kW/s	39	16	31
Inertia (Including Battery backup method absolute encoder)	J <sub>M</sub>	kg·m <sup>2</sup> (GD <sup>2</sup> /4) × 10 <sup>-4</sup>	0.415	1.043	1.823
Aluminium plate		mm	t6 × 250	t6 × 250	t6 × 250

- Constants are values at the time of installing on the aluminum board in the table. They indicate 'thickness' × 'side of square'.
- Items with \* and velocity – torque characteristics indicate values after temperature rise saturation. The others indicate values at 20°C. Each value indicates TYP.

# Materials Servo motor data sheet [Characteristics table]

## AC100V Input specification

Servo Motor model R2EA			04003F	04005F	04008F	06010F	06020F
Servo Amplifier model RS1□			01*	01*	01*	01*	03*
*Rated output	$P_R$	kW	0.03	0.05	0.08	0.1	0.2
*Rated speed	$N_R$	$\text{min}^{-1}$	3000	3000	3000	3000	3000
*Maximum speed	$N_{\max}$	$\text{min}^{-1}$	6000	6000	6000	6000	6000
*Rated torque	$T_R$	$\text{N}\cdot\text{m}$	0.098	0.159	0.255	0.318	0.637
*Continuous stall torque	$T_S$	$\text{N}\cdot\text{m}$	0.108	0.167	0.255	0.318	0.686
*Peak torque	$T_P$	$\text{N}\cdot\text{m}$	0.37	0.59	0.86	1.0	2.2
*Rated current	$I_R$	Arms	0.94	1.2	1.3	1.7	3.1
*Continuous stall current	$I_S$	Arms	1.0	1.3	1.3	1.7	3.2
*Peak current	$I_P$	Arms	3.7	4.9	4.5	5.6	11.9
Torque constant	$K_T$	$\text{N}\cdot\text{m}/\text{Arms}$	0.116	0.142	0.22	0.206	0.224
Voltage constant for each phase	$K_E \phi$	$\text{mV}/\text{min}^{-1}$	4.04	4.97	7.7	7.2	7.82
Phase resistance	$R \phi$	$\Omega$	4.0	3.0	2.9	1.5	0.6
*Rated powerrate	$Q_R$	$\text{kW}/\text{s}$	3.9	6.7	10	8.6	19
Inertia (Including Battery backup method absolute encoder)	$J_M$	$\text{kg}\cdot\text{m}^2(\text{GD}^2/4) \times 10^{-4}$	0.028	0.0409	0.066	0.120	0.222
Aluminium plate		mm	t6 × 250	t6 × 250	t6 × 250	t6 × 250	t6 × 250

- Constants are values at the time of installing on the aluminum board in the table. They indicate 'thickness' × 'side of square'.
- Items with \* and velocity – torque characteristics indicate values after temperature rise saturation. The others indicate values at 20°C. Each value indicates TYP.

## Three-phase AC400V Input specification

Servo Motor model Q2CA			08050H	10100H	13150H	13200H	18350H	18450H	22550H	22700H
Servo Amplifier model RS1□			02*	02*	02*	05*	05*	10*	10*	10*
*Rated output	$P_R$	kW	0.5	1.0	1.5	2.0	3.5	4.5	5.5	7.0
*Rated speed	$N_R$	$\text{min}^{-1}$	2000	2000	2000	2000	2000	2000	2000	2000
*Maximum speed	$N_{\max}$	$\text{min}^{-1}$	6000	3000	3000	3000	3000	3000	3000	3000
*Rated torque	$T_R$	$\text{N}\cdot\text{m}$	2.4	5.0	7.5	9.55	16.7	21.5	26.3	33.4
*Continuous stall torque	$T_S$	$\text{N}\cdot\text{m}$	2.9	6.0	9.0	12.0	22.0	32.0	40.0	50.1
*Peak torque	$T_P$	$\text{N}\cdot\text{m}$	9.0	18.5	20.0	30.0	45.5	70.0	72.0	86.0
*Rated current	$I_R$	Arms	2.4	3.0	4.3	5.7	10.0	13.0	16.3	19.9
*Continuous stall current	$I_S$	Arms	2.9	3.5	5.2	7.1	13.0	19.1	24.0	29.0
*Peak current	$I_P$	Arms	9.6	12.0	12.9	21.0	29.2	48.0	48.0	52.9
Torque constant	$K_T$	$\text{N}\cdot\text{m}/\text{Arms}$	1.13	1.9	1.93	1.87	1.86	1.89	2.04	1.99
Voltage constant for each phase	$K_E \phi$	$\text{mV}/\text{min}^{-1}$	39.4	66.3	67.5	65.2	65.0	65.8	71.3	69.6
Phase resistance	$R \phi$	$\Omega$	2.2	2.4	0.95	0.7	0.26	0.18	0.10	0.048
*Rated powerrate	$Q_R$	$\text{kW}/\text{s}$	31.0	46.0	64.0	77.0	74.0	99.0	61.0	60.0
Inertia (Including Wiring INC)	$J_M$	$\text{kg}\cdot\text{m}^2(\text{GD}^2/4) \times 10^{-4}$	1.84	5.4	8.8	11.8	37.9	46.5	113.5	185.0
Aluminium plate		mm	t6 × 305	T20 × 400	T20 × 400	T20 × 470	T20 × 470	T20 × 470	T20 × 540	T20 × 540


- Constants are values at the time of installing on the aluminum board in the table. They indicate 'thickness' × 'side of square'.
- Items with \* and velocity – torque characteristics indicate values after temperature rise saturation. The others indicate values at 20°C. Each value indicates TYP.

# Materials Servo motor data sheet [Characteristics table]


Q1AA Motor speed-torque characteristics indicate the values in combination with an amplifier 3 phase when amplifier power supply is AC200V. Instant domain decreases when amplifier power supply is below 200V.

Please contact our company separately when the amplifier power supply is AC200V single phase.


Speed – torque characteristics  
Q1AA04003D (30W)




Speed – torque characteristics  
Q1AA04005D (50W)




Speed – torque characteristics  
Q1AA04010D (100W)




Speed – torque characteristics  
Q1AA06020D (200W)




Speed – torque characteristics  
Q1AA06040D (400W)




Speed – torque characteristics  
Q1AA07075D (750W)




Speed – torque characteristics  
Q1AA10100D (1kW)



Speed – torque characteristics  
Q1AA10150D (1.5kW)




Speed – torque characteristics  
Q1AA12100D (1kW)




# Materials Servo motor data sheet [Characteristics table]

Q1EA Motor speed-torque characteristics indicate the values in combination with operation amplifier for single phase when amplifier power supply is AC100V. Instant domain decreases when amplifier power supply is below 100V.


Speed – torque characteristics  
Q1EA04003D (30W)




Speed – torque characteristics  
Q1EA04005D (50W)



Speed – torque characteristics  
Q1EA04010D (100W)




Speed – torque characteristics  
Q1EA06020D (200W)




Q2AA Motor speed-torque characteristics indicate the values in combination with operation amplifier for 3 phase when amplifier power supply is AC 200V. Instant domain decreases when amplifier power supply is below 200V. Please contact our company separately when the amplifier power supply is AC200V single phase.


Speed – torque characteristics  
Q2AA04006D (60W)




Speed – torque characteristics  
Q2AA04010D (100W)




Speed – torque characteristics  
Q2AA05005D (50W)




Speed – torque characteristics  
Q2AA05010D (100W)



Speed – torque characteristics  
Q2AA05020D (200W)




Speed – torque characteristics  
Q2AA07020D (200W)






# Materials Servo motor data sheet [Characteristics table]


Speed – torque characteristics  
Q2AA07030D (300W)




Speed – torque characteristics  
Q2AA07040D (400W)




Speed – torque characteristics  
Q2AA07050D (500W)




Speed – torque characteristics  
Q2AA08050D (500W)




Speed – torque characteristics  
Q2AA08075D (750W)




Speed – torque characteristics  
Q2AA08100D (1kW)




Speed – torque characteristics  
Q2AA10100H (1kW)




Speed – torque characteristics  
Q2AA10150H (1.5kW)




Speed – torque characteristics  
Q2AA13050H (500W)



Speed – torque characteristics  
Q2AA13100H (1kW)




Speed – torque characteristics  
Q2AA13150H (1.5kW)




# Materials Servo motor data sheet [Characteristics table]

Q2EA Motor speed-torque characteristics indicate the values in combination with operation amplifier for single phase when amplifier power supply is AC100V. Instant domain decreases when amplifier power supply is below 100V.


Speed-torque characteristics  
Q2EA04006D (60W)




Speed-torque characteristics  
Q2EA04010D (100W)




Speed-torque characteristics  
Q2EA05005D (50W)




Speed-torque characteristics  
Q2EA05010D (100W)



Speed-torque characteristics  
Q2EA05020D (200W)




Speed-torque characteristics  
Q2EA07020D (200W)



# Materials Servo motor data sheet [Characteristics table]

R2AA Motor speed-torque characteristics indicate the values in combination with operation amplifier for 3 phase and single phase when amplifier power supply is AC 200V. Instant domain decreases when amplifier power supply is below 200V. Please contact our company separately when the amplifier power supply is AC200V single phase.



- Degree of decrease rating : R2AA Motor fixed oil seal and brake  
About oil seal and brake fixed, considering of a rise in heat, continuous zone should apply the following degree of decrease rating.






	Oil seal	non-fixed oil seal	fixed oil seal
Brake			
with no brake		No decrease rating	decrease rating 2
with brake		decrease rating 1	decrease rating 2

Decrease rating 1	Servo Motor Model R2AA	04010F	06040F
	degree of decrease rating %	90	

Decrease rating 2	Servo Motor Model R2AA	04005F	04010F	06040F	08075F
	degree of decrease rating %	90	85	80	90

# Materials Servo motor data sheet [Characteristics table]


R2EA Motor speed-torque characteristics indicate the values in combination with operation amplifier for single phase when amplifier power supply is AC100V. Instandomain decreases when amplifier power supply is below 100V.



# Materials Servo motor data sheet [Characteristics table]


Speed-torque characteristics

Q2CA08050H(500W)




Speed-torque characteristics

Q2CA13150H(1.5kW)




Speed-torque characteristics

Q2CA18350H(3.5kW)




Speed-torque characteristics

Q2CA22550H(5.5kW)




Speed-torque characteristics

Q2CA10100H(1kW)




Speed-torque characteristics

Q2CA13200H(2kW)




Speed-torque characteristics

Q2CA18450H(4.5kW)












Speed-torque characteristics

Q2CA22700H(7kW)







# Materials Servo motor data sheet [Over load characteristics]

Q1AA Motor over load characteristics indicates.









# Materials Servo motor data sheet [Over load characteristics]

Q1EA Motor over load characteristics indicates.




Q2AA Motor over load characteristics indicates.




# Materials Servo motor data sheet [Over load characteristics]

Q2AA Motor over load characteristics indicates.


Over load characteristics  
Q2AA07030D (300W)




Over load characteristics  
Q2AA07040D (400W)




Over load characteristics  
Q2AA07050D (500W)




Over load characteristics  
Q2AA08050D (500W)




Over load characteristics  
Q2AA08075D (750W)




Over load characteristics  
Q2AA08100D (1kW)




Over load characteristics  
Q2AA10100H (1kW)




Over load characteristics  
Q2AA10150H (1.5kW)




Over load characteristics  
Q2AA13050H (500W)



Over load characteristics  
Q2AA13100H (1kW)



Over load characteristics  
Q2AA13150H (1.5kW)







# Materials Servo motor data sheet [Over load characteristics]

Q2EA Motor over load characteristics indicates.


Over load characteristics  
Q2EA04006D (60W)




Over load characteristics  
Q2EA04010D (100W)




Over load characteristics  
Q2EA05005D (50W)




Over load characteristics  
Q2EA05010D (100W)



Over load characteristics  
Q2EA05020D (200W)



Over load characteristics  
Q2EA07020D (200W)



## ■ Input-output connector

Connector table for AC **200V** input type

### 【Control power AC200V input type】

Application	Model number	Contents	Manufacturer	Manufacturer's model number
Single connector	AL-00608710	CN1 Plug and housing	Sumitomo 3M Ltd.	10114-3000PE 10314-52A0-008
	AL-00385596	CN2 Plug and housing	Sumitomo 3M Ltd.	10120-3000PE 10320-52A0-008
	AL-00329461-01	CNA plug	Phoenix Contact Co. Ltd.	MSTB2.5/5-STF-5.08
	AL-Y0000988-01	CNB plug	Phoenix Contact Co. Ltd.	IC2.5/6-STF-5.08
	AL-00329458-01	CNC plug	Phoenix Contact Co. Ltd.	IC2.5/3-STF-5.08
Low voltage circuit Connector set	AL-00661729	CN1,CN2 plug and housing	Sumitomo 3M Ltd.	10114-3000PE 10314-52A0-008 10120-3000PE 10320-52A0-008
Hi voltage circuit Connector set	AL-00416792	CNA,CNB,CNC plug	Phoenix Contact Co. Ltd.	MSTB2.5/5-STF-5.08 IC2.5/3-STF-5.08
Amplifier capacity RS1□01~RS1□05 Standard set	AL-00661731	CN1,CN2 plug and housing CNA,CNC plug	Sumitomo 3M Ltd. Phoenix Contact Co. Ltd.	10114-3000PE 10314-52A0-008 10120-3000PE 10320-52A0-008 MSTB2.5/5-STF-5.08 IC2.5/3-STF-5.08

\* CNB is installed in the servo amplifier. It is not included in the high-voltage circuit connector set.

### 【Control power DC24V input type】

Application	Model number	Contents	Manufacturer	Manufacturer's model number
Single connector	AL-00608710	CN1 Plug and housing	Sumitomo 3M Ltd.	10114-3000PE 10314-52A0-008
	AL-00385596	CN2 Plug and housing	Sumitomo 3M Ltd.	10120-3000PE 10320-52A0-008
	AL-Y0000988-02	CNA plug	Phoenix Contact Co. Ltd.	IC2.5/7-STF-5.08
	AL-00329460-01	CNB plug	Phoenix Contact Co. Ltd.	MSTB2.5/2-STF-5.08
	AL-00329458-01	CNC plug	Phoenix Contact Co. Ltd.	IC2.5/3-STF-5.08
Low voltage circuit Connector set	AL-00661729	CN1,CN2 plug and housing	Sumitomo 3M Ltd.	10114-3000PE 10314-52A0-008 10120-3000PE 10320-52A0-008
Amplifier capacity RS1□01~RS1□05 Standard set	AL-006617184	CN1,CN2 plug and housing CNACNB,CNC plug	Sumitomo 3M Ltd. Phoenix Contact Co. Ltd.	10114-3000PE 10314-52A0-008 10120-3000PE 10320-52A0-008 IC2.5/7-STF-5.08 MSTB2.5/2-STF-5.08 IC2.5/3-STF-5.08

(AC100V input type)

Application	Model number	Contents	Manufacturer	Manufacturer's model number
Single connector	AL-00329461-02	CNA plug	Phoenix Contact Co. Ltd.	MSTB2.5/4-STF-5.08
Amplifier capacity RS1□01~RS1□03 Standard set	AL-00661733	CN1,CN2 plug and housing CNA,CNC plug	Sumitomo 3M Ltd. Phoenix Contact Co. Ltd.	10114-3000PE
				10314-52A0-008
				10120-3000PE
				10320-52A0-008
				MSTB2.5/4-STF-5.08
				IC2.5/3-STF-5.08

\* The control power supply is AC100V input.

Connector table for AC **400V** input type

Application	Model number	Contents	Manufacturer	Manufacturer's model number
Single connector	AL-00385594	CN1 Plug and housing	Sumitomo 3M Ltd.	10150-3000PE
	AL-00385596	CN2 Plug and housing	Sumitomo 3M Ltd.	10350-52A0-008
	AL-Y00003760	CNA plug	Phoenix Contact Co. Ltd.	10120-3000PE
	AL-00329460-01	CNB plug	Phoenix Contact Co. Ltd.	10320-52A0-008
	AL-Y00003761	CNC plug	Phoenix Contact Co. Ltd.	GIC2.5/7-STF-7.62
Low voltage circuit Connector set	AL-00292309	CN1,CN2 plug and housing	Sumitomo 3M Ltd.	MSTB2.5/2-STF-5.08
				10150-3000PE
				10350-52A0-008
				10120-3000PE
Amplifier capacity RS1□02,RS1□05 Standard set	AL-00667138	CN1,CN2 plug and housing CNACNB,CNC plug	Sumitomo 3M Ltd. Phoenix Contact Co. Ltd.	10320-52A0-008
				10150-3000PE
				10350-52A0-008
				10120-3000PE
				10320-52A0-008
				GIC2.5/7-STF-7.62
				MSTB2.5/2-STF-5.08
				GIC2.5/3-STF-7.62

Setup software computer connecting cable


Model number	Remarks
AL-00490833-01	Dedicated cable

## ■ Monitor box

### ● Monitor box and dedicated cable


Model number	Remarks
Q-MON-1	Monitor box +Dedicated cables (2 cables)

Two dedicated cables blow come with this monitor box.



### ● Dedicated cables

Model number	Remarks
AL-00496726-01	Dedicated cables (2 cables)



Terminal name	Function
1A	Analog monitor 1
1B	Analog monitor 2
2A	GND
2B	Digital monitor


	Manufacturer mdel number	Manufacturer
Connector	LY10-DC4	Japan Aviation Electronics Industry, Ltd.
Contact	LY10-C1-1-10000	Japan Aviation Electronics Industry, Ltd.

# Materials Option

# [Lithium battery · EMCKit]

## ■ Lithium battery

Model number	Remarks
AL-00494635-01	ER3VLY




Mass : 0.02kg

	Manufacturer model number	Manufacturer
Connector	IL-2S-S3L-(N)	Japan Aviation Electronics Industry, Ltd.
Contact	IL-C2-1-10000	Japan Aviation Electronics Industry, Ltd.
Battery	ER3VLY	Toshiba Consumer Marketing Ltd.

## ■ EMC countermeasure kit


Model number	Remarks
QS-EMC-KIT1	Noise filter: 3SUP-HK30-ER-6B
	Toroidal core: 251-211

Model number: 3SUP-HK30-ER-6B



Mass : 2.5kg

Model number: 251-11



Mass : 0.3kg

# Materials Encoder clear [Encoder clear/ reset method]

## ■ Encoder clear / Alarm reset method

'Encoder clear / alarm reset method' vary according to the encoder you use. Any alarms will not be reset under the procedure of the list below unless any alarm factors are removed by correction.

### ● Asynchronous encoder

Alarm code	Name		Encoder type	Encoder clear and alarm reset method
A2	Battery abnormal	→	PA035C	After'Encoder clear input' ⇒ 'Alarm reset input'
			RA062C	—
A3	Encoder overheat	→	PA035C	'Alarm reset input'
			RA062C	
A5	Abnormal encoder3	→	PA035C	—
			RA062C	Power restoration
A6	Abnormal encoder4	→	PA035C	—
			RA062C	Power restoration
A7	Abnormal encoder5	→	PA035C	—
			RA062C	Power restoration
A8	Abnormal encoder6	→	PA035C	—
			RA062C	Power restoration
A9	Encoder failure	→	PA035C	Power restoration
			RA062C	
B3	Numerous rotation abnormal	→	PA035C	Power restoration
			RA062C	
B4	One rotation abnormal	→	PA035C	Power restoration
			RA062C	—
B5	Over speed/ Numerous rotation abnormal	→	PA035C	After'Encoder clear input' ⇒ 'Power restoration' or 'Alarm reset input'
			RA062C	
B6	Memory abnormal	→	PA035C	After'Encoder clear input' ⇒ 'Power restoration' or 'Alarm reset input'
			RA062C	
B7	Acceleration abnormal	→	PA035C	—
			RA062C	After'Encoder clear input' ⇒ 'Power restoration'

### ● Manchester encoder

Alarm code	Name		Encoder type	Encoder clear and alarm reset method
A1	Encoder abnormal 1	→	RA062M	Power restoration
A2	Battery abnormal	→	ABS-E	After'Encoder clear input' ⇒ 'Alarm reset input'
B2	Encoder abnormal 2	→	RA062M	Power restoration

## ■ How to use electronic gear

This has a function which can set up the servo motor travel distance equivalent to position command pulse in accordance with the device.

For example : Set-up method when wiring-saving incremental encoder 2000[P/R] is used.

- ① Encoder pulse number equivalent of one rotation of servo motor is  $2000[P/R] \times 4 \text{ times} = 8000 [P/R]$
- ② Feed of command input pulse necessary to revolve once or move one revolution is  $8000 [P/R]$  then.
- ③ Frequency of command input pulse necessary to operate the servo motor at  $4800 \text{ min}^{-1}$  under this condition can be sought by the equation below.

$f = \frac{N}{60} \times \text{Encoder pulse } [P/R] \times 4 \text{times}$	f = Frequency of input pulse N = Revolution number to operate servo motor
---	--

Frequency of the command input pulse necessary to operate the servo motor at  $4800 \text{ min}^{-1}$  under the above condition is  $640 \text{ kHz}$

- ④ If operation is possible under this condition, set-up value of electronic gear will be 1/1.
- ⑤

• Set-up value of electronic gear	: $1/1$
• Command input pulse feed per servo motor rotation	: $8000[P/R]$
• Frequency of command input pulse necessary to operate the servo motor At $4800 \text{ min}^{-1}$	: $640 \text{ kHz}$

If it cannot be used under the above condition



For example

You want to make command input pulse feed per servo motor revolution  $500[P/R]$

- ① Encoder pulse number equivalent of servo motor revolution is  $2000[P/R] \times 4 \text{times} = 8000[P/R]$ .
  - ② Command input pulse feed necessary to revolve servo motor once or move one revolution at this time is  $8000[P/R]$ .
- However, command input pulse feed must be  $500[P/R]$ .

$$\frac{8000}{500} = \frac{16}{1} \text{ times are necessary.}$$

If set-up value of electronic gear is made to be 16/1, command input pulse feed will be  $500[P/R] \times 16/1 = 8000[P/R]$

• Set-up value of electronic gear	: $16/1$
• Command input pulse feed per servo motor rotation	: $500[P/R]$
• Frequency of command input pulse necessary to operate the servo motor At $4800 \text{ min}^{-1}$	: $640 \text{ kHz} / (16/1) = 40 \text{ kHz}$

## Precautions For Adoption

### Cautions

The possibility of moderate or minor injury and the occurrence of physical damage are assumed when the precautions at right column are not observed. Depending on the situation, this may cause serious consequences. Be sure to follow all listed precautions.

### Cautions

- Be sure to read the instruction manual before using this product.
- Take sufficient safety measures and contact us before applying this product to medical equipment that may involve human lives.
- Contact us before adapting this product for use with equipment that could cause serious social or public effects.
- The use of this product in high motion environments where vibration is present, such as in vehicles or shipping vessels, is prohibited.
- Do not convert or modify any equipment components.

\* Please contact our Business Division for questions and consultations regarding the above.

## **SANYO DENKI CO., LTD.**

1-15-1, Kita-Otsuka, Toshima-ku, Tokyo 170-8451, Japan

<http://www.sanyodenki.com>

Phone: +81 3 3917 2223

## **SANYO DENKI AMERICA, INC.**

468 Amapola Avenue Torrance, CA 90501 U.S.A.

Phone: +1 310 783 5400

## **SANYO DENKI EUROPE SA.**

P.A. Paris Nord II 48 Allee des Erables-VILLEPINTE BP.57286 F-95958 ROISSY CDG Cedex France

Phone: +33 1 48 63 26 61

## **SANYO DENKI GERMANY GmbH**

Frankfurter Strasse 63-69 65760 Eschborn Germany

Phone: +49 6196 76113 0

## **SANYO DENKI KOREA CO., LTD.**

9F 5-2, Sunwha-dong Jung-gu Seoul, 100-130, Korea

Phone: +82 2 773 5623

## **SANYO DENKI SHANGHAI CO., LTD.**

Room 2116, Bldg B, FAR EAST INTERNATIONAL PLAZA, No.317 XianXia Rd., Shanghai 200051 China

Phone: +86 21 6235 1107

## **SANYO DENKI TAIWAN CO., LTD.**

Room 1208,12F, No.96 Chung Shan N, Rd., Sec.2, Taipei 104, Taiwan, R.O.C.

Phone: +886 2 2511 3938

## **SANYO DENKI (H.K.) CO., LIMITED**

Room 2305, 23/F, South Tower, Concordia Plaza, 1 Science Museum Rd., TST East, Kowloon, Hong Kong

Phone: +852 2312 6250

## **SANYO DENKI SINGAPORE PTE. LTD.**

10 Hoe Chiang Road #14-03A/04 Keppel Towers Singapore 089315

Phone: +65 6223 1071

The names of companies and/or their products specified in this manual are the trade names, and/or trademarks and/or registered trademarks of such respective companies.

\*Remarks : Specifications Are Subject To Change Without Notice.